

Digital Calendar Day Clock

Congratulations, you have the latest of today's technology, 1 clock – 8 Languages. The clearest "Easy to Read" clock available, using the latest 8" LED Display.



New feature includes an automatic night hours 7 p.m. to 7 a.m. dimmer!

It may be used Self-Standing or Wall Hanging. Care should be taken not to apply any pressure to the high quality Non-reflective LED screen

If there is a plastic anti-scratch screen cover film, please peel off to remove it.

The clock has an **Auto Switch-On** facility when connected to the power supply. If required to **POWER On/Off** press and hold the button for a few seconds. The Dayclox Welcome screen clears after about 7 seconds and the calendar display **Day, Time, Date**, will appear. Remember the power supply must remain connected at all times.

Your Dayclox Digital Calendar Day Clock is guaranteed for a period of 12 months from the date purchased under statutory conditions which does not include accidental damage, misuse, or any form of tampering. Damage to the hidden security seal will make a warranty null and void.

IMPORTANT: Please keep instructions with the clock for future reference.

The Clock is NOT Radio Controlled and does NOT change the time automatically for summer and winter, this will require changing manually.

The back of the clock indicates where to Plug-In the power adaptor for the electricity supply and the Menu buttons - Power On/Off and Control buttons for adjustments.



Making Changes to any of the settings follow these instructions!

Press the MENU button to **Activate the menu display** (illustrated)

Pressing the up or down button to navigate the options and Settings from the top line:

Use the UP/Down button until the menu line changes to **Yellow**

(Please Note: Only the highlighted Blue Box can be changed).



Line 1, Set Date: Pressing buttons < or > a Blue Box will highlight the section of the settings that can be changed < 14 – 08 – 2013 > Use the UP or DOWN buttons to adjust the day. Then press buttons < or > to highlight the month < 14 – 08 – 2013 > then the year < 14 – 08 – 2013 >

Line 2, Clock Mode: – Press OK to select 12 hr / 24 hr Mode: *It is important to select 24 hr Mode before setting the time so the clock knows the difference between 3 a.m. and 3 p.m. - 3 p.m. = 15 hrs in the 24 hour mode.*

Line 3, Set Time: Press the < or > to highlight the hours in a Blue Box < 11 : 00 > use the UP or DOWN buttons to adjust, then press the < or > to adjust the minutes < 11 : 17 > Changing the display for - a.m. / p.m. - Press Menu select **Clock Mode** and press OK button to select 12 hr. Press Menu to complete setting.

Line 4, Languages: Press UP / DOWN button to highlight in Yellow and press the < or > button to forward to the language preferred.

Line 5, Calendar Mode: (Hidden below Languages) press the DOWN button once to select: Pressing OK to select <British Mode> 1 April 2013 or <American Mode > April 1 2013. Then press Menu to exit (the menu closes automatically after 10 seconds)

For Sales & Service Please contact your retailer or our website for information: www.dayclox.com