
SHIMPO-WEST

RK-2 Potter's Wheel INSTRUCTION MANUAL




SHIMPO INDUSTRIAL CO., LTD.

WITH THE WHEEL YOU SHOULD HAVE RECEIVED



CONSTRUCTION AND MAIN PARTS




SETTING UP

In advance to operation, follow instructions $1 \sim 3$ to set up the wheel.

1 Place wheel on end as shown in Draw. No. 1-1


DRAW. No. 1-1



2 Remove the one red bolt and washer (arrow mark) with attached spanner. (Draw. No.1-2)

Do not operate the wheel before removing the red bolt and washer. These parts are provided to hold the motor in place during transit only.

Keep these parts for future use. Whenever transporting the wheel, the motor should be re-secured.



DRAW. No. 1-2

3 Remove plastic coating over the wheel head. (Draw. No. 2)


The wheel head is coated with special plastics. To remove this, pull off the string running across the middle of the wheel head and peel away the plastics.



DRAW. No. 2

HOW TO SET SPLASH PAN

To set two pieces of plastic splash pan, take THREE STEPS illustrated below;




To remove pan, reverse the preceding operations.


HOW TO CHANGE DIRECTION OF ROTATION

Clockwise rotation is possible if you require.

To do this:



PROCEDURE: A→C




WHEN NOT IN USE BE SURE MOTOR IS TURNED OFF

Although the pedal may be in the "STOP" position, the motor may still be running. Never leave the pedal in any position but "STOP" when the motor is off. The pressure of the steel cone on the rubber ring will create a temporary indentation that will cause a rumbling sound when the wheel is turned on. If this does occur, both the sound and the imprint will work themselves out in a few moments.

WHEN WOBBLING

The RK-2 has one adjustable foot. To adjust in case of wobble, loosen top nut of right rear foot and screw foot up or down as required, then tighten top nut.



WHEN REPLACING AN INTERIOR PART OR ADJUSTING, ALWAYS REMOVE THE SPLASH PAN AND SET THE WHEEL ON END AS IN DRAW. NO. 4.

POWER ADJUSTMENT


Power may be increased or decreased by adjusting the pressure between the ring and the cone on the Ringcone Drive System.

To do this:

- 1 With the spanner provided with the wheel, loosen the three bolts illustrated in Draw. No. 4.
- 2 Slide the casting and motor on the shaft (move it towards the pedal to increase power and away to decrease power).

If you move the unit too far up, it will tighten the pressure between the cone and ring to a point where the variable speed control will not work. Make slight adjustments instead of one complete move.






DRAW, No. 4

HOW TO REPLACE THE RING

If you find that your wheel is losing power, this probably means that the rubber drive ring is worn. (Always check your power adjustment before changing the ring).

To replace the ring remove the four pan head screws and the stop board (Draw. No. 5). Slip the old ring off and replace with a new ring.



SPECIFICATIONS

●Wheel head speed: 0~240 r.p.m.

•Direction: Counter-clockwise

•Material of
Light alloy casting

wheel head:

Motor: 200W(1/4 Hp), 115V, 60 Hz,

Single phase

Desired voltages are

available.

● Dimensions: Length 622 mm (24 31/64")

Width 528 mm (20 25/32") Height 499 mm (19 41/64") Diameter of wheel head

300 mm (11 3/4")

•Weight 61 Kg. (134 lbs.)



338 Tonoshiro-cho, Kuze, Minami-ku, Kyoto, Japan Phone: Kyoto <075> 921-7151, Cable "SHIMPO KYOTO"

PRINTED IN JAPAN S-730202000