

MINIMOTORS
Speedway **LEGER**

PERSONAL MOBILITY

User Manual



Company Introduction

Minimotors Inc. is a company which manufactures and distributes personal mobility with a professional production system since 1999.

Minimotors Inc. created the electric mobility brand 'DUALTRON' to meet the world's needs by making personal mobility more innovative, reliable, and convenient from 1999 to the present and making a product that is loved by people all over the globe. Minimotors Inc. is doing its best to become the world's best electric mobility company.



Brand Introduction

The 'SPEEDWAY' brand is a world-class luxury brand produced and designed directly by MINI Motors.

'SPEEDWAY' is easy to carry and developed for urban lifestyles. It has a wide user base since its launch in 2014, and it is a brand of life electric scooter that is steadily loved and innovated repeatedly.



 **Please read the user manual carefully.**

Do not use the product until you understand its functions.
Do not rent the product to anyone who cannot operate the product.

*For the first time, the user should use it with a slow speed for safety.

01. General safety guidelines and restrictions	04
02. Product components	06
03. Name of each part	07
04. How to use the product.....	08
05. How to use the instrument panel	10
06. How to use the charger correctly.....	13
07. Safety precautions for Lithium-ion battery.....	14
08. Safety guidelines before driving.....	15
09. Maintenance	16
10. Important checklist.....	17
11. Product specifications	18

Before Reading the Manual

This manual contains important information to help you to use your product more safely. For your safety, there are warnings of 'Danger', 'Warning', and 'Caution' depending on the degree of danger and the meanings are below.



Indicates a hazardous situation that will result in serious injury.



Indicates a hazardous situation that could result in serious injury.



Indicates a hazardous situation that could result in minor or moderate injury.

✓ **Please read this manual carefully**
before using this product

1) Safety guidelines and restrictions

* Even if the product is within the warranty period, you may be liable for any accident caused by any of the following causes.



1. Be careful of water!

This product and its components are not waterproof.

Do not let any water get into the product and its components.

*Never use it, if the road is wet due to the rain, snow, or hail.

*If you attempt to wash or spread water to any electric devices, it can result in malfunction or fire.



2. Beware of the folding and spinning parts!

If any body part, such as a finger or hair, gets caught in the spinning or folding parts of the product, this may lead to severe injuries. Please be careful.



3. No acrobatics

Stunts such as jumping and dropping are prohibited as they can cause a large impact on the product and can lead to malfunction and accidents.



4. No companion boarding

This product is intended for one adult only, so children, infants, or two people are prohibited from boarding.



5. Do not tune by yourself


Do not open or tune the electric parts (battery, controller or motor system).



6. Comply with the related laws

Driving without a license, under the influence, or with cargo on the scooter is prohibited. (More than bike or bicycle license is required)

Please comply with the Road Traffic Act and related laws and regulations according to the place of use.



7. Beginners and seniors are encouraged to use at low speed

Beginners who are not accustomed to using the product, seniors, and others should avoid high-speed mode driving and are recommended to use low-speed driving.

In addition, please use after practicing how to ride safely in an open space.



8. Do not suddenly brake with front brake

If there is a risk of overturning, sudden deceleration should be done safely. Do not apply any unusual behaviors or artificial force, such as stopping with your feet.



9. Do not accelerate downhill. Slow mode is recommended

Slow down when going downhill. When reducing the speed, use the brakes properly to reduce the heat on the disk and prevent brake overheat.



10. Do not drive on steep slopes

Acceptable gradeability is different for each product. Excessive hill roads exceeding the specification may cause damage to the product (parts) due to temperature cut, overcurrent, or low voltage cut, which may cause the product to malfunction.



11. Safety warning when lifting the product

If the product is lifted by holding only the handle, there is a possibility that the product may be damaged due to deformation of the folding part due to load or movement of the product. When lifting the product, be sure to hold the product's body (footrest) with one hand and hold the handle with the other hand so that you do not get hurt in your back or knees.




12. Be sure to wear safety equipment

For the safety of passengers, be sure to wear a full face helmet and the other protective gear (for knees, elbows, hands, upper body) and do not wear shoes such as slippers or high heels that can interfere with driving.

2) Precaution before driving

1. Night driving should be avoided at all times. Always wear helmets and other body guards and drive safely.
2. Select the mode that suits you and drive. In order to cope with sudden situations, be prepared to slow down by holding the brake at all times.
3. When turning left / right, slow down to avoid the danger of overturning or slipping, then slowly turn safely.
4. To go backwards safely, get off the product only after coming to a complete stop.
5. It is prohibited to use in any places that are slippery, crowded, have a steep slope, or are uneven.
6. When crossing a pedestrian crossing, get off from the product for pedestrian safety.
7. Do not drive in a way that threatens any other means of transport, such as animals, pedestrians, bicycles, motorcycles, cars, etc.
8. When passing speed bumps and road obstacles, be sure to slow down.
9. When decelerating or braking, do not stop with your foot, but by using the brake appropriately.
10. Be careful as there is a risk of burns due to heat from the motor and brake (especially disk rotor) after driving.
11. It is prohibited to drive by holding the handle with one hand; please use both hands at all times.
12. Do not ride or drive when the kick stand is down.



Product components



Checking the components inside of the box

Default battery charger(2A), Default tool, User manual, Body(Lithium battery included)

Product size



* Depending on the method of measurement, errors may occur.

Make a note of the serial number.



The serial number can be used to check information such as date of purchase, warranty period, etc., and product information can be checked even if the product is lost or stolen.
(May vary depending on branch office situation.)

Assembling of the instrument panel, brake



- Locate the instrument panel and tighten the fixing bolts.




-Adjust the position of the brake and tighten the fixing bolt with a hexagon wrench.

Name of each part



Handle



Body frame



How to use the product

1) Product unfolding

Press the folding lever down to release the handle.



1. Raise the handle post (Steering tube)

Press the fixing groove to adjust the height of the handlebar, and then secure the QR lever.



2. Adjusting the height of the handle T-Bar



3. Spread handle T-bar

Open the handlebar.

2) How to start



Step1. Check before power on

If the headlight button is pressed before the product is turned on, the instrument panel will not turn on. In this state, it is designed not to start. [Built-in short-time theft prevention function]

* The power of the instrument panel will turn off automatically after a few minutes of inactivity. At this time, the LED lamp is also turned off, so turn it off with the LED lamp button when you turn it on again, and turn off the main power switch after use.



Step3. Stance for driving

After tilting the kickstand, find a stable position on the footrest and then hold the handle grip comfortably. Be careful not to raise your foot on the rear fender.



Step2. Turning on the instrument panel

Press the POWER button on the instrument panel for 2 seconds to turn it on. You can set the start mode, cruise mode, electronic brake, and ABS function.

Tip



Things to check before power on

Before turning the product on, turn on the power with the LED lamp button turned off.



Step 4. Acceleration and deceleration

Acceleration can be performed by using the throttle of the instrument panel while driving, and the deceleration or stop can be performed by holding the brakes on the handle.

Before driving, be sure to check the folding part, the handle part, and the part where the main fixing part of the product are all fastened well.

CAUTION

And check the position of the fixing slide, the QR lever locking status, and the folding part fixing status

Throttle malfunction caution

Regardless of whether the throttle is operated or not, the motor sensor may continue to operate, causing malfunctions such as sudden acceleration. In this case, hold the brake lever to cancel the operation.

This phenomenon may be caused by corrosion of the throttling, immersion of the throttle, disconnection of the magnet, broken off levers, or breakage of the spring. Do not bounce the throttle lever strongly.

3) How to stop

Step1 Rear brake use

Be sure to use the rear brake first for decelerating when stopping while driving. For safe stop, it is necessary to practice slow down after deceleration with rear brake.

Step2 To stop safely

When stopping, slow down, stop safely, and do not apply artificial force.



Step3 Deceleration and braking using electric brake

Set the use and strength of the electronic brake among the detailed functions of the instrument panel before driving. When the brake lever works, the electronic brake works together to increase the braking force.

Tip Check for safe braking

- For safe braking, check whether the brake lever and disc caliper connection (wire damage, external breakage, etc.) are damaged before and after driving, and check brake wear and looseness of brake inner core (inner wire). In the case of hydraulic brakes, it is also necessary to check the oil leakage or deficiency and always check that the braking force is sufficient.
- Due to various factors such as road surface condition and speed, it may not always be possible to come to a complete stop even when the brake is operated as expected. The electronic brake and ABS functions are auxiliary functions to further increase the braking force. The user should understand the function and expect the operation timing when using this function.

4) Product folding

Fold the handle by pressing the folding lever.



1. Folding handle

Push the handlebar downwards by pressing the fixing stopper.




2. Push in the handlebar

Fold the handlebar.



3. Folding handlepost

How to use the instrument panel



* Blinks 3 times per 10 seconds when the remaining battery power is 10%.
It blinks continuously when the remaining battery power is 0%.


1) Speed step setting

Can adjust with button.

While the instrument panel is on, press to set the speed step. The setting is completed when the selected speed step value is selected.

2) Functions and settings for each main screen

mode Can adjust with button.



Mode	Discription
TRIP	Current mileage(Press and hold ● button to reset to '0')
ODO	Accumulated mileage
CHA	Not use
VOL	Current voltage
TIME	Drived time

3) Instrument panel detailed function

You can change the setting mode by turning on the power of the dashboard and pressing for 2~3 seconds.

In the setting mode, press once to change the internal setting value

* If you change the default setting values P0 (9), P1 (48), P2 (15), P3 (0), correct information will not be displayed.



9(Fixed)	48(Fixed)	15(Fixed)	0(Fixed)	Speed unit 0(Km/h), 1(mph/h)
Start method 0(Acceleration start), 1(Kick start)	Cruise mode 0(OFF) 1(ON)	Slow start 0(Off:Power start ~5(Slow start)	Max output 5~100% (User adjust)	Battery save 1(MAX SAVE) 2(MID SAVE) 3(NO SAVE)
Electronic brake power 0(Off)~5(Powerful)	LCD brightness control 0(Back light off) ~ 5(Brightest)	Auto off time setting 5~30 minutes	ABS setting 0(OFF), 1(ON)	

4) Features of cruise mode (automatic driving)

The cruise control function allows you to maintain the driving speed automatically. Take advantage of cruise features. The advantage of being able to reduce fatigue when traveling long distances and to increase mileage of driving due to constant speed driving.

(1) The start of the cruise function

Select the Cruise function section of the dashboard as 'Settings' and set the throttle to the same Acceleration. The cruise function will start.



(2) End of cruise function


When you hold and release the brake while cruise mode is in effect, the cruise mode is automatically released.

Precautions when using the cruise function

CAUTION

- In case of cruise function, please ride in a position where brake can be used immediately so that cruise function is canceled and braking is possible in preparation for safety situation while driving.
- It is permanently dual drive mode and can be released via throttle and brakes.
* It is not recommended that cruise function is disabled via the throttle.

5) Setting of Electronic brake



How to use the instrument panel

⚠ CAUTION

* Precautions when using electronic brake after a full battery charge

⚠ CAUTION

The electronic brakes do not operate when the battery is fully charged, so be sure to check and operate this device. When the battery is used a little, the electronic brake will operate normally.

6) ABS function setting guide

All electric scooters are subject to sudden braking, causing the wheels to stop spinning (Tire Lock).

As a result, the slip of tire can cause the driver to fall down, which can cause accidents.

This product is equipped with ABS brake function to reduce the tire lock, enabling more secure braking.



ABS OFF



ABS ON

(1) ABS function ON

Set the ABS function part Pd of the dashboard to 1.

(2) ABS function OFF

Set the ABS function part Pd of the dashboard to 0.

* If Pd - ABS function 1 (ON), PA - electronic brake function will operate maximum, when the ABS function is disabled, the previously set electronic brake actuation value is applied.

* ABS brake is an abbreviation of Anti-Lock Brake System. It uses the principle that maximum static friction force is larger than kinetic friction, so that braking distance (distance from breaking to stopping) is shorter than that of normal brake. It has the advantage that the vehicle does not slip well when wheel is rotating, and it is a brake assist system that can stop more safely without wheel lock and slip.

* Precautions when using the ABS function

⚠ CAUTION

ABS has the advantage of being able to stop at the shortest braking distance that can be obtained from the tires and road conditions.

However, due to the principle of repeatedly holding and releasing the brake several times in a second, a lot of vibration occurs in the motor and the body.

Repetitive vibration caused by this may cause frequent loosening of the motor, rim, fixing part, and body fixing bolt.

7) Self-diagnosis through dashboard



Fault type	Diagnosis	Solution
②	System error	* If the error information appears, immediately stop using the product and take the scooter to the service center before use. Excessive use can result in damage to the product and safety accidents.
④	Motor error	
⑤	Accelerator error	
⑥	Controller error	
⑦ ⑧ ⑨	None	

* The number ① is displayed when the cruise function is executed at a constant speed.

* The number ③ is displayed when the brake lever is operated.


(When the indicator lights, the accelerator does not operate.)

How to use a charger correctly









1) Basic charging method

1. Open the chargingport cap and connect it to the connector of the charger and connect it to the household outlet.
2. Charging status indicator
 - (Red) Charging
 - (Green) Charging complete
3. Be sure to close the chargingport cap when driving or storing except when charging.
4. When connecting the connector to the charger port, there may be metallic sparks due to voltage difference, but this is normal.



2) Basic charging method

* Failure of the charger and abnormal conditions can cause electric shock and fire. Learn the correct usage and prevent safety accidents in advance.

<p>1. Manufacturers and sellers are not responsible for any problems arising from any disassembly, modification, or mixing with other chargers.</p> 	<p>2. The charger is forbidden to be used in places subject to high humidity, heat, flammable materials, confined spaces, or where there is no ventilation such as in a car.</p> 
<p>3. The charger is not waterproof. It is thoroughly controlled to prevent moisture from entering the charger.</p> 	<p>4. Children and pets should not be allowed to approach the charger when they come into contact with them, as they may cause an electric shock.</p> 
<p>5. If the charger lamp does not light, charger fall down, strong external shock, long time charge, or cable cover damage, discontinue use immediately and contact the service center</p> 	<p>6. Unplug the charger when you are away from the home for long periods.</p> 

7. Use only genuine charger.
8. Do not insert conductors into the charging port.
9. Do not touch the plug for about 10 seconds after unplugging the charger. There is a risk of electric shock from instantaneous discharge.
10. Do not remove the terminal during charging. Otherwise you may charge the internal circuit of the charger and cause malfunction.
11. Do not operate the product during charging.
12. Charging terminals should be firmly contacted during charging and should not be used if terminals are corroded or damaged.
13. When disconnecting the charger from the product, it is safe to hold the terminal without holding the wire.
14. Be sure to keep the charger disconnected from the product after the charging is complete. The charger must be disconnected if it is not used for longer than a few days, as there is a risk of overcharging when charging more than the time indicated on the product specifications.



Safety precautions for Lithium battery



- 1) Care** Lithium batteries should be protected from direct exposure to children and pets.
- 2) Performance**
1. Lithium battery is affected by external temperature. In the winter, when the temperatures are low, the performance of the battery may be temporarily deteriorated and the mileage and power output is reduced.
 2. Lithium battery has a characteristic that discharge performance is reduced by more than 15% when charging / discharging 300 times or more. If usage time is shortened due to long usage, it should be replaced with a genuine one through the nearest point.
- 3) Charging**
1. Lithium battery should be used only with genuine battery and charger supplied from the manufacturer. Any problems caused by use of battery made by the manufacturer, mixed use, or using the charger are not covered by the manufacturer.
 2. Charging the lithium battery with a non-genuine charger may cause malfunction or fire.
 3. The lithium battery should be charged in a well-ventilated, dry place and around the charger in a place where there is no flammable material.
 4. Lithium battery should be charged at 0 ~ 45 °C and discharged within -10 ~ 60 °C.
Charging or discharging at a temperature outside this range may cause malfunction, fire or explosion.
 5. In case of moving from cold outside to warm indoor, please charge it after 1 ~ 2 hours.
This is to prevent condensation from occurring inside the product due to the temperature difference.
- 4) Storage**
1. Lithium batteries should be kept away from snow, rain and direct sunlight.
Do not store or charge them in a trunk or hot room.
Select a dry place and store at room temperature (10 ~ 20 °C).
 2. When storing for more than 3 months, charge the remaining battery level to 70 ~ 80% (do not store full charge).
- 5) Trouble symptom, safety**
1. Lithium battery should be discontinued immediately if it is damaged or there is leakage of battery, sour odor, appearance deformation, etc. Please contact the place of purchase to get technical support and service.
 2. If overheat, smoke, or ignition is detected in a product with lithium battery, immediately stop charging and use, move the product outdoors as soon as possible, and then use a fire extinguisher to extinguish flames. Do not spray water or immerse the product in any situation, which can lead to more danger.
 3. Lithium battery pack has very high energy density, so if you charge the battery for a long time and there is a case of short-circuit, leakage, bad battery, etc., it can lead to ignition.
Therefore, you should avoid charging for a long time without a person being present to avoid the risk of unexpected fire.
- 6) Misuse** If the lithium battery is short-circuited, the polarity is changed, or if the battery is impacted, malfunction or fire may result.
If you think that the battery has been impacted, you should stop charging and using it and visit the nearest service center for inspection.
- 7) Water inflow** It should be controlled to prevent water inflow into the lithium battery.
There is a risk of fire or electric shock if the charger is connected while moisture is present.
- 8) Caution** Disconnect the battery from the main unit except when recharging and reinstalling.
Do not use for any other purpose.
- 9) Disposal** When disposing of the lithium battery, the battery should be separated from the product at the point of purchase or near the service center and the charge and discharge terminals are not short-circuited. Dispose of it as industrial waste.



Battery disassembly prohibited

Battery disassembly, modification, and repair are not covered under warranty.

1) Required checking before use

1. Check throttle and handle

- Operate the accelerator throttle lever about 2 ~ 3 times to check whether it returns to the home position.
- Be careful that excessive throttle leaning and manipulation of the throttle can cause malfunction due to internal parts damage.



2. Check brake and cable

- The brake braking force is sufficient to check the operating condition. If the braking force is significantly lowered, use it immediately after inspection and action.
- Check that the brake pad is not worn, that the cable is not loose, that the cable is not damaged, and that there is no leakage in the case of hydraulic brakes.
- If there is an unusual feeling or noise during operation, check for breakage, wear, and deformation of the inner wire of the brake cable.
- Check that the bolts and nuts of the brake fixing parts are not loose and that the disc is not deformed or damaged.



3. Check tire pressure and abnormal tread wear

- Check the front and rear tires for wear and punctures and check the value marked on the surface of the tire. When the air pressure is shortened, the possibility of puncture increases, so check always.
- It is necessary to judge the replacement time by observing the appearance of the tire such as tire damage, uneven wear.



4. Tightening check such as folding part and handle part

- Make sure that the bolts and nuts of all parts of the product are tight and safe from loosening. Check the fastening condition and clearance of the folding and fixing parts of the handle.
- Check that the fixed shaft is working smoothly and check that it is correctly positioned where the fixed shaft and the body are in contact before use, and check the deformation of the connecting part and the related parts. If there is any abnormality, stop using it immediately and use it after inspection.



* In these cases, stop driving immediately.

If you encounter any of the following situations while driving, stop driving immediately and contact your nearest branch or service center for proper measures.



If you provide pictures and videos to get an accurate diagnosis, professional counseling is available.

- Unusual heating of the motor
- Brake braking status error
- Error messages on the instrument panel
- When the throttle is not returned to its original position
- When the battery doesn't fully charge and shorter riding distance after a full charge (Battery explosion may cause due to faulty battery cell or battery cell breakdown)
- Abnormal noise is generated
- Product smoke, ignition, sour odor
- When rain or wet with water or in a similar situation
- When other driving is judged to be unreasonable

2) Maintenance and self-maintenance

Electric products can be damaged by various factors.

The life span of each part varies depending on driving habits and driving environment.

Parts that exceed the service life may cause accidents. Let's manage various parts and prevent safety accidents in advance.

1. Check the replacement timing of consumable parts

- ① The components and suspension parts of the tires, tubes, wheels, bearings, headset bearings, discs, brake pads, cables and folding parts, various brackets and other consumable parts require periodic inspection and must always be checked.

Parts Replacement Schedule		
SPEEDWAY LEGER		
No	Parts name	Replacement cycle / km
1	HANDLE T BAR	2YEARS / 5,000
2	STEERING TUBE	2YEARS / 5,000
3	FOLDING JOINT	2YEARS / 7,000
4	FOLDING MOUNT	2YEARS / 7,000
5	FRONT SUSPENSION FORK ASSY	2YEARS / 7,000
6	REAR SUSPENSION ARM	2YEARS / 10,000
7	BATTERY	2YEARS / 20,000
8	Other chassis components	If the exterior is damaged or deformed



Fatigue breakdown and maintenance parts may differ from the example conditions depending on the driving environment and the operating conditions.

Also check parts other than the replacement cycle at all times to check for any signs of abnormality.



2. External damage inspection by driving environment



- ① Replace parts that may be damaged by the external driving environment, such as deformation of parts or tiny cracks due to pressure.
- ② If the product is exposed to strong sunlight for a long time, discoloration may occur.
- ③ In case of jumps, slight impacts such as turning, collision, etc., when driving frequently or for a long time in a poor road condition or driving for thousands of kilometers or more, fatigue breakdown phenomena may happen so please check the parts replacement schedule for each product and replace accordingly for safety.
- ④ Fatigue breakdown and maintenance parts may differ from the example conditions depending on the driving environment and the operating conditions.

Also check parts other than the replacement cycle (maintenance parts) at all times to check for any signs of abnormality.



Important notice

- * Metal vibration may occur due to motor vibration and the vibration of the brake disc and pad during the load section that accelerates during driving. (About 15 ~ 30Km, different for each product)
This is a phenomenon in which all rotations (fans, automobiles, ships, etc.) are vibrating at a specific rotational frequency (rpm) rather than the product.
However, if the continuous noise or metal noise is large, there is a possibility that the disk will become bent and deformed.
- * Please note that after running, there is a risk of burns due to the heat on the motor and brake (especially disk rotor) side.
- * Be careful that the bolts of the motor, rim, and motor shaft may become loosened due to the ABS function.
- * For inspection and repair, remove the side cover, attach the power switch, and attach it with the product's standard bolt. When tightening, carefully remove the cover of the wiring. Bolts other than the rule bolts (long bolts) can cause serious damage to the battery casing (battery cells), which can cause fire or safety accidents.

※ Folding parts and joints where movement occurs due to product characteristics can naturally damage the surface or paint surface during use, especially when operating in incorrect operation and form.

3) Maintenance by self-maintenance

1. How to adjust the brakes

Hold the brake wire end and rotate the brake adjustment nut clockwise.
The more you turn, the better braking and excessive turns may cause the brake pads to come into contact with normal driving.



2. How to adjust the handlebar gap (mudu-bolt or plate bolt)

If there is a free gap on the handle, use a 2.5mm or 3mm hexagon wrench to fine-tune the adjustment bolt that is visible when the handle is folded, then extend the handle to check the free gap condition.

If there is a gap, rotate it a little until there is no gap.



- * **Caution:** When adjusting for free gap, do not fully unfold the handle when the bolt is protruding more than necessary, and excessive coupling may cause external damage to the T-bar.
This case, tighten slightly clockwise again.
If the T-bar and handlebar do not engage normally due to excessive protrusion, tighten the adjusting bolt slightly clockwise again to reduce the protrusion.



Handle Gap Control Bolt

(Handle not developed due to excessive loosening of adjustment bolts)



Damage to the exterior of the T-bar when excessive coupling is made

(Excessively loose adjustment bolts damage the exterior of the T bar)



(Mudu-bolt)



(Plate bolt)

Product Specification

Product Name	SPEEDWAY LEGER	Note
Motor	MAX 1360W BLDC HUB MOTOR	
Battery type	Li-Ion battery pack	
Battery capacity	48V 15.6Ah	792Wh
Charging time (2A)	7hr+	When using standard charger(2A)
Max mileage	45-55km	60kg load 25 degrees of ambient temperature Based on the flat road 15km/h constant speed driving(Best condition)
Max Speed	25km/h	
Folding	Handle post / Handlebar one touch quick folding	
Gradeability	Around 27% (15°)	Weight, road condition, battery status, temperature can affect to the gradeability
Max load	120kg	
Product weight	Around 20.6kg	
Unfolding size	1100 x 530 x 1170mm	Length x Width x Height
Folding size	1040 x 206 x 380mm	Length x Width x Height
Dashboard	EYE throttle (Bettery level, TRIP, ODO, Time, Speed display and mode change.)	Cruise / Electric brake / Battery save function / ABS
Light	Dual LED headlight, taillight, brake light, side led(logo) light are built in	DC to DC converter is built in (12V 3A output)
Brake	Drum brake and electric brake +ABS	
Suspension	Front and rear suspension	
Tire	8 1/2 x 2 wide tube tire (Air pressure Max 50PSI)	
Product material	Frame and handle: Aviation 6061 aluminum	

*The specification can be changed by manufacturer without notice to improve the quality and safety for users.

*The distance can be affected by loaded weight, wind direct (wind speed), road condition, slope and tire condition.

MEMO

A large, empty rectangular area with rounded corners, intended for writing a memo.

SPEEDWAY LEGER

Electric Scooter

User Manual

Zhejiang Minimotors Bike Co., Ltd.

No.1, Baolong road, Lanjiang Street,
Lanxi Economic development zone,
Jinhua city, Zhejiang province, China
Tel : +86-177-0657-4477

www.dual-tron.com

