


C11 STEERING

4. Removal and Installation, Assembly and Disassembly (Cont'd)


[Point 6] End cover removal and installation

Removal

- Drill staked position of gear housing end with 3.0 mm drill until the staking is eliminated.




- Remove end cover assembly with 42 mm open-end wrench.



Installation

- Tighten end cover.
Fasten end cover assembly to gear housing with staking to prevent looseness as shown in figure.




[Point 7] Center bushing and rack oil seal removal and installation

Removal

- Turn pinion housing side and remove center bushing and rack oil seal at same time using 29-mm tape-wrapped socket and extension bar [length of 2 pieces is approx. 500 mm (19.69 in)].

CAUTION:

Do not scratch pinion housing or cylinder inner surface.




Inner side Installation

- Use rack to install.
- Install center bushing and rack oil seal (inner) separately.



CAUTION:

- (1) Do not scratch rack end surface.
- (2) To prevent scratching rack oil seal (inner), wrap the gear teeth of rack with protective plastic film, size: 70 x 100 mm (2.76 x 3.94 in) and insert oil seal above the wrapped sheet. Pull rack gears together with protective sheet until it passes.



C11 STEERING

4. Removal and Installation, Assembly and Disassembly (Cont'd)




Outer side installation

- Use end cover assembly to install outer side.

CAUTION:

To prevent scratching oil seal, wrap end of rack in a protective plastic film, size: 70 x 100 mm (2.76 x 3.94 in) and insert oil seal. Pull plastic film out together with oil seal.




Rack oil seal direction

- Make sure inner and outer side lips of rack oil seal are facing correct direction and install seal.

[Point 8] Rack Teflon ring removal and installation


Removal

- Using a heat gun, heat rack seal ring (made of Teflon) to approximately 40°C (104°F).
- Remove Teflon rack seal ring. Be careful not to scratch rack.
- Replace O-ring and Teflon ring with new parts at same time.




Installation

- Using a heat gun, heat rack seal ring (made of Teflon) to approximately 40°C (104°F) and install on rack by hand.



C11 STEERING

4. Removal and Installation, Assembly and Disassembly (Cont'd)



- Use seal ring correction tool (special service tool), compress periphery of rack seal ring (made of Teflon) to position and secure it on rack.


CAUTION:

Always insert the tool from the rack gear side.

[Point 9] Pinion oil seal removal and installation


Removal

- Using oil seal puller (special service tool), remove oil seal from gear housing.




Installation

- Assemble oil seal with spring facing up as shown in figure.




- Use appropriate sized drift and press in oil seal in gear housing.
Reference: A 26-mm socket can also be used.



[Point 10] Shim selection

- Assemble unit with the same number of shims that were disassembled, whether replacement of pinion assembly gear housing and rear housing is necessary or not.




C11 STEERING

4. Removal and Installation, Assembly and Disassembly (Cont'd)

[Point 11] Pinion Teflon ring removal and installation


Removal

- Install Teflon ring on pinion assembly.
Be careful not to damage pinion oil seal.
- Do not reuse Teflon ring.




Installation

- Using a heat gun, heat pinion seal ring to approximately 40°C (104°F) before installing it onto pinion gear assembly.
- Make sure pinion seal ring is properly settled in valve groove.




[Point 12] Needle bearing grease coating

- When assembling pinion assembly in gear housing, apply a coat of Nissan MP special grease No. 2 to needle bearing roller and pinion oil seal lip.



[Point 13] Rear oil seal grease coating

- Apply coat of Nissan MP special grease No. 2 to rear oil seal lip before assembling rear housing as shown in figure.




[Point 14] Rear housing assembly installation

- Protect rear oil seal from damage by serration part of pinion assembly by wrapping it assembly serration in a protective plastic film, 50 x 70 mm (1.97 x 2.76 in)].


CAUTION:

If protective film is wrapped on bearing insertion surface the housing cannot be assembled.




C11 STEERING


4. Removal and Installation, Assembly and Disassembly (Cont'd)



- Install rear housing assembly straight ahead.




- Insert rear housing assembly in pinion assembly and then remove protective plastic film.




[Point 15] Rear housing cover installation

- Position rack as shown in figure, and determine neutral position.

L dimension:
66.5 mm (2.618 in)



- Install rear cover cap so that protrusion of rear housing cover is positioned as shown in figure.



[Point 16] Spring (diaphragm spring) installation






- Always install retainer, spring washer, washer and diaphragm spring in this order.
- Make sure convex end (painted white) of diaphragm spring faces outward when installing.

C11 STEERING

4. Removal and Installation, Assembly and Disassembly (Cont'd)

[Point 17] Adjusting screw adjustment



① Steering gear assembly adjustment (without fluid in gears)



Note 1: If the sliding force is still out of specification even after readjustment, the steering gear is damaged and should be replaced.


C11 STEERING

4. Removal and Installation, Assembly and Disassembly (Cont'd)



Measure pinion rotation torque with preload gauge. Make sure value is within specification.

Specification N·m (kg-m, ft-lb)	Neutral range (within ± 100°)	Average value A	0.8 - 1.3 (0.08 - 0.13, 0.6 - 0.9)
		Deviation maximum value B	0.4 (0.04, 0.3) max.
	Other	Maximum value C	1.9 (0.19, 1.4) max.
		Deviation maximum value D	0.6 (0.06, 0.4) max.



C11 STEERING

4. Removal and Installation, Assembly and Disassembly (Cont'd)

- ① **Steering gear assembly, on-vehicle inspection (filled with gear oil)**
- After adjusting steering gear as described in previous section, assemble in vehicle and perform following inspection.

Separate steering column lower joint, steering gear, tie-rod and knuckle arm.

While pulling tie-rod slowly in the ± 11.5 mm (± 0.453 in) range from the neutral position, make sure rack sliding force (Note 4) is within specification.

Average rack sliding force A

284 N (29 kg, 64 lb) max.

Note 4: Measure rack sliding force under following conditions.

- ① Engine speed:
Approx. 1,000 rpm
- ② Temperature:
Approx. 55°C (122°F)
- ③ Rack speed:
Approx. 3.5 mm/sec (0.138 in/sec)





End

O.K.

Determination

N.G.

If rack sliding force is still out of specification after readjustment, gear assembly must be replaced.




[Point 18] Dust boot and clamp installation


- Before installing boot, coat the contact surfaces between boot and tie-rod with grease.
- The boot clamps are only located on large diameter side in two positions.
- The housing side and cylinder end side both have a length (ℓ) of 396 mm (15.59 in).
- To install, wrap boot clamp around boot groove twice. Tighten clamp by twisting rings at both ends 4 to 4-1/2 turns with screwdriver while pulling with a force of approx. 98 N (10 kg, 22 lb).

C11 STEERING

4. Removal and Installation, Assembly and Disassembly (Cont'd)





- Twist boot clamp in the direction shown in the figure at left.



- Install boot clamp so that clamped portion will be behind the gear when gear housing is attached to the vehicle. (This will prevent interference with other parts.)
- After twisting clamp 4 to 4-1/2 times, bend it diagonally so it does not contact boot.

Angle A:
 -80° to -100°




[Point 19]

- Set tie-rod length (dimension L) to following specification and tighten lock nut.

Specification:
126.5 mm (4.98 in)

CAUTION:

Always adjust toe-in after completing this operation. This dimension may change after toe-in adjustment.




[Point 20] Rack oil seal, Teflon seal and ring seal inspection

- After assembling steering rack, check sealing as shown in figure.
- Connect vacuum hand pump (special service tool) to tube as shown in figure. Apply vacuum pressure of 53.3 kPa (401 mmHg, 15.75 inHg) for approx. 30 sec and check that there is no needle deflection.

C11 STEERING

4. Removal and Installation, Assembly and Disassembly (Cont'd)



- To check rack seal ring (Teflon) and O-ring sealing, connect gauge to pinion side port as shown in figure. Apply vacuum pressure of 53.3 kPa (400 mmHg, 15.75 inHg) for approx. 30 sec and check that there is no needle deflection.

4-3 OIL PUMP, OIL TANK AND HYDRAULIC TUBES



Refer to C12 SUPER HICAS for power steering pump procedures.

C12 SUPER HICAS



PRECAUTIONS

- The final tightening of rubber bushings should be performed when vehicle is empty and on the ground. Wipe off any oil adhering to part surfaces because it reduces durability.
- Check wheel alignment when preparing suspension parts.
- Use flare nut wrench for removal and installation of steering pipe and power system flare nuts.
- Always adjust front and rear toe-in after power cylinder assembly removal and installation.

SPECIAL SERVICE TOOLS

Tool name Tool number	Description	
Pin punch KV321 01100	 C00-0084	Removing fail-safe valve tube seat
Attachment ST2770 0001	 C00-0144	Assembling and disassembling power steering pump

COMMERCIAL SERVICE TOOLS


Tool name Tool number	Description	
Pitman arm puller HT7256 0000	 C00-0231	Removing power cylinder outer link
CONSULT EG1180 0000	 C00-0239	Control unit input/output (I/O) signal inspection

C12 SUPER HICAS

1. Summary

This section describes SUPER HICAS trouble diagnosis procedures. Refer to C7 FRONT SUSPENSION AND AXLE, C8 REAR SUSPENSION AND AXLE and C11 STEERING for further descriptions of other suspension and steering preparation operations.

System diagram



C12 SUPER HICAS

1. Summary (Cont'd)

Description		Engine	RB26DETT	
		Suspension	Front	Rear
Suspension type		Multi-link independent suspension		
Wheel alignment (empty vehicle)	Toe-in	mm (in)	1 ± 1 (0.04 ± 0.04)	2 ± 2 (0.08 ± 0.08)
	Camber	(°)	-0°55' ± 45'	-1°05' ± 30'
	Caster	(°)	3°40' ± 45'	—
	King pin inclination angle	(°)	15°25' ± 45'	—
	Side slip (reference)	mm (in)	-5 to 5 (-0.20 to 0.20)	
Shock absorber	Damping force [0.3 m (1.0 ft)/s] N·m (kg-m, ft-lb)	Expansion	1,746 (178, 392)	1,108 (113, 249)
		Compression	500 (51, 112)	402 (41, 90)
Coil spring	Spring constant	N/mm (kg/mm, lb/in)	23.5 (2.4, 134)	26.5 (2.7, 151)
	Free length	mm (in)	405 (15.94)	345 (13.58)
	Coil center diameter	mm (in)	110 (4.33) [low side 80 (3.15)]	100 (3.94) [low side 90 (3.54)]
	Wire diameter	mm (in)	12.3 (0.484)	11.8 (0.465)
	Number of active coils		7.92	7.29
Power cylinder	Inner diameter	mm (in)	60 (2.36)	
	Stroke	mm (in)	± 3 ± 0.1 (± 0.118 ± 0.004)	
	Spring rigidity (Static)	kg-s/mm	450 ± 22.5	
	Part number (55710)		05U10 (RB26DETT)	
Pump	Type		Fixed injection volume	
	Part number (49110)		05U00 (RB26DETT)	
Tension rod outer diameter		mm (in)	20 (0.79)	—
Stabilizer outer diameter		mm (in)	20 (0.79)	25.4 (1.000)
Maximum steering angle	(°)	Inner wheel	38° + 1° - 3°	1° [Stroke: 3 mm (0.12 in)]
		Outer wheel	32°	1° [Stroke: 3 mm (0.12 in)]


Inspection specifications

Description	Specification	
Rear housing ball joint	Description	Ball joint
	Sliding torque	N·m (kg-m, ft-lb) 0.3 - 29 (0.03 - 0.3, 0.2 - 2.2)
	Swinging torque (spring scale conversion value)	N (kg, lb) 6.9 - 68.6 (0.7 - 7.0, 1.5 - 15.4)
	Axial end play	mm (in) 0 (0)
	Tightening torque	N·m (kg-m, ft-lb) 45 - 60 (4.6 - 6.1, 33 - 44)
Operation oil	Nissan power steering fluid	

C12 SUPER HICAS


2. On-vehicle Inspection and Adjustment

2-1 INSTALLATION INSPECTION



(1) Engine compartment

- Check the installation of each part and piping and wiring conditions.



(2) Rear undercarriage


- Check installation of each part and pipe condition.
- Check that rubber parts (boots, insulators, etc.) are not cracked or damaged.
- Check installation condition of suspension parts.

C12 SUPER HICAS

2. On-vehicle Inspection and Adjustment (Cont'd)

(3) Rear parcel (trunk)

- Check wiring harness connector condition of HICAS control unit in the middle of rear parcel in trunk.



2-2 WHEEL ALIGNMENT INSPECTION AND ADJUSTMENT


- Refer to C7 FRONT SUSPENSION AND AXLE, C8 REAR SUSPENSION AND AXLE for wheel alignment inspection and adjustment procedures.

2-3 FLUID LEVEL INSPECTION

- Maintain the fluid level so that the lower surface of the float is maintained between the "L" and "H" marks on the gauge rod. The fluid level should be checked when the engine is stopped and the fluid temperature is normal.

CAUTION:

- (1) Never reuse fluid that has been removed.
- (2) Never use any other oil except the recommended type of power steering fluid.





2-4 SYSTEM OPERATION INSPECTION

(1) When CONSULT is used:



Perform the following procedures. (2-man operation)


- ① Have a helper sit in the driver's seat and raise vehicle. (Use a two-pole lift or a center pole lift so that all four wheels are free to rotate.)
- ② Connect CONSULT unit to diagnostic connector and start engine.
- ③ Touch "START" on CONSULT display.
- ④ Touch "HICAS".




C12 SUPER HICAS

2. On-vehicle Inspection and Adjustment (Cont'd)


- ⑤ Touch "ACTIVE TEST".



- ⑥ Touch "SIMULATED DRIVE".




- ⑦ Touch "START" when MAIN SIGNALS display is reversed.



- ⑧ Touch "START". (high-speed mode set)

CAUTION:


After simulated drive condition has continued for 5 minutes, it will automatically cancel and CONSULT unit will then show "TEST IS INTERRUPTED TO AVOID OIL TEMP RISE" display. To cancel this mode during self-diagnosis, simply touch "CANCEL".



- ⑨ Operate engine at speeds greater than 2,000 rpm, and turn steering wheel 180° in one direction from the neutral position. Measure extension value of one power cylinder rod and retraction value of the other. Then, turn steering wheel 180° in the other direction from the neutral position and measure extension value of one cylinder rod and retraction value of the other. Determine strokes of respective power cylinders by adding (measured) extension and retraction values.

CAUTION:

Measure rod strokes in as short a period of time as possible.



C12 SUPER HICAS


2. On-vehicle Inspection and Adjustment (Cont'd)

Specifications mm (in)	When turned to the right: 3 mm (0.12 in)	Left rod: extended, Right rod: retracted
	When turned to the left : 3 mm (0.12 in)	Left rod: retracted, Right rod: extended
	Total stroke: 6 mm (0.24 in)	—

(2) When CONSULT is not used:

Perform the following operations. (2-man operation)

- ① Have a helper sit in the driver's seat and raise vehicle.
(Use a 2-pole lift or a center pole lift so that the four wheels are free to rotate.)
- ② Turn ignition switch OFF.
- ③ Start engine. Turn steering wheel from left to right (at least 20° from the neutral position) 5 times or more, then depress foot brake pedal at least 5 times all within 10 seconds after ignition switch has been turned "ON".
- ④ Set steering wheel to a point approximately 10° from the neutral position and check to ensure that rear wheels turn to the left and right alternately.



- ⑤ Operate engine at speed greater than 2,000 rpm, and turn steering wheel 180° in one direction from the neutral position. Measure extension value of one power cylinder rod and retraction value of the other. Then, turn steering wheel 180° in the other direction from the neutral position and measure extension value of one cylinder rod and retractor value of the other. Determine strokes of respective power cylinders by adding (measured) extension and contraction strokes.

CAUTION:

Measure rod strokes in as short a period of time as possible
Turn ignition switch OFF and cancel self-diagnosis.


Specifications mm (in)	When turned to the right: 3 mm (0.12 in)	Left rod: extended, Right rod: retracted
	When turned to the left : 3 mm (0.12 in)	Left rod: retracted, Right rod: extended
	Total stroke: 6 mm (0.24 in)	—

2-5 FLUID LEAK INSPECTION LOCATIONS

- Refer to C11 STEERING, 2. On-vehicle Inspection and Adjustment for descriptions of SUPER HICAS power steering fluid leak inspection locations.
- This section describes the leak inspection locations for the SUPER HICAS power cylinder.


C12 SUPER HICAS

2. On-vehicle Inspection and Adjustment (Cont'd)



C15-0044B

Note: If leakage locations are not clearly visible, wash area with white gasoline or equivalent solvent and check for leaks again.



C15-0045B

C12 SUPER HICAS

2. On-vehicle Inspection and Adjustment (Cont'd)

Fluid leak location	① Dust boot	② Power cylinder tube connections	③ Power cylinder air bleeder
On-vehicle inspection locations	—	Power steering tube tightening torque <ul style="list-style-type: none">● Right port side: 39 - 49 N·m (4.0 - 5.0 kg-m, 29 - 36 ft-lb)● Left port side: 39 - 49 N·m (4.0 - 5.0 kg-m, 29 - 36 ft-lb)	Air bleeder tightening torque <ul style="list-style-type: none">● Right side: 6 - 8 N·m (0.6 - 0.8 kg-m, 4.3 - 5.8 ft-lb)● Left side: 6 - 8 N·m (0.6 - 0.8 kg-m, 4.3 - 5.8 ft-lb)
Preparation description (parts requiring replacement)	Power cylinder assembly	Tubes	(Air bleeder)
Related parts requiring inspection	—	Power cylinder assembly	
Preparation procedures	<div>Remove power cylinder from vehicle.</div> <div>↓</div> <div>Check contact surfaces inside the power cylinder assembly port and air bleeder for scratches, indentations or damage.</div> <div>↓</div> <div>Replace parts as necessary.</div> <div>↓</div> <div>Install power cylinder in vehicle.</div> <div>↓</div> <div>Bleed air and inspect oil level.</div> <div>↓</div> <div>Inspect for fluid leakage.</div>		

2-6 AIR BLEEDING



- Refer to "4-1 POWER CYLINDER AND LOWER LINK", ① Removal and installation for description HICAS system air bleeding procedures.

C12 SUPER HICAS

3. Trouble Diagnoses

3-1 ELECTRICAL SYSTEM INSPECTION PREPARATION

(1) Circuit diagram and control unit installation position



HICAS control unit installation position

- The unit is located below the rear parcel shelf.

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

(2) Trouble diagnosis when CONSULT is used



① Self-diagnostic items

Diagnostic item	Description	Remarks
CAR SPEED SENSOR [No signal] (· a)	<ul style="list-style-type: none"> No vehicle speed signal is entered after vehicle has been operated above a certain speed. 	
CAR SPEED SENSOR [SIG-SUDDEN TURN] (· b)	<ul style="list-style-type: none"> Vehicle speed signal changes abruptly during operation. 	
STEERING ANGLE SEN [NO ANG SIGNAL] (· a)	<ul style="list-style-type: none"> Steering angle has not changed while driving at a speed of at least 60 km/h (37 MPH). 	
STEERING ANGLE SEN [NO NEUT SIGNAL] (· b)	<ul style="list-style-type: none"> Neutral (ON) signal is not entered after vehicle has been driven. 	
STEERING ANGLE SEN [NEUT SIG-360° OFF] (· c)	<ul style="list-style-type: none"> Neutral (ON) signal is not entered even after steering wheel has been turned at least 360°. 	
STEERING ANGLE SEN [NEUT SIG-30° ON] (· d)	<ul style="list-style-type: none"> Neutral (OFF) signal is not entered even after steering wheel has been turned at least 50°. Neutral (ON) signal is continuously shown at steering angle of at least 30°. 	
FAILSAFE VALVE [ABNORMAL SIGNAL]	<ul style="list-style-type: none"> Output terminal voltage is abnormal due to broken or shorted HICAS fail-safe valve circuit. 	
HICAS SOLENOID-R [ABNORMAL SIGNAL]	<ul style="list-style-type: none"> Output terminal voltage is abnormal due to broken or shorted HICAS solenoid (RH) circuit. 	
HICAS SOLENOID-L [ABNORMAL SIGNAL]	<ul style="list-style-type: none"> Output terminal voltage is abnormal due to broken or shorted HICAS solenoid (LH) circuit. 	
POWER STEERING SOL [ABNORMAL SIGNAL]	<ul style="list-style-type: none"> Output terminal voltage is abnormal due to broken or shorted power steering solenoid circuit. 	

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

② Data monitoring items

○: Standard △: Optional selection

Diagnostic item	Monitor item selection		Remarks
	All signals	Selection from menu	
CAR SPEED (km/h or MPH)	○	△	
STEERING ANG (R/L°)	○	△	Abnormal value is shown before straight-ahead position ("0") is set and after battery is disconnected and reconnected.
NEUTRAL SIG (ON/OFF)	○	△	
STOP LAMP SW (ON/OFF)	○	△	
PKB/CLUTCH SW (ON/OFF)	○	△	Clutch switch signal in M/T vehicles, parking brake switch signal in A/T vehicles.
NEUTRAL SW (ON/OFF)	○	△	Neutral switch signal in M/T vehicles, inhibitor relay (N or P position) in A/T vehicles.
ENG REV (OVER 1,500) or (UNDER 1,500)	○	△	Engine speed greater than/less than 1,500 rpm is shown.
HICAS SOL (R/L A)	○	△	Controlled current flow from control unit to HICAS solenoid and direction of current control are shown.
POWER STR SOL (A)	○	△	Controlled current flow from control unit to power steering is shown.
FAILSAFE/V (ON/OFF)	○	△	ON (when connected) or OFF (when disconnected) is shown.
FAILSAFE (CUT/NON)	○	△	NON (fail-safe valve ON) refers to "normal" condition. CUT (fail-safe valve OFF) when "fail-safe" condition is shown.
WARNING LAMP (ON/OFF)	○	△	Illumination control of control unit HICAS warning lamp is shown.
■ VOLTAGE (V)		△	Voltage measured with voltage probes is shown.
■ PULSE (msec, Hz or %)		△	Value measured with pulse probes is shown. If pulse cannot be measured, "##" is shown. "##" is also shown at left of final data until measurement results are determined.

C12 SUPER HICAS



3. Trouble Diagnoses (Cont'd)

(3) Trouble diagnosis by self-diagnosis


① Self-diagnosis (When CONSULT is used)




- Turn ignition switch OFF.
- Connect CONSULT unit to diagnostic connectors.
(Diagnostic connectors are located in fuse block.)




- Start engine.
- Touch "START" on CONSULT display.



- Touch "HICAS".



- Touch "SELF-DIAG RESULTS".



- Self-diagnostic results are shown on display.



C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)


For reference:

Recording input/output signals using data monitor function. 


- Start engine.
- Touch "START" (on CONSULT display).




- Touch "HICAS".



- Touch "DATA MONITOR".



- Check to ensure that the ALL SIGNALS display is reversed. Touch "START".



- Touch "RECORD" to record data. Make sure that ON-OFF signal is produced when signal is entered from each sensor while monitoring.

CAUTION:

To cancel data recording during operation, touch "CANCEL".

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

② Self-diagnosis (When CONSULT is not used)

Self-diagnosis procedures

① Input starting conditions for self-diagnosis.

- 1) Turn ignition switch "OFF".
- 2) M/T vehicles: Set shift lever in neutral.
A/T vehicles: Set shift lever to "P" or "N".
- 3) Immediately start engine.
- 4) Turn steering wheel from left to right (at least 20° from the neutral position) 5 times or more, then depress foot brake pedal at least 5 times, all within 10 seconds after ignition switch has been turned "ON".

② Input self-diagnosis item.

- 1) Depress and release foot brake pedal.
- 2) Turn steering wheel from left to right (at least 20°) from the neutral position.
- 3) M/T vehicles: Depress clutch and move shift lever to any gear other than neutral and then return clutch and shift lever to original position.
A/T vehicles: Disengage and engage parking brake lever. Move shift lever to any position other than Neutral or Parking and return it to Parking.
- 4) Move car at least 2 to 3 meters (7 to 10 ft) forward and proceed at an indicated speed of at least 2 km/h (1 MPH) in self-diagnosis mode.

③ Self-diagnosis items

- (1) RH solenoid output
- (2) LH solenoid output
- (3) Fail-safe valve output
- (4) Power steering solenoid output
- (5) Vehicle speed signal.
- (6) Steering angle signal.
- (7) Steering angle neutral signal
- (8) (A/T) parking brake signal, (M/T) clutch signal
- (9) (A/T) inhibitor signal, (M/T) neutral signal

④ Self-diagnosis display pattern


- 1) When all systems are normal:
HICAS flashes at 0.25 sec (4 Hz) intervals.
- 2) If fail-safe system was operated (fail-safe valve is operating) when ignition switch was OFF for the last time, fail-safe items will be displayed in numerical order in modes indicated. After all items are displayed, display is repeated again.

Example:

The warning lamp displays abnormal mode (1 sec. ON) in following sequence: (2) HICAS solenoid LH, (4) power steering solenoid and (5) vehicle speed sensor.

CAUTION:

After this display is shown, when ignition key is turned OFF the next display is ⑧.




C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

- 3) If fail-safe system was not operated when ignition switch was OFF for the last time, display will show self-diagnosis results in numerical sequence in modes indicated below. After all self-diagnosis, results are shown and display is repeated again.

Example:

The warning lamp displays abnormal mode (1 sec. ON) in following sequence: (2) HICAS solenoid LH, (4) power steering solenoid and (7) Steering angle neutral signal.



⑧ Canceling the self-diagnosis function

The three methods for canceling the self-diagnosis are described below.

- The self-diagnosis system is canceled by turning ignition switch "OFF".
- The self-diagnosis system is canceled by a vehicle speed of 30 km/h (19 MPH) or over.
- After the self-diagnosis has been operated for approximately 5 minutes, the self-diagnosis system will be automatically canceled.

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

(4) Diagnostic procedures

A. When self-diagnosis function is not used:



1	2	3	●	4	5	6	7
8	9	10	11	✕	13	14	15
16							

Disconnect control unit, steering sensor connectors and reconnect them firmly. Conduct self-diagnosis.

Abnormal

Connector is faulty.

Normal
(self-diagnosis does not start)

17	●	18	19
20	✕	22	23
24			

Control unit terminal

Turn ignition switch "ON". Is stop lamp switch signal input to control unit? Measure voltage across terminals ⑪ ⊕ and ⑭ ⊖.

Abnormal (no voltage change)

Stop lamp switch system is faulty.

Normal
(Brake ON: 12V)
(Brake OFF: 0V)

Turn ignition switch ON and turn steering wheel from left to right (at least 20°) from the neutral position. Is steering angle neutral position signal input to control unit? Measure voltage across terminals ⑦ ⊕ and ⑭ ⊖.

Normal
(Neutral position: approx. 5V)
(More than 20°: 0V)

Control unit is faulty.

Abnormal (no voltage change)

6	7	●	2	1
5	8		4	3

Steering angle sensor terminal

Turn ignition switch ON and turn steering wheel from left to right (at least 20°) from the neutral position. Is steering angle neutral position signal output from angle sensor? Measure voltage across terminals ④ ⊕ and ⑤ ⊖.

Normal (Neutral position: approx. 5V)
(More than 20°: 0V)

Control unit steering angle sensor wiring is faulty.

Abnormal (no voltage change)

Check steering angle sensor for IGN power supply and grounding. (Measure voltage between IGN power terminal ① ⊕ and body ground. Check for continuity between IGN power supply terminal ⑤ ⊕ and body ground.)

Normal (IGN power: Approx. 12V)
(Ground: Continuity exists)

Steering angle sensor is faulty.


Abnormal
(IGN power: 0V)
(Ground: No continuity)

IGN power supply system or ground circuit is faulty.

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)


B. HICAS solenoid (right and left) output is not present. [① Self-diagnosis items (1) and (2)]



C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)


C. Fail-safe output is not present. [C Self-diagnosis items (3)]




C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

D. Power steering solenoid output is not present. [C Self-diagnosis items (4)]




E. Vehicle speed signal is not present. [Self-diagnosis procedure (5)]



C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)


F. Steering angle signal is not present. [C Self-diagnosis items (6) and (7)]




C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

G. Parking brake (A/T) or clutch switch (M/T) input is not present. [① Self-diagnosis items (8)]



H. Inhibitor switch (A/T) or neutral switch (M/T) input is not present. [① Self-diagnosis items (9)]



C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

(5) Control unit inspection table

The standard value (voltage) measured with an analog tester in contact with the control unit terminal are shown below.


Terminal No.		Standard Value	Application
⊕	⊖		
①	⑩ or ⑭	—	Service support CLK input
②		—	Service support RX output
③		Ignition switch ON: Approx. 12V Ignition switch in other position: 0V	IGN power supply
④		Approx. 12V	Battery power supply
⑤		—	Number of ECCS revolution signals
⑥		Rear wheel rotating 0V ↔ greater than 5V (approx.) intermittent	Vehicle speed signal
⑦		Approx. 5V (neutral position)	Steering neutral position sensor
⑧		Solenoid resistance value 4 - 6Ω	Resistance of power steering solenoid
⑨		—	Service support TX output
⑪		Brake ON: Approx. 12V Brake OFF: 0V	Stop lamp switch signal
⑬		Parking brake engaged or clutch pedal depressed: Approx. 5V	(A/T) Parking brake signal (M/T) Clutch signal
⑭		Gear in N, or shift lever in any position other than parking: Approx. 5V	(A/T) Inhibitor signal (M/T) Neutral signal
⑮		Steering wheel turned 0 ↔ approx. 5V, intermittent	Steering angle sensor 1 signal
⑯			Steering angle sensor 2 signal
⑰		—	(Reserved for future switch input function.)
⑱		Solenoid resistance 13 - 17Ω	Fail-safe valve resistance
⑲		Ignition switch ON: Approx. 12V Ignition switch in other position: 0V	IGN power supply
⑳		—	HICAS warning lamp
㉑		Solenoid resistance 4 - 6Ω	HICAS solenoid (R.H.)
㉒		Solenoid resistance 4 - 6Ω	HICAS solenoid (L.H.)

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)


3-2 HYDRAULIC SYSTEM TROUBLE DIAGNOSIS

(1) Diagnosis flowchart



(2) Damage symptom flowchart

A. Warning lamp lights during operation




C15-0151B

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)


B. Abnormal sound is present.



C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

C. Vehicle behavior is abnormal.




C15-0153B

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)


D. Static HICAS characteristic performance check



C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

[Point 1] HICAS pump relief hydraulic inspection



- Connect power steering pressure gauge adaptor (I-type joint) and power steering pressure gauge (special service tool) to HICAS outlet nozzle connector of power steering pump (tandem type).
- Set the power steering pressure gauge adaptor (flare joint) (special service tool) in HICAS high-pressure hose removed from power steering pump. (Note 1)

Raise vehicle.

Bleed air from hydraulic circuit.

Note 2: Refer to "Power steering gear and linkage removal and installation".

Open power steering pressure gauge valve fully and start engine. Move wheel to left and right to heat oil.

Note 1: If the valve is left fully closed while engine is running, the pressure in oil pump rises to relief pressure limit. Do not turn valve fully closed for extended periods because pressure rises to an abnormal level.

Relief pressure limit:
5,884 kPa (60 kg/cm², 853 psi)

Measure relief pressure when valve is fully closed and check that it does not exceed indicated specification limit.

Note 2: Valve must be opened after a maximum of 15 seconds. (If oil temperature rises, it may damage oil pump.)

Abnormal → Replace oil pump assembly.

Normal →

Remove power steering oil pressure gauge. Install high-pressure hose in oil pump outlet connector.

Bleed air from hydraulic system.


Relief pressure inspection - END

C15-0155B

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

[Point 2] HICAS solenoid valve and fail-safe valve inspection (relief pressure inspection)



Raise vehicle.

- Connect power steering pressure gauge adaptor (I-joint) and power steering pressure gauge (special service tool) to ports (C) and (D) of fail-safe valve.
- Set the power steering pressure gauge adaptor (flare joint) (special service tool) in high-pressure hose removed from fail-safe valve. (Note 1)

Bleed air from hydraulic circuit.

Note 2: Refer to "4-1 POWER CYLINDER AND LOWER LINK" removal and installation procedures.

Open power steering pressure gauge valve fully and start engine. Move wheel to left and right to heat oil.

Relief pressure limit:
5,394 kPa (55 kg/cm², 782 psi)

Measure relief pressure when valve is fully closed and check that it does not exceed indicated specification limit.



Abnormal

First replace HICAS solenoid valve and measure power cylinder stroke. Next, replace fail-safe valve.

Normal

Remove power steering oil pressure gauge. Install high-pressure hose in oil pump outlet connector.

Bleed air from hydraulic system.


Relief pressure inspection - END

C15-0156

C12 SUPER HICAS

3. Trouble Diagnoses (Cont'd)

E. Dynamic characteristic inspection



Check pipe and connector joints for indentations or clogging. Replace with new parts as necessary. Bleed air thoroughly. (Note)

Note: Refer to "4-1 POWER CYLINDER AND LOWER LINK" for air bleeding procedures.

Start engine and set self-diagnosis mode. Maintain engine at speed above 2,000 rpm.

Set steering wheel in neutral position and check that rear wheels move in pulse to left and right. (Refer to figure.)

Measure power cylinder stroke to one side for rear wheel pulsation. Is stroke distance greater than 2.0 mm (0.079 in)?

Normal

End

Abnormal

Replace HICAS solenoid valve.

Measure power cylinder stroke to one side for rear wheel pulsation. Is stroke distance greater than 2.0 mm (0.079 in)?

Normal

End



Abnormal

Replace power cylinder.

4. Removal and Installation, Assembly and Disassembly


4-1 POWER CYLINDER AND LOWER LINK

① Removal and installation



[Point 1] Outer link and ball joint separation

- Using Pitman arm puller (commercial service tool), separate power cylinder outer arm link and axle housing ball joint.



CAUTION:

- Install ball joint cap only in right outer link. (Refer to figure.)
- Replace non-reusable parts with new parts after disassembly.

C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)

[Point 2] Power cylinder assembly removal and installation

Removal


- Remove piping around power cylinder, outer link and rear suspension with assembly.

CAUTION:


When removing piping, cover openings so dust, debris and foreign matter cannot enter (especially in pipe connections).

Installation

- When replacing any of the piping surrounding the power cylinder, outer link and rear suspension, attach disassembled parts to suspension members.
- The piping removal and installation sequence is (1), (2), (3) as shown in figure on the preceding page.



- When the power cylinder is installed on suspension member, wipe off all oil, debris and foreign matter from power cylinder side bracket and suspension member contact surfaces. Install bracket left side as reference to determine position of long hole on right side.




[Point 3] Fail-safe valve removal and installation

CAUTION:

- (1) Blow out pipes and ports with compressed air before installation to prevent entry of dirt, dust and foreign matter.
- (2) Perform operations in periphery of piping connections (especially in tube sheet removal and installation) with bare hands, being careful not to allow oil, dust or debris to adhere to the hands.
- (3) Always replace tube sheets that have been removed after every disassembly.


- After removing piping around rear suspension, always blow off piping and fail-safe valve with compressed air.
- Use pin punch (special service tool) to replace tube sheet as shown in figure on left, because scratches or cracks inside tube sheet in fail-safe valve can cause fluid leakage.



C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)

- Assemble tube sheet in port fail-safe valve as shown in figure.



C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)

[Point 4] Air bleeding hydraulic circuit

Air bleeding of HICAS system (power cylinder)

CAUTION:

Air bleeding of HICAS system must be performed after the air bleeding of power steering has been completed.

(1) When using CONSULT

- Connect CONSULT unit to vehicle diagnostic connector.
- Have a helper sit in driver's seat and raise vehicle.

Reference: Use a two-pole lift or a center pole lift so that the four wheels are free to rotate.

Start engine and maintain idle. Loosen left and right air bleeder valves above power cylinder and release oil until there are no more air bubbles.

Tighten left and right air bleeder valves.

- Start engine again.
- Touch "START" on CONSULT display. (Screen will change.)
- Touch "HICAS", "ACTIVE TEST", "SIMULATED DRIVE" and "START" in this order.

CAUTION: After touching "START", check that MAIN SIGNALS is displayed in reverse.


Touch "HIGH-SPEED SET".

* When engine is idling, turn steering wheel 180° from neutral position to right. Open air bleeder on right side of power cylinder gradually, bleed air from circuit and tighten bleeder again. Then return steering wheel to neutral position.

* When engine is idling, turn steering wheel 180° from neutral position to left. Open air bleeder on left side of power cylinder gradually, bleed air from circuit and tighten bleeder again. Then return steering wheel to neutral position.

- Touch "CANCEL" on CONSULT screen and turn ignition switch OFF.

The procedures marked with an asterisk (*) should be repeated until air bubbles no longer occur. Fill reservoir during operation to prevent fluid level from lowering to suction inlet level.



C15-041B

C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)

(2) When CONSULT is not used



Have a helper sit in driver's seat and raise vehicle.

Reference: Use a two-pole lift or a center pole lift so that the four wheels are free to rotate.

Start engine and maintain idle. Loosen left and right air bleeder valves above power cylinder and release oil until there are no more air bubbles.

Tighten left and right air bleeder valves.

Input self-diagnosis item.

- Turn ignition switch OFF.
- Turn steering wheel from neutral to left and right (at least 20° in each direction) 5 times or more while depressing brake pedal at least 5 times, all within 10 seconds after ignition switch has been turned "ON".

Set steering wheel in neutral position (within 10° left and right), and check that both rear wheels are being steered respectively.


* When engine is idling, turn steering wheel 180° from neutral position to right. Open air bleeder on right side of power cylinder gradually, bleed air from circuit and tighten bleeder again. Then return steering wheel to neutral position.

* When engine is idling, turn steering wheel 180° from neutral position to left. Open air bleeder on left side of power cylinder gradually, bleed air from circuit and tighten bleeder again. Then return steering wheel to neutral position.

Turn ignition switch OFF to cancel self-diagnosis.

The procedures marked with an asterisk (*) should be repeated until air bubbles no longer occur. Fill reservoir during operation to prevent fluid level from lowering to suction inlet level.

C15-0158B




[Point 5] Toe-in distance inspection and adjustment

- After installing power cylinder and lower link assembly perform toe-in inspection and check that distance is within specification.
- If value is outside specification, adjust toe-in.

C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)

② Assembly and disassembly




[Point 1] Power cylinder disassembly

CAUTION:

- (1) Blow off piping and ports before operation to prevent dust and foreign matter from entering area.
 - (2) Perform operations in periphery of piping connections (especially in tube sheet removal and installation) with bare hands, being careful not to allow oil, dust or debris to adhere to the hands.
- Do not disassemble any parts other than those shown in above figure (disassembly figure). Only disassemble pipes and inner sockets.

[Point 2] Dust boot installation

- Coat contact surfaces and boot installation groove with grease (Nissan MP special grease No. 2).




[Point 3] Power cylinder inner socket removal and installation

- Remove and install inner socket with power cylinder assembly installed in vehicle.


Removal

- Separate tie-rod from rear axle.
- Remove boot clamp from dust boot. Move left and right dust boots to outer link side.
- Attach tool to socket of left and right inner ball joints. Turn in direction that loosens both sides and remove loosened lower link assembly.




C12 SUPER HICAS


4. Removal and Installation, Assembly and Disassembly (Cont'd)



- Loosen and remove stroke stopper from removed lower link assembly.




- Attach wrench to the two flat areas on rod end from side stroke stopper that was removed from and turn to tighten. Loosen lower link assembly on opposite side and remove.




Installation

- Install stroke stopper and shim on assembled side of lower link assembly.



- Apply a coat of Locktite to inner ball joint screw. Attach wrench to the two flat surfaces on piston rod opposite from assembly side and turn to tighten. Install lower link assembly.



- After installing stroke stopper and shim on opposite side, install lower link assembly. Attach wrench to inner ball joint on opposite side and turn to tighten. Tighten to specified torque.

Inner socket tightening torque:

78 - 98 N·m (8.0 - 10 kg-m, 58 - 72 ft-lb)

C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)

[Point 4] Stroke inspection

- After assembling shim and stroke stopper, check clearance between inner socket and stroke stopper.
Clearance: 3 ± 0.1 mm (0.118 ± 0.004 in)

4. Removal and Installation, Assembly and Disassembly (Cont'd)

(1) Removal and installation

Diagram illustrating the rear suspension and drivetrain assembly, showing the engine, transmission, rear differential, and various linkages. The diagram includes torque specifications for various bolts and washers.

Part E details

Part H details

Additional work required

Remove and install:


- Engine under cover
- Rear muffler

Inspect oil tank fluid level [Point 2]

Bleed air: [Point 3]

Legend:

- N·m (kg-m, ft-lb)
- X: Always replace after every disassembly.




C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)

[Point 1] HICAS solenoid valve piping removal and installation

CAUTION:

- (1) Handle pipes with bare hands and pay attention to prevent dust or foreign matter from adhering.
- (2) Be careful not to install pipes in incorrect location or sequence during assembly.



Removal

- Remove HICAS solenoid valve connector and pipe clamp bracket.
- Remove power steering fluid from vehicle side centralized pipe connection.
- Remove HICAS solenoid valve pump port, tank port and power cylinder port on right side and flare nuts and union bolts on left side. Remove bolts from HICAS solenoid valve mount.

CAUTION:

- (1) **Never disassemble HICAS solenoid valve or fail-safe valve.** This part cannot be disassembled because if the lock nuts on the fixed part of the HICAS valve solenoid are loosened, the pressure adjustment distance will vary.
- (2) Cover caps of removed pipes and hoses with plugs to prevent dust and foreign matter from entering.

Installation

- Temporarily tighten flare nuts and union bolts and tighten HICAS solenoid valve mount bolts. Secure tube clamp bracket and tighten port union bolts.

[Point 2] Fluid tank fluid level inspection

- Refer to "2. On-vehicle Inspection and Adjustment" for inspection procedures.

[Point 3] Air bleeding fluid circuit

- Refer to "4-1 POWER CYLINDER AND LOWER LINK ① Removal and installation" for a description of air bleeding procedures for HICAS system.



C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)

(2) Power steering pump removal and installation, assembly and disassembly

Assembly and disassembly precautions

- ① If oil pump and tank assembly and disassembly is required, perform the following procedures for removal and installation from vehicle.
 - Indicate oil leakage locations with a white marking pen.
 - Remove oil and cap openings.
 - Loosen pulley nut before loosening belts. Tighten tension on all belts before installation.
- ② **Attachment preparation**
 - Prepare the following attachments.





- Wash off grease on oil pump with white gasoline. Cover openings in outlet port, return ports to prevent white gasoline from entering. Be careful not to drop white gasoline on oil seal of drive shaft.
- Never reuse any O-ring, oil seal, snap ring, or washer (copper). Always replace with new part after every use. (New parts are contained in repair kits.)
- Replace entire assembly if front and rear housing, drive shafts, rotor, cam and flow control valve are scratched, dented or scored.

C12 SUPER HICAS


4. Removal and Installation, Assembly and Disassembly (Cont'd)

③ Power steering pump disassembly (Model 05U00)



[Point 1] Pulley removal and installation

- Loosen in unit if pulley nut cannot be loosened when pump is installed in vehicle.
- Secure bracket in vise.
- Place Fillips head screwdriver in pulley hole and through front housing bolt hole to secure pulley and loosen pulley nut.
- Inscribe mating marks on front side of pulley to prevent incorrect pulley alignment and then remove pulley.



[Point 2] Attachment installation



- Secure attachment in vise.
- Install front housing in attachment.

C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)

[Point 3] Cam and gasket installation


- Install the thicker side of cam ($t_1 > t_2$) facing front side.



- Check gasket alignment, and install one each at front housing and center housing and center housing and rear housing.


[Point 4] Rotor installation

- Install rotor so the chamfered side of spline is faces rear housing side and side without chamfering faces front housing side. (Otherwise, install rotor so the punch mark side faces rear housing side and side without punch mark faces front housing side.)



[Point 5] Vane installation

- Assemble so rounded end faces cam surface.




[Point 6] Drive shaft removal and installation

- Pull shaft straight out slowly to remove.

CAUTION:

Be careful not to scratch bushing inside front cover or oil seal.

- Coat drive shaft with power steering fluid and press in slowly to install.
- Press into bottom, pull out 15 mm (0.59 in) and then slowly press in again.




C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)


CAUTION:

Replace oil pump assembly carefully to prevent scratching drive shaft and bushing.



[Point 7] Outlet connector removal

- Outlet connector is installed inside front control valve (sub-spool). Be careful not to drop or deform during removal.
- Do not disassemble outlet connector and flow control valve.



[Point 8] Oil seal removal and installation

- Pay attention not to scratch sliding surface of oil seal during removal and installation.
- Use a screwdriver wrapped in tape to remove seal.

CAUTION:


- (1) Insert screwdriver in position shown in figure.
 - (2) Do not scratch surface A (oil seal installation mating surface) shown in figure.
- If this surface is scratched, replace entire oil pump assembly.

- Use a taped 22-mm box wrench for installation.

CAUTION:

Check that oil seal is positioned straight and lightly tap seal into end of front housing with hammer to install.

- After installation, apply a thin coat of Nissan MP special grease No. 2 around oil seal lip.
- Touch spring with finger to check that it is installed in correct position.




[Point 9] O-ring installation

- Coat O-rings with power steering fluid.
- Install O-rings inside groove in housing.

C12 SUPER HICAS

4. Removal and Installation, Assembly and Disassembly (Cont'd)



[Point 10] Rear housing installation

- Secure front housing in attachment. Position cam, rotor center housing, cam, rotor and rear housing and install.
- Tighten bolts in diagonal sequence. First tighten each bolt to approximately half of specified torque and then tighten again to final torque.

Rear housing installation bolt tightening torque:

RB26DETT

31 - 42 N·m (3.2 - 4.3 kg-m, 23 - 31 ft-lb)

[Point 11] Inspection

- Do not reuse removed rubber parts (O-rings, oil seal and snap rings) or washers (copper). (Replace with parts in repair kit.)
- Replace pump assembly if the following parts are scratched or damaged.
 - ① Front housing and center housing mating surfaces
 - ② Rear housing and cam center housing mating surfaces
 - ③ Front housing oil seal
 - ④ Flow control valve
 - ⑤ Drive shaft
 - ⑥ Rotor

BODY


SECTION **BF**

CONTENTS

D BODY	
D1 BODY	BF- 2
1. Body Construction	BF- 2
2. Sealing	BF- 3
D2 BODY EXTERIOR	BF-10
1. Bumper	BF-10
2. Grille	BF-15
3. Front Fender	BF-16
4. Molding	BF-17
5. Window Glass	BF-22
6. Outside Mirror	BF-24
7. Spoilers	BF-28
8. Drafter	BF-29
9. Center Mudguard and Chipping Protector	BF-30
D3 OPEN-CLOSE MECHANISM	BF-31
1. Hood	BF-31
2. Door	BF-32
2-1 Fitting standard and adjustment	BF-32
2-2 Door assembly removal and installation	BF-33
2-3 Front door trim removal and installation	BF-34
2-4 Front door lock and remote control removal and installation	BF-35
2-5 Front door window and regulator removal and installation	BF-37
2-6 Power door lock trouble diagnosis	BF-41
2-7 Power window trouble diagnosis	BF-44
3. Trunk Lid	BF-51
D4 BODY INTERIOR	BF-53
1. Instrument Panel	BF-53
2. Interior Trim and Equipment	BF-62
3. Seat	BF-66
4. Seat Belts	BF-69

D1 BODY



1. Body Construction



D1 BODY

2. Sealing


2-1 WEATHERSTRIPS




2-door Sports Coupe

D1 BODY


2. Sealing (Cont'd)




Section A—A




Section B—B




Section C—C



Section D—D




Section E—E




Section G—G

D1 BODY

2. Sealing (Cont'd)




Section I—I




D01-0078

Section J—J



D01-0079

Section K—K




D01-0080

Section L—L

D1 BODY


2. Sealing (Cont'd)

2-2 BODY SEALING




D1 BODY


2. Sealing (Cont'd)




View A




View B




View C




View D



View E




View F




View G (2-door)

D1 BODY


2. Sealing (Cont'd)




View H (2-door)




View I (2-door)




View J (2-door)




View K (2-door)




View L



View N




View P




View R

D1 BODY


2. Sealing (Cont'd)




View M



View O



View Q





View S

D2 BODY EXTERIOR

1. Bumper

1-1 BUMPER FASCIA REMOVAL AND INSTALLATION



[Point 1] Bumper fascia removal

- First remove bumper fascia separately because intercooler tube prevents removal of bumper assembly.

[Point 2] Bumper fascia installation



- Install bumper fascia by fitting flange portion of bumper reinforcement into dent of bumper fascia.

D2 BODY EXTERIOR

1. Bumper (Cont'd)

1-2 BUMPER REINFORCEMENT

(1) Removal and installation




[Point 1] Bumper stay removal

- Remove bumper stay securing bolt.
- Loosen bumper stay securing nut, and remove bumper stay from body by sliding forward.

NOTE:

Do not remove bumper stay securing nut. It should only be loosened but kept attached to stud bolt on body side.




[Point 2] Bumper stay installation

- Attach grommet to bumper stay bracket as shown at left, and then fit grommet onto positioning pin located on the upper part of intercooler.

D2 BODY EXTERIOR


1. Bumper (Cont'd)

(2) Bumper reinforcement disassembly



1-3 REAR BUMPER

(1) Removal and installation




D2 BODY EXTERIOR

1. Bumper (Cont'd)


[Point 1] License plate bracket removal

- Remove bolt from rear side of license plate.
- Pull up bracket together with license plate.





[Point 2] License plate bracket installation

- With 2-door type vehicle, install license plate bracket as shown after replacing bumper, because space is limited around license plate bracket securing bolt.



1. Bumper (Cont'd)

(2) Disassembly





[Point 1] Bumper center bracket removal

- Pull out two pawls located at the center of bumper center bracket in the direction of arrow (➡) using standard screwdriver.
- Draw out bumper center bracket from bumper fascia by sliding it either rightward or leftward.

D2 BODY EXTERIOR


2. Grille

2-1 FRONT GRILLE REMOVAL AND INSTALLATION



[Point 1] Turn fastener removal

- Rotate front grille upper side turn fastener 45° by fitting screwdriver tip into slot of turn fastener head, and remove turn fastener.
Wrap vinyl tape or cloth around metal part of screwdriver to prevent grille and bumper from being scratched.




[Point 2] Securing clip removal

- Remove clip by holding with pliers from rear side of hood lock stay.

D2 BODY EXTERIOR

3. Front Fender



3-1 FENDER AND FENDER PROTECTOR REMOVAL AND INSTALLATION



D2 BODY EXTERIOR

4. Molding

4-1 WINDSHIELD MOLDING



[Point 1] Side molding removal and installation


Removal

- ① Using standard screwdriver with its end portion bent as shown, disengage fastener from side molding by sliding lower two side molding clips.

NOTE:

Be sure to apply cushioning cloth under screwdriver to prevent glass from being damaged.

- ② Remove side molding from fastener by pulling out lower end of molding.



D2 BODY EXTERIOR



4. Molding (Cont'd)

Installation

- ① Fit clip into side molding as shown at left.

NOTE:


Four different clips are used; Pay attention not to confuse clips.



- ② Fit upper end of side molding into upper molding, and tap side molding clip portion with hand until clip fits in fastener with a snap.

NOTE:

Do not apply undue force when tapping. If difficult to fit, change clip position slightly.



[Point 2] Upper molding removal and installation

- ① After removing side molding, pull out upper molding by lifting its end up.
- ② Cut sealant at end of glass, and clean panel surface after removing fastener.
- ③ Bond fastener to body using double-faced adhesive tape, then apply primer to panel and molding leg portions.
- ④ Pack sealant between glass and body so that molding leg can be bonded securely.
- ⑤ Squeeze upper molding into position.




NOTE:

Repair panel surface if scratched when cutting sealant.

D2 BODY EXTERIOR

4. Molding (Cont'd)

4-2 REAR WINDOW MOLDING



[Point 1] Upper molding removal and installation

- ① Remove lower molding securing screws, and remove molding from body.
- ② Remove corner molding clips, and remove corner molding from fastener.
- ③ Remove upper molding by lifting its end up.
- ④ Cut sealant at glass end portion, remove faster and clean panel surface.
- ⑤ Bond fastener to body using double-faced adhesive tape, then apply primer to panel and molding leg portion.
- ⑥ Pack sealant between glass and body so that molding leg can be bonded securely.
- ⑦ Bond upper molding and joint molding using sealant to make up sub assembly.
- ⑧ Squeeze upper molding sub assembly into fastener.
- ⑨ Fit clip into corner molding, and fit corner molding to upper molding, then tap molding until it fits snugly into fastener.
- ⑩ Fix lower molding using screws.


NOTE:

Repair panel surface by coating if scratched while cutting sealant.

D2 BODY EXTERIOR

4. Molding (Cont'd)

4-3 DRIP MOLDING REMOVAL AND INSTALLATION





NOTE: Pay attention not to create clearance when installing.

D2 BODY EXTERIOR

4. Molding (Cont'd)

4-4 DOOR OUTSIDE MOLDING REMOVAL AND INSTALLATION




D2 BODY EXTERIOR

5. Window Glass

The windshield, rear window and rear side windows are bonded with urethane sealant. Refer to "Windshield removal and installation" in "Basic Servicing Procedure".



5-1 WINDSHIELD AND REAR WINDOW




D2 BODY EXTERIOR

5. Window Glass (Cont'd)


5-2 REAR SIDE WINDOW GLASSES (2-door Sports Coupe)



Primer application range (all around)



Sealant application quality



NOTE: Do not apply primer to gradation area.


Unit: mm (in)

D2 BODY EXTERIOR


6. Outside Mirror

6-1 STANDARD AND HEATER FITTED DOOR MIRROR

(1) Components




(2) Mirror assembly removal and installation



D2 BODY EXTERIOR

6. Outside Mirror (Cont'd)

(3) Mirror removal and installation



NOTE: To install, proceed as ④ → ③ → ② → ① by reversing the removal sequence.

D2 BODY EXTERIOR


6. Outside Mirror (Cont'd)

(4) Mirror rim removal and installation

Removal

Remove and install: Mirror and actuator [operations (Parts not shown) ①, ② and ③]

- Remove mirror rim securing screws (six) as shown at left.
- Pull out mirror rim from mirror body by detaching rim from mirror body pawl.




(5) Mirror body removal and installation

Removal


Remove and install: Mirror, actuator [operations ①, ② and ③] and mirror rim

- Remove mirror fixing screws (two) as shown at left.
- Remove mirror body after setting it in storage position.



6-2 FENDER MIRROR

(1) Fender mirror removal and installation



D2 BODY EXTERIOR

6. Outside Mirror (Cont'd)

6-3 CHANGE INTO DOOR MIRROR AND CHANGE INTO FENDER MIRROR

(1) Change from door mirror to fender mirror


① Whether changeable or not and required items

Changeability	Harness connector in fender portion	Front door cover	Electric fender mirror components	Installation position
Yes	Not provided	Provided	Provided	See below

NOTE:

Only patrol car specification has electrically operated mirror.

② Installation position



NOTE:

Apply anti-rust coating to drilled holes.

(2) Change from fender mirror to door mirror


① Whether changeable or not and required items

Changeability	Harness up to door	Fender hole stopping patch (service part)	Door mirror
Not provided	Provided	Not provided	Provided


D2 BODY EXTERIOR

7. Spoilers

7-1 FRONT SPOILER REMOVAL AND INSTALLATION




7-2 REAR SPOILER REMOVAL AND INSTALLATION




D2 BODY EXTERIOR

8. Drafter



D2 BODY EXTERIOR


9. Center Mudguard and Chipping Protector (GT-R model)




D3 OPEN-CLOSE DEVICES

1. Hood

1-1 FITTING STANDARD AND ADJUSTMENT




1-2 HOOD ASSEMBLY AND HOOD INSULATOR REMOVAL AND INSTALLATION



D3 OPEN-CLOSE DEVICES

1. Hood (Cont'd)


1-3 HOOD LOCK CONTROL REMOVAL AND INSTALLATION



2. Door

2-1 FITTING STANDARD AND ADJUSTMENT

(1) 2-door Sports Coupe



D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)




[Point 1] Door hinge adjustment

Remove and install: Fender protector (Parts not shown)

- Remove fender rear end securing bolts (four), and adjust door hinge using offset wrench while lifting fender off vehicle body.

NOTES:

- (1) Pay attention not to deform fender when lifting.
- (2) Keep waste cloth inserted under upper part of fender while adjusting.



2-2 DOOR ASSEMBLY REMOVAL AND INSTALLATION

(1) Removal, installation and inspection

- To remove and install, remove check link pin and then remove door side hinge bolts (two each, upper and lower).
- When removing, pay attention not to damage coated surface.

NOTES:



- (1) When removing and installing, support door assembly using jack, cushioned with waste cloth to prevent damage to door.
- (2) Check door hinge for the following points:
Abnormality or large resistance during opening or closing ... Apply grease
Damage or wear on components ... Replace
- (3) Replace check link if damaged or worn abnormally.
- (4) Install check link with RH or LH identification mark facing up.
- (5) Apply "Nissan body grease" to rotating part of hinge and to check link pin.

D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)


2-3 FRONT DOOR TRIM REMOVAL AND INSTALLATION

(1) 2-door Sports Coupe



[Point 1] Inside handle escutcheon removal

- Using standard screwdriver wrapped with vinyl tape, remove escutcheon by disengaging upper and lower pawls.



[Point 2] Power window switch removal

- Insert standard screwdriver tip to front end, and push screwdriver rearward to disengage metal clip, and then remove power window switch.

D3 OPEN-CLOSE DEVICES


2. Door (Cont'd)

[Point 3] Capped screw removal

- Using standard screwdriver, open screw head cap, and then remove screw.



NOTE:

Cap is made integral with screw. Pay attention not to tear off cap from cap base when removing screw.



2-4 FRONT DOOR LOCK AND REMOTE CONTROL REMOVAL AND INSTALLATION

(1) 2-door Sports Coupe



[Point 1] Inside handle rod adjustment

- Fix door lock and inside handle, and adjust bell crank in direction of arrow shown at left to eliminate rod play, then secure with screws.

D3 OPEN-CLOSE DEVICES


2. Door (Cont'd)

[Point 2] Outside handle rod adjustment

- Rotate bushing so that clearance between bushing and rod meets specification shown at left.

NOTE:


Clearance must be greater than 0 mm (0 in), or outside lever must be free when not being operated.



[Point 3] Outside handle single part removal

Removal

- Completely close window.
- Disconnect key cylinder rod and outside handle rod connections.
- Remove two nuts and remove outside handle.




[Point 4] Key cylinder removal and installation

Removal

- Insert tip of small standard screwdriver into clearance between clip and key cylinder to disengage clip, and remove key cylinder.

Installation

- Install clip to key cylinder case, and then insert key cylinder.




[Point 5] Door lock switch removal

Remove and install: Inside and outside handle rods, key cylinder rod (Part not shown)

- Remove rod, and remove door lock assembly screws (three) and door lock switch bolt (one), and then remove door lock assembly.
- Remove screws (two) to separate door lock assembly from door lock switch.

NOTE:

Door lock switch cannot be removed from door lock assembly if the assembly is installed on vehicle. Be sure to remove door lock switch together with door lock assembly.





D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)

2-5 FRONT DOOR WINDOW AND REGULATOR REMOVAL AND INSTALLATION

(1) 2-door Sports Coupe




[Point 1] Door window adjustment

- Door window fitting can basically be adjusted by moving window in four directions as shown below.
- ① Window position (front-end down, rear-end down)
- ② Fore and aft adjustment of window
- ③ Vertical adjustment of window (upper limit)
- ④ Right and left adjustment of window (inward or outward inclination)
- Perform adjustment at the positions shown below.


D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)



Adjustment work

- To adjust door window position, proceed as follows:



Remove body-side weatherstrip when performing these adjustments.

D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)


① Window position adjustment

Remove and install: Body side weatherstrip (Part not shown)

NOTE:

Perform this position adjustment simultaneously with fore-aft adjustment in step ②.


- With window raised, loosen securing bolts C, D, E, and F, and adjust inclination of window using bolts C and D so that a uniform clearance will be obtained between window and retainer at positions A and B.



Window front end down:	Raise adjustment bolt C using bolt D as supporting point.
Window rear end down:	Raise adjustment bolt D using bolt C as supporting point.

② Fore-aft adjustment of window


- Loosen bolts [C, D, E, and F shown in step ① above] and slide regulator in fore-aft direction so that clearance between rear end of window and retainer meet standard shown at left, then temporarily secure bolts by tightening nuts.



- When adjusting, slightly lower window to create clearance between door side stopper and window side stopper.

NOTE:

Do not lower window excessively.




D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)

③ Vertical adjustment of window

- With window fully closed, adjust height of door window stoppers (door side) ③ and ④ so that retainer lower end and window top end positions meet specification shown at left, then secure stoppers with nuts.




④ Right and left adjusting of window


- Use lower two of four adjusting bolts.

NOTES:

- Rotate adjusting bolt in CW direction, and end of window will move outward. Rotate adjusting bolt in CCW direction, and end of window will move inward.
- Slightly lower window, like in the case of fore-aft adjustment, to create a clearance between door side stopper and window side stopper.




- Loosen nuts (front and rear), and loosen adjusting bolt and tilt window fully inward until adjusting bolt flange contacts inner panel.



- With door fully closed in the above-mentioned position, tighten adjusting bolts a few turns until inside of window lightly contacts retainer.

NOTE:

Evenly tighten front and rear adjusting bolts.




D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)

- After completing adjustment, tighten lock nut securely.

NOTE:

When tightening lock nut, hold adjusting bolt using standard screwdriver to prevent rotation.



2-6 POWER DOOR LOCK TROUBLE DIAGNOSIS

(1) Outline of trouble diagnosis (2-door Sports Coupe)


Carry out trouble diagnosis according to flowchart.

Power door lock fails to operate

Any door other than driver seat (front passenger seat) fails to operate.

- Prepare the following tools and equipment for trouble diagnosis.
 - Analog circuit tester
 - Sub harness and battery (for checking door lock actuator operation)
 - Tools for removing and installing parts (screwdriver, wrenches, etc.)
- Carry out the following inspection when diagnosing.
 - *1: Door lock timer connector disconnected
 - *2: Door lock actuator connector disconnected
 - *3: Door lock knob and key cylinder interlocking switch disconnected, or rod disconnected, and bell crank installed.


(2) Components



D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)

(3) System diagram




D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)

(4) Diagnostic chart

- Front passenger seat door lock fails to operate.




D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)

[Point 1] Continuity test on switch


- Manually move rod and check for continuity between terminals. If continuity exists, tester needle will momentarily move from infinity side to zero ohm side.



2-7 POWER WINDOW TROUBLE DIAGNOSIS

(1) Outline of trouble diagnosis (2-door Sports Coupe)

- Troubles on vehicle are classified into four large categories, and trouble diagnosis is performed according to flowchart for each category.
- Trouble diagnostic conditions are: ignition switch ON and power window lock switch in UNLOCK position.



REMARKS:

Nearest switch operation: Attempt to operate door window by operating its nearest power window switch.

Remote switch operation: Attempt to operate front passenger door window by operating power window main switch by driver seat.


- Caution during Trouble Diagnosis**

Trouble diagnosis is performed with ignition switch set ON. When repairing trouble, be sure to disconnect battery negative terminal.

D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)

(2) System diagram




D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)

(3) Diagnostic chart


(A) No door window moves using respective power window switch



D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)


(B) Unable to operate driver seat window alone



D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)


(C) Unable to operate front passenger seat window using the switch on that door



D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)

(D) Front passenger seat window will operate with the switch on that door, but will not operate with remote switch.






D3 OPEN-CLOSE DEVICES

2. Door (Cont'd)


[Point 1] Power window main switch continuity inspection

- Set power window lock switch in locked position (with lock button pressed), and operate driver seat and front passenger seat switches to check continuity between respective terminals using circuit tester.




[Point 2] Power window lock switch continuity inspection

- Set lock switch in unlocked position (with lock button not depressed), and press DOWN end of driver seat manual switch. Check continuity between terminals ② and ⑦ using circuit tester.



[Point 3] Continuity inspection of front passenger seat power window switch

- Operate switch in each position, and check continuity between respective terminals using circuit tester.




D03-0444


D3 OPEN-CLOSE DEVICES

3. Trunk Lid

3-1 FITTING STANDARD AND ADJUSTMENT




3-2 TRUNK LID ASSEMBLY



D3 OPEN-CLOSE DEVICES

3. Trunk Lid (Cont'd)


3-3 TRUNK LID OPENER AND FUEL LID OPENER REMOVAL AND INSTALLATION



D4 BODY INTERIOR

1. Instrument Panel

1-1 INSTRUMENT PANEL ASSEMBLY REMOVAL, INSTALLATION AND DISASSEMBLY




NOTE: Parts with mark * must be removed using screwdriver wrapped with vinyl tape or cloth.

D4 BODY INTERIOR

1. Instrument Panel (Cont'd)


1-2 ACCESSORY PARTS REMOVAL AND INSTALLATION AFTER REMOVING AND INSTALLING INSTRUMENT PANEL ASSEMBLY



D4 BODY INTERIOR


1. Instrument Panel (Cont'd)

Detailed operations



D4 BODY INTERIOR

1. Instrument Panel (Cont'd)



D4 BODY INTERIOR

1. Instrument Panel (Cont'd)

- ⑤1

Glove box lid striker
- ⑤2

Right and left instrument panel masks

 [Point 14] (Single part)
- ⑤3

Instrument panel assembly securing bolts (two), screws (two), and nuts (two)
- ⑤4

Instrument panel assembly

 [Point 15]
 - ⑤5

Side ventilator grille (left)

 (Single part)
 - ⑤6

Side defroster grilles (right, left)

 (Single part)
 - ⑤7

Center ventilator grille

 [Point 16] (Single part)
 - ⑤8

Front defroster grille (right, left)
 - ⑤9

Heater duct and nozzle securing screws (14)
 - ⑥0

Heater duct and nozzle


D4 BODY INTERIOR

1. Instrument Panel (Cont'd)

[Point 1] Side ventilator grille (right) removal


Remove and install: Lower instrument panel cover, hood opener

- Remove ventilator grille securing screws (two) from rear side of lower instrument cover, and remove ventilator grille (right).



[Point 2] Cluster switch A removal

- Remove cluster lid A, and then remove screws (two on each side) from rear side, and separate cluster lid A and cluster switch A.




[Point 3] Control switch removal

- Remove control switch securing screws from rear side of cluster lid A, and then remove switch while pressing it inward.

NOTE:

When installing switch, pay attention not to tighten screws excessively.




[Point 4] Combination switch removal and installation

Removal

- Remove switch knob by pulling in direction of arrow, and remove combination switch by removing securing screws (five) from rear side of cluster lid A.


NOTE:

Control switch must be removed before removing combination switch. (This precaution applies to both right and left sides.)



Installation

- Install switch, and then install switch knob by aligning mark position.
- After installation, check for normal switch operation by operating switch.




D4 BODY INTERIOR

1. Instrument Panel (Cont'd)

[Point 5] Combination meter removal

Remove and install: Cluster lid A (Parts not shown)

- Remove screws (four), and pull out combination meter.



[Point 6] Glove box removal and installation

Removal


- Remove screws (two), and remove damper clip from bracket located inside of glove box.

Installation

- Insert clip into bracket while pulling damper wire, then install glove box fully closed.


NOTE:

Pay attention not to cut off damper wire.




[Point 7] Glove box lid separation

- Remove lid securing screws (eight), and pull off lid hinge pin to disengage hinge, and then remove lower screws (two) to separate glove box lid into inner and outer portions.



[Point 8] Glove box cover installation

- Install glove box light harness connector to cover, and fit cover clamp securely into steering member, and tighten screws (two).




[Point 9] Cluster lid C removal and installation

Removal

- Remove cluster lid securing screws (four), and remove rear end metal clip using standard screwdriver, then remove cluster lid by pulling resin pawls fitted upper end portion forward.

Installation

- Fit resin pawls into respective position, and install cluster lid by pressing it in direction of arrow.




D4 BODY INTERIOR

1. Instrument Panel (Cont'd)

[Point 10] Heater control removal


- After removing audio unit, remove heater control securing screws (two) and remove heater control by pulling it to the side.



[Point 11] Console box removal and installation


Removal

- Remove console box securing screws (two on each side), and then remove console box by disengaging parking brake lever while lifting console box.




Installation

- Install console box by inserting resin pawls securely into respective holes of lower instrument panel.




[Point 12] Lower instrument panel (middle) removal

- To prevent interference with parking brake lever, remove parking brake lever securing bolts (four) first, then remove lower instrument panel (middle) by pulling it rearward.



[Point 13] Instrument panel mask removal

- Remove instrument panel mask by inserting stubby standard screwdriver between mask and instrument panel pad.




D4 BODY INTERIOR

1. Instrument Panel (Cont'd)


[Point 14] Instrument panel installation

- Set instrument panel by aligning locating pin, and then tighten screws in sequence shown at left.
- Make sure each duct is fitted correctly to grille.
- Secure speedometer cable by sliding it into cut-out portion of cable hole in instrument panel.




[Point 15] Ventilator grille removal

- ① Insert thin standard screwdriver **A** through clearance between grille fins.
- ② Pry up resin pawls by inserted screwdriver.
- ③ Insert another standard screwdriver **B** into clearance between grille and instrument panel.
- ④ Carefully pull out grille using screwdriver **B** while prying up resin pawls using screwdriver **A**, and remove grille from instrument panel assembly.



Notes on removal

- Because the grille pawls are positioned deep, do not attempt to pry up grille as shown at left; otherwise, grille main body and grille cover will be damaged.
- If unable to remove grille using method shown in steps ① thru ④, first remove instrument panel assembly, then remove ventilator grille.







D4 BODY INTERIOR

2. Interior Trim and Equipment (Cont'd)

(2) 2-door Sports Coupe




[Point 1] Body side welt installation

- Install body side welt by aligning welt end with cut-out notch of outer panel indicated by arrows at left so that lip will face inside of compartment.

NOTE:

2-door Coupe has notches at (a) and (b) only. (See illustration at left.)



[Point 2] Retainer installation


- Fit floor trim retainer onto sill flange completely.

D4 BODY INTERIOR


2. Interior Trim and Equipment (Cont'd)

2-2 HEAD LINING REMOVAL AND INSTALLATION

(1) Standard model



2-3 CONSOLE BOX REMOVAL AND INSTALLATION



D4 BODY INTERIOR


2. Interior Trim and Equipment (Cont'd)

[Point 1] Capped screw removal


- Open screw head cap using standard screwdriver, and then remove screw.

NOTE:

Cap is made integral with screw. Pay attention not to tear off cap from base.



2-4 TRUNK TRIM REMOVAL AND INSTALLATION




D4 BODY INTERIOR


3. Seat (GT-R model)

3-1 FRONT SEAT REMOVAL & INSTALLATION, AND DISASSEMBLY

Disassembly



Removal and installation



Ⓐ : N·m (kg·m, ft·lb)


■ : Nissan MP special grease No. 2

D4 BODY INTERIOR

3. Seat (GT-R model) (Cont'd)


[Point 1] Reclining device removal

- Remove trim end fastener of seat back assembly, and remove two securing bolts by taking off trim.



[Point 2] Seat trim clip removal (outer side)


- Using clip screwdriver, carefully remove three clips which secure seat trim to slide rail on side face of seat cushion.



[Point 3] Seat trim retainer removal and installation (inner side)


Removal

- Disengage seat trim retainer from seat frame by pushing down with finger.



Installation


- Hook trim & pad assembly to seat frame, and inner side retainer to wire.
- Install trim & pad assembly while making sure trim and retainer are correctly engaged.



D4 BODY INTERIOR

3. Seat (GT-R model) (Cont'd)


3-2 REAR SEAT REMOVAL & INSTALLATION, AND DISASSEMBLY



D4 BODY INTERIOR

4. Seat Belts

4-1 SEAT BELT ANCHORAGE





D4 BODY INTERIOR


4. Seat Belts (Cont'd)

4-2 FRONT SEAT BELT REMOVAL AND INSTALLATION


2-door Sports Coupe




Shoulder anchor section



R.H. lap inner section



R.H. lap outer section



E.L.R. section



: N·m (kg-m, ft-lb)

D04-0123


D4 BODY INTERIOR

4. Seat Belts (Cont'd)


4-3 REAR SEAT BELT REMOVAL AND INSTALLATION




Shoulder anchor section



Floor section



E.L.R. section

 : N·m (kg-m, ft-lb)

D04-0108

Inspection

- Check whether seat belt can be handled normally.
- Check seat belt webbing for damage, wear, discoloration, and metal parts for deformation.

NOTES:

- (1) Use neutral detergent to clean webbing.
- (2) Do not disassemble belt buckle and E.L.R. assembly.

HEATER & AIR CONDITIONER

SECTION **HA**

CONTENTS

H HEATER & AIR CONDITIONER	
H1 AIR CONDITIONER	HA- 2
1. Full Automatic Air Conditioner	HA- 2
1-1 Prior to trouble diagnosis	HA- 2
1-2 System diagram	HA- 3
1-3 Self-diagnosis	HA- 4
1-4 Sensor inspection	HA-10
1-5 Actuator inspection	HA-15
1-6 Actuator removal and installation	HA-23

H1 AIR CONDITIONER


1. Full Automatic Air Conditioner

1-1 PRIOR TO TROUBLE DIAGNOSIS

This fully automatic air conditioner has a self-diagnostic function for checking its major components. Using this self-diagnostic function, it is possible to check whether the signal issued from each sensor is within the effective range of the respective sensor characteristics, and whether each actuator can respond correctly to a control signal issued by force under a predetermined condition. It is also possible to check the function of the display section, mode signal, and each sensor. This means that, using the self-diagnostic function, most components of this fully automatic air conditioner can be checked. After identifying a faulty section, however, each sensor or actuator must be examined using conventional method.


If an error in the electrical system is determined as the cause of a fault, for example, it is also necessary to check fuses, connectors, and terminals, etc. in addition to self-diagnosis.

Fuses that need inspection



No.	Capacity	Power supply system	Major load (Air conditioner)
4	15A	ACC	Blower fan motor, auto amplifier
5			
10			Magnet clutch
20	10A	IGN	Air conditioner relay, intake door actuator, HI relay, auto amplifier
23		BAT	Auto amplifier

The basic troubleshooting flow diagram is shown below:




(*) NOTE:

Self-diagnostic function is unable to check such phenomena that cannot be reproduced.

H1 AIR CONDITIONER


1. Full Automatic Air Conditioner (Cont'd)

1-2 SYSTEM DIAGRAM



H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)



1-3 SELF-DIAGNOSIS

(1) Self-diagnosis set

To change from ordinary automatic air conditioner control mode into self-diagnosis mode, depress automatic air conditioner OFF switch for more than five seconds within 10 seconds after turning ignition switch to ON from OFF. Start engine to prevent discharging discharged battery when performing self-diagnosis.

To return to automatic air conditioner control mode from self-diagnostic mode, turn ignition switch OFF, or depress air conditioner switch.

Self-diagnostic program is designed to facilitate detection of a fault. It consists of the following five self-diagnostic steps and one customizing step.


Steps 1-5 can be selected by depressing HOT switch or COLD switch. Steps 5 and 6 can be selected by depressing fan switch.

NOTE:

Step 6 is not used for trouble diagnosis.

Description of each step

Step 1:	Segment check (Display section and LED)
Step 2:	Sensor check
Step 3:	Mode door position check
Step 4:	Actuator operation check
Step 5:	Sensor recognition temperature display
Step 6:	<ul style="list-style-type: none">● To set difference between display temperature and sensed temperature● To memorize intake port when ignition switch is OFF



(2) Step 1 (Display section and LED segment check)

Normal: All display and LEDs are lit.

Abnormal: Failed portion is not lit.

H1 AIR CONDITIONER



1. Full Automatic Air Conditioner (Cont'd)

(3) Step 2 (Sensor check)

Step 2 is selected by depressing HOT switch(△)while in step 1 status.

Microcomputer detects whether each sensor input signal satisfies set conditions, and results are displayed on display section.

Normal: '20' is displayed in display section.



Abnormal: Failed sensor number is displayed. If sensor short-circuit is detected, a minus sign (-) is also indicated.

If error is detected in two or more sensors, each sensor number is displayed by flashing twice in turn.

NOTE:

If vehicle is positioned in dark place or if sunlight is exceptionally strong, then sunload sensor error may be indicated.

Display number and corresponding sensor, and judgment criteria

Display No.	Sensor	When disconnected	When shorted
20	(Normal)	—	—
21	Outside air sensor	Below -60°C (-76°F)	Above 100°C (212°F)
22	Inside air sensor	Below -60°C (-76°F)	Above 100°C (212°F)
23	Water temperature sensor	Below -50°C (-58°F)	Above 150°C (302°F)
24	Intake temperature sensor	Below -50°C (-58°F)	Above 100°C (212°F)
25	Sunload sensor	Below 0.030 kW (26 kcal/h, 103 BTU/h)/m² [0.0028 kW (2.42 kcal/h, 9.6 BTU/ h)/sq ft]	Above 1.323 kW (1,138 kcal/h, 4,516 BTU/h)/m² [0.1229 kW (105.72 kcal/h, 419.5 BTU/h)/ sq ft]
26	PBR (Note)	Above 4.9V	Below 0.1V
27	Refrigerant temperature sensor	Below -50°C (-58°F)	Above 100°C (212°F)

NOTE:

PBR is judged based on air mix door opening of 40%.

(Full cold: 0%, full hot: 100%)

If sensor is judged as faulty in step 2, check single sensor according to "1-4. SENSOR INSPECTION", and determine whether failure is in sensor or harness.

H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

(4) Step 3 (Mode door position check)

Depress HOT switch (Δ) while in step 2 status, and step 3 will be selected.

In this step, mode door actuator operates, and whether input signal from position detection switch is normal is checked by microcomputer, and the results are indicated on display section.

NOTE:

Approximately 16 seconds are required to complete inspection of all modes.

NORMAL: '30' will be displayed.


ABNORMAL: Number of faulty modes are displayed.

If two or more modes are faulty, each mode number is displayed by flashing twice in turn.

NOTE:

Connector disconnection is indicated by the following pattern:


31 → 32 → 34 → 35 → 36.



Display number and corresponding mode

Display No.	Mode	Display No.	Mode
30	(Normal)	34	FOOT
31	VENT	35	D/F
32	B/L	36	DEF


If any mode is judged as faulty in step 3, it indicates that harness or mode door actuator is faulty.



(5) Step 4 (Each actuator operation check)

If HOT switch (Δ) is depressed while in step 3, step 4 is selected, and '41' displayed. If AMB switch (**AMB**) is depressed in this status, displayed number will change to 42, 43, ... upon each depression of switch, and return to 41 after 47 is displayed.

Auto amplifier provides specified output to each actuator, blower motor and compressor corresponding to these displayed numbers. Check operation of these units visually, or by listening or feeling vibration.




H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

NOTE:

Output to compressor is provided as magnet clutch ON-OFF signal and control valve output signal. Control valve output signal causes compressor swash plate inclination angle to change to control compressor delivery. This can be checked by measuring auto amplifier output voltage using a circuit tester.




Display number and operation status

Display number	Intake door	Air mix door	Mode door	Blower motor	Compressor	
					Magnet clutch ON-OFF	Output voltage to control valve
41	Inside air	Full cold	VENT	5V	ON	Approx. 1V
42	Inside air	Full cold	VENT	5V	ON	Approx. 4.5V
43	Inside air	Full cold	B/L	10.5V	ON	Approx. 2.5V
44	Half-outside air	Full hot	B/L	8.5V	ON	Approx. 2.5V
45	Outside air	Full hot	FOOT	8.5V	ON	Approx. 4.5V
46	Outside air	Full hot	D/F	8.5V	OFF	0V
47	Outside air	Full hot	DEF	12V	ON	Approx. 2.5V


If abnormality of any portion is detected in step 4, be sure to perform inspection according to "1-5 ACTUATOR INSPECTION" flowchart.

Abnormal section	Flowchart
Intake door	1-5 (1) Intake door system
Air mix door	1-5 (2) Air mix door system
Blower motor	1-5 (3) Blower motor system
Compressor	1-5 (4) Compressor system



(6) Step 5 (Sensor recognition temperature indication)



If HOT switch (Δ) is depressed while in step 4, then step 5 is selected and '5' is indicated in display section. If AMB switch (**AMB**) is depressed in this status, temperatures sensed by outside air sensor, inside air sensor, suction temperature sensor and refrigerant temperature sensor are displayed in the following sequence.




H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

If temperature displayed in step 5 is excessively different from actual temperature, check suspected sensor according to "1-4 SENSOR INSPECTION".






(7) Step 6 (Not used when troubleshooting)

Depress fan switch () while in step 5, then step 6 is selected and display appears as shown at left. If fan switch is depressed again, step 5 is selected again.

① Setting difference between indicated temperature and sensed temperature

- If passenger's bodily sensation differs from the temperature set on the display section, then the auto amplifier sensing temperature can be changed with respect to the displayed temperature.




In this case, depress HOT switch () or COLD switch () in step 6. Each time the switch is depressed, displayed temperature will change by 0.5°C. In this way, sensed temperature can be varied in the range from +3.0 to -3.0°C.

(Example)

If the sensed temperature is set -3.0°C as shown at left with respect to the set display temperature of 25°C, the auto amplifier sensing temperature will be 22.0°C ($25.0 - 3.0 = 22.0$). Thus, the actual temperature is controlled at a level lower than the displayed temperature.

② Memorizing intake door position when turning ignition switch OFF

The intake door position when turning the ignition switch OFF can be memorized, and the air conditioner can be started at the memorized intake door position.

To use this function, depress REC switch () in step 6. This will cause the **AUTO** display to go out and the memory function to be activated. Pressing the REC switch again will cause **AUTO** to be displayed and the memory function canceled.


NOTE:

Even if condition ① or ② is set in step 6, the set condition will be canceled when the battery is disconnected. If step 6 is set at customer's request, it is necessary to explain this point to the customer.

H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

(8) Self-diagnostic procedure flowchart



E14-0374

H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)




1-4 SENSOR INSPECTION

(1) Outside air sensor

Disconnect outside air sensor connector, and measure resistance value between terminals on sensor side.

NOTE:

Perform this check with ignition switch set in OFF position. If the outside air sensor connector or auto amplifier connector is disconnected with the ignition switch ON, the outside air temperature is sensed as extremely low. If the connector is connected after turning the ignition switch OFF, and if the ignition switch is set again to ON, the outside air temperature correcting function prevents the sensing value from rising quickly to correct level. As a result, the compressor remains OFF, and heating function operates. In this case, disconnect the outside air sensor with the ignition switch ON, and then reconnect the sensor connector.





(2) Inside air sensor

Disconnect inside air sensor connector, and measure resistance between terminals on sensor side.


H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)



(3) Water temperature sensor

Disconnect water temperature sensor connector, and measure resistance value between terminals on sensor side.






H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

(4) Intake air temperature sensor

Disconnect intake air temperature sensor connector, and measure resistance between terminals on sensor side.



(5) Sunload sensor

With sunload sensor connector connected, measure voltage between terminals.

Ignition switch	Terminals		Standard value
	Positive ⊕	Negative ⊖	
ON	①	②	See characteristic curve.



NOTE:

When performing this check indoors, move a 60 watt lamp toward or away from sensor while reading voltage.

Reference: Sunload by direct sunlight during fine weather is equivalent to 0.768 kW (660 kcal/h, 2,619 BTU/h)/m² [0.0713 kW (61.31 kcal/h, 243.4 BTU/h)/sq ft].

H1 AIR CONDITIONER


1. Full Automatic Air Conditioner (Cont'd)



(6) PBR

With air mix door actuator connector connected, measure voltage between terminals.

Ignition switch	Terminals		Standard value
	Positive ⊕	Negative ⊖	
ON	3	5	See characteristic curve.





H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

(7) Refrigerant temperature sensor

Disconnect refrigerant temperature sensor connector, and measure resistance between terminals on sensor side.




H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

1-5 ACTUATOR INSPECTION


(2) Intake door system

Before inspection, check intake door actuator and automatic amplifier connectors.



(2) Air mix door system

Before inspection, check air mix door actuator and automatic amplifier connectors.




H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

[Point 1] Intake door actuator power inspection

- Remove intake door actuator, and measure voltage between vehicle-side connector and GND.


Measuring range	Ignition switch	Measuring terminals		Standard value
		Positive ⊕	Negative ⊖	
Ⓥ	ON	①	GND	Approx. 12V



[Point 2] Automatic amplifier output inspection

- Remove automatic amplifier, and measure voltage by applying circuit tester probes to 16-terminal connector. Use step 4 of self-diagnostic mode and keep connector connected during measurement.

Measuring range	Ignition switch	Measuring terminal		Digital display value	Standard value	Remarks
		⊕	⊖			
V	ON (Self-diagnostic mode)	24	GND	41, 42, 43	Approx. 0V	Inside air
				Others	Approx. 12V	
		25		44	Approx. 0V	Half-outside air
				Others	Approx. 12V	
		26		45, 46, 47	Approx. 0V	Outside air
				Others	Approx. 12V	



NOTE:


If standard value of approx. 12V is not present, internal circuit of intake door actuator may be disconnected.

H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

[Point 3] Automatic amplifier output inspection

- With air mix door actuator connector connected, measure voltage using step 4 of self-diagnostic mode.




Measuring range	Ignition switch	Measuring terminal		Digital display value	Standard value	Function of air mix door
		⊕	⊖			
V	ON (Self-diagnostic mode)	①	②	43 → 44	Approx. 10V	Moves to full hot
		②	①	47 → 41	Approx. 10V	Moves to full cold

(3) Blower motor system

Before inspection, check blower motor, fan control amplifier, HI relay and automatic amplifier connectors.

① Blower motor fails to run in HI position.





E14-0365

H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)


② Unable to change blower motor speed, or motor fails to run at any position other than HI.



[Point 4] HI relay power and GND circuit inspection

- Disconnect HI relay connector, and measure voltage and check continuity between vehicle-side connector and GND.

Measuring range	Ignition switch	Fan switch	Measuring terminals		Standard value
			⊕	⊖	
V	ACC	OFF	③	GND	Approx. 12V
	ON		②		
Ω	OFF		⑤		0Ω



[Point 5] Automatic amplifier output inspection

- With HI relay connector connected, measure voltage using step 4 of self-diagnostic mode.


Measuring range	Ignition switch	Measuring terminals		Digital display value	Standard value
		⊕	⊖		
V	ON (Self-diagnostic mode)	①	GND	41 - 46	Approx. 12V
				47	Below 1.5V

H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

[Point 6] Fan control amplifier power and GND circuit inspection


- Disconnect fan control amplifier connector, and measure voltage and check continuity between vehicle-side connector and GND.



Measuring range	Ignition switch	Fan switch	Measuring terminals		Standard value
			⊕	⊖	
V	ACC	OFF	①	GND	Approx. 12V
Ω	OFF		②		0Ω

[Point 7] Automatic amplifier output inspection

- With fan control amplifier connector connected, measure voltage using step 4 of self-diagnostic mode.



Measuring range	Ignition switch	Measuring terminals		Digital display value	Standard value
		⊕	⊖		
V	ON (Self-diagnostic mode)	④	GND	41 - 46	1 - 3V


H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)

(4) Compressor system

Before inspection, check air conditioner relay, dual pressure switch, automatic amplifier magnet clutch connectors.

① Magnet clutch system



ECCS C/U (RB26DETT)




H1 AIR CONDITIONER


1. Full Automatic Air Conditioner (Cont'd)

[Point 8] Air conditioner relay power supply and magnet clutch circuit inspection

- Remove air conditioner relay, and measure voltage and resistance between vehicle-side connector and GND.




Measuring range	Ignition switch	Measuring terminal		Standard value	Remarks
		⊕	⊖		
V	ON	②	GND	Approx. 12V	IGN power
	ACC	③			ACC power
Ω	OFF	⑤	GND	Approx. 3.5Ω	Magnet clutch coil resistance



[Point 9] Magnet clutch inspection

- Disconnect magnet-clutch connector, and measure resistance between clutch-side connector and GND.

Measuring range	Measuring terminals		Standard value
	⊕	⊖	
Ω	①	GND	Approx. 3.5Ω



[Point 10] Air conditioner control circuit inspection

- With harness connected to ECCS control unit, measure voltage and check relay operation by applying tester probes as shown.

① Air conditioner control circuit inspection

Measuring range	Ignition switch	Measuring terminals		Standard value
		⊕	⊖	
V	ON	⑨	GND	Approx. 12V

② Air conditioner relay operation inspection

Ignition switch	Terminal to be shorted to GND	Air conditioner relay operation
ON (Engine is running)	④	Air conditioner relay must turn ON.

H1 AIR CONDITIONER

1. Full Automatic Air Conditioner (Cont'd)


[Point 11] Dual pressure switch continuity inspection

- Disconnect dual pressure switch connector, and measure resistance by applying tester probes to switch side connector as shown.


Measuring range	Measuring terminals	Standard value
Ω	① - ②	Approx. 0Ω

NOTE:

If dual pressure switch is OFF, the cause may be a faulty air conditioner cycle.



② Control valve system




H1 AIR CONDITIONER


1. Full Automatic Air Conditioner (Cont'd)

[Point 12] Automatic amplifier output signal inspection

- Remove automatic amplifier. With connector connected, measure voltage by applying tester probes to the 20-terminal connector using step 4 of self-diagnostic mode.




Measuring range	Ignition switch	Measuring terminals		Digital display value	Standard value
		⊕	⊖		
V	ON (Self-diagnostic mode)	34	GND	41	Approx. 1V
				42, 45	Approx. 4.5V
				43, 44, 47	Approx. 2V



[Point 13] Coil resistance inspection in control valve

- Disconnect control valve connector, and measure resistance of coil by applying tester probes to valve-side connector.

Measuring range	Measuring terminals	Standard value
Ω	① - ②	Approx. 7Ω



1-6 ACTUATOR REMOVAL AND INSTALLATION

(1) Intake door actuator

Removal

Remove and install: Glove box, glove box cover (Parts not shown)

- Remove harness and securing bolts (two), and remove intake door actuator.

NOTE:

Remove actuator in REC state.

Installation

- Connect intake door actuator connector to vehicle harness.
- Set ignition switch to ACC, and set push control REC switch to ON. (Actuator is set in REC state.)
- Install intake door actuator while fixing actuator link in inside air position.
- Operate REC switch to see if actuator link is movable over full stroke range.

H1 AIR CONDITIONER


1. Full Automatic Air Conditioner (Cont'd)

(2) Air mix door actuator

Removal


Remove and install: Automatic transmission finisher, cluster lid C, audio unit, heater nozzle (left)

- Remove connector and securing bolts (three), and remove rod from rod holder.



Installation

- Connect air mix door actuator connector to vehicle-side harness.
- Set ignition switch to ON, and activate self-diagnostic mode step 4, then set full cold status (display value 41, 42, or 43). After this, turn OFF ignition switch.
- Install air mix door actuator.
- Fix air mix door actuator to rod holder while pressing door link toward full cold (driver seat).
- Activate step 4 of self-diagnostic mode. Make sure that air mix door moves over full stroke range when display value is changed from 43 to 44 or from 47 to 41.



(3) Mode door actuator removal and installation

Removal

Remove and install: Instrument panel lower cover

- Remove connector and securing bolts (three), and remove rod by rotating rod holder with standard screwdriver.

NOTE:

Remove rod holder in DEF state.

Installation

- Connect mode door actuator connector to vehicle-side harness.
- Set ignition switch to ACC, and set push control DEF switch to ON. (Actuator is set in DEF state.)
- Install mode door actuator.
- Fix side link to rod holder while holding side link in DEF mode position (by rotating counterclockwise until it stops).
- Operate mode switch and make sure that side link is capable of moving over full stroke range.

ELECTRICAL SYSTEM

SECTION **EL**

CONTENTS

E BODY ELECTRICAL UNITS

E1 LIGHTS	EL- 2
1. Headlight Assembly	EL- 2
2. Backup Light (2-door model)	EL- 3
E2 INSTRUMENTS	EL- 4
1. Combination Meter	EL- 4
2. Sub Meter	EL- 5
E3 AUDIO UNITS	EL- 7
1. Antenna	EL- 7
E4 WINDOW EQUIPMENT	EL- 8
1. Windshield Wipers	EL- 8
2. Window Washer	EL-10

E5 ELECTRICAL WIRING DIAGRAMS

Abbreviations and Cable Colours	EL-11
Relays and Fuses	EL-12



WIRING DIAGRAMS

– C-1 4WD vehicles (RB20DET/RB26DETT)	Fig. No. 1
– W-1 4WD vehicles (RB20DET/RB26DETT)	Fig. No. 2
– RB26DETT Engine Harness	Fig. No. 3
– E-TS System	Fig. No. 5
– Door Harness	Fig. No. 6
– Hicas System	Fig. No. 7
– Air Conditioner	Fig. No. 8

E1 LIGHTS

1. Headlight Assembly

1-1 HEADLIGHT REMOVAL AND INSTALLATION




1-2 AIMING HEADLIGHT

- Refer to the Basic Service Manual <A801001> for headlight aiming procedures.


(1) Modified 4-bulb type projector headlight

- ① Dimmer beam



- ② Main beam

E1 LIGHTS




2. Backup Light (2-door model)

2-1 BACKUP LIGHT REMOVAL AND INSTALLATION

Removal

- Remove license plate bracket securing bolt (one), and pull up license plate, then remove light securing screws (two), and then remove backup light.
- Replace bulb after removing light main body.




3. High-mount Stop Light (2-door model)

3-1 LIGHT REMOVAL AND INSTALLATION

Removal

- Remove light securing screws (four), and remove connector from light main body.



4. Rear Combination Light

4-1 LIGHT REMOVAL AND INSTALLATION

(1) 2-door model

Removal

Remove and install: Trunk rear finisher

- Heat sealing material fitted around rear combination light using drier and remove light assembly from trunk side.


Installation

- Remove butyl seal from body surface and rear side of light, and apply repair butyl seal to rear surface of rear combination light assembly. Install light assembly after heating butyl seal using dryer.

E2 INSTRUMENTS


1. Combination Meter

1-1 COMPONENTS



1. Combination Meter (GT-R model)


1-2 REAR SIDE SHAPE AND INTERNAL CIRCUIT




E2 INSTRUMENTS

2. Sub Meter

2-1 METER REMOVAL AND INSTALLATION



2-2 DISASSEMBLY




N12-1685


E2 INSTRUMENTS

2. Sub Meter (Cont'd)

2-3 REAR SIDE SHAPE AND INTERNAL CIRCUIT




E3 AUDIO UNITS



1. Antenna

1-1 FULL AUTOMATIC ANTENNA ASSEMBLY REMOVAL AND INSTALLATION


Remove and install: Trunk side finisher (left) (Parts not shown)



1-2 ANTENNA ROD REPLACEMENT

Removal

- Remove antenna nut and antenna base.
- Turn ON radio receiver power switch to raise antenna.
- At this moment, antenna rod and antenna rope can be pulled out by another operator.



Installation (only when installing new part)

- Extend antenna cable end so that it can be easily taken up with motor.
- Turn OFF radio receiver power switch to retract antenna.
- Operator standing outside vehicle: Insert antenna cable into rod hole with gear side facing antenna motor (rear side of vehicle). After confirming that antenna cable has wound around motor, set root portion of rod into pipe, and allow motor to completely retract antenna rod.

NOTE:

If motor stops during operation, turn radio receiver ON then OFF to rotate motor in retracting direction.

Replacement rod part No.

28215 89904

Table 1 Demographic characteristics of study population



E4 WINDOW EQUIPMENT

1. Windshield wipers (Cont'd)


Semi-concealed type (standard)

Unit: mm (in)

Dimension A	17 - 32 (0.67 - 1.26)
Dimension B	23 - 37 (0.91 - 1.46)


1-2 REAR WIPER

(1) Rear wiper arm and motor removal and installation



NOTE:

If wiper link comes off specified auto stop position, motor may start rotating even though wiper switch is OFF. To prevent this, be sure to keep wiper motor disconnected.



Wiper arm stop position

(2) Wiper arm adjustment

- When adjusting wiper arm position, operate wiper motor once, and allow it to stop at auto stop position.


Dimension A	17 - 32 mm (0.67 - 1.26 in)
-------------	-----------------------------

E4 WINDOW EQUIPMENT


2. Window Washers

2-1 WASHER NOZZLE INJECTION POINT

(1) Front washer




(2) Rear washer



2-2 WASHER NOZZLE ADJUSTMENT


(1) Front washer

- Paying attention not to deform injection nozzle opening, insert a needle into nozzle, and adjust nozzle direction.



(2) Rear washer


- Adjust nozzle direction using a pipe with I.D. 3 mm (0.12 in). Pay attention not to damage nozzle port.



2-3 WASHER TANK

(1) Washer tank removal and installation

Remove and install: Air cleaner (Parts not shown)



■ Chassis Marking Start Number

E-BNR32 vehicle BNR32-000001

■ Abbreviations

Abbreviation	Name	Abbreviation	Name
ACC	Accessory	AMP	Ammeter
A/C	Air conditioner	BUST	Vacuum gauge
A/P	Air purifier	FUEL	Fuel gauge
ASCD	Auto speed control device	OIL	Oil pressure gauge
A/T	Automatic transmission	OIL TEMP	Oil temperature gauge
C/B	Circuit breaker	TACHO	Tachometer
DSV	Double solenoid vacuum valve	TEMP	Water temperature gauge
ELR	Emergency locking retractor	VOLT	Voltmeter
EPS	Electronically controlled power steering	ANTI LOCK	4-wheel antiskid warning light
FICD	Fast idle control device	BATT	Battery fluid level warning light
F/L	Fusible link	BEAM	Main beam pilot lamp
IGN	Ignition	BELT	Seat belt warning light
ILCON	Illumination control	BRAKE	Brake warning light
ILL	Illumination light	CHECK	Check engine light
IND.L	Indicator light	CHG	Charge warning light
M/T	Manual transmission	CLUTCH	Clutch fluid level warning light
PBR	Potentiometer balance resistor	CRUISE	Cruise display light
P.L	Pilot lamp	DEF	Rear defogger pilot lamp
P/S	Power steering	DOOR	Open door warning light
PTC	Potentiometer temperature control	EXH TEMP	Exhaust gas temperature warning lamp
P/Tr	Power transistor	FAN BELT	Loose fan belt warning light
P/W	Power window	FILTER	Fuel filter water level warning light
ST	Start	FUEL	Low fuel level warning light
S/V	Solenoid valve	FUSE	Fuse blown warning light
SW	Switch	GLOW	Glow pilot lamp
Tr	Transistor	HICAS	Low HICAS oil level warning light
V/R	Voltage regulator	OIL	Oil pressure warning light
W.L	Warning light	RAD	Low radiator fluid level warning light
2WD	2-wheel drive	STOP	Stop light burnout warning light
4WAS	4-wheel antiskid	TAIL	Tail lamp burnout warning light
4WD	4-wheel drive	TURN	Turn signal pilot lamp
		WASH	Low washer fluid warning light

■ Cable Colors

B	BR	CH	DG	G	GY	L	LG	OR	P	PU	R	SB	W	Y
Black	Brown	Charcoal	Dark green	Green	Gray	Blue	Bluish green	Orange	Pink	Purple	Red	Sky blue	White	Yellow

■ Relays

Note: The part numbers listed in the remarks column identify different manufacturers and the parts affected are interchangeable.

Type	Sketch	Terminal symbol	Identification color	Remarks
1M			Green	Part number 25230 - R8100
1M			Blue	Part number 25230 - C 9970 25230 - C 9980 25230 - C 9985
			Green	25230 - C 9965 For EGI
1M			Blue	Part number 25230 - C 9990
1T			Black	Part number 25230 - R8201
1T			Black	Part number 25230 - C 9961 25230 - C 9971
2M			Brown	Part number 25230 - C 9920 25230 - C 9921
2M			Brown	Part number 25230 - C 9963
1M18			Gray	Part number 25230 - C 9915 25230 - C 9916 25230 - C 9918
1M18			Gray	Part number 25230 - C 9962 25230 - C 9972

■ Fuses

The fuse numbers indicated in the following table agree with those shown in the circuit and wiring diagrams.

(1) Passenger compartment

#1	#2	#3	#4/#5	#6	#7	#8	#9	#10	#11	#12	#13
4WD	Electronic parts	Transmission control	Blower motor	Wiper	Engine control	Fuel pump	Audio set	Air conditioner	Mirror, rear wiper	Cigarette lighter	Fog lamp
10A	10A	10A	15A	15A	20A	10A	15A	10A	10A	15A	15A
IGN		ACC		IGN		ACC		BAT		BAT	
BAT	ST	BAT	BAT	IGN	IGN	BAT	BAT	IGN	IGN	IGN	IGN
20A	10A	10A	10A	10A	10A	10A	10A	10A	10A	10A	20A
Antilock brake	Starter input	Hazard light	Shift lock	Tail light	Air conditioner	Meter	Turn signal light	Electronic parts	Stop light	Interior light	Rear defogger
#14	#15	#16	#17	#18	#19	#20	#21	#22	#23	#24	#25

(2) Engine compartment (Relay box)

	VIII	VI	V	IV	III	II	I	
#31	HORN 10A	FL 25A	FL 25A	FL 25A	FL 30A	FL 30A	FL 75A	A/T IND
#32	H/LAMP RH. 15A	RAD FAN	ENG CONT	POWER WDW	ANTI SKID	IGN SW	PTC HEATER 4WD	
#33	H/LAMP LH. 15A							
	H/LAMP	INHIBIT	AIR CON	BLOWER				HORN
				RAD FAN				

SERVICE DATA

SECTION SD

CONTENTS

F SERVICE DATA	
F1 NEW VEHICLE AND PERIODIC INSPECTION AND MAINTENANCE STANDARDS	SD- 2
1. Engine	SD- 2
2. Chassis	SD- 4
F2 PERIODIC REPLACEMENT PARTS	SD- 8
1. Engine	SD- 8
2. Chassis	SD- 8
F3 LUBRICANTS AND SERVICE POINTS	SD- 9
1. Engine	SD- 9
2. Chassis	SD- 9
F4 SERVICE DATA	SD-10
1. Tightening Torque	SD-10
2. Engine Specifications and Major Data	SD-13

F1 NEW VEHICLE AND PERIODIC INSPECTION AND MAINTENANCE STANDARDS

1. Engine

* :Items marked with an asterisk in parentheses do not require periodic inspection. These items are indicated for reference only.

Item		Inspection		RB26DETT
		New engine	Periodic	
Engine	Cylinder head tightening torque N·m (kg-m, ft-lb)	—	○ (for business use)	① 29 (3, 22) ② 108 (11, 80) ③ 0 (0, 0) ④ 29 (3, 22) ⑤ 108 ± 5 (11 ± 0.5, 79.6 ± 3.6)
	Intake and exhaust manifold tightening torque N·m (kg-m, ft-lb)	—	—	Intake: 16 - 21 (1.6 - 2.1, 12 - 15) Exhaust: 18 - 24 (1.8 - 2.4, 13 - 17)
	Valve clearances (when hot) - intake and exhaust mm (in)	—	—	Intake: 0.51 (0.020) Exhaust: 0.44 (0.017) (when cold)
	Standard compression pressure kPa (kg/cm ² , psi)/rpm	—	○	1,177 (12.0, 171)/ 300
	Limit kPa (kg/cm ² , psi)/rpm	—	○	883 (9.0, 128)/ 300
	Difference limit among cylinders kPa (kg/cm ² , psi)/rpm	—	○	98 (1.0, 14)
	Idle rpm rpm	—	○	M/T: 950
Emission control systems	CO/HC concentration %/rpm	○	○	Less than 0.1/ greater than 50
	Dashpot "touch" rpm rpm	—	○	—
	TV valve operating temperature °C (°F)	—	—	—
	Catalytic converter tightening torque N·m (kg-m, ft-lb)	—	○	31 - 42 (3.2 - 4.3, 23 - 31)
	Exhaust temperature sensor tightening torque N·m (kg-m, ft-lb)	—	○	25 - 34 (2.5 - 3.5, 18 - 25)
Engine electrical system	Ignition timing °BTDC/rpm	—	○	M/T: 20/950
	Spark plug gap mm (in)	—	○	1.0 - 1.1 (0.039 - 0.043) (Adjustment not required)
	Specific gravity of battery electrolyte 20°C (68°F)	○	○	1.22 - 1.29

F1 NEW VEHICLE AND PERIODIC INSPECTION AND MAINTENANCE STANDARDS

1. Engine (Cont'd)

Cooling system	Coolant pressurization limit		kPa (kg/cm ² , psi)	—	○	98 (1.0, 14)
	Radiator cap relief pressure		kPa (kg/cm ² , psi)	—	○	59 - 98 (0.6 - 1.0, 9 - 14)
	Coolant quantity	Radiator		○	○	Up to lower end of filler opening
		Reservoir tank				Between MIN and MAX
	Fan belt tension [when pressed midpoint with a force of approx. 98 N (10 kg, 22 lb)] mm (in)	When new		○	○	3.0 - 5.0 (0.118 - 0.197)
		When read-justed		○	○	4.0 - 6.0 (0.157 - 0.236)
		Service limit				7.5 (0.295)
Exhaust system	Tightening torque		N·m (kg-m, ft-lb)	○	○	
	● Heat-shield plate					5 - 7 (0.5 - 0.7, 3.6 - 5.1)
	● Exhaust manifold-to-front tube					45 - 60 (4.6 - 6.1, 33 - 44)
	● Front tube-to-catalytic converter					43 - 55 (4.4 - 5.6, 32 - 41)
	● Catalytic converter-to-center tube					43 - 55 (4.4 - 5.6, 32 - 41)

F1 NEW VEHICLE AND PERIODIC INSPECTION AND MAINTENANCE STANDARDS

2. Chassis

	Item	New vehicle inspection	Periodic inspection	Inspection standards
Clutch	Pedal free play (at clevis) mm (in)	○	○	5 - 12 (0.20 - 0.47) [1 - 3 (0.04 - 0.12)]
	Pedal-to-floor (when released) mm (in)		○	81 (3.19)
	Free pedal height mm (in)	○		171.7 - 181.7 (6.76 - 7.15)
	Tightening torque of joints N-m (kg-m, ft-lb)		○	
Propeller (drive) shaft	● Front propeller shaft-to-front final drive			24 - 32 (2.4 - 3.3, 17 - 24)
	● Rear propeller shaft-to-rear final drive			64 - 74 (6.5 - 7.5, 47 - 54)
	● Transfer-to-rear propeller shaft			88 - 98 (9.0 - 10, 65 - 72)
	● Center propeller shaft-to-bearing bracket			Bolt: 32 - 38 (3.3 - 3.9, 24 - 28) Nut: 20 - 23 (2.0 - 2.3, 14 - 17)
	● Center flange-to-propeller shaft			64 - 74 (6.5 - 7.5, 47 - 54)
	● Center flange lock nuts			245 - 294 (25 - 30, 181 - 217)
	● Side shaft-to-front drive shaft			16 - 21 (1.6 - 2.1, 12 - 15)
	● Side flange-to-rear drive shaft			83 - 93 (8.5 - 9.5, 61 - 69)
	Propeller shaft runout		○	Less than 6 (0.6, 4.3)
	Wheel alignment		○	
Front suspension and axle	● Toe-in mm (in)			1 ± 1 (0.04 ± 0.04)
	● Camber degree			-0°55' ± 45'
	● Caster degree			RB26DETT: 3°40' ± 45'
	● Kingpin inclination degree			15°25' ± 45'
	Front wheel bearing play		○	
	● Tightening torque N-m (kg-m, ft-lb)			235 - 314 (24 - 32, 174 - 231)
	● Axial end play mm (in)			Less than 0.05 (0.0020)
	Tightening torque of fasteners/ joints N-m (kg-m, ft-lb)			
	● Suspension member securing nuts			74 - 88 (7.5 - 9.0, 54 - 65)
	● Suspension member-to-lower link ball joint			63 - 78 (6.4 - 8.0, 46 - 58)
	● Lower link ball joint-to-lower link			96 - 120 (9.8 - 12.2, 71 - 88)
	● Lower link-to-suspension lower ball joint			96 - 120 (9.8 - 12.2, 71 - 88)
	● Tension rod-to-suspension member			88 - 108 (9.0 - 11, 65 - 80)
	● Tension rod-to-lower link			108 - 127 (11 - 13, 80 - 94)
	● Ball joint-to-knuckle spindle			72 - 97 (7.3 - 9.9, 53 - 72)
	● Kingpin-to-3rd link			98 - 118 (10 - 12, 72 - 87)
	● Knuckle spindle-to-king pin			147 - 186 (15 - 19, 108 - 137)
	● 3rd link-to-upper link			88 - 108 (9.0 - 11, 65 - 80)
	● Upper link-to-bracket			88 - 108 (9.0 - 11, 65 - 80)
	● Upper link bracket-to-car body			88 - 108 (9.0 - 11, 65 - 80)
	● Spring upper seat lock nuts			18 - 24 (1.8 - 2.4, 13 - 17)
	● Shock absorber-to-3rd link			108 - 127 (11 - 13, 80 - 94)
	● Shock absorber-to-car body			39 - 54 (4.0 - 5.5, 29 - 40)
	● 3rd link-to-connecting rod			41 - 47 (4.2 - 4.8, 30 - 35)
	● Connecting rod-to-stabilizer			41 - 47 (4.2 - 4.8, 30 - 35)
	● Stabilizer bracket			39 - 49 (4.0 - 5.0, 29 - 36)
Rear suspension and axle	Wheel alignment			
	● Toe-in mm (in)		○	2 ± 2 (0.08 ± 0.08)
	● Camber degree			RB26DETT: -1°05' ± 30'
	Rear wheel bearing play			
	● Wheel bearing tightening torque N-m (kg-m, ft-lb)			206 - 275 (21 - 28, 152 - 203)
	● Wheel bearing end play mm (in)			0 (0)
	Tightening torque N-m (kg-m, ft-lb)		○	
	● Suspension member securing nuts			98 - 118 (10 - 12, 72 - 87)
	● Final drive (on housing side) to suspension member			98 - 118 (10 - 12, 72 - 87)

F1 NEW VEHICLE AND PERIODIC INSPECTION AND MAINTENANCE STANDARDS

2. Chassis (Cont'd)

	Item	New vehicle inspection	Periodic inspection	Inspection standards												
Rear suspension and axle	● Final drive (on differential case side) to suspension member			98 - 118 (10 - 12, 72 - 87)												
	● Suspension member-to-lower arm			98 - 118 (10 - 12, 72 - 87)												
	● Suspension member-to-upper link (front end)			77 - 98 (7.9 - 10, 57 - 72)												
	● Suspension member-to-upper link (rear end)			77 - 98 (7.9 - 10, 57 - 72)												
	● Suspension member-to-lower link			69 - 88 (7.0 - 9.0, 51 - 65)												
	● Upper link (front end)-to-axle housing			77 - 98 (7.9 - 10, 57 - 72)												
	● Upper link (rear end)-to-axle housing			77 - 98 (7.9 - 10, 57 - 72)												
	● Lower link-to-axle housing			71 - 86 (7.2 - 8.8, 52 - 64)												
	● Lower arm-to-connecting rod			9 - 12 (0.9 - 1.2, 6.5 - 8.7)												
	● Connecting rod-to- stabilizer			9 - 12 (0.9 - 1.2, 6.5 - 8.7)												
	● Stabilizer bracket			43 - 55 (4.4 - 5.6, 32 - 41)												
	● Shock absorber-to- axle housing			88 - 108 (9.0 - 11, 65 - 80)												
	● Shock absorber-to- car body			16 - 19 (1.6 - 1.9, 12 - 14)												
	● Spring upper seat lock nuts			18 - 24 (1.8 - 2.4, 13 - 17)												
● Member stay-to-car body			43 - 55 (4.4 - 5.6, 32 - 41)													
Road wheels and tires	Air pressure	○	○	(See text)												
	Tire groove wear limit mm (in)		○	1.6 (0.063)												
	Wheel nut tightening torque N-m (kg-m, ft-lb)	○	○	98 - 118 (10 - 12, 72 - 87)												
Foot brake	Pedal play mm (in)	○	○	3 - 11 (0.12 - 0.43)												
	Pedal-to-floor clearance (when depressed) mm (in)		○	Greater than 85 (3.35)												
	Pedal height (From upper surface of floor panel) mm (in)	○		M/T: 172.5 - 182.5 (6.79 - 7.19)												
	Pad wear mm (in)		○	<table><tr><td>Type</td><td colspan="2">OPZ25VR OPZ11VB</td></tr><tr><td>Item</td><td></td><td></td></tr><tr><td>Standard thickness</td><td colspan="2">10 (0.39)</td></tr><tr><td>Service limit</td><td colspan="2">2.0 (0.079)</td></tr></table>	Type	OPZ25VR OPZ11VB		Item			Standard thickness	10 (0.39)		Service limit	2.0 (0.079)	
	Type	OPZ25VR OPZ11VB														
	Item															
	Standard thickness	10 (0.39)														
Service limit	2.0 (0.079)															
Disk wear mm (in)		○	<table><tr><td>Type</td><td>OPZ25VR</td><td>OPZ11VB</td></tr><tr><td>Item</td><td></td><td></td></tr><tr><td>Standard thickness</td><td>32 (1.26)</td><td>18 (0.71)</td></tr><tr><td>Service limit</td><td>30 (1.18)</td><td>16 (0.63)</td></tr></table>	Type	OPZ25VR	OPZ11VB	Item			Standard thickness	32 (1.26)	18 (0.71)	Service limit	30 (1.18)	16 (0.63)	
Type	OPZ25VR	OPZ11VB														
Item																
Standard thickness	32 (1.26)	18 (0.71)														
Service limit	30 (1.18)	16 (0.63)														
Brake hose and tube installation		○														
● Flare nut tightening torque N-m (kg-m, ft-lb)			15 - 18 (1.5 - 1.8, 11 - 13)													
Parking brake	Brake drum wear mm (in)		○	<table><tr><td>Type</td><td>LT23C</td><td>DS17HD</td></tr><tr><td>Item</td><td></td><td></td></tr><tr><td>Standard I.D.</td><td>228.6 (9)</td><td>172 (6.77)</td></tr><tr><td>I.D. service limit</td><td>230 (9.06)</td><td>173 (6.81)</td></tr></table>	Type	LT23C	DS17HD	Item			Standard I.D.	228.6 (9)	172 (6.77)	I.D. service limit	230 (9.06)	173 (6.81)
	Type	LT23C	DS17HD													
	Item															
	Standard I.D.	228.6 (9)	172 (6.77)													
I.D. service limit	230 (9.06)	173 (6.81)														
Brake lining wear mm (in)		○	<table><tr><td>Type</td><td>LT23C</td><td>DS17HD</td></tr><tr><td>Item</td><td></td><td></td></tr><tr><td>Standard thickness</td><td>4.5 (0.177)</td><td>3.0 (0.118)</td></tr><tr><td>Service limit</td><td>1.5 (0.059)</td><td>1.5 (0.059)</td></tr></table>	Type	LT23C	DS17HD	Item			Standard thickness	4.5 (0.177)	3.0 (0.118)	Service limit	1.5 (0.059)	1.5 (0.059)	
Type	LT23C	DS17HD														
Item																
Standard thickness	4.5 (0.177)	3.0 (0.118)														
Service limit	1.5 (0.059)	1.5 (0.059)														
Lever pull, with a force of 196 N (20 kg, 44 lb) Center lever type: (notch)		○	○	6 - 8												

F1 NEW VEHICLE AND PERIODIC INSPECTION AND MAINTENANCE STANDARDS

2. Chassis (Cont'd)

Steering system	Steering wheel tightening torque N·m (kg-m, ft-lb)	○	○	29 - 39 (3.0 - 4.0, 22 - 29)										
	Steering wheel play mm (in)	○	○	0 - 35 (0 - 1.38)										
	Steering gear tightening torque N·m (kg-m, ft-lb)		○											
	● Steering gear securing bolts			88 - 108 (9.0 - 11, 65 - 80)										
	● Ball joint-to-knuckle spindle			29 - 39 (3.0 - 4.0, 22 - 29)										
	Rod and arm tightening torque N·m (kg-m, ft-lb)		○											
	● Lower joint securing bolts			24 - 29 (2.4 - 3.0, 17 - 22)										
	● Steering gear-to-inner socket			78 - 98 (8.0 - 10, 58 - 72)										
	● Side rod lock nuts			78 - 98 (8.0 - 10, 58 - 72)										
	Power steering belt tension (deflection when pressed midpoint of belt) mm (in)	○	○	<table><tr><th>Deflection Engine</th><th>When new</th><th>When read- justed</th><th>Service limit</th></tr><tr><td>RB-series engine</td><td>8 - 10 (0.31 - 0.39)</td><td>9 - 11 (0.35 - 0.43)</td><td>15 (0.59)</td></tr></table>				Deflection Engine	When new	When read- justed	Service limit	RB-series engine	8 - 10 (0.31 - 0.39)	9 - 11 (0.35 - 0.43)
Deflection Engine	When new	When read- justed	Service limit											
RB-series engine	8 - 10 (0.31 - 0.39)	9 - 11 (0.35 - 0.43)	15 (0.59)											
Steering system	Power steering system tightening torque N·m (kg-m, ft-lb)		○											
	● Oil pump securing bolts			31 - 42 (3.2 - 4.3, 23 - 31) 16 - 21 (1.6 - 2.1, 12 - 15) (Adjustment side)										
	● Oil pump pulley securing nuts			54 - 68 (5.5 - 6.9, 40 - 50)										
	● Reservoir tank securing bolts			3 - 4 (0.3 - 0.4, 2.2 - 2.9)										
	● Low pressure oil tube-to-steering gear			27 - 39 (2.8 - 4.0, 20 - 29)										
	● High pressure oil tube-to-steering gear			15 - 25 (1.5 - 2.5, 11 - 18)										
	● High pressure oil tube-to-oil pump			49 - 69 (5.0 - 7.0, 36 - 51)										
	● Right tube clamp bracket-to-car body			3 - 4 (0.3 - 0.4, 2.2 - 2.9) [8 - 11 (0.8 - 1.1, 5.8 - 8.0)]										
	● Front tube clamp bracket-to-car body			3 - 4 (0.3 - 0.4, 2.2 - 2.9)										
	● Cylinder tube-to-gear housing			20 - 26 (2.0 - 2.7, 14 - 20)										
SUPER HICAS	● Tightening torque of power cylinder fasteners/joints N·m (kg-m, ft-lb)		○											
	● Power cylinder securing bolts			84 - 108 (8.6 - 11, 62 - 80)										
	● Outer link rod lock nuts			37 - 46 (3.8 - 4.7, 27 - 34)										
	● Power cylinder outer ring-to-axle housing			45 - 60 (4.6 - 6.1, 33 - 44)										
	● Stroke stopper lock nuts			49 - 69 (5.0 - 7.0, 36 - 51)										
	Tightening torque of power steering system fasteners/joints N·m (kg-m, ft-lb)		○											
	● Oil pump securing bolts			31 - 42 (3.2 - 4.3, 23 - 31) 16 - 21 (1.6 - 2.1, 12 - 15) (Adjustment side)										
	● Reservoir tank securing bolts			3 - 4 (0.3 - 0.4, 2.2 - 2.9)										
	● HICAS solenoid valve union bolts (on reservoir tank side)			49 - 69 (5.0 - 7.0, 36 - 51)										
	● HICAS solenoid valve union bolts (on oil pump side)			49 - 69 (5.0 - 7.0, 36 - 51)										
	● HICAS solenoid valve (on high and low pressure sides)			39 - 51 (4.0 - 5.2, 29 - 38)										
	● Solenoid valve-to-bracket			18 - 24 (1.8 - 2.4, 13 - 17)										
	Oil pump-to-steering gear (on high pressure side of power steering)			15 - 25 (1.5 - 2.5, 11 - 18)										
	Steering gear-to-reservoir tank (on low pressure side of power steering)			27 - 39 (2.8 - 4.0, 20 - 29)										
	HICAS solenoid valve-to-oil pump			49 - 69 (5.0 - 7.0, 36 - 51)										
	HICAS solenoid valve-to-reservoir tank			49 - 69 (5.0 - 7.0, 36 - 51)										
	Power cylinder tube			39 - 49 (4.0 - 5.0, 29 - 36)										
	Cylinder tube clamp			4.4 - 5.8 (0.45 - 0.59, 3.3 - 4.3)										
	Hose clamp			8 - 11 (0.8 - 1.1, 5.8 - 8.0)										
	● Cutoff valve bracket securing bolts			13 - 16 (1.3 - 1.6, 9 - 12) (front) 4.4 - 5.8 (0.45 - 0.59, 3.3 - 4.3) (rear)										
	● Cutoff valve-to-power cylinder union bolts			49 - 69 (5.0 - 7.0, 36 - 51)										
	● Rear central piping-to-cutoff valve			39 - 49 (4.0 - 5.0, 29 - 36)										

F2 PERIODIC REPLACEMENT PARTS AND MAINTENANCE STANDARDS

1. Engine

Periodic replacement parts	Replacement interval
Air cleaner element	Every 60,000 km (36,000 miles)
Timing belt	Every 100,000 km (60,000 miles)
Engine oil	Every 5,000 km (3,000 miles)
Oil filter	Every 10,000 km (6,000 miles) or yearly
Fuel filter	Every 100,000 km (60,000 miles)
Fuel hose (except for type D)	First time: After 5 years Thereafter: Every 4 years
	Every 2 years (inside engine compartment) Every 4 years (outside engine compartment)
LLC	First time: After 3 years Thereafter: Every 2 years
	Every 2 years
Catalyst	Yearly
Spark plug	Every 100,000 km (60,000 miles)

2. Chassis

Periodic replacement parts		Replacement interval
Brake system	Brake hose	First time: After 5 years Thereafter: Every 4 years
		Every 4 years
	Brake fluid	First time: After 3 years Thereafter: Every 2 years
		Yearly
	Master cylinder cup and dust seal	First time: After 3 years Thereafter: Every 2 years
		Every 2 years
	Wheel cylinder (including caliper) cup and dust seal	First time: After 5 years Thereafter: Every 4 years
		Every 2 years
Suspension ball joint grease		Every 120,000 km (72,000 miles) or every 4 years
Manual transmission fluid		Every 100,000 km (60,000 miles) or every 2 years
Differential fluid		Every 100,000 km (60,000 miles) or every 2 years

F3 LUBRICANTS AND SERVICE POINTS AND MAINTENANCE STANDARDS

1. Engine

Inspection and service points	Lubricant type	Remarks
Throttle chamber linkage	Nissan MP No. 2 Grease	Apply during disassembly.
Accelerator linkage	NISSAN MP No. 2 Grease or Chassis Grease	Apply during disassembly.

2. Chassis

Inspection and service points	Lubricant type	Remarks
Clutch disc spline	Nissan Clutch Grease (KRI06-00010)	
Main drive shaft spline		
Clutch release mechanism	Nissan Clutch Sleeve Grease (KRI06-00010)	
Manual transmission	Nissan Gear Oil MP-G Special GL-475W-90	Gear Oil GL-4 MP-G 80W-90 (for extremely cold areas)
Automatic transmission	Nissanmatic Fluid D	
Transfer	Nissanmatic Fluid D	
ETS hydraulic unit	Nissan Power Steering Fluid Special	
Propeller shaft center bearing washer	Nissan Clutch Molybdenum Grease	
Propeller shaft universal joint	Nissan MP Special Grease No. 2	
Front final drive	F160	Nissan Gear Oil Hypoid GL-5 85W-90
Rear final drive	R200 (Mechanical LSD)	Nissan Gear Oil Hypoid LSD GL-5 80W-90
Drive shaft	Fixed joint	6080 grease (Kyodo brand)
	Sliding joint	
Front and rear wheel bearings	Nissan MP Special Grease No. 2	
Brake (Master cylinder)	Nissan Brake Fluid No. 2500 (NR-3)	
Cylinder rubber parts (Brake system)	Nissan Rubber Lubricant (KRE12-00030)	
Disc brake	Nissan Disc Brake Grease (KRF16-00005)	
Brake pedal fulcrum pin or shaft	Nissan MP Special Grease No. 2	
Parking brake cable	Nissan MP Special Grease No. 2	
Power steering	Nissan Power Steering Fluid	

F4 SERVICE DATA AND MAINTENANCE STANDARDS

1. Tightening Torque

1-1 ENGINE COMPONENTS

	Components	Tightening torque		
		RB26DETT		
		N·m	kg·m	ft·lb
Engine body	Main bearing cap bolts	46 - 52	4.7 - 5.3	34 - 38
	Connecting bolts and nuts	① 14 - 16	1.4 - 1.6 ② (60° - 65°)	10 - 12
	Flywheel bolts (M/T models)	142 - 152	14.5 - 15.5	105 - 112
	Drive plate bolts (A/T models)	—	—	—
	Crank pulley bolts	446 - 466	45.5 - 47.5	329 - 344
	Oil strainer securing bolt	16 - 21	1.6 - 2.1	12 - 15
	Rear oil seal retainer securing bolts	6.3 - 8.3	0.64 - 0.85	4.6 - 6.1
	Oil pump securing bolts	10 - 12	1.0 - 1.2	7 - 9
	Water pump securing bolts	M6: 7 - 8	0.7 - 0.8	5.1 - 5.8
		M8: 16 - 21	1.6 - 2.1	12 - 15
		M10: 30 - 40	3.1 - 4.1	22 - 30
	Cam pulley securing bolts	14 - 19	1.4 - 1.9	10 - 14
	Camshaft retainer securing bolts	9.0 - 11.8	0.92 - 1.2	6.7 - 8.7
	Rocker cover screws	2 - 4	0.2 - 0.4	1.4 - 2.9
	Timing belt cover	3 - 5	0.3 - 0.5	2.2 - 3.6
	Belt tensioner securing nut	43 - 58	4.4 - 5.9	32 - 43
	Water drain plug	34 - 44	3.5 - 4.5	25 - 33
	Blow-by control valve	29 - 39	3.0 - 4.0	22 - 29
	Oil pan drain plug	29 - 39	3.0 - 4.0	22 - 29
	Oil pan securing bolts	M6: 6.3 - 8.3	0.64 - 0.85	4.6 - 6.1
		M10: 31 - 42	3.2 - 4.3	23 - 31
	Oil filter stud: (cylinder block side)	29 - 39	3.0 - 4.0	22 - 29
	(oil filter side)	15 - 21	1.5 - 2.1	11 - 15
Intake and exhaust systems	Cylinder head bolts	M12: ① 29	3	22
		② 108	11	80
		③ 0 (Lower)	0	0
		④ 29	3	22
		⑤ (85° - 90°) or 103 - 113	(85° - 90°) or 10.5 - 11.5	(85° - 90°) or 76 - 83
		M6: 9.0 - 11.8	0.92 - 1.2	6.7 - 8.7
	Intake manifold securing bolts	16 - 21	1.6 - 2.1	12 - 15
	Intake manifold securing nuts	16 - 21	1.6 - 2.1	12 - 15
	Collector bolts	16 - 21	1.6 - 2.1	12 - 15
	Exhaust manifold securing nuts	18 - 24	1.8 - 2.4	13 - 17
	O ₂ sensor securing nuts	18 - 24	1.8 - 2.4	13 - 17
	Throttle chamber securing bolts	16 - 21	1.6 - 2.1	12 - 15
	Throttle valve switch	2.0 - 2.4	0.2 - 0.24	1.4 - 1.7
	Intake manifold support bracket securing bolts	—	—	—
	Turbocharger inlet nuts	23 - 29	2.3 - 3.0	17 - 22
	Turbocharger outlet nuts	23 - 29	2.3 - 3.0	17 - 22
	Water bypass tube	15 - 20	1.5 - 2.0	11 - 14

F4 SERVICE DATA AND MAINTENANCE STANDARDS

1. Tightening Torque (Cont'd)

	Components	Tightening torque		
		RB26DET		
		N·m	kg-m	ft-lb
Intake and exhaust systems	Turbocharger oil tube (turbo side)	17 - 21	1.7 - 2.1	12 - 15
	Turbocharger oil tube (cylinder block side)	15 - 20	1.5 - 2.0	11 - 14
	Turbocharger water tube (turbo side)	20 - 31	2 - 3.2	14 - 23
	Turbocharger water tube (cylinder block side)	20 - 31	2 - 3.2	14 - 23
Sensors and others	Crank angle sensor	4 - 5	0.4 - 0.5	2.9 - 3.6
	Crank angle sensor bracket	16 - 21	1.6 - 2.1	12 - 15
	Spark plugs	20 - 29	2.0 - 3.0	14 - 22
	Engine temperature sensor	20 - 29	2.0 - 3.0	14 - 22
	Thermal transmitter	15 - 20	1.5 - 2.0	11 - 14
	Knock sensor	21 - 26	2.1 - 2.7	15 - 20
	O ₂ sensor	18 - 24	1.8 - 2.4	13 - 17
	Exhaust temperature sensor	25 - 34	2.5 - 3.5	18 - 25
	Injector holder securing bolts	4 - 5	0.4 - 0.5	2.9 - 3.6
	Air regulator securing bolts	8.4 - 10.8	0.86 - 1.1	6.2 - 8.0
	IAA unit securing bolts	—	—	—
	Water outlet securing bolts	16 - 21	1.6 - 2.1	12 - 15
	Water inlet securing bolts	—	—	—
	Alternator securing-adjusting bolts	9.1 - 11.8	0.93 - 1.2	6.7 - 8.7
	Alternator securing nuts	45 - 60	4.6 - 6.1	33 - 44
	Starter motor securing bolts	30 - 40	3.1 - 4.1	22 - 30
	Compressor securing bolts	37 - 50	3.8 - 5.1	27 - 37
	Compressor bracket securing bolts	37 - 50	3.8 - 5.1	27 - 37
	Power steering bracket securing bolts	37 - 50	3.8 - 5.1	27 - 37
	Power steering adjustment bar securing bolts	14 - 19	1.4 - 1.9	10 - 14
	Ignition coil bracket securing bolts	9.1 - 11.8	0.93 - 1.2	6.7 - 8.7

F4 SERVICE DATA AND MAINTENANCE STANDARDS

1. Tightening Torque (Cont'd)

1-2 MANUAL TRANSMISSION COMPONENTS

Unit: N·m (kg-m, ft-lb)

Components	Type	FS5R30A
Rear extension securing bolts		31 - 42 (3.2 - 4.3, 23 - 31)
Front cover securing bolts		16 - 21 (1.6 - 2.1, 12 - 15)
Check ball plug		19 - 25 (1.9 - 2.6, 14 - 19)
Filler plug		25 - 34 (2.5 - 3.5, 18 - 25)
Drain plug		25 - 34 (2.5 - 3.5, 18 - 25)
Reverse lamp switch		20 - 29 (2.0 - 3.0, 14 - 22)
Neutral switch		20 - 29 (2.0 - 3.0, 14 - 22)
Control housing-to-rear extension		
M8 bolts		16 - 21 (1.6 - 2.1, 12 - 15)
Select check plug		20 - 29 (2.0 - 3.0, 14 - 22)
Bearing retainer-to- adapter plate		16 - 21 (1.6 - 2.1, 12 - 15)
5-R fork rod securing bolts		16 - 21 (1.6 - 2.1, 12 - 15)
Reverse fork securing bolts		19 - 25 (1.9 - 2.6, 14 - 19)
Rear guide plate securing bolts		6.3 - 8.3 (0.64 - 0.85, 4.6 - 6.1)

F4 SERVICE DATA AND MAINTENANCE STANDARDS

1. Tightening Torque (Cont'd)

1-3 F160 FINAL DRIVE

Unit: N·m (kg-m, ft-lb)

Components	Tightening torque
Drive gear securing bolts	93 - 113 (9.5 - 11.5, 69 - 83)
Drive pinion securing bolts	167 - 196 (17 - 20, 123 - 145)
Side retainer securing bolts	16 - 19 (1.6 - 1.9, 12 - 14)
Side shaft securing bolts	16 - 21 (1.6 - 2.1, 12 - 15)
Carrier cover securing bolts	29 - 37 (3.0 - 3.8, 22 - 27)

1-4 R200 FINAL DRIVE

Unit: N·m (kg-m, ft-lb)

Components	Tightening torque
Drive gear securing bolts	177 - 196 (18.0 - 20.0, 130 - 145)
Bearing cap securing bolt	88 - 98 (9 - 10, 65 - 72)
Drive pinion securing nut	186 - 294 (19 - 30, 137 - 217)
Carrier case cover securing nuts	39 - 49 (4 - 5, 29 - 36)
Drain plug	59 - 98 (6 - 10, 43 - 72)
Filler plug	59 - 98 (6 - 10, 43 - 72)

F4 SERVICE DATA AND MAINTENANCE STANDARDS

2. Engine Specifications and Major Data


	Item	RB26DETT
Cylinder block	Bore diameter	mm (in) 86.000 - 86.030 (3.3858 - 3.3870)
	Wear limit	mm (in) 0.2 (0.008)
	Out-of-roundness	mm (in) 0.015 (0.0006)
	Taper	mm (in) 0.010 (0.0004)
	Warpage limit of cylinder block upper surface	mm (in) 0.1 (0.004)
Cylinder head	Ream limit of valve guide holes	mm (in) 10.46 - 10.67 (0.4118 - 0.4201)
	Intake	
	Exhaust	11.46 - 11.47 (0.4512 - 0.4516)
	Ream limit of inside diameter	mm (in) 6.000 - 6.018 (0.2362 - 0.2369)
	Intake	
	Exhaust	7.000 - 7.018 (0.2756 - 0.2763)
	Service limit of valve guide-to-valve stem clearance	mm (in) 0.080 - 0.113 (0.0031 - 0.0044)
Piston rings	Warpage limit of lower surface	mm (in) 0.2 (0.008)
	Cylinder head gasket thickness	mm (in) 1.2 (0.047)
	Piston type	Thermal flow
	Standard outside diameter of piston skirt	mm (in) 85.955 - 85.985 (3.3840 - 3.3852)
	Piston skirt-to-cylinder clearance	mm (in) 0.035 - 0.055 (0.0014 - 0.0022)
	Standard piston pin outside diameter	mm (in) 20.989 - 21.001 (0.8263 - 0.8268)
	Piston pin-to-piston pin bore clearance	mm (in) 0 to -0.004 (0 to -0.0002)
	Piston ring end clearance	mm (in) 0.24 - 0.34 (0.0094 - 0.0134)
	Top	
	Second	0.42 - 0.57 (0.0165 - 0.0224)
	Oil	0.20 - 0.60 (0.0079 - 0.0236)
	Piston ring side clearance	mm (in) 0.040 - 0.075 (0.0016 - 0.0030)
Connecting rod	Top	
	Second	0.030 - 0.065 (0.0012 - 0.0026)
	Oil	0.065 - 0.135 (0.0026 - 0.0053)
	Center-to-center distance of large and small end bores	mm (in) 121.45 - 121.55 (4.7815 - 4.7854)
	Large end bore diameter	mm (in) 47.989 - 48.007 (1.8893 - 1.8900)
	Bend and twist limit [per 100 mm (3.94 in) in length]	Bend 0.15 (0.0059) and Twist 0.3 (0.012)
	mm (in)	
Crankshaft	Large end side clearance	mm (in) 0.2 - 0.3 (0.008 - 0.012)
	Large end oil clearance	mm (in) 0.020 - 0.040 (0.0008 - 0.0016)
	Piston pin-to-connecting rod small end bore clearance	mm (in) 0.005 - 0.017 (0.0002 - 0.0007)
	Standard journal diameter	mm (in) 54.951 - 54.975 (2.1634 - 2.1644)
	Standard pin diameter	mm (in) 47.961 - 47.974 (1.8882 - 1.8887)
	Out-of-roundness and taper of journal	mm (in) Less than 0.005 (0.0002)
	Out-of-roundness and taper of pin	mm (in) Less than 0.005 (0.0002)
Camshaft	Main bearing oil clearance	mm (in) 0.028 - 0.047 (0.0011 - 0.0019) (selective fit)
	Standard thrust clearance	mm (in) 0.2 - 0.3 (0.008 - 0.012)
	Cam nose height (oblong diameter)	mm (in) 40.580 - 40.583 (1.5976 - 1.5978)
	Intake	
	Exhaust	40.280 - 40.283 (1.5858 - 1.5859)
	Bend limit	mm (in) 0.05 (0.0020)
	Standard cam bracket inside diameter	mm (in) No. 1 - No. 7 28.000 - 28.021 (1.1024 - 1.1032)
	Standard cam journal outside diameter	mm (in) No. 1 - No. 7 27.935 - 27.955 (1.0998 - 1.1006)


F4 SERVICE DATA AND MAINTENANCE STANDARDS


2. Engine Specifications and Major Data (Cont'd)

	Item	RB26DETT
Camshaft	Standard bracket-to-journal clearance mm (in)	No. 1 - No. 7 0.045 - 0.086 (0.0018 - 0.0034)
	Standard end play mm (in)	0.030 - 0.080 (0.0012 - 0.0031)
Valves and valve springs	Standard valve lifter outside diameter mm (in)	30.955 - 30.965 (1.2187 - 1.2191)
	Lifter guide bore diameter mm (in)	31.000 - 31.020 (1.2205 - 1.2213)
	Standard lifter-to-lifter guide clearance mm (in)	0.035 - 0.065 (0.0014 - 0.0026)
	Valve face outside diameter mm (in)	34.5 - 34.7 (1.358 - 1.366) 30.0 - 30.2 (1.181 - 1.189)
	Valve stem outside diameter mm (in)	5.980 - 5.965 (0.2354 - 0.2348) 6.920 - 6.905 (0.2724 - 0.2718)
	Valve spring squareness limit mm (in)	1.8 (0.071) (Single spring)
	Standard valve spring free length mm (in)	46.54 (1.8323) (Single spring)
	Standard as-installed load of valve spring N (kg, lb)	235.4 (24.0, 52.9) [35 mm (1.38 in)] (Single spring)
Flywheel	Runout limit (on clutch disc mating surface) (M/T models) mm (in)	1.0 (0.039)


FIG. NO. 1 C-1 4WD vehicles (RB20DET/RB26DETT equipped models)












Cont'd Fig. No. 1 C-1 4WD Vehicles (RB20DET/RB26DETT equipped models)









Oil temperature sensor	Inhibitor SW	A/T S/V
		Oil level sensor






This harness diff
GT-R model and
- GT-R model u
kind of harness
- GTS-4 model
M/T and A/T :
with auto spo
without auto s
Auto spoiler n
have ASCD ci

*5: Grounded shield




ig wheel SW



1






* Ground shield










Body

This ha for GT- and cor A/T mo






1st version: To W-5 (auto spoiler)

*13: Grounded shield







Body GND



(03) RB26DETT






50	60
49	59
48	58
47	57
46	56
45	55
44	54
43	53
42	52
41	51
30	40
29	39
28	38
27	37
26	36
25	35
24	34
23	33
22	32
21	31
10	20
9	19
8	18
7	17
6	16
5	15
4	14
3	13
2	12
1	11
108	116
107	115
106	114
105	113
104	112
103	111
102	110
101	109

ECCS control unit

Fig. No. 5 W-3 E-TS SYSTEM






Fig. No. 6 W-4 DOOR HARNESS






Fig. 7 W-5 HICAS SYSTEM






(Terminal arrangement of joint connector section may vary within the dotted-line area.)


Fig. No. 8 W-6 AIR CONDITIONER HARNESS

Electrically controlled active
full-automatic air conditioner




ENGINE COMPARTMENT – RELAY BOX



ENGINE COMPTARTMENT – RELAY BOX




TRANSFER CASE COOLER




SIDE REPEATER LAMPS




OIL TEMPERATURE WARNING
BRAKE LIGHT WARNING
DIMMER SW INSTRUMENT PANEL ILLUMINATION




REAR LAMPS AND H.M.S.L.



TRANSFER CASE COOLER



A



VIEW A

AUS-6

ETC ELECTRONIC TORQUE SPLIT CONTROLLER

HKS ELECTRONICS TECHNOLOGY

HKS

Pursuing the Ultimate in Engine Performance and Efficiency.
HKS Company Limited

札幌営業所 (011)723-1110
仙台営業所 (022)259-2626
東京営業所 (0425)81-4080
名古屋営業所 (052)354-6833
大阪営業所 (0727)28-3663
広島営業所 (082)871-1020
福岡営業所 (092)471-5931

ETC取扱説明書

この度は、HKSエレクトロニック トルク スプリット コントローラー (ETC)をお買い上げ下さいまして誠にありがとうございます。
本商品は、精密機械であるため、取り付けに際しては本書にしたがって、充分注意して行って下さい。
お取付の前に取扱説明書をよくお読み下さい。お読みになった後は大切に保管して下さい。

特徴

- ノーマルのETSシステム(BNR32、HNR32に搭載)の作動に関わらず、前輪に伝えるトルクを任意に設定する事により、個々のドライバーの好みとするドライブフィーリングを得られる商品です。
- ETC作動中ノーマルのトルクメーターは、ETCのボリュームで設定したトルク値を表示します。
- ETC作動中にABS(アンチロックブレーキ)が作動するとETCはノーマル復帰し、ABSの作動が停止すればETCは、ON又はAUTOに戻ります。


目次

パーツリスト	1
全体配線図	2
取付方法	3
ETC本体説明	4
注意事項	5

1 パーツリスト

- ETC本体 1 台
- ETCリレーボックス 1 台
- ETCハーネス 1 台
- 延長ハーネス 1 本
- 両面テープ 3 枚
- 取扱説明書 1 部
- 保証書 1 部


2 全体配線図



3 取付方法

- (1) バッテリーの(+)端子を外します。
- (2) トランクルーム内にあるETSコントロールユニットに、ETCハーネスを接続します。
- (3) リレーボックスから出ている9極メスカブラーと3極メスカブラーにETCハーネスから出ている9極オスカブラーと3極オスカブラーを接続します。
- (4) リレーボックスをハーネスの届く範囲で、両面テープにて固定して下さい。
- (5) トランクルームから延長ハーネスを室内に通し、リレーボックスから出ている9極オスカブラーに延長ハーネスの9極メスカブラーを接続します。
- (6) ETCハーネスから出ているメスギボシ端子とリレーボックスから出ているオスギボシ端子を接続します。
- (7) ETC本体を、室内に通した9極メスカブラーに接続し、両面テープ等で任意の場所へ固定して下さい。
- (8) バッテリーの(+)端子を接続します。

4 ETC本体説明



(1) POWERボリューム

- OFF ノーマル状態
- ON 常時GROSS、FINEボリュームで設定したトルクを前輪にかけます。
- AUTO 車速がおおよそ15km/h以上でGROSS、FINEボリュームで設定したトルクを前輪にかけ、車速が15km/h以下でノーマル状態になります。

(2) GROSSボリューム

OPTION... ETCには、OPTION入力端子が装備されており、後にシステムの拡張が可能となっております。

1~6 前輪にかけられるトルクを大まかに設定出来ます。

(3) FINEボリューム

0~9 前輪にかけられるトルクを微調整出来ます。

LED点灯条件

- POWER LED IG ONで常時点灯
- AUTO LED POWERボリュームがAUTOモードでなおかつ、車速がおおよそ15km/h以上で点灯。
- GROSS FINE LED POWERボリュームがON又はAUTOモードで点灯(但しAUTOモードでは車速がおおよそ15km/h以上になった時点灯)
- OPTION LED POWERボリュームがON又はAUTOで、且つGROSSボリュームがOPTIONを選択した時に点灯(但しAUTOモードでは車速がおおよそ15km/h以上になった時点灯)

(注) ABS作動中はAUTO LED、GROSS LED、FINE LEDともに消灯し、ABS解除後は、上記のように点灯します。

5 注意事項

ETCを取付、使用する際以下の注意事項を必ず守って下さい。

- (1) バッテリーの(+)端子を外してから、作業を行って下さい。
- (2) ETCは、構造上完全なFRとは成らず前輪に多少のトルクがかかるため、パワーチェックの際には、フロントプロペラシャフトを外すか、エンジンルーム内に有る4WDのヒューズブルリンクを外し2WDに成っている事を確認のうえ行って下さい。
- (3) 前輪に常に高トルクをかけていると駆動系に負担がかかりますので、必要の無いときはノーマルもしくはFRに近い状態で使用して下さい。