


Instructions to access the Programming Menu



To access programming
 Power-off then power-on the equipment...
 ← 1) Switch CBS-2111 power “OFF”
 and then
 2) Turn main power switch to “ON”
 (switch is located on the lower back)
 The touch screen will illuminate.
Immediately
 Touch and hold finger to enter programming →
 In 5-8 seconds “PROGRAM” screen will
 appear. “PROGRAM” in first column below

FETCO

XTS™

EXTRACTOR
TOUCHSCREEN

TBS_2111

©2016 all rights reserved

✓

🌡️ 📄


90°C

TOUCH and HOLD

Programming-category screens: Menu Tree Menu Features: Batch Parameters


XTS Main Menu

Menu Chart



PROGRAM	Programming Items	Factory set Default	Programming Range	Notes
Batch 1 *	• Batch Summary	Display Summary	Batch1 Summary ➡➡	Summary-continued
			Batch Name 1	Bypass Delay 1:00
			Brew Temp. 90°C	Number of Pulses 4
			Brew Volume 4.00 Liter	Prewet Percent 0%
			Brew Time 6:00	Prewet Delay 0:00
			Bypass Vol. 2.00 Liter	Drip Delay 1:30
			Total Time 9:30	Alarm At End NO
	• Batch Temp	90 °C	90 °C 80 97	This sets the brew temperature for batch-1
	• Brew Volume	4.00 liter [0.50-4:00]	4.00 liter 0.50 6:00	Volume of Coffee (tea to hot water bypass [2:1])
	• Bypass Volume	2.00 liter	2.00 liter 0:00 5.50	Volume of HOT water to add to hot brew
	• Bypass Delay	1:00 mm:ss	1:00 mm:ss 0:00 12:00	Allows for hot water tank recovery
	• Prewet Percent	0%	0 % 0 15	Prewetting helps stabilize ground coffee
Pause after prewet spray completes	• Prewet Delay.	0:00 mm:ss	0:00 mm:ss 0 1	This feature appears ONLY if Prewet >0:00
	• Brew Time	6:00 mm:ss	6:00 mm:ss 1:00 12:00	
	• Nr Of Pulses	4	4 1 30	
This is a Safety Feature	• Drip Delay	1:30 mm:ss	1:30 mm:ss 0:30 10:00	NEVER remove brewbasket during drip-out
	• Alarm at End	NO	NO YES NO	
Notice ➔	*Batches 1 & 5 are mandatory and are always permanently selected Batch 2,3,4,6,7&8 may each be selectively hidden with the Batch ON/OFF selector screen			
Batch 2	• Batch ON/OFF	ON	ON ON OFF	
	• Batch Summary	Display Summary		[See BATCH 1]
	• Batch Temp	90 °C	90 °C 80 97	This sets the brew temperature for batch-1
	• Brew Volume	4.00 liter [0.50-4:00]	4.00 liter 0.50 6:00	Volume of Coffee (tea to hot water bypass [2:1])
	• Bypass Volume	2.00 liter	2.00 liter 0:00 5.50	Volume of HOT water to add to hot brew
	• Bypass Delay	1:00 mm:ss	1:00 mm:ss 0:00 12:00	Allows for hot water tank recovery
	• Prewet Percent	0%	0 % 0 15	Prewetting helps stabilize ground coffee
Pause after prewet spray completes	• Prewet Delay.	0:00 mm:ss	0:00 mm:ss 0 1	This feature appears ONLY if Prewet >0:00
	• Brew Time	6:00 mm:ss	6:00 mm:ss 1:00 12:00	
	• Nr Of Pulses	4	4 1 30	
This is a Safety Feature	• Drip Delay	1:30 mm:ss	1:30 mm:ss 0:30 10:00	NEVER remove brewbasket during drip-out
	• Alarm at End	NO	NO YES NO	

PROGRAMMING MENU-Continued

PROGRAM Continued	Programming Items	Factory set Default	Programming Range	Notes
Batch 3	(See Batch 2)			
Batch 4	(See Batch 2)			
Batch 5	(See Batch 1)			
Batch 6	(See Batch 2)			
Batch 7	(See Batch 2)			
Batch 8	(See Batch 2)			
Batch Copy	Copy From Batch	COPY from B.(1-8)?		
	Copy To Batch	COPY to B.(1-8)?		
	Copy?	B1→B2? (example)	NO  YES NO	

*Batch 1 & 5 are mandatory and cannot be disabled. Other batches can be disabled ["hidden"], and removed from display


Programming Batch Temperature

Individual temperature settings can be programmed for all eight recipes. This accommodates many different brew temperature requirements of the coffee product used. The hot water tank temperature automatically sets to the lowest programmed recipe setting. If a brew is started for a higher temperature setting, the brewer will pause and quickly heat the hot water tank to the temperature setting of the recipe before starting the brew. This is rapid: taking only minutes.

Tank temperature is too low for brew setup

- 1) If the tank temperature is LOWER than the temperature setting—the brewer will display the “Not Ready” icon:
 The hot water tank will quickly reheat and the “Ready” icon will display when heated to the set temperature:

Tank temperature is too high for brew setup

- 2) If the tank temperature is HIGHER than the temperature setting—the brewer will flash the “PURGE” icon: 
“PURGE” to cool feature

Purge is drawing a small amount of hot water from the hot water tank—the temperature of the tank is automatically reduced by cool, fresh refill water from the mains. When the “PURGE” icon is activated for 5 seconds approximately ≈150ml/4 fl.oz hot water is released as bypass water and the tank temperature is reduced.


- a) The hot water tank temperature can be quickly lowered by touching the “PURGE” icon for five seconds. The single purge is adequate for most adjustments.






Note: the purged water increases the contents of the dispenser. The 150ml released is a negligible addition for most brews—but should be noted for dispensers without headspace or for multiple purges

- b) Water may be drawn from the hot water service faucet to lower hot water tank temperature. The “PURGE” function is preferred as it offers better control.

- c) Tank temperature override

The brew can be started at the high temperature by touching and holding the “START” icon to override the icon. The brew may be exposed to some brewing water that is higher than temperature setpoint.

Recipe temperature setting table				Purge to lower brew water temperature				
GENERAL Factory Set Temperature Summary				SETTINGS BY USER Temperature Summary as Set By User Fill this in and save for future reference				Recipes show the temperature setting. These can be set by user from 80-97°. PURGE Icon →  Touch the purge icon for 5 sec. This will lower hot water tank temperature 3-4 degrees
1	90°C	5	90°C	1		5		
2	90°C	6	90°C	2		6		
3	90°C	7	90°C	3		7		
4	90°C	8	90°C	4		8		

GENERAL	Programming Items	Factory set Default	Programming Range (display)	Notes
Ready Temp		+ / - 2°C		Range when "READY" icon will show
Brew at Temp.	"OFF" allows brewing at any temperature.	AUTO		SEE NOTE! (Below)
Units of Meas. <Toggle Temp-Vol.>	• Temperature	°C		
<Toggle Temp-Vol.>	• Volume	Liters		
Logo Timeout		1:00 mm:ss		


NOTE: FOR BREW AT TEMPERATURE DEFINITONS

BREW AT TEMP: AUTO
(DEFAULT: FACTORY PROGRAMMED INTO BREWER)

This allows the "BREW START" to active.
 If the hot water tank is at the selected temperature—the brew will start.
 If the temperature is too low—*not at the selected temperature*, the brewer will wait until the proper temperature is reached and then wil automatically begin brewing.
 A thermometer icon screen will display showing the tank temperature. (example: right)


IMPORTANT:
















ALWAYS have dispenser(s) under the brew baskets when in the BREW AT TEMP mode.



BREW AT TEMP: OFF **USER SELECTABLE**

Allows brewing at any temperature. (Not recommended-it is possible to start brew with brew water at incorrect temperature.)

INPUTS	Programming Items	Factory set Default	Programming Range (display)	Notes
Display Inputs	• Input Summary		Brew Basket Sensor <input type="checkbox"/> Liquid Level Sensor <input checked="" type="checkbox"/> Temperature Probe <input checked="" type="checkbox"/> SD Card <input type="checkbox"/>	
Cal. Touch Scr		Calibrate	Calibrate 	If <u>Yes</u> : Follow directions on the touch screen

OUTPUTS	Programming Items	Factory set Default	Programming Range (display)	Notes
Brew Valve Calibrate/Test	• Brew Valve	(Press to test)	 < OUTPUTS > < Brew Valve > < Calibrate/Test> Cal Test Press To Cal/Test BASKET IN PLACE TEMP READY  	Runs valve to verify flow. Have container under brew basket!
Brew Valve-CALIBRATE	• Brew Valve		 < OUTPUTS > < Brew Valve > < Calibrate/Test> Cal Test Press To Cal/Test BASKET IN PLACE TEMP READY  	See pages 10-12 for detailed calibration procedure and screens
BYPASS Valve-CALIBRATE	• BYPASS Valve		 < OUTPUTS > < Brew Valve > < Calibrate/Test> Cal To Stop press Cal. CAL IN PROGRESS   	See pages 10-12 for detailed calibration procedure and screens
Fill Valve	• Fill Valve Test	(Press to test)	TEST Press To Test 	Operates fill valve. Have container under both brew baskets!
Heater	• Heater Test	(Press to test)	TEST Press To Test 	Energizes Heater(s) Use for servicing.
Buzzer	• Buzzer Test	(Press to test)	TEST Press To Test 	Confirms "BEEP" Use for servicing.
Screen	• Screen Contrast	Contrast	8  1 10	
	• S. Brightness	Brightness	8  1 10	

How to calibrate the flow rate for the brew valve or bypass valve


Set the flow rates of brew valve to adjust for taste profile and for batch size.

Built-in algorithms in Brewer controller software corrects brew parameter to customer preferences or to trim variations in flow control components

NOTICE: This operation requires operator to activate brew or bypass function for one minute—and to measure the output

1) MEASURE THE FLOW RATE:

- Enter programming mode, scroll left to “OUTPUTS”
- Scroll down to “Brew Valve Calibrate/Test”
- (or)
- “Bypass Valve Calibrate/Test”
- Next: scroll down to “Calibrate Test”



- Place 3 liter/1 gal measuring container under empty brew basket.
- The water dispensed may be accurately measured or weighed. Use a scale for at least 3 kg/8lb
- Press The CAL button. **→! The valve will open for one minute**
- It is very important for this test to measure the flow for the entire minute.**

Measure the results of the flow in the measuring container and hold the number.

2) AUTOMATIC Built-in CALIBRATE THE FLOW RATE


- Enter this number, in milliliters, into the calibration slider for the Valve tested in the OUTPUT MENU.
- Enter in milliliters.** If measured in fluid ounces (fl.oz) multiply by 29.57 to convert to milliliters
- After entering the measured volume, exit PROGRAMMING and return to the normal screens

By entering the new flow rate number into the brewer, the software automatically corrects the valve flow discrepancy



From calibrate-test screen, brewer automatically dispenses for 60 seconds. The calibration test flow is carefully measured in milliliters.

A 3 liter/1 gal measuring container is recommended.




Scroll from the calibrate-test screen into the FLOW RATE screen. Enter the calibration test flow on the slider using the + and - icons. EXIT and SAVE as prompted.

Built in software will automatically calibrate the BREW valve.


Calibration must be repeated for the BYPASS valve

EXAMPLE: Calibrate BREW VALVE.



1) Enter PROGRAMMING menu
 (See page 5: INSTRUCTIONS TO ACCESS PROGRAMMING MENUS)
 Scroll to "OUTPUTS" in PROGRAMMING
 Scroll down to **BREW VALVE**


(The following areas may be accessed in this PROGRAMMING position: BREW VALVE, BYPASS VALVE, Fill Valve, Heater, Buzzer, Screen. To access these: with the 2nd level highlighted as shown—scroll through the positions with the right/left arrows. Only the Brew and Bypass valves can be calibrated)



Scroll down to "**Calibrate/Test**"

(The following areas may be accessed in this PROGRAMMING position: Calibrate/Test and Flow Rate. To access these: with the 3rd level highlighted as shown—scroll through the positions with the right/left arrows. CBS-2111 automatically calibrates based on the flow entered. The highlighted FLOW RATE is used to enter the flow rate and for Service and to fine tune the flow.)

Scroll down to "**Cal Test**"




Have 3 Liter/1Gallon measuring container under brew basket

In "Cal Test

PRESS CAL and remove finger—do not hold


The CBS-2111 will dispense for exactly one minute and automatically stop.

Carefully measure the amount of water, in milliliters, that was dispensed
 This is the calibration test flow
 The calibration results are entered into the slider that automatically displays



ENTER THE CALIBRATION TEST FLOW RESULTS


The calibration is adjusted by the CBS-2111XTS software by entering the amount of water into the slider that was dispensed in 60 seconds.
The slider shows 1218 mlpm (milliliters per minute)-enter your results.
 Using the + and - icons, enter the amount of water dispensed on the slider.
 Enter in milliliters (multiply fluid ounces by 29.6 to obtain milliliters)



Scroll UP and OUT and save calibration as directed by screen prompts.

Brew valve is automatically calibrated on saving the test flow entered.
EXIT TO COMPLETE CALIBRATION

EXAMPLE: Calibrate BYPASS VALVE.




1) Enter PROGRAMMING menu
(See page 5: INSTRUCTIONS TO ACCESS PROGRAMMING MENUS)

Scroll to “**OUTPUTS**” in PROGRAMMING


Scroll down to **BYPASS VALVE**

(The following areas may be accessed in this PROGRAMMING position: BREW VALVE, BYPASS VALVE, Fill Valve, Heater, Buzzer, Screen. To access these: with the 2nd level highlighted as shown—scroll through the positions with the right/left arrows. Only the Brew and Bypass valves can be calibrated)



Scroll down to “**Calibrate/Test**”


(The following areas may be accessed in this PROGRAMMING position: Calibrate/Test and Flow Rate. To access these: with the 3rd level highlighted as shown—scroll through the positions with the right/left arrows. CBS-2111 automatically calibrates based on the flow volume entered. The highlighted FLOW RATE is used to enter the flow rate and for Service and to fine tune the flow.)



Scroll down to “**Cal Test**”

Have 3 Liter/1Gallon measuring container under bypass basket

In “Cal Test”




PRESS CAL and remove finger—do not hold

The CBS-2111 will dispense for exactly one minute and automatically stop.

Carefully measure the amount of water, in milliliters, that was dispensed
This is the calibration test flow
The calibration results are entered into the slider that automatically displays

ENTER THE CALIBRATION TEST FLOW RESULTS

The calibration is adjusted by the CBS-2111XTS software by entering the amount of water into the slider that was dispensed in 60 seconds.
The slider shows 1218 mlpm (milliliters per minute)-enter your results.
Using the + and – icons, enter the amount of water dispensed on the slider.
Enter in milliliters (multiply fluid ounces by 29.6 to obtain milliliters)



Scroll UP and OUT and save calibration as directed by screen prompts.

Bypass valve is automatically calibrated on saving the test flow entered.

OTHER	Programming Items	Factory set Default	Programming Range (display)	Notes
Error Codes	• Display Errors	(Codes)	1: 2: 3:	Chart on next page
	• Reset Errors	(Reset)	Reset ----- YES NO	!!Clear only with guidance from factory or service !! Setup upload
Copy Program	• From SD to B.	SD→ Brewer	SD→ Brewer ----- YES NO	Please insert SD card with the setup data!
	• From B to SD	Brewer→ SD	Brewer→ SD ----- YES NO	Setup download Please insert SD card with sufficient space (≥2GB)
Upload Logo		Upload Logo	UPLOAD LOGO Are you sure ----- YES NO	Please insert SD card with logo file!
Res to Factory		Reset to default	Reset to Default Are you sure ----- YES NO	Completely overwrites all user setup, including user logo.
Counters	• Display Counters -OR- • Reset Counters	Counters Display Total Counters	TOTAL COUNTER Brews 0 Brews activated 0 Brew [liters] 0 Bypass Activated 0 Bypass. L [liters] 0 Fill valve Activated 0 Fill Valve [liters] 0 Heater Activated 0 Heater "on" time 0	Resetting will restart counters from zero when selected
	• Reset Counters	Reset All Counters	Reset All Counters Are you sure ----- YES NO	
Firmware	• Firmware Version -Software type	Firmware Version	Display Versions TBS_2111 SW ver. 1.05 HW ver. BL ver. 1.1.4 QP ver. 4.5.03	Displays firmware version
	• Update Firmware	UPDATE	UPDATE ----- YES NO	Firmware upload Please insert SD card with the firmware file!
DEMO Mode [Not on all units]	DEMO ON/OFF	May not be included	OFF ----- ON OFF	Demonstrates the controls for training. Disables all components in demo mode.
Some software versions will not have "DEMO- MODE"				