


# Equity

## .9-inch LED Alarm Clock with USB Charging Port



Model: 30024 & 30025  
DC: 011419

### POWER UP

1. Insert the 120 volt power cord into an outlet, then into your clock. Optional: Insert one 9 volt battery for backup.

2. 12:00 will flash as an indication to set the time and/or alarm.

### TIME SETTING

1. Continuously hold down the TIME button, then:
  - Press the HOUR button to set your hour.
  - Press the MINUTE button to set your minutes.

**Note:** The PM indicator will appear when you advance to PM time.

2. Release the TIME button when the correct time is shown on the display.

### BACKLIGHT

Your backlight has three levels: High, Low, and Off.

- Press the SNOOZE/LIGHT button to adjust.

### USB CHARGING PORT

- Connect your external device's USB charging cable (not included) to the USB charging port.

- USB Power Output: 5V 1A maximum current.

- Charge devices that are self-regulating.

### TIME ALARM

1. Continuously hold down the ALARM button, then:
  - Press the HOUR button to set your hour.
  - Press the MINUTE button to set your minutes.

**Note:** The PM indicator will appear when you advance to PM time.

2. Release the ALARM button when the correct alarm time is set.

### ALARM ON/OFF

**ON:** Slide the ALARM ON/OFF switch to the ON position to turn the alarm ON. The alarm light indicator will appear.

**OFF:** Slide the ALARM ON/OFF switch to the OFF position to turn the alarm OFF. The alarm light indicator will disappear.

### SNOOZE

- When the alarm sounds press the SNOOZE/LIGHT button to silence the alarm for 10 minutes.

- Snooze may be repeated.

**Note:** This is a Ascending alarm. It will sound with increased frequency for 2 minutes then shut off if no buttons are pressed.

### BATTERY BACKUP

- Insert one "9V" battery into the battery compartment on the back of the clock. The battery will keep the alarm and time settings until the power is restored.
- The LED display will not light-up but the alarm will sound at the preset alarm time.
- If there is no battery installed but the power is interrupted, the display will flash at 12:00 and the time and alarm need to be set again.

### CARE & MAINTENANCE

- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of your clock prior to battery installation.
- Ensure the battery is installed with correct polarity (+ and -).
- Remove battery from equipment when it is not used for an extended period of time.
- Promptly remove an expired battery.

### POWER REQUIREMENTS


**Power:** 120V power cord  
Requires one 9V battery for back-up not included

**Dimensions:** 5.00 "W x 2.00"D x 2.85"H

**WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.**

**Caution: To prevent electrical shock do not use this (polarized) plug with an extension cord, receptacle, or other outlet unless the blades can be fully inserted to prevent blade exposure.**

**ATTENTION: POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT, OU UNE AUTRE SORTIE DE COURANT SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES À FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOURVERT**



 **WARNING:** This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

**SAFETY INSTRUCTIONS**

1. Read Instructions - All the safety and operating instructions should be read before the appliance is operated.
2. Retain Instructions - The safety and operating instructions should be retained for future reference.
3. Water and Moisture - The appliance should not be used near water - for example, near a bathub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool and the like.
4. Ventilation - The appliance should be situated so that its location or position does not interfere with its proper ventilation. For Example, the appliance should not be situated on a bed, sofa, rug or similar surface that may block the ventilation openings, or place in a built-in installation such as a bookcase or cabinet that may impede the flow of air through the ventilation openings
5. Heat - The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
6. Power Sources - The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
7. Grounding or Polarization - Precautions should be taken so that the grounding or polarization means of an appliance is not defeated.
8. Power - Cord Protection - Power supply cords should be routed so that they are not likely to be walked on, or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and at the point where they exit from the appliance.
9. Cleaning - The appliance should be cleaned only as recommended by the manufacturer.
10. Object and Liquid Entry - Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
11. Damage Requiring Service - The appliance should be serviced by qualified service personnel when:
  - A. The power supply cord or the plug has been damaged.
  - B. Objects have fallen, or liquid has been spilled into the appliance; or
  - C. The appliance has been exposed to rain; or
  - D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
  - E. The appliance has been dropped, or the enclosure damaged.
12. Servicing - The user should not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.



Please help in the preservation of the environment and return used batteries to an authorized depot. Remove the battery from the clock if you do not intend to use it for an extended period of time.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**WARRANTY & SUPPORT**

Equity provides a 2-year limited warranty on this product from the date of consumer purchase against defects for material and workmanship. During this period such defects will be repaired, or the product will be replaced at Equity's option, without charge. This warranty does not cover damage caused by misuse or negligence.

ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD ENDING TWO YEARS FROM DATE OF PURCHASE.

Some states do not allow limitations on how long an implied warranty lasts so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.

If your product is not working properly, please send:  
Your product. A letter explaining the problem and \$5.00 for postage and handling to:

Equity by La Crosse  
Warranty Department  
2830 26th St S.  
La Crosse, WI 54601  
[www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

Made in China

Printed in China

**FCC STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

**Operation is subject to the following two conditions:**  
**(1) This device may not cause harmful interference, and**  
**(2) This device must accept any interference received, including interference that may cause undesired operation.**

**Caution!**  
The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.  
All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.  
This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.