LA CROSSE® TECHNOLOGY

ATOMIC DIGITAL WALL CLOCK WITH INDOOR/OUTDOOR TEMPERATURE QUICK START GUIDE



MODEL: 513-1918B DC: 102819

Find your full manual and product information here: bit.ly/laxtech_support

POWER UP


.

1. Insert 2-AA batteries into your Outdoor Sensor.

2. Insert 3-AAA batteries into your Digital Clock.

3. Once the Outdoor Sensor is reading to your clock, place it outside in a shaded location to protect it from the sun's heat.

Watch sensor mounting video: bit.ly/TH_SensorMounting



ATOMIC TIME SIGNAL - WWVB

- Your Clock will automatically search for the Atomic Time Signal at UTC 7:00, 8:00, 9:00, 10:00, and 11:00.
- Press the PLUS (+) button to manually start or stop search for the WWVB Atomic Time Signal.
- While searching, the Tower Icon ${}^{(\!\!\!\!\ p)}$ will flash. The Tower Icon will be solid when the WWVB Signal is received by your clock.
- For information about WWVB Atomic Time visit: bit.ly/AtomicTime

SETTINGS

1. Hold the SET button to enter the Settings Menu.

2. Use the + or - button to adjust values.

3. Press the SET button to confirm and move to next item.

Settings Menu Order:

- Language English | Spanish | French
- Beep ON | OFF
- Atomic ON | OFF
- Daylight Saving Time
- DST AUTO ON (Gain 1 hour in spring, lose 1 hour in fall)
- DST OFF (Remain in Standard Time all year long)
- DST ON (Remain in Daylight Saving Time all year long)
- Time Zone

• Hour	TIME ZONE
Minutes	AST = Atlantic EST = Eastern
• Year	CST = Central
• Month	MST = Mountain
• Date	PST = Pacific AKT = Alaska
 Fahrenheit Celsius 	HAT = Hawaii

Language: Whichever language is selected, the following instructions and weekday will be presented in that language.

Weekday: Weekday will set automatically when Year, Month and Date are set.

BUTTON FUNCTIONS

The buttons are located at the top of your clock.

SNOOZE ALARM SET +

SNOOZE Press to exit Settings Menu. When Alarm Sounds press to Snooze Alarm for 10 minutes. ALARM Hold to enter Alarm Settings. Press to activate/deactivate alarm. Alarm Icon \$ will show when alarm is active. SET Hold to enter the Settings Menu. Press to change Date Display. PLUS (+) Hold to search for Outdoor Sensor. Press to manually search for the WWVB Atomic Time Signal. Settings Menu: Press to increase value. Hold to increase quickly. MINUS (-) Settings Menu: Press to decrease value. Hold to decrease quickly.		
ALARM Alarm Icon 4 will show when alarm is active. SET Hold to enter the Settings Menu. Press to change Date Display. PLUS (+) Hold to search for Outdoor Sensor. Press to manually search for the WWVB Atomic Time Signal. Settings Menu: Press to increase value. Hold to increase quickly.	SNOOZE	
SE I Press to change Date Display. PLUS (+) Hold to search for Outdoor Sensor. Press to manually search for the WWVB Atomic Time Signal. Settings Menu: Press to increase value. Hold to increase quickly.	ALARM	
PLUS (+) Press to manually search for the WWVB Atomic Time Signal. Settings Menu: Press to increase value. Hold to increase quickly.	SET	5
MINUS (-) Settings Menu: Press to decrease value. Hold to decrease quickly.	PLUS (+)	Press to manually search for the WWVB Atomic Time Signal.
	MINUS (-)	Settings Menu: Press to decrease value. Hold to decrease quickly.

CUSTOM DATE DISPLAY

Press the SET button to change the Custom Date Display.





*Not included

SENSOR WEATHER SHIELD*

- The Sensor Weather Shield is designed to protect your outdoor sensor from rain and snow.
- This shield will offer limited protection from the sun's heat.
- Optional purchase at: <u>bit.ly/925-1418</u>

WE'RE HERE TO HELP!

If you require additional support, get in touch with our friendly customer support team based out of La Crosse, WI.

Phone: 1-608-782-1610 Online: bit.ly/contact_techsupport

Our knowledgeable customer support team is available: Monday-Friday, 8am-6pm CST.

JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



SPECIFICATIONS

Indoor Temperature Range: 32°F to 122°F (0°C to 50°C)

Outdoor Temperature Range: -40°F to 140°F (-40°C to 60°C) Transmission Range: Over 330 ft. (100 meters) RF 433MHz (open air)

Power Requirements: 513-1918B: 3 "AAA" batteries (sold separately) TX191: 2 "AA" batteries (sold separately)

Battery Life: 513-1918B: Over 18 months TX191: Over 18 months

Dimensions: 513-1918B: 8.97" W × 0.94" D × 7.12" H (22.78 W × 2.38 D × 18.08 H cm) TX191: 1.57" W × 0.95" D × 4.49" H (3.98 L × 2.41 W × 11.40 H cm)

WARRANTY INFO

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship. La Crosse Technology, Ltd, 2830 S. 26th St., La Crosse, WI 54601 For Full Warranty Details, Visit: www.lacrossetechnology.com/support

CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
 Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

WARNING: This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: www.P65Warnings.ca.gov

