

617-106/617-106B FAQs

The links below will work in most PDF viewers and link to the topic area by clicking the link. We recommend Adobe Reader version 10 or greater available at: <http://get.adobe.com/reader>

CONTENTS

617-106/617-106B FAQs	1
Factory Restart	1
How tall are the numbers on each side?.....	1
Power Requirements	1
Battery Backup.....	2
Three Custom Display Options	2
12-Hour or 24-Hour time format.....	2
Manually Set Time/Date: Program Menu.....	2
Set one or both Alarms.....	3
Adjustable Backlight.....	4
USB Charging Port	4
Clock has distorted or frozen display	4

Factory Restart

Explanation: The factory restart returns the clock to an “out-of-the-box” state and often resolves an issue.

Factory Restart:

1. Remove all power (batteries and AC) from the clock.
2. Press one of the buttons on the alarm at least 20 times to clear all memory.
3. **Leave unpowered for 15 minutes** (very important).
4. Insert the AC cord into the wall outlet then into the clock.

How tall are the numbers on each side?

- 0.9” Front white LED digits
- 0.6” Sides white LED digits

Power Requirements

- This clock is powered by a 5 volt AC power adapter
- Optional 9-volt battery is used for backup.

Battery Backup

- Insert one “9V” battery into the battery compartment on the back of the clock. The battery will keep the alarm and time settings until the power is restored.
- The LED display will not light-up but alarms will sound at their preset alarm time.
- If there is no battery installed but the power is interrupted, the display will flash at 12:00 and the time and alarm need to be set again.

Three Custom Display Options

Your clock has three unique displays to provide the Time, Date, Temperature and Alarm, information you need.

Main Front Display: Press the SET button to change the display.

- Press 1: Time Mode (Default)
- Press 2: Temp/Humidity Mode
- Press 3: Date Mode
- Press 4: Alarm 1 Set Time
- Press 5: Alarm 2 Set Time

Left Side Display: Press the “1” with circling arrow button to change the display.

- Press 1: Time Mode
- Press 2: Temp/Humidity Mode
- Press 3: Date Mode (Default)
- Press 4: Alarm 1 Set Time
- Press 5: Alarm 2 Set Time

Right Side Display: Press the “2” with circling arrow button to change the display.

- Press 1: Time Mode
- Press 2: Temp/Humidity Mode (Default)
- Press 3: Date Mode
- Press 4: Alarm 1 Set Time
- Press 5: Alarm 2 Set Time

12-Hour or 24-Hour time format

- Time can display in 12-hour (am, pm) or 24-hour format.
- Default is 12-hour time.
- Use the [Program Menu](#) to switch time formats.

Manually Set Time/Date: Program Menu

1. Hold the **SET** button 2 seconds to enter settings mode.
2. Press the + or - button to adjust the flashing values.
3. Hold the + or - buttons to adjust quickly.
4. Press the **SET** button to confirm adjustments and move to the next item.
5. Press the **SNOOZE** button at any time to exit.

Settings order:

- 12/24 Hour
- Hour
- Minutes
- Year
- Month
- Date
- Temperature Fahrenheit/Celsius

To begin:

1. Hold the SET button for 2 seconds to enter setting mode. **12Hr** will flash. Press the + or - button to select 12 or 24 hour time format.
2. Press SET to confirm and move to the hour. The **12:00** will show and **12:** will flash. Press the + or - button to choose the hour.
3. Press SET to confirm and move to the minutes. The **12:00** will show and **:00** will flash. Press the + or - button to choose the minutes.
4. Press SET to confirm and move to the year. The **2020** will show, **20** will flash. Press the + or - button to change the year.
5. Press SET to confirm and move to the calendar. The **01 M - 01 D** will show. **01 M -** will flash. Press the + or - button to change the month.
6. Press SET to confirm and move to the date. The **01 M - 01 D** will show. **- 01 D** will flash. Press the + or - button to change the date.
7. Press SET to confirm and move to the temperature unit. **°F** will show. **°F** will flash. Press the + or - button if you prefer **°C** (Celsius).
8. Press SET to confirm and exit.

Set one or both Alarms

- Hold the ALARM (1 or 2) button 2 seconds to enter alarm settings mode.
- Press the + or - button to adjust the flashing values.
- Hold the + or - buttons to adjust quickly.
- Press the ALARM button to confirm adjustments and move to the next item.
- Press the SNOOZE/LIGHT button at any time to exit.

Set Alarm:

1. Hold the ALARM (1 or 2) button for 2 seconds to enter setting mode. 6:30, the coordinating ALARM BELL ICON will show, and 6: will flash. Press the + or - button to choose the hour.
2. Press ALARM to confirm and move to the minutes. The 6:30 and the coordinating ALARM BELL ICON will show and: 30 will flash. Press the + or - button to choose the minutes.
3. Press ALARM to confirm and exit. The alarm is now active.

Activate/Deactivate Alarm:

- The alarm is active when set.
- From normal time display, press and release the ALARM (1 or 2) button to deactivate or activate the alarm. The alarm time will show on the front main LED display for 2 seconds.

- Coordinating alarm icon (bell 1 or bell 2) will show then active.

Snooze:

- When alarm sounds, press the SNOOZE button to silence alarm for 10 minutes.
- The coordinating alarm icon (bell 1 or bell 2) will flash
- Press any button except SNOOZE to silence the alarm for 24 hours

Note: When SNOOZE is active, during this time, user will not be able to adjust the LED brightness.

Adjustable Backlight

Press the SNOOZE/LIGHT button to adjust the brightness of your clock's LCD.

- 100% Brightness (default)
- 50% Brightness
- 12% Brightness
- 0% OFF

USB Charging Port

Connect your external device's USB charging cable (not included) to the USB Charging Port.

- This is a power output charging port. It does not provide power to the alarm clock.
- Charging times will vary.
- USB Power Output: 1 Amp maximum current.
- Charge 1 Amp devices or devices that are self-regulating.

Clock has distorted or frozen display

Explanation: On a brand new clock, check for thin plastic film of **printed scratch guard** that may be on the screen of the clock. This thin piece of plastic has printed numbers for store displays. When the batteries are installed, the "real" numbers show behind the printed scratch guard and create distortion.

- With all power removed, the clock should be blank.
- If numbers still appear, please check for scratch guard.

Power:

- Check that the power adapter and batteries are installed correctly.
- This is generally a power related issue.
- Batteries may be overpowered or underpowered.
- Remove batteries from clock.
- Press any button 20 times. Leave the batteries out of the display for 2 hours.
- Insert batteries into the clock.