

ATOMIC ANALOG WATCH FAQs

The links below will work in most PDF viewers and link to the topic area by clicking the link. We recommend Adobe Reader version 10 or greater available at: <http://get.adobe.com/reader>

CONTENTS

Atomic Analog Watch FAQs	1
Hour is incorrect.	1
Minutes are incorrect	1
Time did not change into or out of Daylight Saving time	1
Set Time Manually	2
How do I replace the battery?	2
Buttons are not responsive	3

Hour is incorrect.

Normally upon purchase, the watch will be set to Pacific Time. You may select your time zone manually. Hold the **RECESSED BUTTON** for about 3-4 seconds. The current hour is shown at the right of the display. The left side displays the current time zone selection.

1. Press and release the **PUSH-PIECE** to reach your desired time zone.
2. Once you have selected your correct time zone, to exit this setting press and release the **RECESSED BUTTON** or wait about 15 seconds without pressing any buttons and the watch will automatically return to its normal display setting.
 - North American Time Zones will show a letter.
 - Eastern Time Zone- **E** (with hour flashing)
 - Central Time Zone- **C** (with hour flashing)
 - Mountain Time Zone-**M** (with hour flashing)
 - Pacific Time Zone- **P** (with hour flashing)
 - Alaskan Time Zone- **AK** (with hour flashing)
 - Hawaiian Time Zone-**HA** (with hour flashing)

Minutes are incorrect

1. Check hand alignment. Press and hold the PUSH PIECE button on the right side of the watch for 5-7 seconds, the hands will start to spin (and seconds will be counting in digital display) when the hands stop.
2. Set-12 will flash on the digital display. If the hands stop at exactly 12:00, they do not need to be realigned.
3. If the hands did not stop at 12:00, press, release the RECESSED button once, then press, and hold it down to move the hands of the watch. As the hands approach 11:50, release the RECESSED button and press and release the same button to move the minute hand in half-minute increments up to exactly 12:00
4. Once the hands are aligned to 12:00 wait for the Set-12 to stop flashing in the digital display. (About 15 seconds) and the hands will automatically set to the correct time for the time zone selected.
5. Check the battery if it has been more than one year.

Time did not change into or out of Daylight Saving time

Check your time zone.

1. Hold the **RECESSED BUTTON** for about 3-4 seconds. The current hour is shown at the right of the display. The left side displays the current time zone selection.
2. Press and release the **PUSH-PIECE** to reach your desired time zone.

3. Once you have selected your correct time zone, to exit this setting press and release the **RECESSED BUTTON** or wait about 15 seconds without pressing any buttons and the watch will automatically return to its normal display setting.
 - North American Time Zones will show a letter.
 - Eastern Time Zone- **E** (with hour flashing)
 - Central Time Zone- **C** (with hour flashing)
 - Mountain Time Zone-**M** (with hour flashing)
 - Pacific Time Zone- **P** (with hour flashing)
 - Alaskan Time Zone- **AK** (with hour flashing)
 - Hawaiian Time Zone-**HA** (with hour flashing)

Set Time Manually

Setting Menu Order:

- Seconds
- Minutes
- Hours
- Year
- Month
- Day

To set Time and Date:

1. Hold both the PUSH-PIECE and the RECESSED BUTTONS together for about 4 seconds.
2. The Seconds will flash in the LCD display. Press and release the **PUSH-PIECE** button. The seconds will be set to zero (00).
3. Press the RECESSED button. The Minutes will flash. Press and release the **PUSH-PIECE** to set the Minutes.
4. Press the RECESSED button. The Hour will flash. Press and release the **PUSH-PIECE** to set the Hour.
5. Press the RECESSED button. The Year will flash. Press and release the **PUSH-PIECE** to set the Year.
6. Press the RECESSED button. The Month will flash. Press and release the **PUSH-PIECE** to set the Month.
7. Press the RECESSED button. The Day will flash. Press and release the **PUSH-PIECE** to set the Day.
8. Press the RECESSED button. The hands will spin and stop at the time you set.

Note: When the watch receives the Atomic Time Signal, if the hour is incorrect, check your Time Zone.

How do I replace the battery?

The easiest way is to contact our Customer Service Department:

Online: bit.ly/contact_techsupport

Note: Having someone else replace the battery will void the warranty.

1. Pry off the Front of the case. (Look for a small notch by the number 7). Be careful not to scratch the case.
2. Gently “dump” the movement out of the case being careful not to touch the hands on the movement.
3. Turn the movement over by holding the sides. Unscrew the metal plate that holds the battery in. [You do not need to completely remove the metal plate, just loosen enough to remove the battery.](#)
4. Replace the battery with a fresh **CR2025** battery. Screw the battery tab securely to the battery.
5. **READ the inside of the back case.**

8888- Push "A" (recessed button) once.
SET-12-Push "A" again. Hold button until hands are exactly at 12:00.
00 Push "B" (push piece button) once to start reception.

6. Gently install the movement being careful not to touch the hands. You will need to push the metal tabs on the side of the movement in a little bit to allow room for the buttons to set properly (If you do not the buttons will not allow the movement to lay flat in the case).
7. Place the Crystal (front of the watch) onto the back of the case. Again, be careful not to touch the hands on the movement.
8. Push the recessed button once. Then hold the recessed button until the hands reach 12:00. (As you approach 12:00, press and release the RECESSED button to avoid going past 12:00). "SET 12 will show in the LCD. Press the PUSH PIECE button to activate the watch.
9. Set the time:
 - The Seconds will flash in the LCD display. Press and release the **PUSH-PIECE** button. The seconds will be set to zero (00).
 - Press the RECESSED button. The Minutes will flash. Press and release the **PUSH-PIECE** to set the Minutes.
 - Press the RECESSED button. The Hour will flash. Press and release the **PUSH-PIECE** to set the Hour.
 - Press the RECESSED button. The Year will flash. Press and release the **PUSH-PIECE** to set the Year.
 - Press the RECESSED button. The Month will flash. Press and release the **PUSH-PIECE** to set the Month.
 - Press the RECESSED button. The Day will flash. Press and release the **PUSH-PIECE** to set the Day.
 - Press the RECESSED button. The hands will spin and stop at the time you set.
10. Check your time zone.
 - Hold the **RECESSED BUTTON** for about 3-4 seconds. The current hour is shown at the right of the display. The left side displays the current time zone selection.
 - Press and release the **PUSH-PIECE** to reach your desired time zone.
 - Once you have selected your correct time zone, to exit this setting press and release the **RECESSED BUTTON** or wait about 15 seconds without pressing any buttons and the watch will automatically return to its normal display setting.
 - North American Time Zones will show a letter.
 - Eastern Time Zone- **E** (with hour flashing)
 - Central Time Zone- **C** (with hour flashing)
 - Mountain Time Zone-**M** (with hour flashing)
 - Pacific Time Zone- **P** (with hour flashing)
 - Alaskan Time Zone- **AK** (with hour flashing)
 - Hawaiian Time Zone-**HA** (with hour flashing)

Buttons are not responsive

- Test the battery if it has been more than a year.
- This can happen after a battery change if the position of the movement is disturbed or put in incorrectly so the buttons do not line up to the movement.
- Contact customer support <http://www.lacrossetechnology.com/support/>