

Contents

| Language | Page |
|----------------|-----------|
| <i>English</i> | 1 |
| <i>French</i> | 74 |
| <i>Spanish</i> | |

TABLE OF CONTENTS

| Topic | Page |
|---|------|
| Inventory of Contents | |
| Features | |
| Setting Up | |
| Battery Installation | |
| Function keys | |
| LCD Screen and Settings | |
| WWVB Radio Controlled Time | |
| Manual Settings | |
| Weather Forecast and Tendency | |
| Display of Indoor Temperature and Humidity Reading | |
| Display of Outdoor Temperature and Humidity Reading | |
| Display of Indoor Minimum / Maximum records | |
| Display of Outdoor Minimum / Maximum records | |
| 915 MHz Reception | |
| Mounting | |
| Troubleshooting | |
| Maintenance and Care | |
| Specifications | |
| Warranty Information | |

This product offers:



INSTANT TRANSMISSION is the state-of-the-art new wireless transmission technology, exclusively designed and developed by LA CROSSE TECHNOLOGY. **INSTANT TRANSMISSION** offers you an immediate update (every 16 seconds!) of all your outdoor data measured from the sensors: follow your climatic variations in real-time!

INVENTORY OF CONTENTS


1. Wireless Weather Station
2. Wireless Thermo-hygro Sensor (TX27U) and mounting bracket.
3. Instruction Manual and Warranty Card.

ADDITIONAL EQUIPMENT (not included)

1. 1 Philips screwdriver.
2. 2 Fresh "AAA" IEC LR3, 1.5V Alkaline Batteries.
3. 1 Fresh CR2032, 3.0V Battery.

FEATURES:

Weather Station



- WWVB Radio controlled time with manual setting options
- Time reception ON/OFF
- 12/24 hour time display
- Hour and minute display
- Time zone option ± 12 hours
- Wireless transmission at 915 MHz
- Signal reception intervals of 16-seconds
- Weather forecasting with 15 easy-to-read icons featuring Oscar Outlook Forecaster
- Weather forecast icon sensitivity setting
- Temperature display in degrees Fahrenheit ($^{\circ}\text{F}$) or Celsius ($^{\circ}\text{C}$) selectable
- Outdoor temperature and humidity display with MIN/MAX recording
- All MIN/MAX outdoor recordings show date and time received
- All MIN/MAX recordings can be reset
- Can receive up to three outdoor sensors
- LCD contrast setting
- Low battery indicator
- Table standing/ Wall mounting

SETTING UP:

When one sensor is used

1. First, insert the battery into the thermo-hygro sensor. (see **"Install and replace batteries in the thermo-hygro sensor"**).
2. Immediately after and within 2 minutes, insert the batteries into Weather Station (see **"Install and replace batteries in the Weather Station"**). Once the batteries are in place, all segments of the LCD will light up briefly. Following the time as 12:00 and the "Oscar Outlook" icon will be displayed. If these are not displayed after 60 seconds, remove the batteries and wait for at least 10 seconds before reinserting them.
3. After inserting the battery into the sensor, the Weather Station will start receiving data from the sensor. The outdoor temperature/ humidity and the signal reception icon should then be displayed on the Weather Station. If this does not

happen after 15 minutes, the batteries will need to be removed from both units and reset from step 1.

4. In order to ensure sufficient 915 MHz transmission there should be a distance of no more than 330 feet (100 meters) between the final position of the Weather Station and the sensor (see notes on "**Mounting**" and "**915 MHz Reception**").

When more than one sensor is to be used

1. User shall remove all the batteries from the Weather Station and sensors and wait 60 seconds if setting has been done with one sensor before.
2. Insert the batteries to the first sensor.
3. Within 30 seconds of powering up the first sensor, insert the batteries into to the Weather Station. Once the batteries are in place, all segments of the LCD will light up briefly. Following time as 12:00 and the Oscar Outlook icon will be displayed. If they are not shown in LCD after 60 seconds, remove the batteries and wait for at least 60 seconds before reinserting them.
4. The outdoor temperature and humidity from the first sensor (channel 1) should then be displayed on the Weather Station. Also, the signal reception icon will be displayed. If this does not happen after 2 minutes, the batteries will need to be removed from both units and reset from step 1.
5. Insert the battery into the second sensor immediately after (**within 10 seconds after**) inserting battery to the Weather Station.
6. The outdoor temperature and humidity from the second sensor and the "channel 2" icon should then be displayed on the Weather Station. If this does not happen after 2 minute, the batteries will need to be removed from all the units and reset from step 1.
7. Insert the batteries into the third sensor immediately after (**within 10 seconds after**) inserting battery to the second sensor.
8. Then within 2 minutes, the channel 3 outdoor data from the third sensor will be displayed and the channel icon will shift back to "1" once the third sensor is successfully received. If this is not happen, user shall restart the setting up from step 1.
9. In order to ensure sufficient 915 MHz transmission there should be a distance of no more than 330 feet (100 meters) between the final position of the Weather Station and the sensor (see notes on "**Mounting**" and "**915 MHz Reception**").

Note:

After the three sensors have been set up, user may need to check the readings displayed on the Weather Station against those being shown on the sensor displays, in order to recognize which channel each sensor is displayed.

If the signal reception is not successful on the first frequency (915MHz) for 45 seconds, the frequency is changed to 920MHz and the learning is tried for another 45 seconds. If still not successful the reception is tried for 45 seconds on 910MHz. This will also be done for re-synchronization.

IMPORTANT:


Transmission problems will arise if the setting for additional sensors is not followed as described above. Should transmission problems occur, it is necessary to remove the batteries from all units and follow the set-up from step 1.

10. Once the remote temperature has been received and displayed on the Weather Station, the WWVB time code reception is automatically started. This takes typically between 3-5 minutes in good conditions. (Depending on location, it may take up to four nights to first receive the WWVB signal.)
11. If after 10 minutes, the WWVB time has not been received, press the SET key to manually enter a time initially.

Note:

Daily WWVB reception is attempted for a full hour between 12:00 am to 6:00 am. If the reception is not successful, there will no further reception attempt until the following day. When this is successful, the received time will override the manually set time. The date is also updated with the received time. (Please refer also to notes on "**WWVB Radio controlled Time**" and "**Manual Time Setting**").

The Outdoor Thermo-hygro Sensor




- Remote transmission of outdoor temperature and humidity to Weather Station by 915 MHz
- LCD alternates between temperature and humidity readings.
- Water-resistant casing
- Wall mounting case
- Mount in a sheltered location. Avoid direct rain and sunlight

BATTERY INSTALLATION

INSTALL AND REPLACE BATTERIES IN THE WEATHER STATION

The Weather Station uses 2 x AAA, Alkaline batteries. To install and replace the batteries, please follow the steps below:



1. Remove the cover at the back of the Weather Station.
2. Insert batteries observing the correct polarity (see marking).
3. Replace compartment cover.

INSTALL AND REPLACE BATTERIES IN THE THERMO-HYGRO SENSOR

The Thermo-hygro Sensor uses 1 x 3.0V IEC CR2032, Lithium battery. To install and replace the battery, please follow the steps below:



1. Pull out the battery holder at the bottom of the sensor.
2. Insert the battery, observing the correct polarity (see marking).
3. Replace the battery holder on the unit.

Note:

In the event of changing batteries in any of the units, all units need to be reset by following the setting up procedures. This is because a random security code is assigned by the sensor at start-up and this code must be received and stored by the Weather Station in the first 3 minutes of power being supplied to it

BATTERY CHANGE:


It is recommended to replace the batteries in all units on an annual basis to ensure optimum accuracy of these units.



**Please participate in the preservation of the environment.
Return used batteries to an authorized depot.**

FUNCTION KEYS:**Weather Station:**

The Weather Station has four easy to use function keys.

**SET key (Setting):**

- To enter the set mode for the following functions: LCD Contrast, Time Zone, Daylight Saving Time ON/OFF, Time Reception ON/OFF, 12/24 Hour Time Display, Manual Time, Year, Month, Date, °F/°C, and Weather Forecast Sensitivity settings.

- Press to reset the minimum or maximum temperature and humidity records of the indoor or the currently selected outdoor channel (will reset all records to current level)

MIN/ MAX

- To toggle between the minimum/maximum outdoor temperature and minimum/maximum indoor temperature and humidity data

Note: The time/date shown is corresponding to MIN/MAX temperature data.


+ key

- To toggle between the current time and current "Indoor Temp + Humidity" display
- To make adjustment for various settings

CH key

- To toggle between the Outdoor Sensors 1, 2 and 3 (if more than 1 sensor is used)
- To exit from the manual setting mode

LCD SCREEN AND SETTINGS:



*When the outdoor signal is successfully received by the Weather Station, this icon will be switched on. (If not successful, the icon will not be shown in LCD) The user can easily see whether the last reception was successful (icon on) or not (icon off). On the other hand, the short blinking of the icon shows that a reception is currently taking place.

The LCD screen is organized into 3 easy-to-read sections displaying the information for time and indoor data, weather forecast, and outdoor data.

Section 1 - TIME / INDOOR TEMPERATURE AND INDOOR HUMIDITY

- In standard mode, display the radio controlled time.
- Display "Indoor Temperature + Indoor Humidity" when the "+" key is pressed

Section 2 - WEATHER ICON (FEATURED BY OSCAR OUTLOOK)

- The weather forecast is displayed using 15 different icons (featuring Oscar Outlook) which change their appearance depending on the air pressure development (past air pressure change) and the current outdoor temperature.
- Display the weather tendency indicator
- Format of the Oscar Outlook icons refers to the **"WEATHER FORECAST AND TENDENCY"**
- A signal reception symbol will be shown indicating that receiver is receiving outdoor temperature.

Section 3 - OUTDOOR TEMPERATURE AND HUMIDITY

- Display the current outdoor temperature and humidity.
- By pressing the MIN/ MAX key, display the stored MIN/MAX outdoor temperature and humidity, with simultaneous display of MIN/ MAX icon.
- By pressing the CH key, display outdoor sensor data (up to three outdoor sensors). The channel number 1, 2 or 3 will be shown.

WWVB RADIO CONTROLLED TIME

The NIST (National Institute of Standards and Technology—Time and Frequency Division) WWVB radio station is located in Ft. Collins, Colorado, and transmits the exact time signal

continuously throughout the United States at 60 kHz. The signal can be received up to 2,000 miles away through the internal antenna in the Wireless Weather Station. However, due to the nature of the Earth's Ionosphere, reception is very limited during daylight hours. The wireless weather station will search for a signal every night when reception is best.

The WWVB radio station receives the time data from the NIST Atomic clock in Boulder, Colorado. A team of atomic physicists is continually measuring every second, of every day, to an accuracy of ten billionths of a second per day. These physicists have created an international standard, measuring a second as 9,192,631,770 vibrations of a Cesium-133 atom in a vacuum. For more detail, visit <http://www.boulder.nist.gov/timefreq.htm>. To listen to the NIST time, call (303)499-7111. This number will connect you to an automated time, announced at the top of the minute in "Coordinated Universal Time", which is also known as Greenwich Mean Time (GMT). This time does not follow Daylight Saving Time changes. After the top of the minute, a tone will sound for every second. It is possible that your wireless weather station may not be exactly on the second due to the variance in the quartz. However, the clock will adjust the quartz timing over the course of several days to be very accurate; under 0.10 seconds per day.

MANUAL SETTINGS:

The following manual settings can be done in the setting mode:

- LCD contrast setting
- Time zone setting
- Daylight saving time setting
- Time reception ON/OFF setting
- 12/24-Hour setting
- Manual time setting
- Calendar setting
- °F/ °C setting
- Weather forecasting icon sensitivity setting

Press the SET key to advance to the setting mode:

LCD CONTRAST SETTING

lcd 5 — flashing

The LCD contrast can be set to 8 different levels to suit the user's needs (default LCD contrast setting is LCD 4). To set the desired contrast level:

1. The above display will be seen. Press the + key to select the level of contrast desired.
2. Press the SET key to confirm and enter the **"Time Zone setting"** or exit the setting mode by pressing the CH key

TIME ZONE SETTING:

04 — flashing

The time zone default is "EST -5". To set a different time zone:

1. The current time zone value starts flashing.
2. Use the + key to set the time zone. The range runs from -5, -6, -7 ...-12, 12, 11, 10... 0, -1, -2, -3, -4 hr, in consecutive 1-hour intervals.
(The U.S. time zones are: -5hr(EST), -6hr(CST), -7hr(MST) and -8hr(PST), -9hr (ALA) and -10hr (HAW).)
3. Confirm with the SET key and enter the **Daylight Saving Time (DST) setting**.

DAYLIGHT SAVING TIME SETTING ON/ OFF

05:07 — flashing

1. The digit "DST ON" will start flashing on the LCD.
2. Use the + key to turn On or OFF the daylight saving time function.
3. Confirm with the SET key and enter the "**Time reception On/Off setting**" or exit the setting mode by pressing the CH key.

TIME RECEPTION ON/OFF SETTING



In area where reception of the WWVB time is not possible, the time reception function can be turned OFF. The clock will then work as a normal Quartz clock. (Default setting is ON).

4. The digit "ON" and the time reception icon will start flashing on the LCD.
5. Use the + key to turn OFF the time reception function.
6. Confirm with the SET key and enter the "**12/24-Hour Display setting**" or exit the setting mode by pressing the CH key.

Note:

If the Time Reception function is turned OFF manually, the clock will not attempt any reception of the WWVB time as long as the Time Reception OFF function is activated. The Time Reception icon will not be displayed on the LCD.

12/24 HOUR TIME DISPLAY SETTING



1. After setting time reception ON/OFF, press the SET key, “12h” or “24h” flashes in the LCD. (default 12 h)
2. Press the + key to select the “12h” or “24h” display mode.
3. Press the SET again to confirm and to enter the **“Manual Time setting”** or exit the setting mode by pressing the CH key.

Note: When 24h mode display is selected, the calendar format will be date and month display. When 12h mode display is selected, the calendar format will be month and date display.

MANUAL TIME SETTING

In case the Weather Station is not able to detect the WWVB-signal (disturbances, transmitting distance, etc.), the time can be manually set. The clock will then work as a normal Quartz clock.



To set the clock:

1. The hour and minute digits start flashing in the time display section.
2. Use the + key to adjust the hours and then press SET key to go to the minute setting.
3. The minute will be flashing. Press the + key to just the minutes.
4. Confirm with the SET key and enter the **“Calendar Setting”** or exit the setting mode by pressing the CH key

CALENDAR SETTING


DATE
20 06 — Year

DATE
2 . 1
"Date. Month." (for 24h time display)
"Month. Date." (for 12h time display)

The date default of the Weather Station is January 1st, 2006 (01.01.06), after initial set-up. The date is only used for recording of MIN/MAX values and only show during set-up. Once the radio-controlled time signals are received, the date is automatically updated. However, if the signals are not received, the date can also be set manually. To do this:

1. Using the + key, set the year. The range runs from 2003 to 2029 (default is 2006).
2. Press the SET key to enter the month setting mode.
3. The month digit will be flashing. Press the + key to set the month and then press the SET key to go to the date setting.
4. The date digit will be flashing. Press the + key to set the date.
5. Confirm with the SET key and enter the **"°F/°C TEMPERATURE UNIT SETTING"** or exit the setting mode by pressing the CH key.

°F/°C TEMPERATURE UNIT SETTING




The default temperature reading is set to °F (degree Fahrenheit). To select °C (degree Celsius):

1. The “°F/ °C” will be flashing, use the + key to toggle between “°F” and “°C”.
2. Once the desired temperature unit has been chosen, confirm with the SET key and enter the “**Weather Forecast Icon Sensitivity setting**” or exit the setting mode by pressing the CH key.

WEATHER FORECASTING ICON SENSITIVITY SETTING

For locations with rapid changes of weather conditions, the threshold can be set to a different level for faster display of changing weather conditions.













1. Using the + key to set the weather sensitivity level. There are 3 levels of sensitivity: 1, 2 and 3; level 1 is the most sensitive setting, level 3 is the least sensitive setting (default setting is "3").
2. Confirm with the SET key and exit the **Manual settings**.






WEATHER FORECAST AND TENDENCY:

The weather forecast icons (Oscar Outlook):

One of the 15 different weather icons (featuring Oscar Outlook with different clothing suggestions) is displayed in the centre of LCD, which indicates the different forecast weather condition due to air pressure level (Sunny, Sunny + Cloudy or Cloudy + Rainy) and the current outdoor temperature (Temperature value detected by Channel 1):

| | $\geq 78.8^{\circ}\text{F}$ (26°C) | $66.2 - 78.6^{\circ}\text{F}$ ($19 - 25.9^{\circ}\text{C}$) | $50 - 66^{\circ}\text{F}$ ($10 - 18.9^{\circ}\text{C}$) | $32 - 49.8^{\circ}\text{F}$ ($0 - 9.9^{\circ}\text{C}$) | $< 32^{\circ}\text{F}$ (0°C) |
|-------|---|---|---|---|---|
| Sunny |  |  |  |  |  |

| | $\geq 78.8^{\circ}\text{F}$ (26°C) | $66.2 - 78.6^{\circ}\text{F}$ ($19 - 25.9^{\circ}\text{C}$) | $50 - 66^{\circ}\text{F}$ ($10 - 8.9^{\circ}\text{C}$) | $32 - 49.8^{\circ}\text{F}$ ($0 - 9.9^{\circ}\text{C}$) | $< 32^{\circ}\text{F}$ (0°C) |
|----------------|---|---|---|---|---|
| Sunny + Cloudy |  |  |  |  |  |

| | ≥ 78.8°F (26°C) | 66.2 – 8.6°F (19 – 25.9°C) | 50-66°F (10 – 8.9°C) | 32 – 49.8°F (0 – 9.9°C) | < 32°F (0°C) |
|---------------------------|---|---|---|---|---|
| Cloudy + Rainy |  |  |  |  |  |

Note:

After setting up, readings for weather forecasts should be disregarded for the next 48-60 hours. This will allow sufficient time for the Weather Station to collect air pressure data at a constant altitude and therefore result in a more accurate forecast. Common to weather forecasting, absolute accuracy cannot be guaranteed. The weather forecasting feature is estimated to have an accuracy level of about 75% due to the varying areas the Weather Station has been designed for use in. In areas that experience sudden changes in weather (for example from sunny to rain), the Weather Station will be more accurate compared to use in areas where the weather is stagnant most of the time (for example mostly sunny).

If the Weather Station is moved to another location significantly higher or lower than its initial standing point (for example from the ground floor to the upper floor of a house), remove the batteries and re-insert them after about 30 seconds. By doing this, the Weather Station will not mistake the new location as being a possible change in air-pressure when really it is due to the slight change of altitude. Again, disregard weather forecasts for the next 48-60 hours as this will allow time for operation at a constant altitude.

THE WEATHER TENDENCY INDICATOR

Working together with the weather icons are the weather tendency indicators (the upward and downward arrows located near Oscar Outlook). When the indicator points upwards, the air-pressure is increasing and the weather is expected to improve, but when indicator points downwards, the air-pressure is dropping and the weather is expected to become worse.


Therefore, the user may see how the weather has changed and is expected to change. For example, if the indicator is pointing downwards together with cloudy icons, the last noticeable change in the weather was when it was sunny (the sunny icon only). Therefore, the next change in the weather will be the cloudy icons since the indicator is pointing downwards.

Note:


Once the weather tendency indicator has registered a change in air pressure, it will remain permanently visualized on the LCD.

DISPLAY OF INDOOR TEMPERATURE AND HUMIDITY READING:

The indoor temperature and humidity are measured and displayed on the first section of the LCD when the + key is pressed.




DISPLAY OF OUTDOOR TEMPERATURE AND HUMIDITY READING:



The last LCD section shows the outdoor temperature and a channel number under the temperature will also show if more than one sensor has been used.

DISPLAY OF INDOOR MINIMUM AND MAXIMUM RECORDS:

1. In normal display mode, press the MIN/ MAX button five times. The maximum indoor temperature and humidity will be shown in the bottom section of LCD. Also the time of recording this temperature will be displayed.



2. Press the MIN/ MAX button once more to display the date of recording of this temperature reading.
3. Then press the MIN/MAX button one more time, the minimum indoor temperature and humidity will be shown in the bottom section of LCD. Also the time of recording this temperature will be displayed
4. By pressing the MIN/MAX button one more time, the date of recording this temperature will be shown.
5. Press one more time the MIN/ MAX button to go back to the normal display.

RESETTING THE INDOOR MINIMUM /MAXIMUM RECORDS


1. In normal display mode, press the MIN/ MAX button to advance to the indoor MIN/ MAX display.
2. Press the SET key once, this will reset the currently shown indoor minimum or and maximum data recorded to the current time, date, temperature and humidity.

Note:

The indoor minimum and maximum record is to be reset separately.

DISPLAY OF OUTDOOR MINIMUM/ MAXIMUM AND RECORDS:

1. In normal display mode, press the CH button to select the desired channel. The channel ID will be displayed above the outdoor temperature reading.
2. Press the MIN/MAX button once, the max temperature of the selected channel will be displayed. Also the time of recording this temperature will be displayed.
3. Press the MIN/MAX button once more, the date of recording this reading will be shown.
4. By pressing MIN/MAX button once more, the min temperature of the selected channel will be shown. Also the time of recording this temperature will be displayed.



6. By pressing the MIN/MAX button one more time, the date of recording this temperature will be shown.
7. Press one more time the MIN/ MAX button to advance to the indoor MIN/ MAX display

RESETTING THE OUTDOOR MINIMUM /MAXIMUM RECORDS

Note:

- It is required to reset the min/ max records of different channels separately.
 - The outdoor minimum and maximum record of each channel is to be reset separately.
1. In normal display mode, press the CH button to select a channel. The channel Identification No. (channel No.) will be displayed above the outdoor temperature reading.

Note: The sensor number will only be displayed if more than one sensor is applied.

2. Press the MIN/ MAX button once. The "max" icon will be displayed.
3. Press the SET button; this will reset the outdoor maximum temperature and humidity record to the current value.
4. Press MIN/ MAX button twice more to show the minimum data. The "min" icon will be displayed.
5. Press the SET button; this will reset the outdoor minimum temperature and humidity record to the current value.
6. Press the MIN/MAX key six more times to return to the normal display.

915 MHz RECEPTION

The Weather Station should receive the temperature data within 15 minutes after set-up. If the temperature data is not received 15 minutes after setting up (not successfully continuously, the outdoor display shows "- - -"), please check the following points:

1. The distance of the weather station or sensor should be at least 1.5 to 2 meters away from any interfering sources such as computer monitors or TV sets.
2. Avoid positioning the Weather Station onto or in the immediate proximity of metal window frames.
3. Using other electrical products such as headphones or speakers operating on the same signal frequency (915MHz) may prevent correct signal transmission and reception.
4. Neighbors using electrical devices operating on the 915MHz signal frequency can also cause interference.

Note:

When the 915MHz signal is received correctly, do not re-open the battery cover of either the sensor or Weather Station, as the batteries may spring free from the contacts and force a false reset. Should this happen accidentally then reset all units (see **Setting up** above) otherwise transmission problems may occur.


The transmission range is about 330 feet (100 m) from the sensor to the Weather Station (in open space). However, this depends on the surrounding environment and interference levels. If no reception is possible despite the observation of these factors, all system units have to be reset (see **Setting up**).

MOUNTING

POSITIONING THE WEATHER STATION:

The Weather Station has been designed to be hung onto a wall or free standing.

To wall mount



Choose a sheltered place. Avoid direct rain and sunshine.
Before wall mounting, please check that the outdoor temperature and humidity values can be received from the desired locations.

1. Fix a screw (not supplied) into the desired wall, leaving the head extended out the by about 5mm.
2. Remove the stand from the Weather Station by pulling it away from the base and hang the station onto the screw. Remember to ensure that it locks into place before releasing.


Free standing

With the
placed onto any



detachable stand, the Weather Station can be
flat surface.

POSITIONING




THE THERMO-HYGRO SENSOR:

The sensor is supplied with a holder that may be attached to a wall with the two screws supplied.

The sensor can also be position on a flat surface by securing the stand to the bottom of the sensor.

To wall mount:



1. Secure the bracket onto a desired wall using the screws and plastic anchors.
2. Clip the remote thermo-hygro sensor onto the bracket.

Note:

Before permanently fixing the sensor wall base, place all units in the desired locations to check that the outdoor temperature reading is receivable. In event that the signal is not received, relocate the sensors or move them slightly as this may help the signal reception.

CARE AND MAINTENANCE:

- Extreme temperatures, vibration and shock should be avoided as these may cause damage to the unit and give inaccurate forecasts and readings.
- When cleaning the display and casings, use a soft damp cloth only. Do not use solvents or scouring agents as they may mark the LCD and casings.
- Do not submerge the unit in water.
- Immediately remove all low powered batteries to avoid leakage and damage. Replace only with new batteries of the recommended type.
- Do not make any repair attempts to the unit. Return them to their original point of purchase for repair by a qualified engineer. Opening and tampering with the unit may invalidate their guarantee.
- Do not expose the units to extreme and sudden temperature changes, this may lead to rapid changes in forecasts and readings and thereby reduce their accuracy.

SPECIFICATIONS:

Temperature measuring range:

- Indoor : 14.1°F to +139.8°F with 0.2°F resolution
(-9.9°C to +59.9°C with 0.1°C resolution,
"OF.L" displayed if outside this range)
- Outdoor : -39.8°F to +139.8°F with 0.2°F resolution
(-39.9°C to +59.9°C with 0.1°C resolution,
"OF.L" displayed if outside this range)

Relative humidity measuring range:

1% to 99% with 1% resolution (displays "-" when lower than 1 %; displays "99" % if higher than 99 %)

- Indoor temperature checking interval : every 15 seconds
- Indoor humidity checking interval : every 20 seconds
- Outdoor data reception : every 16 seconds

Power supply:

- Weather Station : 2 x AAA, IEC, LR3, 1.5V
- Thermo-hygro Sensor : 1 x CR2032, 3.0V
- Battery life cycle : Approximately 12 months (Alkaline batteries recommended)

Dimensions (L x W x H)

- Weather Station : 2.29" x 0.69" x 5.19"
- Thermo-hygro Sensor : 1.44" x 0.53" x 3.46"

WARRANTY INFORMATION

La Crosse Technology, Ltd provides a 1-year limited warranty on this product against manufacturing defects in materials and workmanship.

This limited warranty begins on the original date of purchase, is valid only on products purchased and used in North America and only to the original purchaser of this product. To receive warranty service, the purchaser must contact La Crosse Technology, Ltd for problem determination and service procedures. Warranty service can only be performed by a La Crosse Technology, Ltd authorized service center. The original dated bill of sale must be presented upon request as proof of purchase to La Crosse Technology, Ltd or La Crosse Technology, Ltd's authorized service center.

La Crosse Technology, Ltd will repair or replace this product, at our option and at no charge as stipulated herein, with new or reconditioned parts or products if found to be defective during the limited warranty period specified above. All replaced parts and products become the property of La Crosse Technology, Ltd and must be returned to La Crosse Technology, Ltd. Replacement parts and products assume the remaining original warranty, or ninety (90) days, whichever is longer. La Crosse Technology, Ltd will pay all expenses for labor and materials for all repairs covered by this warranty. If necessary repairs are not covered by this warranty, or if a product is examined which is not in need of repair, you will be charged for the repairs or examination. The owner must pay any shipping charges incurred in getting your La Crosse Technology, Ltd product to a La Crosse Technology, Ltd authorized service center. La Crosse Technology, Ltd will pay ground return shipping charges to the owner of the product to a USA address only.

Your La Crosse Technology, Ltd warranty covers all defects in material and workmanship with the following specified exceptions: (1) damage caused by accident, unreasonable use or neglect (including the lack of reasonable and necessary maintenance); (2) damage occurring during shipment (claims must be presented to the carrier); (3) damage to, or deterioration of, any accessory or decorative surface; (4) damage resulting from failure to follow instructions contained in your owner's manual; (5) damage resulting from the performance of repairs or alterations by someone other than an authorized La Crosse Technology, Ltd authorized service center; (6) units used for other than home use (7) applications and uses that this product was not intended or (8) the products inability to receive a signal due to any source of interference.. This warranty covers only actual defects within the product itself, and does not cover the cost of installation or removal from a fixed installation, normal set-up or adjustments,

claims based on misrepresentation by the seller or performance variations resulting from installation-related circumstances.

LA CROSSE TECHNOLOGY, LTD WILL NOT ASSUME LIABILITY FOR INCIDENTAL, CONSEQUENTIAL, PUNITIVE, OR OTHER SIMILAR DAMAGES ASSOCIATED WITH THE OPERATION OR MALFUNCTION OF THIS PRODUCT. THIS PRODUCT IS NOT TO BE USED FOR MEDICAL PURPOSES OR FOR PUBLIC INFORMATION. THIS PRODUCT IS NOT A TOY. KEEP OUT OF CHILDREN'S REACH.

This warranty gives you specific legal rights. You may also have other rights specific to your State. Some States do not allow the exclusion of consequential or incidental damages therefore the above exclusion of limitation may not apply to you.

For warranty work, technical support, or information contact:

La Crosse Technology, Ltd
2809 Losey Blvd. S.
La Crosse, WI 54601
Phone: 608.782.1610
Fax: 608.796.1020

e-mail:
support@lacrossetechnology.com
(warranty work)

sales@lacrossetechnology.com
(information on other products)

web:
www.lacrossetechnology.com

Question? Instructions? Please visit:
www.lacrossetechnology.com/9620it

All rights reserved. This handbook must not be reproduced in any form, even in excerpts, or duplicated or processed using electronic, mechanical or chemical procedures without written permission of the publisher.

This handbook may contain mistakes and printing errors. The information in this handbook is regularly checked and corrections made in the next issue. We accept no liability for technical mistakes or printing errors, or their consequences.

All trademarks and patents are acknowledged.

EJIN9620