


# COSORI®

## User Manual

Pro LE 4.7-Litre Air Fryer

Pro LE Series

Model: CAF-L501 Series



EN

DE

ES

FR

IT

NL

PL

SV

Questions or Concerns?

[support.eu@cosori.com](mailto:support.eu@cosori.com)

EN

## ENGLISH

## Table of Contents

Package Contents	2
Specifications	2
Important Safeguards	6
Getting to Know Your Air Fryer	8
Air Fryer Diagram	8
Display Messages	9
Before First Use	10
Using Your Air Fryer	11
Care & Maintenance	15
Troubleshooting	16
Warranty Information	17
Customer Support	17

## Package Contents

- 1 x Pro LE 4.7-Litre Air Fryer
- 1 x Recipe Book
- 1 x User Manual

## Specifications

<b>Power Supply</b>	AC 220-240V, 50/60Hz
<b>Rated Power</b>	1500W
<b>Capacity</b>	4.7 L / 5.0 qt (serves 3–5 people)
<b>Temperature Range</b>	75°–230°C
<b>Time Range</b>	1–60 min
<b>Dimensions</b>	27.2 x 27.5 x 30.3 cm / 10.7 x 10.8 x 11.9 in
<b>Weight</b>	4.54 kg / 10 lb
<b>Standby power</b>	<0.5W

DE

## DEUTSCH

## Inhaltsverzeichnis

Lieferumfang	2
Technische Daten	2
Wichtige Sicherheitshinweise	18
Ihre Heißluftfritteuse	20
Diagramm der Heißluftfritteuse	20
Display-Meldungen	21
Vor dem ersten Gebrauch	22
Der Gebrauch Ihrer Heißluftfritteuse	23
Pflege und Wartung	27
Problemlösung	28
Garantie	29
Kundendienst	29

## Lieferumfang

- 1 x 4,7 Liter Pro LE Heißluftfritteuse
- 1 x Rezeptbuch
- 1 x Bedienungsanleitung

## Technische Daten

<b>Stromversorgung</b>	AC 220–240 V, 50/60 Hz
<b>Nennleistung</b>	1500 W
<b>Fassungsvermögen</b>	4,7 l / 5,0 qt (für 3–5 Personen)
<b>Temperaturbereich</b>	75–230 °C
<b>Zeitspanne</b>	1–60 Minuten
<b>Abmessungen</b>	27,2 x 27,5 x 30,3 cm / 10,7 x 10,8 x 11,9 Zoll
<b>Gewicht</b>	4,54 kg / 10 lb
<b>Standby-Stromverbrauch</b>	<0,5 W

ES

## ESPAÑOL

### Índice

Contenido de la caja	3
Especificaciones	3
Precauciones importantes	30
Componentes de la freidora por aire	32
Diagrama de la freidora por aire	32
Mensajes en pantalla	33
Antes del primer uso	34
Uso de la freidora por aire	35
Cuidado y mantenimiento	39
Solución de problemas	40
Información sobre la garantía	41
Atención al Cliente	41

### Contenido de la caja

- 1 freidora por aire Pro LE de 4,7 litros
- 1 libro de recetas
- 1 manual del usuario

### Especificaciones

<b>Fuente de alimentación</b>	CA 220-240 V, 50/60 Hz
<b>Potencia nominal</b>	1500 W
<b>Capacidad</b>	4,7 L (5,0 qt) (3-5 raciones)
<b>Rango de temperaturas</b>	75°-230 °C
<b>Rango de tiempo</b>	1-60 min.
<b>Dimensiones</b>	27,2 x 27,5 x 30,3 cm (10,7 x 10,8 x 11,9 in)
<b>Peso</b>	4,54 kg (10 lb)
<b>Consumo en modo de espera</b>	<0,5 W

FR

## FRANÇAIS

### Table des matières

Contenu de l'emballage	3
Caractéristiques techniques	3
Consignes de sécurité importantes	42
Prise en main de la friteuse sans huile	44
Schéma de la friteuse sans huile	44
Messages à l'écran	45
Avant la première utilisation	46
Utilisation de votre friteuse sans huile	47
Entretien et maintenance	51
Dépannage	52
Informations relatives à la garantie	53
Service client	53

### Contenu de l'emballage

- 1 Friteuse sans huile Pro LE 4,7 litres
- 1 Livre de recettes
- 1 Notice d'utilisation

### Caractéristiques techniques

<b>Alimentation électrique</b>	220 à 240 V c.a., 50 à 60 Hz
<b>Puissance nominale</b>	1 500 W
<b>Capacité</b>	4,7 L/5,0 qt (pour 3 à 5 personnes)
<b>Plage de températures</b>	75°-230°C
<b>Plage de durée de cuisson</b>	1 à 60 minutes
<b>Dimensions</b>	27,2 x 27,5 x 30,3 cm/1 0,7 x 10,8 x 11,9 po
<b>Poids</b>	4,54 kg/10 lb
<b>Consommation en veille</b>	<0,5 W

IT

## ITALIANO

## Indice

Contenuto della confezione	4
Specifiche	4
Importanti misure di sicurezza	54
Descrizione della friggitrice ad aria	56
Diagramma della friggitrice ad aria	56
Messaggi sul display	57
Prima dell'utilizzo iniziale	58
Uso della friggitrice ad aria	59
Cura e manutenzione	63
Risoluzione dei problemi	64
Informazioni sulla garanzia	65
Assistenza Clienti	65

## Contenuto della confezione

- 1 friggitrice ad aria Pro LE da 4,7 litri
- 1 libro di ricette
- 1 manuale di istruzioni

## Specifiche

<b>Alimentazione elettrica</b>	c.a. 220–240 V, 50/60 Hz
<b>Potenza nominale</b>	1500 W
<b>Capacità</b>	4,7 l (5,0 quarti) (porzioni per 3–5 persone)
<b>Gamma di temperature</b>	75°–230°C
<b>Intervallo di temporizzazione</b>	1–60 min.
<b>Dimensioni</b>	27,2 x 27,5 x 30,3 cm (10,7 x 10,8 x 11,9 pollici)
<b>Peso</b>	4,54 kg (10 libbre)
<b>Energia di riserva</b>	<0,5 W

NL

## NEDERLANDS

## Inhoud

Inhoud verpakking	4
Specificaties	4
Belangrijke veiligheidsopmerkingen	66
Bekend raken met uw airfryer	68
airfryer-diagram	68
Displayberichten	69
Voor het eerste gebruik	70
Gebruiken van uw airfryer	71
Verzorging & onderhoud	75
Probleemoplossing	76
Garantie-informatie	77
Klantenservice	77

## Inhoud verpakking

- 1 x Pro LE 4,7-liter airfryer
- 1 x Receptenboek
- 1 x Gebruikershandleiding

## Specificaties

<b>Voeding</b>	AC 220–240V, 50/60Hz
<b>Nominaal vermogen</b>	1500W
<b>Capaciteit</b>	4,7 L / 5.0 qt (voor 3–5 personen)
<b>Temperatuurbereik</b>	75°–230°C
<b>Tijdbereik</b>	1–60 min
<b>Afmetingen</b>	27,2 x 27,5 x 30,3 cm / 10,7 x 10,8 x 11,9 in
<b>Gewicht</b>	4,54 kg / 10 lb
<b>Stand-byvermogen</b>	<0,5W

PL

## POLSKIE

## Spis treści

Zawartość opakowania	5
Dane techniczne	5
Istotne środki bezpieczeństwa	78
Prezentacja frytkownicy beztłuszczowej	80
Schemat frytkownicy beztłuszczowej	80
Wyświetlanie komunikatów	81
Przed pierwszym użyciem	82
Korzystanie z frytkownicy beztłuszczowej	83
Czyszczenie i konserwacja	87
Rozwiązywanie problemów	88
Informacje o gwarancji	89
Dział obsługi klienta	89

## Zawartość opakowania

- 1 x frytkownica beztłuszczowa Pro LE 4,7 litra
- 1 x książka z przepisami
- 1 x podręcznik użytkownika

## Dane techniczne

<b>Zasilanie</b>	AC 220-240 V, 50/60 Hz
<b>Moc znamionowa</b>	1500 W
<b>Pojemność</b>	4,7 l / 5,0 kwart (dla 3-5 osób)
<b>Zakres temperatury</b>	75°C – 230°C
<b>Zakres czasu</b>	1-60 min
<b>Wymiary</b>	27,2 x 27,5 x 30,3 cm / 10,7 x 10,8 x 11,9 cala
<b>Waga</b>	4,54 kg / 10 funtów
<b>Zasilanie w stanie gotowości</b>	<0,5 W

SV

## SVENSKA

## Innehållsförteckning

Förpackningens innehåll	5
Specifikationer	5
Viktiga säkerhetsinstruktioner	90
Lär känna din Air Fryer	92
Air Fryer-diagram	92
Visa meddelanden	93
Innan första användningstillfället	94
Använda din Air Fryer	95
Skötsel och underhåll	99
Felsökning	100
Garantiinformation	101
Kundsupport	101

## Förpackningens innehåll

- 1 x Pro LE 4.7-Litre Air Fryer
- 1 x Receptbok
- 1 x Bruksanvisning

## Specifikationer

<b>Elförsörjning</b>	AC 220-240V, 50/60Hz
<b>Nominell ström</b>	1500W
<b>Kapacitet</b>	4,7 L / 5,0 qt (3-5 portioner)
<b>Temperaturområde</b>	75°-230°C
<b>Tidsområde</b>	1-60 min
<b>Mått</b>	27,2 x 27,5 x 30,3 cm /10,7 x 10,8 x 11,9 in
<b>Vikt</b>	4,54 kg/10 lb
<b>Standby-effekt</b>	<0,5W

# READ AND SAVE THESE INSTRUCTIONS

## IMPORTANT SAFEGUARDS

---

**Follow basic safety precautions when using your air fryer.**  
**Read all instructions.**

### Key Safety Points

- **Do not** touch hot surfaces. Use handle.
- Use caution when turning the basket over after cooking, as the hot crisper plate may fall out and create a safety hazard.
- **Do not** block any ventilation openings. Hot steam is released through openings. Keep your hands and face clear of openings.

### General Safety

- **Do not** immerse the air fryer housing, cord, or plug in water or liquid.
- Closely supervise children near your air fryer.
- Unplug when not in use, and before cleaning. Allow to cool before putting on or taking off parts.
- **Do not** use your air fryer if it is damaged, not working, or if the cord or plug is damaged. Contact **Customer Support** (see page 17).
- **Do not** use third-party replacement parts or accessories, as this may cause injuries.
- **Do not** use outdoors.
- **Do not** place the air fryer or any of its parts on a stove, near gas or electric burners, or in a heated oven.

- Be extremely cautious when moving your air fryer (or removing the basket) if it contains hot oil or other hot liquids.
- **Do not** clean with metal scouring pads. Metal fragments can break off the pad and touch electrical parts, creating a risk of electric shock.
- **Do not** place anything on top of your air fryer. **Do not** store anything inside your air fryer.
- **Do not** strike or hit the top of the air fryer with hard objects, as this may cause the tempered glass to crack. Tempered glass is stronger and fractures more safely than ordinary glass, but it may shatter unexpectedly after being cracked. If you see a crack, contact **Customer Support** (see page 17).
- This air fryer can be used by children 8 years and older as well as persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the air purifier in a safe way and understand the hazards involved.
- Children should not play with the air fryer.
- Cleaning and user maintenance should not be made by children without supervision.
- This air fryer is not intended to be operated by means of an external timer or separate remote-control system.

- **Only** use your air fryer as directed in this manual.
- Not for commercial use. Household use **only**.

## While Air Frying

- An air fryer works with hot air **only**. **Never** fill the baskets with oil or fat.
- **Never** use your air fryer without the basket in place.
- **Do not** place oversized foods or metal utensils into your air fryer.
- **Do not** overfill the air fryer basket. Heaping amounts of food may touch the heating coils and cause a fire hazard.
- **Do not** touch accessories during or immediately after air frying.
- **Do not** place paper, cardboard, non-heat-resistant plastic, or similar materials, into your air fryer. You may use parchment paper or foil.
- **Never** put baking or parchment paper into the air fryer without food on top. Air circulation can cause paper to lift and touch heating coils.
- **Always** use heat-safe containers. Be extremely cautious if using containers that aren't metal or glass.
- Keep your air fryer away from flammable materials (curtains, tablecloths, etc). Use on a flat, stable, heat-resistant surface away from heat sources or liquids.
- Immediately turn off and unplug your air fryer if you see dark smoke coming out. White smoke is normal, caused by heating fat or food splashing, but dark smoke means that food is burning or there is a circuit problem. Wait for smoke to clear before pulling the basket out. If the cause was not burnt food, contact **Customer Support** (page 17).

- **Do not** leave your air fryer unattended while in use.

## Plug & Cord

- **Do not** let the power cord (or any extension cord) hang over the edge of a table or counter, or touch hot surfaces.
- Remove and discard the protective cover fitted over the power plug of the air fryer to prevent choking hazards.
- **Never** use an outlet below the counter when plugging in your air fryer.
- Keep the air fryer and its cord out of reach of children less than 8 years old.

## Electromagnetic Fields (EMF)

The Cosori Air Fryer complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.

For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.


## GETTING TO KNOW YOUR AIR FRYER

Your Cosori Air Fryer uses rapid 360° air circulation technology to cook with little to no oil for quick, crispy, delicious food with up to 85% fewer calories than deep fryers. With user-friendly, one-touch controls, a nonstick basket, and an intuitive, safe design, the Cosori Air Fryer is the star of your kitchen.

**Note:**

- **Do not** try to open the top of the air fryer. This is not a lid.
- The basket and crisper plate are made of aluminium metal with nonstick coating. They are PFOA -free and BPA free.

### Air Fryer Diagram




- |                   |                          |                      |
|-------------------|--------------------------|----------------------|
| A. Air Inlet      | E. Basket Handle         | I. Air Outlet Spacer |
| B. Control Screen | F. Basket Release Button | J. Power Cord        |
| C. Crisper Plate  | G. Housing Handles       |                      |
| D. Basket         | H. Air Outlet            |                      |




Display Diagram

**Note:** When you press a button to use a function or program, it will turn white to show that it's active.




**Note:** This turns the Shake Reminder on/off.

Control Panel




Display Messages




Reminder to shake or flip food




Air fryer is preheated and ready to start cooking



Air fryer is cooking



Cooking is paused



Cooking program has ended

## BEFORE FIRST USE

### Setting Up

1. Remove all packaging from the air fryer, including any temporary stickers.
2. Place the air fryer on a stable, level, heat-resistant surface. Keep away from areas that can be damaged by steam (such as walls or cupboards).

**Note:** Leave 13 cm / 5 inches of space behind and above the air fryer. [Figure 1.1] Leave enough room in front of the air fryer to remove the basket.

3. Hold down the basket release button, and pull the handle to remove the basket. Remove all plastic from the basket.
4. Wash both the basket and crisper plate thoroughly, using either a dishwasher or a non-abrasive sponge.
5. Wipe the inside and outside of the air fryer with a slightly moist cloth. Dry with a towel.
6. Insert the crisper plate back into the basket, and place the basket inside the air fryer.




Figure 1.1

### Test Run

A test run will help you become familiar with your air fryer, make sure it's working correctly, and clean it of possible residues in the process.

1. Make sure the air fryer basket is empty and plug in the air fryer.
2. Press **PREHEAT**. The display will show "205°C" and "4 MIN".
3. Press ►|| to begin preheating. When preheating is done, the air fryer will beep.
4. Pull out the basket and let it cool for 4 minutes. Then place the basket back into the air fryer.
5. Press **STEAK** to select the **Steak** function. The display will show "230°C" and "6 MIN".
6. Press **TIME** once. The time will change to 5 minutes.
7. Press ►|| to begin. When finished, the air fryer will beep.
8. Remove the basket. This time, let the basket cool completely for 10–30 minutes.

**Note:**

- Use caution when turning the basket over after cooking, as the hot crisper plate may fall out and create a safety hazard.
- **Do not** unscrew the basket handle from the basket.

## Rubber Stoppers

- The crisper plate contains 4 rubber stoppers made of safe, FDA-approved material. These stoppers keep the crisper plate fitted to the bottom of the basket, prevent the crisper plate from directly touching the basket, and in rare cases, damaging the nonstick coating on the basket.
- Only** remove the rubber stoppers for cleaning purposes. For easy removal, start from the bottom of the crisper plate and pull out one side of the stopper at a time. [Figure 1.2]
- To place the rubber stoppers back onto the crisper plate, first soak them in water. Then, push each stopper back in through the bottom of the crisper plate. Push in one side of the stopper at a time.






Figure 1.2

# USING YOUR AIR FRYER

## Preheating

We recommend preheating before placing food inside the air fryer, unless your air fryer is already hot. Food will not cook thoroughly without preheating.

1. Plug in. Press  to turn on the air fryer display.
2. Press **PREHEAT**. The display will show "205°C" and "4 MIN".
3. Optionally, press the + or – buttons to change the temperature. The time will adjust automatically.
4. Press  to begin preheating.
5. When preheating is done, the air fryer will beep 3 times. The display will show the set preheat temperature. [Figure 2.1]

**Note:** If no buttons are pressed for 3 minutes, the air fryer will clear all settings and go into standby.

Temperature	Time
205°–230°C	4 minutes
145°–200°C	3 minutes
75°–140°C	2 minutes



Figure 2.1

## Air Frying

### Note:

- **Do not** place anything on top of your air fryer. This may interfere with your cooking program or cause cracks in the glass on the display. [Figure 2.1]
- An air fryer is not a deep fryer. **Do not** fill the basket with oil, frying fat, or any liquid.
- When taking the basket out of the air fryer, be careful of hot steam.




Figure 2.1

## Cooking Functions

Using a cooking function is the easiest way to air fry. Cooking functions are programmed with an ideal time and temperature for cooking certain foods.

1. Press the function's button to select the function. The air fryer will automatically change to the function's default settings.
2. You can change a function's time (1–60 minutes), temperature (75°–230°C), and Shake Reminder.
3. Press and hold the + or – button to rapidly increase or decrease the time or temperature.
4. Add or remove a Shake Reminder by pressing **SHAKE**.
5. To go back to a function's default settings, press the function's button again.

**Note:** Results may vary. Check out our Recipe Book for a guide to using cooking functions for perfect results.

Function	Default Temperature	Default Time (minutes)	Shake Reminder?*
Chicken	190°C	20 minutes	-
French Fries**	195°C	25 minutes	((SHAKE))
Frozen Foods	175°C	10 minutes	-
Steak	230°C	6 minutes	-
Seafood	175°C	8 minutes	((SHAKE))
Veggies	170°C	10 minutes	((SHAKE))
Bacon	160°C	8 minutes	-
Preheat	205°C	4 minutes	-
Keep Warm	75°C	5 minutes	-

\* See **Shaking Food** (page 13).

\*\* See **Cooking Guide** (page 14) for more tips on air frying French fries.

## Air Frying

1. **Preheat your air fryer** (see page 11).
2. When your air fryer displays **READY**, add food to the basket.
  - For the best results, add the crisper plate into the basket to allow excess oil to drip down to the bottom of the basket.
3. Select a cooking function (see page 12).

**Note:** Cooking functions are programmed with an ideal time and temperature for cooking certain foods. You can also set a custom time and temperature without choosing a cooking function.

4. Optionally, change the temperature and time, and add a Shake Reminder. You can do this anytime during cooking.
  - a. Press the + or – buttons to change the temperature (75°–230°C) or time (1–60 minutes).


**Note:**

- To rapidly increase or decrease time or temperature, press and hold the + or – buttons.
- Press **SHAKE** to add or remove a Shake Reminder during cooking.

5. Press **▶||** to begin air frying.
6. When the Shake Reminder is turned on, it will appear halfway through cooking time. The air fryer will beep 5 times, and **(Shake)** will blink on the display.
  - a. Press the basket release button to take the basket out of the air fryer, being careful of hot steam. The air fryer will pause cooking automatically, and the display will turn off until the basket is replaced.
  - b. Shake or flip the food.
  - c. Put the basket back into the air fryer.

**Note:** See **Shaking Food** (page 13)

7. The air fryer will beep 3 times when finished. The display will show:



8. Optionally, press **Keep Warm**. Press the + or – buttons to change the time (1–60 minutes).
9. Press the basket release button to take the basket out of the air fryer, being careful of hot steam.
10. Allow to cool before cleaning.

## Shaking Food

### How to Shake

- During cooking, press and hold the basket release button to take the basket out of the air fryer, and shake, mix, or flip the food.

**A.** To shake food:

1. Hold the basket just above a heat-resistant surface for safety purposes.
2. Shake the basket.

**Note:** Do not use this method if there is a risk of hot liquids splashing.

**B.** If the basket is too heavy to shake and there are hot liquids present:

1. Place the basket on a heat-resistant holder or surface.
2. Use tongs to mix or flip the food.

- When you take the basket out, the air fryer will pause cooking automatically. As a safety feature, the display will turn off until the basket is replaced.
- When you replace the basket, cooking will automatically resume.
- Avoid shaking longer than 30 seconds, as the air fryer may start to cool down.

## What to Shake

- Small foods that are stacked will usually need shaking, such as fries or nuggets.
- Without shaking, foods may not be crispy or evenly cooked.
- You can flip other foods, such as steak, to ensure even browning.

## When to Shake

- Shake or flip food once halfway through cooking, or more if desired.
- The Shake Reminder is designed to remind you to check on your food. Tap **SHAKE** to turn on the Shake Reminder. Certain cooking functions use the Shake Reminder automatically (see **Cooking Functions**, page 12).

## Shake Reminder

- The Shake Reminder will alert you with 5 beeps, and **(Shake)** will blink on the display.
- If you do not remove the basket, the Shake Reminder will beep again after 1 minute and the display will show a solid **(Shake)**.
- The Shake Reminder will go away once you take out the basket.

## Cooking Guide

### Overfilling

- If the basket is overfilled, food will cook unevenly.

### Using Oil

- Adding a small amount of oil to your food will make it crispier. Use no more than 30 mL / 2 US tbsp of oil.
- Oil sprays are excellent for applying small amounts of oil evenly to all food items.

## Food Tips

- You can air fry any frozen foods or goods that can be baked in an oven.
- To make cakes, hand pies, or any food with filling or batter, place food in a heat-safe container before placing in the basket.
- Air frying high-fat foods will cause fat to drip to the bottom of the baskets. To avoid excess smoke while cooking, pour out fat drippings after cooking.
- Liquid-marinated foods create splatter and excess smoke. Pat these foods dry before air frying.

## French Fries

- Add 8–15 mL / ½–1 US tbsp oil for crispiness.
- When making fries from raw potatoes, soak uncooked fries in water for 15 minutes to remove starch prior to frying. Pat dry with a towel before adding oil.
- Cut uncooked fries smaller for crispier results. Try cutting fries into 0.6- by 7.6-cm / ¼- by 3-inch strips.

**Note:** For more from the Cosori Kitchen, check out our *Recipe Book* and *Tips from the Chef*.

## More Functions

### Pausing

1. Press ►|| to pause cooking. The air fryer will stop heating, and ►|| will turn blue until you press ►|| to resume cooking.
2. After 30 minutes of inactivity, the air fryer will turn off.
3. This function allows you to pause the cooking program without removing the basket from the air fryer.

### Automatically Resume Cooking

- If you pull out the basket, the air fryer will pause cooking automatically. The display will turn off temporarily as a safety feature.
- When you return the basket, the air fryer will automatically resume cooking based on your previous settings.

### Automatically Shutoff

- If the air fryer has no active cooking programs, the air fryer will clear all settings and turn off after 3 minutes of inactivity.

### Overheat Protection

- If the air fryer overheats, it will automatically shut down as a safety feature.
- Let the air fryer cool down completely before using it again.

## CARE & MAINTENANCE

#### Note:

- **Always** clean the air fryer basket and crisper plate after every use.
  - Lining the basket with foil (except the crisper plate) may make cleanup easier.
1. Turn off and unplug the air fryer. Allow it to cool completely before cleaning. Pull out the basket for faster cooling.
  2. Wipe the outside of the air fryer with a moist cloth, if necessary.
  3. The basket and crisper plate are dishwasher safe. You can also wash the basket and crisper plate with hot, soapy water and a non-abrasive sponge. Soak if necessary.

**Note:** The basket and crisper plate have a nonstick coating. Avoid using metal utensils and abrasive cleaning materials.

4. For stubborn grease:
  - a. In a small bowl, mix 30 mL / 2 US tbsp of baking soda and 15 mL / 1 US tbsp of water to form a spreadable paste.

- b. Use a sponge to spread the paste on the basket and crisper plate and scrub. Let the basket and crisper plate sit for 15 minutes before rinsing.
  - c. Wash basket with soap and water before using.
5. Clean the inside of the air fryer with a slightly moist, non-abrasive sponge or cloth. **Do not** immerse in water. [Figure 3.1] If needed, clean the heating coil to remove food debris.
  6. Dry before using.

**Note:** Make sure the heating coil is completely dry before turning on the air fryer.



Figure 3.1

## TROUBLESHOOTING

Problem	Possible Solution
The air fryer will not turn on.	Make sure the air fryer is plugged in.
	Push the basket securely into the air fryer.
Foods are not completely cooked.	Place smaller batches of ingredients into the inner basket. If the basket is overstuffed, then ingredients will be undercooked.
	Increase cooking temperature or time.
Foods are cooked unevenly.	Foods that are stacked on top of each other or close to each other need to be shaken or flipped during cooking (see <b>Shaking Food</b> , page 13).
Foods are not crispy after air frying.	Spraying or brushing a small amount of oil on foods can increase crispiness (see <b>Cooking Guide</b> , page 14).
French fries are not fried correctly.	See <b>French Fries</b> , page 14.
Basket will not slide into the air fryer securely.	Make sure the basket is not overfilled with food.
White smoke or steam is coming out of the air fryer.	The air fryer may produce some white smoke or steam when you use it for the first time or during cooking. This is normal.
	Make sure the basket and the inside of the air fryer are cleaned properly and not greasy.
	Cooking greasy foods will cause oil to collect beneath the crisper plate. This oil will produce white smoke, and the basket may be hotter than usual. This is normal, and should not affect cooking. Handle the basket with care.
Dark smoke is coming out of the air fryer.	Immediately unplug your air fryer. Dark smoke means that food is burning or there is a circuit problem. Wait for smoke to clear before pulling the basket out. If the cause was not burnt food, contact <b>Customer Support</b> (page 17).
The air fryer has a plastic smell.	Any air fryer may have a plastic smell from the manufacturing process. This is normal. Follow the instructions for a <b>Test Run</b> (page 10) to get rid of the plastic smell. If a plastic smell is still present, please contact <b>Customer Support</b> (see page 17).
Display shows Error Code "E1".	There is an open circuit in the temperature monitor. Contact <b>Customer Support</b> (see page 17).
Display shows Error Code "E2".	There is a short circuit in the temperature monitor. Contact <b>Customer Support</b> (see page 17).
Display shows Error Code "E3".	Turn off and unplug the air fryer and allow it to cool completely. If the display continues to show "E3", contact <b>Customer Support</b> (see page 17).

If your problem is not listed, please contact **Customer Support** (see page 17).



## WARRANTY INFORMATION

---

<b>Product Name</b>	Pro LE 4.7-Litre Air Fryer
<b>Model</b>	CAF-L501 Series
<i>For your own reference, we strongly recommend that you record your order ID and date of purchase.</i>	
<b>Order ID</b>	
<b>Date of Purchase</b>	

### TERMS & POLICY

Arovast Corporation warrants all products to be of the highest quality in material, craftsmanship, and service for 2 years, effective from the date of purchase to the end of the warranty period. Warranty lengths may vary between product categories.

If you have any questions or concerns about your new product, please contact our helpful Customer Support Team.

## CUSTOMER SUPPORT

---

### **Arovast Corporation**

1202 N. Miller St., Suite A  
Anaheim, CA 92806  
USA

**Email:** support.eu@cosori.com

\*Please have your order invoice and order ID ready before contacting Customer Support.