

TransSteel 2500c
TransSteel 2500c MV
TransSteel 2700c
TransSteel 2700c MV
TransSteel 3500c


Operating Instructions

EN

MIG/MAG Power source



42,0426,0107,EN 037-18052020



Dear reader,

Introduction

Thank you for the trust you have placed in our company and congratulations on buying this high-quality Fronius product. These instructions will help you familiarise yourself with the product. Reading the instructions carefully will enable you to learn about the many different features it has to offer. This will allow you to make full use of its advantages.

Please also note the safety rules to ensure greater safety when using the product. Careful handling of the product will repay you with years of safe and reliable operation. These are essential prerequisites for excellent results.

Explanation of safety notices



DANGER!

Indicates immediate danger.

- ▶ If not avoided, death or serious injury will result.
-



WARNING!

Indicates a potentially hazardous situation.

- ▶ If not avoided, death or serious injury may result.
-



CAUTION!

Indicates a situation where damage or injury could occur.

- ▶ If not avoided, minor injury and/or damage to property may result.
-

NOTE!

Indicates a risk of flawed results and possible damage to the equipment.

Contents

| | |
|---|-----------|
| Safety rules | 9 |
| General | 9 |
| Proper use | 9 |
| Environmental conditions | 9 |
| Obligations of the operator | 10 |
| Obligations of personnel | 10 |
| Mains connection | 10 |
| Protecting yourself and others | 10 |
| Danger from toxic gases and vapours | 11 |
| Danger from flying sparks | 12 |
| Risks from mains current and welding current | 12 |
| Meandering welding currents | 13 |
| EMC Device Classifications | 13 |
| EMC measures | 13 |
| EMF measures | 14 |
| Specific hazards | 14 |
| Requirement for the shielding gas | 15 |
| Danger from shielding gas cylinders | 15 |
| Danger from escaping shielding gas | 16 |
| Safety measures in normal operation | 16 |
| Commissioning, maintenance and repair | 17 |
| Safety inspection | 17 |
| Disposal | 17 |
| Safety symbols | 18 |
| Data protection | 18 |
| Copyright | 18 |
| General information | 19 |
| General | 21 |
| Device concept | 21 |
| Functional principle | 21 |
| Application areas | 21 |
| Warning notices on the device | 22 |
| System components | 23 |
| General | 23 |
| Safety | 23 |
| Overview | 23 |
| Options | 25 |
| VRD: safety function | 25 |
| VRD: safety principle | 25 |
| Control elements and connections | 27 |
| Synergic Central control panel | 29 |
| General | 29 |
| Safety | 29 |
| Synergic control panel | 30 |
| Service parameters | 32 |
| Keylock | 33 |
| Connections, switches and mechanical components | 34 |
| Front and rear sides, TSt 2500c / TSt 2700c | 34 |
| Front and rear sides, TSt 3500c | 35 |
| Side view | 36 |
| Installation and commissioning | 37 |
| Minimum equipment needed for welding task | 39 |
| General | 39 |
| MIG/MAG welding, gas-cooled | 39 |

| | |
|--|----|
| MIG/MAG welding, water-cooled | 39 |
| Manual metal arc welding | 39 |
| Before installation and commissioning | 40 |
| Safety | 40 |
| Utilisation for intended purpose only | 40 |
| Setup regulations | 40 |
| Mains connection | 41 |
| Connecting the mains cable | 42 |
| General | 42 |
| Stipulated mains cables and strain-relief devices | 42 |
| Connecting the mains cable | 42 |
| Fitting the strain-relief device, TSt 2500c MV / TSt 2700c, single-phase operation | 43 |
| Fitting the strain-relief device, TSt 2500c / TSt 2700c | 44 |
| Fitting the strain-relief device, TSt 2500c MV / TSt 2700c MV | 45 |
| Fitting the strain-relief device, TSt 3500c | 46 |
| Fitting the Canada / U S strain-relief device, TSt 3500c | 47 |
| Generator-powered operation | 48 |
| Generator-powered operation | 48 |
| Single-phase operation | 49 |
| Single-phase operation | 49 |
| Explanation of the term „duty cycle“ in single-phase operation | 50 |
| Welding time in single-phase operation | 50 |
| Fitting/connecting the system components | 52 |
| Information on system components | 52 |
| Mounting on the trolley | 52 |
| Connecting the gas cylinder | 52 |
| Connecting a MIG/MAG welding torch | 53 |
| Establishing a ground (earth) connection | 54 |
| Inserting/replacing feed rollers | 54 |
| Inserting the wirepool/basket-type spool | 55 |
| Feeding in the wire electrode | 56 |
| Setting the contact pressure | 58 |
| Adjusting the brake | 59 |
| Design of the brake | 60 |
| Start-up | 61 |
| General | 61 |
| Prerequisites | 61 |
| Commissioning | 61 |

Welding **63**

| | |
|---|----|
| Power limitation | 65 |
| Safety function | 65 |
| MIG/MAG modes | 66 |
| General | 66 |
| Symbols and their explanations | 66 |
| 2-step mode | 67 |
| 4-step mode | 67 |
| Special 4-step mode | 67 |
| Spot welding | 67 |
| 2-step stitch welding | 68 |
| 4-step stitch welding | 68 |
| MIG/MAG welding | 69 |
| Safety | 69 |
| Overview | 69 |
| MIG/MAG standard synergic welding | 70 |
| MIG/MAG standard synergic welding | 70 |
| Corrections during welding | 71 |
| MIG/MAG standard manual welding | 72 |
| General | 72 |
| Available parameters | 72 |
| MIG/MAG standard manual welding | 72 |
| Corrections during welding | 73 |
| MMA welding | 74 |

| | |
|---|-----------|
| Safety..... | 74 |
| Preparation | 74 |
| MMA welding | 74 |
| Corrections during welding | 75 |
| HotStart function | 75 |
| Anti-stick function..... | 76 |
| Saving and retrieving operating points..... | 77 |
| General | 77 |
| Saving operating points | 77 |
| Retrieving operating points | 77 |
| Deleting operating points | 77 |
| Retrieving operating points on the Up/Down welding torch | 77 |
| Setup settings | 79 |
| Setup menu..... | 81 |
| General remarks | 81 |
| Configuring the setup parameters..... | 81 |
| Setup parameters for MIG/MAG standard manual welding | 82 |
| Setup parameters for MIG/MAG standard synergic welding..... | 84 |
| Setup parameters for MMA welding..... | 86 |
| Setup menu - Level 2..... | 87 |
| Restrictions | 87 |
| Configuring the setup parameters..... | 87 |
| Parameters for MIG/MAG welding in the Setup menu level 2 | 89 |
| Parameters for manual metal arc (MMA) welding in the Setup menu level 2 | 90 |
| Measuring welding circuit resistance r | 91 |
| General | 91 |
| Measure the welding circuit resistance r..... | 91 |
| Displaying welding circuit inductivity L | 93 |
| General | 93 |
| Displaying welding circuit inductivity L..... | 93 |
| Laying the hosepacks correctly..... | 93 |
| Troubleshooting and maintenance | 95 |
| Troubleshooting | 97 |
| General | 97 |
| Safety..... | 97 |
| Fault diagnosis..... | 97 |
| Displayed service codes | 100 |
| Care, maintenance and disposal | 106 |
| General | 106 |
| Safety..... | 106 |
| At every start-up..... | 106 |
| If necessary..... | 106 |
| Every 2 months | 106 |
| Every 6 months | 107 |
| Disposal | 107 |
| Technical data..... | 108 |
| Special voltages..... | 108 |
| Explanation of the term "duty cycle" | 108 |
| TSt 2500c..... | 109 |
| TSt 2500c MV | 110 |
| TSt 2700c..... | 112 |
| TSt 2700c MV | 113 |
| TSt 3500c..... | 115 |
| Appendix | 117 |
| Quick reference..... | 117 |
| TSt 2500c / TSt 2700c welding program table | 119 |
| TSt 2500c USA / TSt 2700c USA welding program table | 120 |
| TransSteel 3500 Euro welding program tables | 121 |
| TransSteel 3500 US welding program tables | 122 |

Safety rules

General

The device is manufactured using state-of-the-art technology and according to recognised safety standards. If used incorrectly or misused, however, it can cause:

- injury or death to the operator or a third party,
- damage to the device and other material assets belonging to the operating company,
- inefficient operation of the device.

All persons involved in commissioning, operating, maintaining and servicing the device must:

- be suitably qualified,
- have sufficient knowledge of welding and
- read and follow these operating instructions carefully.

The operating instructions must always be at hand wherever the device is being used. In addition to the operating instructions, attention must also be paid to any generally applicable and local regulations regarding accident prevention and environmental protection.

All safety and danger notices on the device

- must be in a legible state,
- must not be damaged,
- must not be removed,
- must not be covered, pasted or painted over.

For the location of the safety and danger notices on the device, refer to the section headed "General" in the operating instructions for the device.

Before switching on the device, rectify any faults that could compromise safety.

This is for your personal safety!

Proper use

The device is to be used exclusively for its intended purpose.

The device is intended solely for the welding processes specified on the rating plate. Any use above and beyond this purpose is deemed improper. The manufacturer shall not be held liable for any damage arising from such usage.

Proper use includes:

- carefully reading and following all the instructions given in the operating instructions
- studying and obeying all safety and danger notices carefully
- performing all stipulated inspection and maintenance work.

Never use the device for the following purposes:

- Thawing out pipes
- Charging batteries
- Starting engines

The device is designed for use in industry and the workshop. The manufacturer accepts no responsibility for any damage caused through use in a domestic setting.

The manufacturer likewise accepts no liability for inadequate or incorrect results.

Environmental conditions

Operation or storage of the device outside the stipulated area will be deemed as not in accordance with the intended purpose. The manufacturer shall not be held liable for any damage arising from such usage.

Ambient temperature range:

- during operation: -10 °C to + 40 °C (14 °F to 104 °F)
 - during transport and storage: -20 °C to +55 °C (-4 °F to 131 °F)
-

Relative humidity:

- up to 50% at 40 °C (104 °F)
 - up to 90% at 20 °C (68 °F)
-

The surrounding air must be free from dust, acids, corrosive gases or substances, etc.
Can be used at altitudes of up to 2000 m (6561 ft. 8.16 in.)

Obligations of the operator

The operator must only allow persons to work with the device who:

- are familiar with the fundamental instructions regarding safety at work and accident prevention and have been instructed in how to use the device
 - have read and understood these operating instructions, especially the section "safety rules", and have confirmed as much with their signatures
 - are trained to produce the required results.
-

Checks must be carried out at regular intervals to ensure that operators are working in a safety-conscious manner.

Obligations of personnel

Before using the device, all persons instructed to do so undertake:

- to observe the basic instructions regarding safety at work and accident prevention
 - to read these operating instructions, especially the "Safety rules" section and sign to confirm that they have understood them and will follow them.
-

Before leaving the workplace, ensure that people or property cannot come to any harm in your absence.

Mains connection

Devices with a higher rating may affect the energy quality of the mains due to their current consumption.

This may affect a number device types in terms of:

- Connection restrictions
- Criteria with regard to the maximum permissible mains impedance ^{*)}
- Criteria with regard to the minimum short-circuit power requirement ^{*)}

^{*)} at the interface with the public grid
see "Technical data"

In this case, the plant operator or the person using the device should check whether the device may be connected, where appropriate by discussing the matter with the power supply company.

IMPORTANT! Ensure that the mains connection is earthed properly

Protecting yourself and others

Anyone working with the device exposes themselves to numerous risks, e.g.

- flying sparks and hot pieces of metal
 - Arc radiation, which can damage eyes and skin
 - Hazardous electromagnetic fields, which can endanger the lives of those using cardiac pacemakers
 - Risk of electrocution from mains current and welding current
 - Greater noise pollution
 - Harmful welding fumes and gases
-

Suitable protective clothing must be worn when working with the device. The protective clothing must have the following properties:

- Flame-resistant
- Insulating and dry
- Covers the whole body, is undamaged and in good condition
- Safety helmet
- Trousers with no turn-ups

Protective clothing refers to a variety of different items. Operators should:

- Protect eyes and face from UV rays, heat and sparks using a protective visor and regulation filter
- Wear regulation protective goggles with side protection behind the protective visor
- Wear stout footwear that provides insulation even in wet conditions
- Protect the hands with suitable gloves (electrically insulated and providing protection against heat)
- Wear ear protection to reduce the harmful effects of noise and to prevent injury

Keep all persons, especially children, out of the working area while any devices are in operation or welding is in progress. If, however, there are people in the vicinity:

- Make them aware of all the dangers (risk of dazzling by the arc, injury from flying sparks, harmful welding fumes, noise, possible risks from mains current and welding current, etc.)
- Provide suitable protective equipment
- Alternatively, erect suitable safety screens/curtains.

Danger from toxic gases and vapours

The fumes produced during welding contain harmful gases and vapours.

Welding fumes contain substances that cause cancer, as stated in Monograph 118 of the International Agency for Research on Cancer.

Use at-source extraction and a room extraction system.

If necessary, use a welding torch with an integrated extraction device.

Keep your face away from welding fumes and gases.

Fumes and hazardous gases

- must not be breathed in
- must be extracted from the working area using appropriate methods.

Ensure an adequate supply of fresh air. Ensure that there is a ventilation rate of at least 20 m³ per hour at all times.

Otherwise, a welding helmet with an air supply must be worn.

If there is any doubt about whether the extraction capacity is sufficient, the measured toxic emission values should be compared with the permissible limit values.

The following components are responsible, amongst other things, for the degree of toxicity of welding fumes:

- Metals used for the workpiece
- Electrodes
- Coatings
- Cleaners, degreasers, etc.
- Welding process used

The relevant material safety data sheets and manufacturer's specifications for the listed components should therefore be studied carefully.

Recommendations for trade fair scenarios, risk management measures and for identifying working conditions can be found on the European Welding Association website under Health & Safety (<https://european-welding.org>).

Flammable vapours (e.g. solvent fumes) should be kept away from the arc's radiation area.

Close the shielding gas cylinder valve or main gas supply if no welding is taking place.

Danger from flying sparks

Flying sparks may cause fires or explosions.

Never weld close to flammable materials.

Flammable materials must be at least 11 metres (36 ft. 1.07 in.) away from the arc, or alternatively covered with an approved cover.

A suitable, tested fire extinguisher must be available and ready for use.

Sparks and pieces of hot metal may also get into adjacent areas through small gaps or openings. Take appropriate precautions to prevent any danger of injury or fire.

Welding must not be performed in areas that are subject to fire or explosion or near sealed tanks, vessels or pipes unless these have been prepared in accordance with the relevant national and international standards.

Do not carry out welding on containers that are being or have been used to store gases, propellants, mineral oils or similar products. Residues pose an explosive hazard.

Risks from mains current and welding current

An electric shock is potentially life threatening and can be fatal.

Do not touch live parts either inside or outside the device.

During MIG/MAG welding and TIG welding, the welding wire, the wirespool, the feed rollers and all pieces of metal that are in contact with the welding wire are live.

Always set the wirefeeder up on a sufficiently insulated surface or use a suitable, insulated wirefeeder holder.

Make sure that you and others are protected with an adequately insulated, dry base or cover for the earth or ground potential. This base or cover must extend over the entire area between the body and the earth or ground potential.

All cables and leads must be secured, undamaged, insulated and adequately dimensioned. Replace loose connections and scorched, damaged, or inadequately dimensioned cables and leads immediately.

Use the handle to ensure the power connections are tight before every use.

In the case of power cables with a bayonet connector, rotate the power cable around the longitudinal axis by at least 180° and pretension.

Do not wrap cables or leads around the body or parts of the body.

The electrode (rod electrode, tungsten electrode, welding wire, etc.) must

- never be immersed in liquid for cooling
- Never touch the electrode when the power source is switched on.

Double the open circuit voltage of a power source can occur between the welding electrodes of two power sources. Touching the potentials of both electrodes at the same time may be fatal under certain circumstances.

Arrange for the mains cable to be checked regularly by a qualified electrician to ensure the ground conductor is functioning properly.

Protection class I devices require a mains supply with ground conductor and a connector system with ground conductor contact for proper operation.

Operation of the device on a mains supply without ground conductor and on a socket without ground conductor contact is only permitted if all national regulations for protective separation are observed.

Otherwise, this is considered gross negligence. The manufacturer shall not be held liable for any damage arising from such usage.

If necessary, provide adequate earthing for the workpiece.

Switch off unused devices.

Wear a safety harness if working at height.

Before working on the device, switch it off and pull out the mains plug.

Attach a clearly legible and easy-to-understand warning sign to the device to prevent anyone from plugging the mains plug back in and switching it on again.

After opening the device:

- Discharge all live components
- Ensure that all components in the device are de-energised.

If work on live parts is required, appoint a second person to switch off the main switch at the right moment.

Meandering welding currents

If the following instructions are ignored, meandering welding currents can develop with the following consequences:

- Fire hazard
- Overheating of parts connected to the workpiece
- Irreparable damage to ground conductors
- Damage to device and other electrical equipment

Ensure that the workpiece is held securely by the workpiece clamp.

Attach the workpiece clamp as close as possible to the area that is to be welded.

Position the device with sufficient insulation against electrically conductive environments, e.g. Insulation against conductive floor or insulation to conductive racks.

If distribution boards, twin-head mounts, etc., are being used, note the following: The electrode of the welding torch / electrode holder that is not used is also live. Make sure that the welding torch / electrode holder that is not used is kept sufficiently insulated.

In the case of automated MIG/MAG applications, ensure that only an insulated wire electrode is routed from the welding wire drum, large wirefeeder spool or wirepool to the wirefeeder.

EMC Device Classifications

Devices in emission class A:

- Are only designed for use in industrial settings
- Can cause line-bound and radiated interference in other areas

Devices in emission class B:

- Satisfy the emissions criteria for residential and industrial areas. This is also true for residential areas in which the energy is supplied from the public low-voltage mains.

EMC device classification as per the rating plate or technical data.

EMC measures

In certain cases, even though a device complies with the standard limit values for emissions, it may affect the application area for which it was designed (e.g. when there is sensitive equipment at the same location, or if the site where the device is installed is close to

either radio or television receivers).

If this is the case, then the operator is obliged to take appropriate action to rectify the situation.

Check and evaluate the immunity to interference of nearby devices according to national and international regulations. Examples of equipment that may be susceptible to interference from the device include:

- Safety devices
 - Power, signal and data transfer lines
 - IT and telecommunications devices
 - Measuring and calibrating devices
-

Supporting measures for avoidance of EMC problems:

1. Mains supply
 - If electromagnetic interference arises despite correct mains connection, additional measures are necessary (e.g. use a suitable line filter).
 2. Welding power leads
 - must be kept as short as possible
 - must run close together (to avoid EMF problems)
 - must be kept well apart from other leads
 3. Equipotential bonding
 4. Earthing of the workpiece
 - If necessary, establish an earth connection using suitable capacitors.
 5. Shielding, if necessary
 - Shield off other nearby devices
 - Shield off entire welding installation
-

EMF measures

Electromagnetic fields may pose as yet unknown risks to health:

- effects on the health of others in the vicinity, e.g. wearers of pacemakers and hearing aids
 - wearers of pacemakers must seek advice from their doctor before approaching the device or any welding that is in progress
 - for safety reasons, keep distances between the welding cables and the welder's head/torso as large as possible
 - do not carry welding cables and hosepacks over the shoulders or wind them around any part of the body
-

Specific hazards

Keep hands, hair, clothing and tools away from moving parts. For example:

- Fans
 - Cogs
 - Rollers
 - Shafts
 - Wirespools and welding wires
-

Do not reach into the rotating cogs of the wire drive or into rotating drive components.

Covers and side panels may only be opened/removed while maintenance or repair work is being carried out.

During operation

- Ensure that all covers are closed and all side panels are fitted properly.
 - Keep all covers and side panels closed.
-

The welding wire emerging from the welding torch poses a high risk of injury (piercing of the hand, injuries to the face and eyes, etc.).

Therefore always keep the welding torch away from the body (devices with wire-feed unit) and wear suitable protective goggles.

Never touch the workpiece during or after welding - risk of burns.

Slag can jump off cooling workpieces. The specified protective equipment must therefore also be worn when reworking workpieces, and steps must be taken to ensure that other people are also adequately protected.

Welding torches and other parts with a high operating temperature must be allowed to cool down before handling.

Special provisions apply in areas at risk of fire or explosion - observe relevant national and international regulations.

Power sources for work in areas with increased electric risk (e.g. near boilers) must carry the "Safety" sign. However, the power source must not be located in such areas.

Risk of scalding from escaping coolant. Switch off cooling unit before disconnecting coolant flow or return lines.

Observe the information on the coolant safety data sheet when handling coolant. The coolant safety data sheet may be obtained from your service centre or downloaded from the manufacturer's website.

Use only suitable load-carrying equipment supplied by the manufacturer when transporting devices by crane.

- Hook chains and/or ropes onto all suspension points provided on the load-carrying equipment.
- Chains and ropes must be at the smallest angle possible to the vertical.
- Remove gas cylinder and wire-feed unit (MIG/MAG and TIG devices).

If the wire-feed unit is attached to a crane holder during welding, always use a suitable, insulated wirefeeder hoisting attachment (MIG/MAG and TIG devices).

If the device has a carrying strap or handle, this is intended solely for carrying by hand. The carrying strap is not to be used if transporting with a crane, counterbalanced lift truck or other mechanical hoist.

All lifting accessories (straps, handles, chains, etc.) used in connection with the device or its components must be tested regularly (e.g. for mechanical damage, corrosion or changes caused by other environmental factors).

The testing interval and scope of testing must comply with applicable national standards and directives as a minimum.

Odourless and colourless shielding gas may escape unnoticed if an adapter is used for the shielding gas connection. Prior to assembly, seal the device-side thread of the adapter for the shielding gas connection using suitable Teflon tape.

Requirement for the shielding gas

Especially with ring lines, contaminated shielding gas can cause damage to equipment and reduce welding quality.

Meet the following requirements regarding shielding gas quality:

- Solid particle size < 40 µm
- Pressure condensation point < -20 °C
- Max. oil content < 25 mg/m³

Use filters if necessary.

Danger from shielding gas cylinders

Shielding gas cylinders contain gas under pressure and can explode if damaged. As the shielding gas cylinders are part of the welding equipment, they must be handled with the greatest of care.

Protect shielding gas cylinders containing compressed gas from excessive heat, mechanical impact, slag, naked flames, sparks and arcs.

Mount the shielding gas cylinders vertically and secure according to instructions to prevent them falling over.

Keep the shielding gas cylinders well away from any welding or other electrical circuits.

Never hang a welding torch on a shielding gas cylinder.

Never touch a shielding gas cylinder with an electrode.

Risk of explosion - never attempt to weld a pressurised shielding gas cylinder.

Only use shielding gas cylinders suitable for the application in hand, along with the correct and appropriate accessories (regulator, hoses and fittings). Only use shielding gas cylinders and accessories that are in good condition.

Turn your face to one side when opening the valve of a shielding gas cylinder.

Close the shielding gas cylinder valve if no welding is taking place.

If the shielding gas cylinder is not connected, leave the valve cap in place on the cylinder.

The manufacturer's instructions must be observed as well as applicable national and international regulations for shielding gas cylinders and accessories.

Danger from escaping shielding gas

Risk of suffocation from the uncontrolled escape of shielding gas

Shielding gas is colourless and odourless and, in the event of a leak, can displace the oxygen in the ambient air.

- Ensure an adequate supply of fresh air with a ventilation rate of at least 20 m³/hour.
 - Observe safety and maintenance instructions on the shielding gas cylinder or the main gas supply.
 - Close the shielding gas cylinder valve or main gas supply if no welding is taking place.
 - Check the shielding gas cylinder or main gas supply for uncontrolled gas leakage before every start-up.
-

Safety measures in normal operation

Only operate the device when all safety devices are fully functional. If the safety devices are not fully functional, there is a risk of

- injury or death to the operator or a third party
 - damage to the device and other material assets belonging to the operator
 - inefficient operation of the device
-

Any safety devices that are not functioning properly must be repaired before switching on the device.

Never bypass or disable safety devices.

Before switching on the device, ensure that no one is likely to be endangered.

Check the device at least once a week for obvious damage and proper functioning of safety devices.

Always fasten the shielding gas cylinder securely and remove it beforehand if the device is to be transported by crane.

Only the manufacturer's original coolant is suitable for use with our devices due to its properties (electrical conductivity, anti-freeze agent, material compatibility, flammability, etc.).

Only use suitable original coolant from the manufacturer.

Do not mix the manufacturer's original coolant with other coolants.

Only connect the manufacturer's system components to the cooling circuit.

The manufacturer accepts no liability for damage resulting from use of other system components or a different coolant. In addition, all warranty claims will be forfeited.

Cooling Liquid FCL 10/20 does not ignite. The ethanol-based coolant can ignite under certain conditions. Transport the coolant only in its original, sealed containers and keep well away from any sources of ignition.

Used coolant must be disposed of properly in accordance with the relevant national and international regulations. The coolant safety data sheet may be obtained from your service centre or downloaded from the manufacturer's website.

Check the coolant level before starting to weld, while the system is still cool.

Commissioning, maintenance and repair

It is impossible to guarantee that bought-in parts are designed and manufactured to meet the demands made of them, or that they satisfy safety requirements.

- Use only original spare and wearing parts (also applies to standard parts).
 - Do not carry out any modifications, alterations, etc. to the device without the manufacturer's consent.
 - Components that are not in perfect condition must be replaced immediately.
 - When ordering, please give the exact designation and part number as shown in the spare parts list, as well as the serial number of your device.
-

The housing screws provide the ground conductor connection for earthing the housing parts.

Only use original housing screws in the correct number and tightened to the specified torque.

Safety inspection

The manufacturer recommends that a safety inspection of the device is performed at least once every 12 months.

The manufacturer recommends that the power source be calibrated during the same 12-month period.

A safety inspection should be carried out by a qualified electrician

- after any changes are made
 - after any additional parts are installed, or after any conversions
 - after repair, care and maintenance has been carried out
 - at least every twelve months.
-

For safety inspections, follow the appropriate national and international standards and directives.

Further details on safety inspection and calibration can be obtained from your service centre. They will provide you on request with any documents you may require.

Disposal

Do not dispose of this device with normal domestic waste! To comply with the European Directive on Waste Electrical and Electronic Equipment and its implementation as national law, electrical equipment that has reached the end of its life must be collected separately and returned to an approved recycling facility. Any device that you no longer require must either be returned to your dealer or given to one of the approved collection and recycling facilities in your area. Ignoring this European Directive may have potentially adverse effects on the environment and your health!

Safety symbols

Devices with the CE mark satisfy the essential requirements of the low-voltage and electromagnetic compatibility directives (e.g. relevant product standards of the EN 60 974 series).

Fronius International GmbH hereby declares that the device is compliant with Directive 2014/53/EU. The full text on the EU Declaration of Conformity can be found at the following address: <http://www.fronius.com>

Devices marked with the CSA test mark satisfy the requirements of the relevant standards for Canada and the USA.

Data protection

The user is responsible for the safekeeping of any changes made to the factory settings. The manufacturer accepts no liability for any deleted personal settings.


Copyright

Copyright of these operating instructions remains with the manufacturer.

The text and illustrations are all technically correct at the time of printing. We reserve the right to make changes. The contents of the operating instructions shall not provide the basis for any claims whatsoever on the part of the purchaser. If you have any suggestions for improvement, or can point out any mistakes that you have found in the instructions, we will be most grateful for your comments.

General information

Device concept



The TransSteel (TSt) 2500c, 2700c and 3500c power sources are completely digitised, microprocessor-controlled inverter power sources.

The modular design and potential for system add-ons ensure a high degree of flexibility. The devices are designed for the welding of steel.

All devices are suitable for:

- MIG/MAG welding
- MMA welding

Functional principle

The central control and regulation unit of the power sources is coupled with a digital signal processor. The central control and regulation unit and signal processor control the entire welding process.

During the welding process, the actual data is measured continuously and the device responds immediately to any changes. Control algorithms ensure that the desired target state is maintained.

The device has a "Power limitation" safety feature. This means that the power source can be operated at the power limit without compromising process safety.

This results in:

- a precise welding process
- a high degree of reproducibility of all results
- excellent weld properties.

Application areas

The devices are used in workshops and industry for manual applications with classical steel and galvanised sheets.

The TSt 2500c and TSt 2700c power sources are primarily used in light-gauge steel sheet (light steelwork) applications. Repair, maintenance, and assembly work in shipyards, automotive suppliers, workshops or the furniture construction industry are among the typical application areas. The TSt 2500c et TSt 2700c power sources thus position themselves in their power category between the trade/workshop sector and the industry sector.

The TSt 3500c power sources are designed for:

- Machine and equipment construction
- Steelwork
- Plant and container construction
- Metal and gantry construction
- Rail vehicle construction

Warning notices on the device

Warning notices and safety symbols are affixed to the power sources. These warning notices and safety symbols must not be removed or painted over. They warn against operating the device incorrectly, as this may result in serious injury and damage.

| | | | |
|--|--|--|--|
| WARNING | | ARC RAYS can burn eyes and skin; NOISE can damage hearing. <ul style="list-style-type: none"> ● Wear welding helmet with correct filter. ● Wear correct eye, ear and body protection. | Read American National Standard Z49.1, "Safety in Welding and Cutting" From American Welding Society, 550 N.W. LeJeune Rd., Miami, FL 33126; OSHA Safety and Health Standards, 29 CFR 1910, from U.S. Government Printing Office, Washington, DC 20402. CSA, W117-2 M87 Code for Safety in Welding and Cutting. 42.0409.5074 |
| Do not Remove, Destroy, Or Cover This Label | | | |
| ARC WELDING can be hazardous. <ul style="list-style-type: none"> ● Read and follow all labels and the Owner's Manual carefully ● Only qualified persons are to install, operate, or service this unit according to all applicable codes and safety practices. ● Keep children away. ● Pacemaker wearers keep away. ● Welding wire and drive parts may be at welding voltage. | EXPLODING PARTS can injure. <ul style="list-style-type: none"> ● Failed parts can explode or cause other parts to explode when power is applied. ● Always wear a face shield and long sleeves when servicing. | ELECTRIC SHOCK can kill; SIGNIFICANT DC VOLTAGE exists after removal of input power <ul style="list-style-type: none"> ● Always wait 60 seconds after power is turned off before working on unit. ● Check input capacitor voltage, and be sure it is near 0 before touching parts. | |
| ELECTRIC SHOCK can kill. <ul style="list-style-type: none"> ● Always wear dry insulating gloves. ● Insulate yourself from work and ground. ● Do not touch live electrical parts. ● Disconnect input power before servicing. ● Keep all panels and covers securely in place. | AVERTISSEMENT | | |
| FUMES AND GASES can be hazardous. <ul style="list-style-type: none"> ● Keep your head out of the fumes. ● Ventilate area, or use breathing device. ● Read Material Safety Data Sheets (MSDSs) and manufacturer's instructions for materials used. | UN CHOC ELECTRIQUE peut etre mortel. <ul style="list-style-type: none"> ● Installation et raccordement de cette machine doivent etre conformes a tous les pertinents. | | |
| WELDING can cause fire or explosion. <ul style="list-style-type: none"> ● Do not weld near flammable material. ● Watch for fire: keep extinguisher nearby. ● Do not locate unit over combustible surfaces. ● Do not weld on closed containers. | SOUDEAGE A L'ARC peut etre hasardeux. <ul style="list-style-type: none"> ● Lire le manuel d' instructions avant utilisation. ● Ne pas installer sur une surface combustible. ● Les fils de soudage et pieces conductrices peuvent etre a la tension de soudage. | | |

inside

Safety symbols on the rating plate

- Welding is dangerous. The following basic requirements must be met:
- welders must be sufficiently qualified
 - suitable protective equipment must be used
 - all persons not involved in the welding process must be kept at a safe distance

- Do not use the functions described here until you have thoroughly read and understood the following documents:
- these operating instructions
 - all the operating instructions for the system components, especially the safety rules

System components

General

The power sources can be operated with various system components and options. This makes it possible to optimise procedures and to simplify machine handling and operation, as necessitated by the particular field of application in which the power source is to be used.

Safety




WARNING!

Operating the equipment incorrectly can cause serious injury and damage.

Do not use the functions described until you have thoroughly read and understood the following documents:


- ▶ these operating instructions
- ▶ all the operating instructions for the system components, especially the safety rules

Overview



TSt 2500c / TSt 2700c

| No. | Function |
|-----|--|
| (1) | Welding torch |
| (2) | Gas cylinder holder stabiliser |
| (3) | Power source |
| (4) | Trolley and gas cylinder holder |
| (5) | Grounding (earthing) cable and electrode cable |



TSt 3500c

| No. | Function |
|-----|--|
| (1) | Welding torch |
| (2) | Gas cylinder holder stabiliser |
| (3) | Power source |
| (4) | Cooling unit TSt 3500c only |
| (5) | Trolley and gas cylinder holder |
| (6) | Grounding (earthing) cable and electrode cable |

Options

VRD: safety function

A Voltage Reduction Device (VRD) is an optional safety device for reducing the voltage. It is recommended for environments in which the risk of an electric shock or electrical accident is increased considerably during arc welding:

- Due to a low human body resistance of the welder
- If the welder is exposed to a clear risk of touching the workpiece or other parts of the welding circuit

A low human body resistance is possible when there is:

- water in the area
- humidity
- heat, particularly ambient temperatures in excess of 32°C (89.6°F)

In wet, damp or hot locations, humidity or sweat can significantly reduce the skin resistance and the insulation resistance of protective equipment and clothing.

Such environments can include:


- Temporary dams for draining certain areas of a site during construction work (cofferdams)
- Trenches
- Mines
- Rain
- Areas partly submerged by water
- Spraywater areas

The VRD option reduces the voltage between the electrode and the workpiece. In safe conditions, the indicator for the currently selected welding process is permanently lit. A safe condition is defined as follows:

- The output voltage in an open circuit is limited to 35 V.


For as long as the welding operation is active (welding circuit resistance < 200 Ohm), the indicator of the currently selected welding process flashes and the output voltage may exceed 35 V.

VRD: safety principle



The welding circuit resistance is greater than the minimum human body resistance (greater than or equal to 200 Ohm):

- VRD is active
- Open circuit voltage is limited to 35 V
- Unintentional contact with the output voltage does not put the welder at risk



The welding circuit resistance is less than the minimum human body resistance (less than 200 Ohm):

- VRD is inactive
- Output voltage not restricted in order to ensure sufficient welding power
- Example: Welding starts

In MMA welding mode:

Within 0.3 seconds of end of welding:

- VRD is active again
- The output voltage is limited to 35 V once more

Control elements and connections

Synergic Central control panel

General

The functions on the control panel are all arranged in a logical way. The individual parameters required for welding can be

- selected easily using buttons
- altered using buttons or the adjusting dial
- displayed on the digital display during welding

The power source uses the Synergic control panel and certain general items of data such as sheet thickness, filler metal, wire diameter and shielding gas to calculate the best welding parameters. As a result, stored knowledge is available at all times. All the parameters can be adjusted manually. The Synergic control panel also allows parameters to be set manually.

NOTE!

Due to software updates, you may find that your device has certain functions that are not described in these operating instructions or vice versa.

Individual illustrations may also differ slightly from the actual controls on your device, but these controls function in exactly the same way.

Safety




WARNING!

Operating the equipment incorrectly can cause serious injury and damage.

Do not use the functions described until you have thoroughly read and understood the following documents:

- ▶ these operating instructions
- ▶ all the operating instructions for the system components, especially the safety rules

Synergic control panel



No. Function

(1) "Parameter selection" button (right)

for selecting the following welding parameters and for changing parameters in the Setup menu

The relevant symbol lights up when a welding parameter is selected.

A Arc length correction
for correcting the arc length

V Welding voltage in V *)
Before the start of welding, the system automatically displays a standard value based on the programmed parameters. During welding, the actual value is displayed.

m Dynamic
for influencing the short-circuiting dynamic at the moment of droplet transfer
- ... harder, more stable arc
0 ... neutral arc
+ ... soft, low-spatter arc

kJ Real Energy Input
for displaying the energy applied during the welding operation. **)

-
- (2) **"Parameter selection" button (left)**
for selecting the following welding parameters and for changing parameters in the Setup menu

The relevant symbol lights up when a welding parameter is selected.

 **Sheet thickness in mm or in.**

If the welding current to be selected is not known it is sufficient to enter the sheet thickness. The required welding current and any other parameters marked with *) will then be adjusted automatically.

A **Welding current in A *)**




Before the start of welding, the device automatically displays a standard value based on the programmed parameters. During welding, the actual value is displayed.




 **Wire feed speed in m/min or ipm *)**

-
- (3) **Adjusting dial (right)**
for changing the arc length correction, welding voltage and arc-force dynamic parameters as well as changing parameters in the Setup menu

-
- (4) **Adjusting dial (left)**
for changing the sheet thickness, welding current and wire feed speed parameters as well as changing parameters in the Setup menu

-
- (5) **"Save" buttons (Easy Job)**
for saving up to 5 operating points

-
- (6) **"Process" button ***)**
for selecting the welding process
-  MANUAL - MIG/MAG standard manual welding
 -  SYNERGIC - MIG/MAG standard synergic welding
 -  STICK - manual metal arc welding

-
- (7) **"Mode" button**
for selecting the operating mode
-  2 T - 2-step mode
 -  4 T - 4-step mode
 -  S 4 T - Special 4-step mode

-
- (8) **"Shielding gas" button**
for selecting the shielding gas to be used. Parameter SP is reserved for additional shielding gases.
The LED lights up next to the selected shielding gas.

-
- (9) **"Wire diameter" button**
for selecting the wire diameter to be used. Parameter SP is reserved for additional wire diameters.
The LED lights up next to the selected wire diameter.

-
- (10) **"Material" button**
for selecting the filler metal to be used. Parameter SP is reserved for additional filler metals.
The LED lights up next to the selected filler metal.





-
- (11) **"Gas-test" button**
to set the required gas flow rate at the pressure regulator.
Tap button once: shielding gas flows out
Tap button again: shielding gas flow stops
If the "Gas-test" button is not tapped again, the shielding gas flow will stop after 30 s.
-
- (12) **"Wire threading" button**
Press and hold the button:
Thread the wire into the torch hosepack with no accompanying flow of gas
While the button is being held down, the wire drive runs at feeder inching speed.
-
- (13) **Intermediate arc indicator**
A spatter-prone "intermediate arc" occurs between the dip transfer arc and the spray arc. To alert you to this critical area - and help you avoid it - the intermediate arc indicator lights up.
-
- (14) **HOLD indicator**
At the end of each welding operation, the actual values for welding current and welding voltage are stored, and the HOLD indicator lights up.
-
- (15) **SF - spot / stitch welding indicator**
lights up if a value has been entered for the spot / stitch welding time Setup parameter (SPt) (spot or stitch welding operating mode is enabled)
-

- *) If one of these parameters is selected in the MIG/MAG standard synergic welding process, then the synergic function ensures that all other parameters, including the welding voltage parameter, are adjusted automatically.
- **) The Real Energy Input display must be activated in level 2 of the Setup menu – EnE parameter. The value continuously rises during welding in line with the permanently increasing energy yield. The final value at the end of welding remains stored until welding starts again or the power source is switched back on - the HOLD indicator lights up.
- ***) In conjunction with the VRD option, the currently selected welding process indicator is simultaneously an additional indicator:
- The indicator is permanently lit: The Voltage Reduction Device (VRD) is active and is limiting the output voltage to less than 35 V.
 - The indicator starts to flash as soon as a welding action starts in which the output voltage can exceed 35 V.

Service parameters

Various service parameters can be retrieved by pressing the "Parameter selection" buttons at the same time.

Opening the display

-  **1** Press and hold the "Parameter selection" button (left)
-  **2** Press the "Parameter selection" button (right)
-   **3** Release the "Parameter selection" buttons

The first parameter ("Firmware version") is displayed, e.g. "1.00 | 4.21"

Selecting parameters



1 Select the required setup parameter using the "Mode" and "Process" buttons or the left-hand adjusting dial



Available parameters

| | |
|---|--|
| Example: 1.00 4.21 | Firmware version |
| Example: 2 491 | Welding program configuration |
| Example: r 2 290 | Number of the currently selected welding program |
| Example: iFd 0.0 | Motor current for wire drive in A The value changes as soon as the motor is running. |
| 654 32.1 = 65,432.1 hours = 65,432 hours 6 mins | Indicates the actual arc time since using for the first time Note: The arc time indicator is not suitable as a basis for calculating hiring fees, for warranty purposes, etc. |
| 2nd | 2nd menu level for service engineers |

Keylock

A keylock can be selected to prevent the settings from being inadvertently changed on the control panel. As long as the keylock is active

- no settings can be made on the control panel
- only parameter settings can be retrieved
- any assigned "Save" button can be retrieved provided that an assigned "Save" button was selected when the keylock was enabled

Activate/deactivate the keylock as follows:



1 Press and hold the "Mode" button



2 Press the "Parameter selection" button (right)



3 Release the "Mode" and "Parameter Selection" buttons

Keylock activated:


The message "CLO | SEd" appears on the displays.

Keylock deactivated:

The message "OP | En" appears on the displays.

Connections, switches and mechanical components

Front and rear sides, TSt 2500c / TSt 2700c




TSt 2500c / TSt 2700c

| No. | Function |
|-----|----------|
|-----|----------|

- | | |
|-----|--|
| (1) | Welding torch connection for connecting the welding torch |
| (2) | (-) - Current socket with bayonet latch used for <ul style="list-style-type: none"> - connecting the grounding (earthing) cable during MIG/MAG welding - connecting the electrode cable or grounding (earthing) cable during MMA welding (depending on the type of electrode used) |
| (3) | LocalNet connection Standardised connection for remote control |
| (4) | (+) - Current socket with bayonet latch used for <ul style="list-style-type: none"> - connecting the electrode cable or grounding (earthing) cable during MMA welding (depending on the type of electrode used) |
| (5) | Shielding gas connection |
| (6) | Mains switch for switching the power source on and off |
| (7) | Mains cable with strain relief device |
| (8) | Air filter |


Front and rear sides, TSt 3500c



TSt 3500c

| No. | Function |
|-----|--|
| (1) | Welding torch connection for connecting the welding torch |
| (2) | (-) - Current socket with bayonet latch used for <ul style="list-style-type: none"> - connecting the grounding (earthing) cable during MIG/MAG welding - connecting the electrode cable or grounding (earthing) cable during MMA welding (depending on the type of electrode used) |
| (3) | (+) - Current socket with bayonet latch used for <ul style="list-style-type: none"> - connecting the electrode cable or grounding (earthing) cable during MMA welding (depending on the type of electrode used) |
| (4) | LocalNet connection Standardised connection for remote control |
| (5) | Mains switch for switching the power source on and off |
| (6) | Mains cable with strain relief device |
| (7) | Air filter |
| (8) | Shielding gas connection |

Side view



| No. | Function |
|-----|---|
| (1) | Wirepool holder with brake for holding standard wirepools with a max. diameter of 300 mm (11.81 in.) and a max. weight of up to 19 kg (41.89 lbs.) |
| (2) | 4-roller drive |
| (3) | LED wirepool interior lighting (TSt 2500c, TSt 2700c only) with the setup parameter LED the turn-off time is adjustable |

Installation and commissioning

Minimum equipment needed for welding task

General

Depending on which welding process you intend to use, a certain minimum equipment level will be needed in order to work with the power source. The welding processes and the minimum equipment levels required for the welding task are then described.

MIG/MAG welding, gas-cooled

- Power source
 - Grounding (earthing) cable
 - MIG/MAG welding torch, gas-cooled
 - Gas connection (shielding gas supply)
 - Wire electrode
-

MIG/MAG welding, water-cooled

- Power source
 - Cooling unit including coolant
 - Grounding (earthing) cable
 - MIG/MAG welding torch, water-cooled
 - Gas connection (shielding gas supply)
 - Wire electrode
-

Manual metal arc welding

- Power source
- Grounding (earthing) cable
- Electrode holder
- Rod electrode

Before installation and commissioning

Safety



WARNING!

Operating the equipment incorrectly can cause serious injury and damage.

Do not use the functions described until you have thoroughly read and understood the following documents:

- ▶ these operating instructions
 - ▶ all the operating instructions for the system components, especially the safety rules
-



WARNING!

An electric shock can be fatal.

If the power source is connected to the mains electricity supply during installation, there is a high risk of very serious injury and damage. Before carrying out any work on the device make sure that:

- ▶ the power source mains switch is in the "O" position
 - ▶ the power source is unplugged from the mains
-

Utilisation for intended purpose only

The power source may only be used for MIG/MAG and MMA welding. Any other form of usage is deemed "not in accordance with the intended purpose". The manufacturer shall not be held liable for any damages arising from such usage.

Utilisation in accordance with the "intended purpose" also comprises

- following all the information in the operating instructions
 - carrying out all the specified inspection and servicing work
-

Setup regulations

The device is tested to IP 23, meaning:

- protection against penetration by solid foreign bodies with diameters > 12 mm (0.49 in.)
- protection against water sprayed directly at any angle up to 60° from the vertical

The device can be set up and operated outdoors in accordance with degree of protection IP 23.

Avoid direct wetting (e.g. from rain).



WARNING!

If one of these machines topples over or falls it could cause serious or even fatal injury.

Place device on a solid, level surface in such a way that it remains stable.



CAUTION!

Electroconductive metallic dust may damage the device.

The air filter is a very important safety feature for achieving IP 23. Always fit the air filter when operating the device.

The venting duct is a very important safety feature. When choosing the installation location, ensure that the cooling air can enter and exit unhindered through the air ducts on the front and back of the device. Electroconductive metallic dust (e.g. from grinding work) must not be allowed to get sucked into the device.

Mains connection The devices are designed to run on the mains voltage shown on the respective rating plates. If your version of the device does not come with mains cables and plugs ready-fitted, these must be fitted in accordance with national regulations and standards. For details of fuse protection of the mains lead, please see the Technical Data.

NOTE!

Inadequately dimensioned electrical installations can cause serious damage.

The incoming mains lead and its fuse must be dimensioned to suit the local power supply. The technical data shown on the rating plate applies.

Connecting the mains cable

General

A strain-relief device for the following cable cross-sections is fitted to the power source:

| Power source | Cable cross-section | |
|-----------------------|---------------------|--------|
| | Canada / US | Europe |
| TSt 2500c / TSt 2700c | AWG 14 to AWG 6 *) | 4G2.5 |
| TSt 3500c | AWG 12 *) | 4G2.5 |

*) Canada / US cable type: Extra-hard usage

Strain-relief devices for other cable cross-sections must be designed accordingly.

Stipulated mains cables and strain-relief devices

| Power source | Mains voltage | Cable cross-section | |
|-----------------------|-----------------|---------------------|--------------|
| | | Canada / US | Europe |
| TSt 2500c / TSt 2700c | 1 x 230 / 240 V | AWG 14 (15 A) *) | 3G2.5 (16 A) |
| TSt 2500c / TSt 2700c | 1 x 240 V | AWG 12 (20 A) *) | - |
| TSt 2500c / TSt 2700c | 1 x 240 V | AWG 12 (30 A) *) | - |
| TSt 2500c / TSt 2700c | 3 x 200 V | AWG 12 | 4G2.5 |
| TSt 2500c / TSt 2700c | 3 x 230 / 240 V | AWG 14 | 4G2.5 |
| TSt 2500c / TSt 2700c | 3 x 380 / 400 V | AWG 14 *) | 4G2.5 |
| | 3 x 460 V | AWG 14 *) | 4G2.5 |
| TSt 3500c | 3 x 380 / 400 V | AWG 12 *) | 4G2.5 |
| | 3 x 460 V | AWG 12 *) | 4G2.5 |

*) Canada / US cable type: Extra-hard usage

The item numbers of the different cables can be found in the spare parts list.

American Wire Gauge

Connecting the mains cable

If no mains cable is connected, a mains cable that is suitable for the connection voltage must be fitted before commissioning.

CAUTION!

If no ferrules are used, there is a risk of injury and damage from short circuits between the phase conductors or between the phase conductors and the PE conductor.

Fit ferrules to all phase conductors and the PE conductor of the stripped mains cable.






The ground conductor should be approx. 10 - 15 mm (0.4 - 0.6 in.) longer than the phase conductors.

An illustration of the mains cable connection can be found in the following sections for fitting the strain-relief device. To connect the mains cable, proceed as follows:

- 1 Remove the side panel from the device

- 2 Push the mains cable in far enough to make it possible to connect the ground conductor and the phase conductors to the block terminal properly.
- 3 Fit ferrules to the ground conductor and phase conductors
- 4 Connect the ground conductor and phase conductors to the block terminal
- 5 Use the strain-relief device to secure the mains cable
- 6 Fit the side panel of the device






Fitting the strain-relief device, TSt 2500c MV / TSt 2700c, single-phase operation



IMPORTANT!

Tie the phase conductors near the strain-relief device using cable ties.






Fitting the strain-relief device, TSt 2500c / TSt 2700c



IMPORTANT!

Tie the phase conductors near the strain-relief device using cable ties.





Fitting the strain-relief device, TSt 2500c MV / TSt 2700c MV



IMPORTANT!

Tie the phase conductors near the strain-relief device using cable ties.





Fitting the strain-relief device, TSt 3500c



IMPORTANT!

Tie the phase conductors near the luster terminal using cable ties.

Fitting the Canada / U S strain-relief device, TSt 3500c



IMPORTANT!

Tie the phase conductors near the luster terminal using cable ties.

Generator-powered operation

Generator-powered operation

The power source is generator-compatible.

The maximum apparent power $S_{1\max}$ of the power source must be known in order to select the correct generator output.

The maximum apparent power $S_{1\max}$ of the power source is calculated as follows:

3-phase devices:

$$S_{1\max} = I_{1\max} \times U_1 \times \sqrt{3}$$

Single-phase devices:

$$S_{1\max} = I_{1\max} \times U_1$$

See device rating plate or technical data for $I_{1\max}$ and U_1 values

The generator apparent power S_{GEN} needed is calculated using the following rule of thumb:

$$S_{\text{GEN}} = S_{1\max} \times 1.35$$

A smaller generator may be used when not welding at full power.

IMPORTANT! The generator apparent power S_{GEN} must always be higher than the maximum apparent power $S_{1\max}$ of the power source.

When using single-phase devices with a 3-phase generator, note that the specified generator apparent power is often only available as a whole across all three phases of the generator. If necessary, obtain further information on the single-phase power of the generator from the generator manufacturer.

NOTE!

The voltage delivered by the generator must never exceed the upper or lower limits of the mains voltage tolerance range.

Details of the mains voltage tolerance can be found in the "Technical data" section.

Single-phase operation

Single-phase operation

As an alternative to three-phase operation, the multivoltage variant (MV) of the power source enables a welding operation with limited power or duration from just a single-phase supply. The maximum possible welding power is limited due to the dimensioning of the mains fuse protection, upon which the safety cut-out of the power source is dependant.

If the mains cable has a 20 A or 30 A fuse, the FUS parameter may be changed to 20 A or 30 A. Welding with a higher maximum power or for longer periods is therefore possible. The FUS parameter is in the level 2 Setup menu and can be set for a single-phase supply as well as to a US setting (SEt parameter to US).

In order to use the power source in single-phase operation, the following prerequisites must be fulfilled:

- Correct single-phase power source supply in accordance with the chapter "Installation and commissioning," section "Connecting the mains cable" - "Fitting the strain-relief device, single-phase operation."

The following table shows which mains voltages and fuse values limit the welding current in single-phase operation:

| Mains voltage | Fuse value | Welding current limitation |
|---------------|------------|--|
| 230 V | 10 A | MIG/MAG welding: max. 170 A; 100 A at 100%* MMA welding: max. 140 A; 100 A at 100%* |
| 230 V | 13 A | MIG/MAG welding: max. 160 A; 150 A at 100%* MMA welding: max. 140 A; 120 A at 100%* |
| 230 V | 16 A | MIG/MAG welding: max. 180 A; 145 A at 100%* MMA welding: max. 150 A; 130 A at 100%* |
| 240 V | 15 A | MIG/MAG welding: max. 180 A; 145 A at 100%* MMA welding: max. 150 A; 125 A at 100%* |
| 240 V | 20 A | MIG/MAG welding: max. 200 A; 160 A at 100%* MMA welding: max. 180 A; 140 A at 100%* |
| 240 V | 30 A | MIG/MAG welding: max. 220 A; 175 A at 100%* MMA welding: max. 180 A; 140 A at 100%* |

* The 100% values relate to welding with no time limits and without cooling breaks

The welding current data applies at an ambient temperature of 40°C (104°F).

At a mains voltage of 240 V and a fuse value of 30 A the maximum value of 220 A for the MIG/MAG welding for instance is possible at a duty cycle of 40 %.

In single-phase operation a safety cut-out function prevents a triggering of the fuse at higher welding power values. The safety cut-out function is active at fuse values of 15 A, 16 A and 20 A and determines the possible welding time, without triggering of the fuse. If a cut-out of the welding current results due to exceeding the pre-calculated welding time, the service code „toF“ is displayed. In addition to the readout „toF“ from now on a countdown runs for displaying the remaining waiting time, until the welding readiness is restored. Then the message disappears and the power source is operational again.


At a fuse value of 30 A the temperature monitoring of the power source ensures the timely shutdown of the welding current, yet before the fuse triggers. This results in the display of the service codes „to1“ to „to7“. Detailed information concerning the service codes „to1“ to „to7“ is located in chapter „Troubleshooting and maintenance, section „Displayed service codes“. If there is no defect or soiling of the cooling components, here the power source is also ready for welding again after an adequate welding break.

Explanation of the term „duty cycle“ in single-phase operation

For single-phase operation duty cycle values are given in the chapter „Technical data“, depending on the existing fuse value and the welding current. The percentage rates of this duty cycle values indeed relate as well to the 10-minute cycle, as explained in chapter „Technical data“ for the general duty cycle, however the cooling phase of the fuse is rated at only approximately 60 s. Thereafter, the power source is already operational again.


For reasons of technical standards the duty cycle in single-phase operation is only given for the time until the cut-out within the first welding cycle takes place. If the reference to the 10 minute cycle would also persist with regard to the cooling phase, which is usually valid for specifying the duty cycle, in practice longer welding phases than specified would be possible. You see that the specification relates to cooling phases of only approximately 60 s, after which the power source is already operational again.

The example given in the following shows the standard compliant welding and break cycles, at a welding current of 180 A and a duty cycle of 15 %.



Welding time in single-phase operation

The following diagram shows the welding time, which is possible according to the technical standards, depending on the given fuse value and the welding current.



Legend

- Mains fuse protection 10 A
- Mains fuse protection 13 A
- - - Mains fuse protection 15 A
- Mains fuse protection 16 A
- . - . Mains fuse protection 20 A

Fitting/connecting the system components

Information on system components

The steps and activities described below include references to various system components, such as

- Trolley
- Cooling units (TSt 3500c only)
- Welding torches, etc.

For more detailed information about installing and connecting the system components, please refer to the appropriate operating instructions.

Mounting on the trolley


WARNING!

Work that is carried out incorrectly can cause serious injury and damage.


The following activities must only be carried out by trained and qualified personnel. All instructions in the section headed "Safety rules" must be observed.

The following diagram shows an overview of how the individual system components are put together.

For detailed information about the individual steps, please refer to the corresponding operating instructions for the system components.



TSt 2500c / TSt 2700c



TSt 3500c

Connecting the gas cylinder


WARNING!

If gas cylinders topple over, there is a risk of very serious injury and damage.


When using gas cylinders

- ▶ place them on a solid, level surface in such a way that they remain stable
- ▶ secure the gas cylinders to prevent them from falling over
- ▶ fit the optional wirefeeder holder

Follow the gas cylinder manufacturer's safety rules.



TSt 2500c / TSt 2700c



TSt 3500c

- 1 Secure the gas cylinder with a belt
- 2 Briefly open the gas cylinder valve to remove any dust or dirt
- 3 Check the seal on the pressure regulator

NOTE!

US devices (TSt 3500c only) are supplied with an adapter for the gas hose:


- ▶ Seal male thread spacers on the gas solenoid valve using suitable means before screwing on the adapter.
- ▶ Test the adapter to ensure that it is gas-tight.

Connecting a MIG/MAG welding torch


NOTE!

When connecting the welding torch, check that

- ▶ all connections are connected properly
- ▶ all cables, leads and hosepacks are undamaged and correctly insulated.



Establishing a ground (earth) connection



Inserting/replacing feed rollers



⚠ CAUTION!



Risk of injury if the feed roller holders fly upwards.

When unlocking the lever, keep fingers away from the area to the left and right of the lever.

In order to achieve optimum wire electrode feed, the feed rollers must be suitable for the diameter and alloy of the wire being welded.

An overview of the available feed rollers can be found in the spare parts lists.





Inserting the wire-spool/basket-type spool

 **CAUTION!**

Risk of injury from springiness of spooled wire electrode.

When inserting the wirepool / basket-type spool, hold the end of the wire electrode firmly to avoid injuries caused by the wire electrode springing back.

 **CAUTION!**



Risk of injury from falling wirepool/basket-type spool.


Make sure that the wirepool or basket-type spool with basket-type spool adapter is fitted securely to the wirepool holder.

 **CAUTION!**

Risk of injury and material damage if the wirepool/basket-type spool topples over because the locking ring has been placed the wrong way round.



Always place the locking ring as shown in the diagram on the left.





NOTE!

When working with basket-type spools, only use the basket-type spool adapter included in the scope of supply.



Feeding in the wire electrode

⚠ CAUTION!



Risk of injury from springiness of spooled wire electrode.

When inserting the wire electrode into the 4-roller drive, hold the end of the wire electrode firmly to avoid injuries caused by the wire springing back.

⚠ CAUTION!

Risk of damage to the welding torch from sharp end of wire electrode.

Deburr the end of the wire electrode well before feeding in.




⚠ CAUTION!

Risk of injury from wire electrode emerging at speed.

When pressing the "Wire threading" button or the torch trigger, keep the welding torch away from your face and body, and wear suitable protective goggles.

IMPORTANT! To facilitate wire threading, the following sequences are possible when the "Wire threading" button is pressed and held down.



- Hold the button for up to **one second** ... the wire feed speed stays at 1 m/min or 39.37 ipm for the first second.
- Hold the button for up to **2.5 seconds** ... after one second, the wire feed speed increases over the next 1.5 seconds.
- Hold the button for **more than 2.5 seconds** ... after 2.5 seconds, the wire is fed at a constant rate equal to the wire feed speed set for the Fdi welding parameter.

If you release the "Wire threading" button and press it again before one second has elapsed, the sequence starts again from the beginning. This makes it possible to continuously position the wire at a low wire feed speed of 1 m/min or 39.37 ipm where necessary.

If there is no "Wire threading" / "Gas-test" button, the **torch trigger** can be used in the usual way. Before using the torch trigger for wire threading, proceed as follows:

- 1** Press the "Mode" button to select 2-step mode
- 2** Set the "Ito" parameter to "Off" in the Setup menu

⚠ CAUTION!

Risk of injury and damage from electric shock and from the wire electrode emerging from the torch.


When pressing the torch trigger

- ▶ keep the welding torch away from your face and body
- ▶ wear suitable protective goggles
- ▶ do not point the welding torch at people
- ▶ make sure that the wire electrode does not touch any conductive or earthed parts (e.g. Housing etc.)

IMPORTANT! If the **torch trigger** is pressed instead of the "Wire threading"/"Gas-test" button, the welding wire runs at the feeder creep speed (depending on the welding program) for the first 3 seconds. After these 3 seconds, wirefeeding is briefly interrupted.

The welding system detects that the welding process should not start, but that the wire is to be fed in. At the same time, the gas solenoid valve closes, and the welding voltage on the wire electrode is switched off.


If the torch trigger is kept pressed, wire feeding restarts immediately without shielding gas and welding voltage, and the process continues as described above.



Setting the contact pressure

NOTE!

Set the contact pressure in such a way that the wire electrode is not deformed but nevertheless ensures proper wirefeed.






| Standard values | U-grooved rollers |
|--------------------------|-------------------|
| Steel | 4 - 5 |
| CrNi | 4 - 5 |
| Tubular cored electrodes | 2 - 3 |


Adjusting the brake

NOTE!

After releasing the torch trigger the wire spool must stop unreeling. If it continues unreeling, readjust the brake.



Design of the brake



WARNING!

Fitting the equipment incorrectly can cause serious injury and damage.

- ▶ Do not dismantle the brake.
- ▶ Maintenance and servicing of brakes is to be carried out by trained, qualified personnel only.

The brake is only available as a complete unit.
This illustration is for information purposes only.

Start-up

General



WARNING!

Operating the equipment incorrectly can cause serious injury and damage.

Do not use the functions described until you have thoroughly read and understood the following documents:

- ▶ these operating instructions
- ▶ all the operating instructions for the system components, especially the safety rules

The device is started up by pressing the torch trigger (for manual applications).

Prerequisites

The following conditions must be satisfied before the device is started:

- Welding torch connected
- Feed rollers inserted
- Wirespool or basket-type spool with adapter inserted
- Wire electrode fed in
- Brake adjusted
- Feed roller contact pressure set
- All covers closed, all side panels in place, all protection devices intact and in their proper place
- Where applicable, water connections connected

Commissioning

Before proceeding further as described in the "Welding mode" section, the following activities are required for the "MIG/MAG standard synergic welding" and "MIG/MAG standard manual welding" processes:

- 1 Plug in the mains plug
- 2 Turn the mains switch to position "I"

Welding

Power limitation

Safety function

"Power limitation" is a safety function for MIG/MAG welding. This means that the power source can be operated at the power limit whilst maintaining process safety.

Wire feed speed is a determining parameter for welding power. If it is too high, the arc gets smaller and smaller and may be extinguished. In order to prevent this, the welding power is lowered.

- For the selected "MIG/MAG standard synergic welding" process, the symbol for the "Wire feed speed" parameter flashes as soon as the safety function trips. The flashing continues until the next welding start-up, or until the next parameter change.

If the "Wire feed speed" parameter is selected, the reduced value for wire feed speed is displayed.

MIG/MAG modes

General



WARNING!


Operating the equipment incorrectly can cause serious injury and damage.

Do not use the functions described until you have thoroughly read and understood the following documents:


- ▶ these operating instructions
- ▶ all the operating instructions for the system components, especially the safety rules

For details of the meaning, settings, setting range and units of the available welding parameters (e.g. gas pre-flow time), please refer to the "Set-up parameters" section.


Symbols and their explanations



Press the torch trigger



Hold the torch trigger



Release the torch trigger

GPr

Gas pre-flow time

I-S

Starting current

can be increased or decreased depending on the application

SL

Slope: the starting current is continuously lowered as far as the welding current and the welding current as far as the final current

I

Welding-current phase: uniform thermal input into the base material, whose temperature is raised by the advancing heat

I-E

Final current

for filling the end-crater.

GPo

Gas post-flow time


SPT

Spot welding time / stitch welding time

SPb

Stitch pause time


2-step mode



"2-step mode" is suitable for


- Tacking work
- Short weld seams

4-step mode




"4-step mode" is suitable for longer weld seams.

Special 4-step mode




Special 4-step mode allows the starting and final current to be configured in addition to the advantages of 4-step mode.

Spot welding




The "Spot welding" mode is suitable for welded joints on overlapped sheets.

2-step stitch welding



The "2-step stitch welding" mode is suitable for welding short weld seams on thin sheets, to prevent the weld seams from dropping through the base material.

4-step stitch welding



The "4-step stitch welding" mode is suitable for welding longer weld seams on thin sheets, to prevent the weld seams from dropping through the base material.

MIG/MAG welding

Safety



WARNING!

Operating the equipment incorrectly can cause serious injury and damage.

Do not use the functions described until you have thoroughly read and understood the following documents:

- ▶ these operating instructions
 - ▶ all the operating instructions for the system components, especially the safety rules
-



WARNING!

An electric shock can be fatal.

If the power source is connected to the mains electricity supply during installation, there is a high risk of very serious injury and damage. Before carrying out any work on the device make sure that:

- ▶ the power source mains switch is in the "O" position
 - ▶ the power source is unplugged from the mains
-





Overview

MIG/MAG welding is composed of the following sections:

- MIG/MAG standard synergic welding
- MIG/MAG standard manual welding



MIG/MAG standard synergic welding

MIG/MAG standard synergic welding

- 1 Press the "Material" button to select the filler metal to be used.
- 2 Press the "Wire diameter" button to select the diameter of the wire electrode used.
- 3 Press the "Shielding gas" button to select the shielding gas to be used.
The assignment of the SP position is in the welding program tables in the appendix.
- 4 Press the "Process" button to select the desired welding process:
 -  MIG/MAG standard synergic welding
- 5 Press the "Mode" button to select the desired MIG/MAG mode:
 -  2-step mode
 -  4-step mode
 -  Special 4-step mode

IMPORTANT!

Under certain circumstances, it may not be possible to change welding parameters that have been set on the control panel of a system component (TR 2000 or TR 3000 remote control) on the control panel of the power source.

-
- 6 Use the "Parameter selection" buttons to select the welding parameters to be used to specify the welding power:
 -  Sheet thickness
 - A** Welding current
 -  Wire speed
 - V** Welding voltage
 - 7 Use the appropriate adjusting dial to set the relevant welding parameters.
The welding parameter values are shown in the digital display located above them.

All welding parameter set values remain stored until the next time they are changed. This applies even if the power source is switched off and on again. To display the actual welding current during welding, select the welding current parameter.

- 8 Open the gas cylinder valve
- 9 Setting the shielding gas flow rate:
 - Tap the "Gas-test" button
 - Turn the adjusting screw on the underside of the pressure regulator until the pressure gauge shows the required gas flow rate
 - Tap the "Gas-test" button again

CAUTION!

Risk of injury and damage from electric shock and from the wire electrode emerging from the torch.

When pressing the torch trigger

- ▶ keep the welding torch away from your face and body
 - ▶ wear suitable protective goggles
 - ▶ do not point the welding torch at people
 - ▶ make sure that the wire electrode does not touch any conductive or earthed parts (e.g. housing)
-

- 10 Press the torch trigger and start welding
-

Corrections during welding

To obtain the best possible welding results, the arc length correction and dynamic welding parameters will sometimes need to be corrected.

- 1 Press the "Parameter selection" buttons to select the parameters you wish to correct.
- 2 Use the adjusting dials to set the selected welding parameters to the required values. Welding parameter values are shown in the indicators located above them.

MIG/MAG standard manual welding





General

The MIG/MAG standard manual welding process is a MIG/MAG welding process with no synergic function.

Changing one parameter does not result in any automatic adjustments to the other parameters. All of the variable parameters must therefore be adjusted individually, as dictated by the welding process in question.

Available parameters

The following parameters are available in MIG/MAG manual welding:

| | |
|--|--|
|  | Wire feed speed 1 m/min (39.37 ipm.) - maximum wire feed speed, e.g. 25 m/min (984.25 ipm.) |
|  | Welding voltage TSt 2500c: 14.4 - 34.5 V TSt 2700c: 14.4 - 34.9 V TSt 3500c: 14.5 - 38.5 V |
|  | Dynamic ... for influencing the short-circuiting dynamic at the moment of droplet transfer |
|  | Welding current only for displaying the actual value |

MIG/MAG standard manual welding

1 Press the "Process" button to select the desired welding process:

 MIG/MAG standard manual welding

2 Press the "Mode" button to select the desired MIG/MAG mode:

 2-step mode

 4-step mode

In MIG/MAG standard manual welding, special 4-step mode corresponds to conventional 4-step mode.

IMPORTANT! Under certain circumstances, it may not be possible to change welding parameters that have been set on the control panel of a system component (TR 2000 or TR 3000 remote control) on the control panel of the wirefeeder.

3 Press the "Parameter selection" button to select the wire speed parameter

4 Use the adjusting dial to set the desired value for the wire speed

5 Press the "Parameter selection" button to select the welding voltage parameter

6 Use the adjusting dial to set the desired value for the welding voltage

The welding parameter values are shown in the digital display located above them.

All welding parameter set values remain stored until the next time they are changed. This applies even if the power source is switched off and on again. To display the actual welding current during welding, select the welding current parameter.

To display the actual welding current during welding:

- Press the "Parameter selection" button to select the welding current parameter
- The actual welding current is shown on the digital display during welding.

7 Open the gas cylinder valve

8 Setting the shielding gas flow rate:

- Tap the "Gas-test" button
- Turn the adjusting screw on the underside of the pressure regulator until the pressure gauge shows the required gas flow rate
- Tap the "Gas-test" button again



CAUTION!

Risk of injury and damage from electric shock and from the wire electrode emerging from the torch.

When pressing the torch trigger

- ▶ keep the welding torch away from your face and body
- ▶ wear suitable protective goggles
- ▶ do not point the welding torch at people
- ▶ make sure that the wire electrode does not touch any conductive or earthed parts (e.g. housing)

9 Press the torch trigger and start welding

Corrections during welding

To obtain the best possible welding results, the arc-force dynamic parameter will sometimes need to be adjusted.

1 Press the "Parameter selection" button to select the arc-force dynamic parameter

2 Use the adjusting dial to set the desired arc-force dynamic value

The welding parameter value is shown in the digital display located above it.

MMA welding

Safety



WARNING!

Operating the equipment incorrectly can cause serious injury and damage.

Do not use the functions described until you have thoroughly read and understood the following documents:

- ▶ these operating instructions
 - ▶ all the operating instructions for the system components, especially the safety rules
-



WARNING!

An electric shock can be fatal.

If the machine is plugged into the mains electricity supply during installation, there is a high risk of very serious injury and damage. Do not carry out any work on the device unless

- ▶ the mains switch is in the "O" position,
 - ▶ the device is unplugged from the mains.
-

Preparation

- 1 Move the mains switch to the "O" position
- 2 Disconnect the mains plug

IMPORTANT!

Check the rod electrode packaging to determine whether the rod electrodes are for (+) or (-) welding.

- 3 Plug the grounding (earthing) cable into the (-) or (+) current socket (depending upon which type of electrode is to be used) and latch it by turning it clockwise
 - 4 Use the other end of the grounding (earthing) cable to establish a connection to the workpiece
 - 5 Plug the electrode holder cable bayonet plug into the free current socket with the opposite polarity, according to the type of electrode, and turn it clockwise to latch it in place
 - 6 Plug in the mains plug
-


MMA welding



CAUTION!

Risk of injury and damage from electric shock.

As soon as the mains switch is in the "I" position, the rod electrode in the electrode holder is live. Make sure that the rod electrode does not touch any persons or electrically conducting or earthed parts (e.g. the housing, etc.).

- 1 Move the mains switch to the "I" position: all the indicators on the control panel will briefly light up
- 2 Press the "Process" button to select the MMA welding process:

The welding voltage is connected to the welding socket with a 3-second time lag.

IMPORTANT!

Under certain circumstances, welding parameters that have been set on a system component control panel (TR 2000 and TR 3000) may not be changed on the control panel of the power source.

-
- 3 Press the "Parameter selection" button to select the amperage parameter.
 - 4 Use the adjusting dial to set the desired amperage.
The amperage value is displayed in the left-hand digital display.

All welding parameter set values remain stored until the next time they are changed. This applies even if the power source is switched off and on again in the meantime.

- 5 Start welding

To display the actual welding current during welding:

- Press the "Parameter selection" button to select the welding current parameter
- The actual welding current is shown on the digital display during welding.

Corrections during welding

To obtain the best possible welding results, the arc-force dynamic parameter will sometimes need to be adjusted.

- 1 Press the "Parameter selection" button to select the arc-force dynamic parameter
- 2 Use the adjusting dial to set the desired arc-force dynamic value
The welding parameter value is shown in the digital display located above it.


HotStart function

To obtain optimum welding results, it will sometimes be necessary to adjust the HotStart function.

Advantages

- Improved ignition, even when using electrodes with poor ignition properties
- Better fusion of the base material during the start-up phase, meaning fewer cold-shut defects
- Largely prevents slag inclusions

For details on setting the available welding parameters, please refer to "Setup parameters", "Setup menu - level 2".



Legend

H_{ti} : Hot-current time,
 0 - 2 s, factory setting: 0.5 s
 H_{CU} : HotStart-current,
 100 - 200 %, factory setting 150 %
 I_H : Main current = set welding current

Function

During the specified hot-current time (H_{ti}), the welding current is increased to a certain value. This value (H_{CU}) is higher than the selected welding current (I_H).

Anti-stick function

As the arc becomes shorter, the welding voltage may drop so far that the rod electrode will tend to "stick". This may also cause "burn-out" of the rod electrode.

Electrode burn-out is prevented by activating the anti-stick function. If the rod electrode begins to stick, the power source immediately switches the welding current off. After the rod electrode has been detached from the workpiece, the welding operation can be continued without difficulty.

The anti-stick (A_{st}) function can be activated and deactivated in the Setup parameters in "Setup menu: level 2".

Saving and retrieving operating points

General

The "Save" buttons allow up to 5 operating points to be saved. Every operating point matches the settings on the control panel.

IMPORTANT! Setup parameters are not saved at this time.

Saving operating points

1 Press and hold one of the "Save" buttons to save the current settings on the control panel, e.g.:



- The left indicator displays "Pro"
- After a short time, the left indicator switches to the original value

2 Release the "Save" button

Retrieving operating points

1 To retrieve saved settings, press the corresponding "Save" button briefly, e.g.:



- The control panel will show the saved settings

Deleting operating points

1 Press and hold the relevant "Save" button to delete the memory content of that "Save" button, e.g.:



- The left indicator displays "Pro"
- After a short time, the left indicator switches to the original value

2 Keep the "Save" button held down

- The left display shows "CLr".
- After a while, both displays show "---"

3 Release the "Save" button

Retrieving operating points on the Up/Down welding torch

One of the "Save" buttons on the control panel must be pressed to retrieve the saved settings using the Up/Down welding torch.

1 Press one of the "Save" buttons on the control panel, e.g.:



- The control panel will show the saved settings

The "Save" buttons can now be selected using the buttons on the Up/Down welding torch. Vacant "Save" buttons are skipped.


In addition to the "Save" button number lighting up, a number is displayed directly on the Up/Down welding torch:




Number 1



Number 2



Number 3



Number 4



Number 5





Setup settings

Setup menu

General remarks The Setup menu provides simple access to expert knowledge in the power source and to additional functions. The Setup menu can be used to make simple adjustments of the parameters to suit the various job settings.





Configuring the setup parameters Configuring the setup parameters is described here with reference to the "MIG/MAG standard synergic welding" process. The procedure for changing other setup parameters is identical.

Accessing the Setup menu




-  **1** Use the "Process" button to select the "MIG/MAG standard synergic welding" process
-  **2** Press and hold the "Mode" button
-  **3** Press the "Process" button
-  **4** Release the "Mode" and "Process" buttons

The control panel is now in the Setup menu for the "MIG/MAG standard synergic welding" process - the last setup parameter that was selected is displayed.

Changing welding parameters

-  **5** Select the required setup parameter using the "Mode" and "Process" buttons or the left-hand adjusting dial
- 
-  **6** Change the value of the setup parameter using the "Parameter selection" buttons or the right-hand adjusting dial
- 

Exiting the Setup menu

-  **7** Press and hold the "Mode" button
-  **8** Press the "Process" button
-  **9** Release the "Mode" and "Process" buttons

**Setup parameters
for MIG/MAG
standard manual
welding**

"Min." and "max." are used for setting ranges that differ according to power source, welding program, etc.

GPr Gas pre-flow time

Unit: s
Setting range: 0 - 9.9
Factory setting: 0.1

GPo Gas post-flow time

Unit: s
Setting range: 0 - 9.9
Factory setting: 0.5

Fdi Feeder inching speed

Unit: m/min (ipm)
Setting range: 1 - max. (39.37 - max.)
Factory setting: 10 (393.7)

SL Slope (special 4-step mode only)

Unit: s
Setting range: 0 - 9.9
Factory setting: 0.1

I-S I (current) - Starting - Starting current (special 4-step mode only)

Unit: % (of welding current)
Setting range: 0 - 200
Factory setting: 100

I-E I (current) - End: Final current (special 4-step mode only)

Unit: % (of welding current)
Setting range: 0 - 200
Factory setting: 50

t-S t (time) - Starting - Starting current duration (special 4-step mode only)

Unit: s
Setting range: OFF, 0.1 - 9.9
Factory setting: OFF

t-S t (time) - End: Final current duration (special 4-step mode only)

Unit: s
Setting range: OFF, 0.1 - 9.9
Factory setting: OFF

bbc burn-back time correction

Wire burn-back effect due to wire withdrawal at end of welding
Unit: -
Setting range: 0 - 20
Factory setting: 0

IGC Ignition current

Unit: A
Setting range: 100 - 650
Factory setting: 500

Ito Ignition time-out - length of wire that is fed before the safety cut-out is triggered

Unit: mm (in.)

Setting range: OFF, 5 - 100 (OFF, 0.2 - 3.94)

Factory setting: OFF

NOTE!

The "Ignition time-out" function (ito) is a safety function.

The length of wire that is fed before the safety cut-out trips may differ from the preset wire length, particularly when the wire is being fed at high speeds.

Spt Spot time - spot / stitch welding time

Unit: s

Setting range: OFF, 0.1 - 5

Factory setting: OFF

SPb Spot break - stitch pause time

Unit: s

Setting range: OFF, 0.1 - 10 (in 0.1 s increments)

Factory setting: OFF

FAC Factory - reset power source to factory settings

Press and hold down one of the "Parameter selection" buttons for 2 s to restore the factory settings

- when "PrG" appears on the digital display, the power source has been reset

IMPORTANT! When the power source is reset, all personal settings in the Setup menu are lost.

Operating points that were saved using the "Save" buttons are retained when the power source is reset. The functions in the second level of the Setup menu (2nd) are also not deleted. Exception: Ignition time-out function parameter (ito).

2nd Second level of the Setup menu (see "Setup menu - level 2")

**Setup parameters
for MIG/MAG
standard syner-
gic welding**

"Min." and "max." are used for setting ranges that differ according to power source, welding program, etc.

GPr Gas pre-flow time
Unit: s
Setting range: 0 - 9.9
Factory setting: 0.1

GPo Gas post-flow time
Unit: s
Setting range: 0 - 9.9
Factory setting: 0.1

SL Slope
Unit: s
Setting range: 0 - 9.9
Factory setting: 0.1

I-S I (current) - Starting current
Unit: % (of welding current)
Setting range: 0 - 200
Factory setting: 100

I-E I (current) - End: Final current
Unit: % (of welding current)
Setting range: 0 - 200
Factory setting: 50

t-S t (time) - Starting - Starting current duration
Unit: s
Setting range: OFF, 0.1 - 9.9
Factory setting: OFF

t-E t (time) - End: Final current time
Unit: s
Setting range: OFF, 0.1 - 9.9
Factory setting: OFF

Fdi Feeder inching - feeder inching speed
Unit: m/min (ipm.)
Setting range: 1 - max. (39.37 - max.)
Factory setting: 10 (393.7)

bbc burn-back time correction -
Burn back effect due to wire withdrawal at end of welding
Unit: s
Setting range: Aut, 0 - 0.3
Factory setting: Aut

Ito Ignition time-out function - Length of wire that is fed before the safety cut-out is triggered
Unit: mm (in.)
Setting range: Off, 5 - 100 (Off, 0.2 - 3.94)
Factory setting: OFF

The "Ignition time-out" function (ito) is a safety function.

The length of wire that is fed before the safety cut-out trips may differ from the preset wire length, particularly when the wire is being fed at fast wire feed speeds.

The "Ignition time-out" function (ito) is explained in the "Special functions and options" section.

SPT Spot time - spot / stitch welding time

Unit: s

Setting range: OFF, 0.1 - 5

Factory setting: OFF

SPb Spot break - stitch pause time

Unit: s

Setting range: OFF, 0.1 - 10 (in 0.1 s increments)

Factory setting: OFF

FAC Factory - reset power source to factory settings

Press and hold down one of the "Parameter selection" buttons for 2 s to restore the factory settings

- when "PrG" appears on the digital display, the power source has been reset.

IMPORTANT! When the power source is reset, all personal settings in the Setup menu are lost.

When the power source is reset, operating points that were saved using the "Save" buttons are not deleted, but are retained in the memory. The functions in the second level of the Setup menu (2nd) are also not deleted. Exception: Ignition time-out function parameter (ito).

2nd Second level of the Setup menu (see "Setup menu - level 2")

**Setup parameters
for MMA welding**

IMPORTANT! If you reset the power source using the FAC factory setup parameter, the hot-current time (Hti) and HotStart current (HCU) setup parameters are also reset.

HCU HotStart current

Unit: %

Setting range: 100 - 200

Factory setting: 150

Hti Hot-current time

Unit: s

Setting range: 0 - 2.0

Factory setting: 0.5

Ast Anti-Stick

Unit: -

Setting range: On, OFF

Factory setting: OFF

FAC Factory - Reset power source to factory setting

Press and hold down one of the "Parameter selection" buttons for 2 s to restore the factory settings

- when "PrG" appears on the digital display, the power source has been reset.

IMPORTANT! When the power source is reset, all personal settings are lost.

When the power source is reset, operating points that were saved using the "Save" buttons are not deleted, but are retained in the memory. The functions in the second level of the Setup menu (2nd) are also not deleted. Exception: Ignition time-out function parameter (ito).

2nd Second level of the Setup menu (see "Setup menu - level 2")

Setup menu - Level 2

Restrictions

In conjunction with the level 2 of the Setup menu, the following restrictions occur:

Level 2 of the Setup menu cannot be selected:

- during welding
- if the "Gas test" function is active
- if the "Wire threading" function is active
- if the "Wire withdrawal" function is active
- if the "Blow through" function is active

If level 2 of the Setup menu is selected, the following functions are not available, even in robot mode:

- Welding start-up - the "Power source ready" signal will not be emitted
- Gas testing
- Threading the wire
- Wire withdrawal
- Blow-through

Configuring the setup parameters

Accessing the Setup menu



1 Press and hold the "Mode" button



2 Press the "Process" button



3 Release the "Mode" and "Process" buttons

The control panel is now in the Setup menu - the last setup parameter that was selected is displayed.

Selecting the "2nd" parameter



4 Use the "Mode" and "Process" buttons or the left-hand adjusting dial to select the "2nd" setup parameter



Accessing the Level 2 Setup menu



5 Press and hold the "Mode" button



6 Press the "Process" button



7 Release the "Mode" and "Process" buttons

Changing welding parameters



8 Use the "Mode" and "Process" buttons or the left-hand adjusting dial to select the required setup parameter



9 Change the value of the setup parameter using the "Parameter selection" buttons or the right-hand adjusting dial



Exiting the Level 2 Setup menu



10 Press and hold the "Mode" button



11 Press the "Process" button



12 Release the "Mode" and "Process" buttons

Exiting the Setup menu



13 Press and hold the "Mode" button



14 Press the "Process" button



15 Release the "Mode" and "Process" buttons

**Parameters for
MIG/MAG welding
in the Setup menu
level 2**

| | |
|------------|---|
| C-C | <p>Cooling unit Control (only with connected cooling unit)</p> <p>Unit: - Setting range: Aut, On, OFF Factory setting: Aut</p> <p>Aut: The cooling unit cuts out after a 2-minute welding off-time.</p> <p>IMPORTANT! If the coolant temperature and flow monitoring options have been installed in the cooling unit, the cooling unit cuts out as soon as the return-flow temperature drops below 50 °C, but at the earliest after a 2-minute welding off-time.</p> <p>On: The cooling unit is always ON OFF: The cooling unit is always OFF</p> <p>IMPORTANT! If the FAC welding parameter is used, the C-C parameter is not reset to the factory setting. If the MMA welding process is selected, the cooling unit is always switched off, even if the switch is in the "On" position.</p> |
| C-t | <p>Cooling Time (only with connected cooling unit)</p> <p>Time from when flow monitoring is triggered until the "no H2O" service code is output. For example, if there are air bubbles in the cooling system, the cooling unit will not cut out until the end of this preset time.</p> <p>Unit: s Setting range: 5 - 25 Factory setting: 10</p> <p>IMPORTANT! Every time the power source is switched on, the cooling unit carries out a test run for 180 seconds.</p> |
| SEt | <p>Setting - country-specific setting (Standard/USA) ... Std / US</p> <p>Unit: - Setting range: Std, US (Standard / USA) Factory setting: Standard version: Std (measurements: cm / mm) USA version: US (measurements: inches)</p> |
| r | <p>r (resistance) - welding circuit resistance (in mOhm) see "Measuring welding circuit resistance r"</p> |
| L | <p>L (inductivity) - welding circuit inductivity (in microhenry) see "Displaying welding circuit inductivity L"</p> |

EnE Real Energy Input – electrical energy of the arc relative to the welding speed

Unit: kJ

Setting range: ON / OFF

Factory setting: OFF

Since the full range of values (1 kJ - 99999 kJ) cannot be displayed on the three-digit display, the following display format has been selected:

Value in kJ / indicator on display:

1 to 999 / 1 to 999

1000 to 9999 / 1.00 to 9.99 (without "ones" digit, e.g. 5270 kJ -> 5.27)

10000 to 99999 / 10.0 to 99.9

(without "ones" and "tens" digits, e.g. 23580 kJ -> 23.6)

ALC Arc Length Correction - correction of the arc length via the welding voltage

Setting range: ON / OFF

Factory setting: OFF

The arc length depends on the welding voltage. The welding voltage can be adjusted to suit individual needs in Synergic operation.

If the ALC parameter is set to "OFF", the welding voltage cannot be adjusted. The welding voltage is automatically determined by the selected welding current or wire speed. If the arc length correction is adjusted, the voltage changes, but the welding current and wire speed remain the same. When setting the arc length correction using the adjusting dial, the left display is used for the correction value of the arc length. The welding voltage value on the right display changes simultaneously. Afterwards the left display shows the original value, e.g. welding current.

Parameters for manual metal arc (MMA) welding in the Setup menu level 2

r r (resistance) - welding circuit resistance (in mOhm)
see "Measuring welding circuit resistance r"

L L (inductivity) - welding circuit inductivity (in microhenry)
see "Displaying welding circuit inductivity L"

Measuring welding circuit resistance r

General

Measuring the welding circuit resistance r makes it possible to have a constant welding result at all times, even with hosepacks of different lengths. The welding voltage at the arc is then always precisely regulated, regardless of the length and cross-sectional area of the hosepack. The use of arc length correction is no longer required.

The calculated welding circuit resistance is shown on the display.

r = welding circuit resistance in milliohm (mOhm)

If the welding circuit resistance r has been measured correctly, the set welding voltage will correspond exactly to the welding voltage at the arc. If you manually measure the voltage on the output jacks of the power source, this voltage will be higher than the welding voltage at the arc - that is, higher by the same amount as the voltage drop of the hosepack.

NOTE!

The welding circuit resistance r depends on the hosepack used:

- ▶ If the length or cross-sectional area of the hosepack has changed, measure the welding circuit resistance r again
- ▶ Measure the welding circuit resistance for every welding process separately with the appropriate welding power-leads

Measure the welding circuit resistance r

NOTE!

In order to obtain good welding results, it is essential to measure the welding circuit resistance correctly.

Make sure that the contact between the earthing clamp and the workpiece is on a cleaned workpiece surface.

- 1 Establish a grounding (earthing) connection to the workpiece
- 2 Accessing the Level 2 (2nd) Setup menu
- 3 Select parameter "r"
- 4 Remove the gas nozzle from the welding torch
- 5 Screw on the contact tip

NOTE!

Make sure that the contact between the contact tip and the workpiece is on a cleaned workpiece surface.

- 6 Place the contact tip flush against the workpiece surface
- 7 Press the torch trigger briefly
 - The welding circuit resistance is calculated. "run" is shown on the display during the measurement.

The measurement is finished when the welding circuit resistance is shown on the display in mOhm (e.g. 11.4).

8 Fit the gas nozzle back onto the welding torch

Displaying welding circuit inductivity L

General

Laying of the hosepacks has a significant effect on welding circuit inductivity and therefore affects the welding process. It is important to lay the hosepacks correctly in order to obtain the best possible welding result.

Displaying welding circuit inductivity L


The setup parameter "L" is used to display the most recently calculated welding circuit inductivity. The welding circuit inductivity is calibrated at the same time as the welding circuit resistance r is calculated. Detailed information can be found in the "Measuring welding circuit resistance r " section.

- 1 Access the setup menu level 2 (2nd)
- 2 Select parameter "L"

The most recently calculated welding circuit inductivity L is shown on the right-hand digital display.

L ... Welding circuit inductivity (in microhenry)

Laying the hosepacks correctly



Troubleshooting and maintenance

Troubleshooting

General

The devices are equipped with an intelligent safety system. This means that to a large extent it has been possible to dispense with melting-type fuses. Melting-type fuses therefore no longer need to be replaced. After a possible malfunction has been remedied, the device is ready for use again.

Safety



WARNING!

Work that is carried out incorrectly can cause serious injury or damage.

The following activities must only be carried out by trained and qualified personnel. Observe the safety rules in the power source operating instructions.



WARNING!

An electric shock can be fatal.

Before opening the unit

- ▶ Turn the mains switch to the "O" position
 - ▶ Unplug the device from the mains
 - ▶ Put up an easy-to-understand warning sign to stop anybody inadvertently switching it back on again
 - ▶ Using a suitable measuring device, check to make sure that electrically charged components (e.g. capacitors) have discharged
-



CAUTION!

Inadequate PE conductor connections can cause serious injury and damage.

The housing screws provide a suitable PE conductor connection for earthing (grounding) the housing and must NOT be replaced by any other screws which do not provide a reliable PE conductor connection.

Fault diagnosis

Make a note of the serial number and configuration of the device and contact our After-Sales Service team with a detailed description of the error, if

- errors occur that are not listed below
 - the troubleshooting measures listed are unsuccessful
-

Power source has no function

Mains switch is on, but indicators are not lit up

Cause: There is a break in the mains lead; the mains plug is not plugged in

Remedy: Check the mains lead, ensure that the mains plug is plugged in

Cause: Mains socket or mains plug faulty

Remedy: Replace faulty parts

Cause: Mains fuse protection

Remedy: Change the mains fuse protection

Nothing happens when the torch trigger is pressed

Power source mains switch is ON and indicators are lit up

Cause: Only for welding torches with an external control plug: The control plug is not plugged in

Remedy: Plug in the control plug

Cause: Welding torch or welding torch control line is faulty

Remedy: Replace welding torch

Nothing happens when the torch trigger is pressed

Power source mains switch is on, power source ON indication is lit up on the power source, indications on wire-feed unit are not lit up

Cause: The interconnecting hosepack is faulty or not connected properly

Remedy: Check interconnecting hosepack

No welding current

Mains switch is on, one of the overtemperature service codes "to" is displayed. Detailed information on the service codes "to0" to "to6" can be found in the section "Displayed service codes".

Cause: Overload

Remedy: Take the duty cycle into account

Cause: Thermostatic safety cut-out has tripped

Remedy: Wait until the power source automatically comes back on after the end of the cooling phase

Cause: Limited supply of cooling air

Remedy: Remove air filter on the rear of the housing from the side and clean. Ensure that the cooling air ducts are accessible.

Cause: The fan in the power source is faulty

Remedy: Contact After-Sales Service

No welding current

Mains switch is ON and indicators are lit up

Cause: Grounding (earthing) connection is incorrect

Remedy: Check the grounding (earthing) connection for correct polarity

Cause: There is a break in the power cable in the welding torch

Remedy: Replace the welding torch

No protective gas shield

All other functions are OK

- Cause: Gas cylinder is empty
Remedy: Change the gas cylinder
- Cause: The gas pressure regulator is faulty
Remedy: Replace the gas pressure regulator
- Cause: Gas hose is not fitted or is damaged
Remedy: Fit or change the gas hose
- Cause: Welding torch is faulty
Remedy: Change the welding torch
- Cause: Gas solenoid valve is faulty
Remedy: Contact After-Sales Service

Irregular wire feed speed

- Cause: Braking force has been set too high
Remedy: Loosen the brake
- Cause: Hole in the contact tip is too narrow
Remedy: Use a suitable contact tip
- Cause: Faulty inner liner in welding torch
Remedy: Check the inner liner for kinks, dirt, etc. and replace if necessary
- Cause: The feed rollers are not suitable for the wire electrode being used
Remedy: Use suitable feed rollers
- Cause: Feed rollers have the wrong contact pressure
Remedy: Optimise the contact pressure

Wirefeed problems

when using applications with long welding torch hosepacks

- Cause: Incorrect arrangement of welding torch hosepack
Remedy: Arrange the welding torch hosepack in as straight a line as possible, avoiding bends

Welding torch becomes very hot

- Cause: The specification of the welding torch is inadequate
Remedy: Observe the duty cycle and loading limits
- Cause: Only on water-cooled systems: Inadequate coolant flow
Remedy: Check coolant level, coolant flow, for coolant contamination, etc. For further information refer to the cooling unit operating instructions.
-

Poor weld properties

Cause: Incorrect welding parameters

Remedy: Check the settings

Cause: Poor ground earth connection

Remedy: Ensure good contact to workpiece

Cause: Inadequate or no protective gas shield

Remedy: Check the pressure regulator, gas hose, gas solenoid valve, torch gas connection, etc.

Cause: Welding torch is leaking

Remedy: Change the welding torch

Cause: Wrong contact tip, or contact tip is worn out

Remedy: Replace the contact tip

Cause: Wrong wire alloy or wrong wire diameter

Remedy: Check the wire electrode that has been inserted

Cause: Wrong wire alloy or wrong wire diameter

Remedy: Check weldability of the base material

Cause: The shielding gas is not suitable for this wire alloy

Remedy: Use the correct shielding gas

Displayed service codes

If an error message that is not described here appears on the displays, proceed as follows to resolve the problem:

- 1 Turn the power source mains switch to the "O" position
- 2 Wait 10 seconds
- 3 Move the mains switch to the I position

If the error occurs again despite several attempts to eliminate it, or if the troubleshooting measures listed here are unsuccessful.

- 1 Make a note of the error message displayed
- 2 Note down the configuration of the power source
- 3 Contact our After-Sales Service team with a detailed description of the error

ESr | 20

Cause: The selected cooling unit is not compatible with the power source

Remedy: Connect compatible cooling unit

Cause: An invalid welding process was called up on the robot interface (no. 37) or an empty flag was selected (no. 32)

Remedy: Call up a valid welding process or select assigned "Save" button

ELn | 8

Cause: The connected wire-feed unit is not supported

Remedy: Connect supported wire-feed unit

ELn | 12

Cause: Different control panels for selecting materials are in the system

Remedy: Connect similar control panels to select materials

ELn | 13

Cause: Invalid change of welding process during welding

Remedy: During welding do not carry out any illegal change of the welding process, re-set error message by pressing any button

ELn | 14

Cause: More than only one robot interface is connected

Remedy: Only one robot interface may be connected, check the system configuration

ELn | 15

Cause: More than only one remote control unit is connected

Remedy: Only one remote control unit may be connected, check the system configuration

Err | IP

Cause: The control unit of the power source has detected a primary overvoltage

Remedy: Check mains voltage, if the service code still remains, switch off the power source, wait for 10 seconds and then switch the power source on again, if the error keeps recurring, contact After-Sales Service

Err | PE

Cause: The earth current watchdog has triggered the safety cut-out of the power source.

Remedy: Switch off the power source
Place the power source on an insulating surface
Connect the grounding (earthing) cable to a section of the workpiece that is closer to the arc
Wait for 10 seconds and then switch the power source on again

If you have tried this several times and the error keeps recurring, contact After-Sales Service

Err | Ur

Cause: If the VRD option is available, the open circuit voltage limit of 35 V has been exceeded.

Remedy: Switch off power source
Wait for 10 seconds and then switch the power source on again

no | UrL

Cause: The VRD option has tripped too early.

Remedy: Check whether all welding power-leads and control lines are connected.

Switch off the power source
Wait 10 seconds and switch the power source back on again

If the error occurs again - contact After Sales Service.

E-Stop

Cause: "External stop" has tripped

Remedy: Remedy the event that triggered the external stop

-St | oP-

Cause: At the robot interface the flag was not deleted by the robot

Remedy: Delete the signal robot ready at the robot interface

PHA | SE

Cause: Phase failure

with TSt 2500c / TSt 2700c in particular:

If the failure occurs during welding, the welding operation stops.

with TSt 2500c MV / TSt 2700c MV in particular:

A single-phase operation with limited power is possible:

When switching on the power source, "PHA | SE1" is displayed in order to show that a power reduction will be in effect.

If a change in supply from three-phase to single-phase occurs during welding (display: "PHA | SE1") or from single-phase to three-phase (display: "PH | ASE 3"), the welding operation stops.

Remedy: Check the mains fuse, mains cable and mains plug.

Switch off the power source, wait 10 seconds and switch the power source back on again.

PHA | SE1

Cause: The power source is operated in single-phase mode.

Remedy: -

PHA | SE3

Cause: The power source is operated in 3-phase mode

Remedy: -

Err | 51

Cause: Mains undervoltage: The mains voltage has fallen below the tolerance range

Remedy: Check the mains voltage, if the error keeps recurring, contact the After-Sales Service

Err | 52

Cause: Mains overvoltage: The mains voltage has risen above the tolerance range

Remedy: Check the mains voltage, if the error keeps recurring, contact the After-Sales Service

EFd 5

Cause: Incorrect wire-feed unit connected

Remedy: Connect correct wire-feed unit

EFd 8

Cause: Overtemperature on the wire-feed unit

Remedy: Allow wire-feed unit to cool down

EFd | 81, EFd | 83

Cause: Fault in the wire feed system (overcurrent in wire-feed unit drive)

Remedy: Arrange the hosepack in as straight a line as possible; check that there are no kinks or dirt in the inner liner; check the contact pressure on the 4 roller drive

Cause: Wire-feed unit motor is sticking or defective

Remedy: Check the wire-feed unit motor or contact After-Sales Service

to0 | xxx

Note: xxx stands for a temperature value

Cause: Overtemperature in the primary circuit of the power source

Remedy: Allow power source to cool down, check air filter and clean if necessary, check that fan is on

to1 | xxx

Note: xxx stands for a temperature value

Cause: Overtemperature on the booster located in the power source

Remedy: Allow power source to cool down, check air filter and clean if necessary, check that fan is on

to2 | xxx

Note: xxx stands for a temperature value

Cause: Overtemperature in the secondary circuit of the power source

Remedy: Allow power source to cool down, check that fan is on

to3 | xxx

Remark: xxx stands for a temperature value

Cause: Overtemperature in the wire-feed unit motor

Remedy: Allow wire-feed unit to cool down

to4 | xxx

Remark: xxx stands for a temperature value

Cause: Overtemperature in welding torch

Remedy: Allow welding torch to cool down

to5 | xxx

Note: xxx stands for a temperature value

Cause: Overtemperature in cooling unit

Remedy: Allow cooling unit to cool down, check that fan is on

to6 | xxx

Note: xxx stands for a temperature value

Cause: Overtemperature at the transformer of the power source

Remedy: Allow power source to cool down, check air filter and clean if necessary, check that fan is on

to7 | xxx

Note: xxx stands for a temperature value

Cause: Overtemperature in the power source

Remedy: Allow power source to cool down, check air filter and clean if necessary, check that fan is on

toF | xxx

Cause: With the TSt 2500c MV / TSt 2700c MV power source operating in single-phase mode, the power source safety cut-out has tripped in order to prevent the mains fuse from tripping.

Remedy: After a pause in welding of around 60 s, the message disappears and the power source is operational again.

tu0 | xxx

Remark: xxx stands for a temperature value

Cause: Undertemperature in the power source primary circuit

Remedy: Place power source in a heated room and allow to warm up

tu1 | xxx

Note: xxx stands for a temperature value

Cause: Undertemperature on the booster located in the power source

Remedy: Place power source in a heated room and allow it to warm up

tu2 | xxx

Remark: xxx stands for a temperature value

Cause: Undertemperature in the power source secondary circuit

Remedy: Place power source in a heated room and allow to warm up

tu3 | xxx

Remark: xxx stands for a temperature value

Cause: Undertemperature in the wire-feed unit motor

Remedy: Place wire-feed unit in a heated room and allow to warm up

tu4 | xxx

Remark: xxx stands for a temperature value

Cause: Undertemperature in the welding torch

Remedy: Place welding torch in a heated room and allow to warm up

tu5 | xxx

Remark: xxx stands for a temperature value

Cause: Undertemperature in the cooling unit

Remedy: Place cooling unit in a heated room and allow to warm up

tu6 | xxx

Note: xxx stands for a temperature value

Cause: Undertemperature on the transformer of the power source

Remedy: Place power source in a heated room and allow it to warm up

tu7 | xxx

Note: xxx stands for a temperature value

Cause: Undertemperature in the power source

Remedy: Place power source in a heated room and allow it to warm up

no | H2O

Cause: Coolant flow rate too low

Remedy: Check coolant flow rate and cooling unit, including cooling circuit (for minimum coolant flow, see "Technical Data" section in the device operating instructions)

hot | H2O

Cause: The coolant temperature is too high

Remedy: Allow cooling unit and cooling circuit to cool down, until "hot | H2O" is no longer displayed. Open the cooling unit and clean the cooler, check fan is working properly. Robot interface or field bus coupler: before resuming welding, set the "Source error reset" signal.

no | Prg

Cause: No preconfigured program has been selected

Remedy: Select a configured program

no | IGn

Cause: "Ignition time out" function is active; no current started flowing before the length of wire specified in the set-up menu had been fed. The power source safety cut-out has tripped.

Remedy: Shorten the wire end; press the torch trigger again; clean the surface of the workpiece; if necessary, increase the wire length until the safety cut-out trips in "Set-up menu: Level 2".

EPG | 17

Cause: The welding program selected is invalid

Remedy: Select valid welding program

EPG | 29

Cause: The required wire-feed unit is not available for the selected characteristic

Remedy: Connect correct wire-feed unit, check plug connections for the hosepack

EPG | 35

Cause: Measurement of the welding circuit resistance "r" failed

Remedy: Check grounding cable, current cable or hosepack and replace if necessary, recalculate welding circuit resistance "r"

no | GAS

Cause: The Gas watchdog option has detected that there is no gas pressure

Remedy: Connect a new gas cylinder or open the gas cylinder valve/pressure regulator, restart "Gas watchdog" option, reset "no | GAS" error message by pressing any button.

Care, maintenance and disposal

General

Under normal operating conditions, the welding system requires only a minimum of care and maintenance. However, it is vital to observe some important points to ensure the welding system remains in a usable condition for many years.

Safety



WARNING!

An electric shock can be fatal.

Before opening the device

- ▶ Turn the mains switch to the "O" position
 - ▶ Unplug the machine from the mains
 - ▶ Prevent it from being switched on again
 - ▶ Using a suitable measuring instrument, check to make sure that electrically charged components (e.g. capacitors) have discharged
-



WARNING!

Work that is carried out incorrectly can cause serious injury and damage.

The following activities must only be carried out by trained and qualified personnel. All instructions in the section headed "Safety rules" must be observed.

At every start-up

- Check mains plug, mains cable, welding torch, interconnecting hosepack and grounding (earthing) connection for damage
- Check that there is a gap of 0.5 m (1 ft. 8 in.) all around the device to ensure that cooling air can flow and escape unhindered

NOTE!

Air inlets and outlets must never be covered, not even partially.

If necessary

If a lot of dust has accumulated:

TSt 2500c / TSt 2700c

- Remove the fin element on the rear of the housing
- Detach the air filter located behind and clean

TSt 3500c

- Remove the air filter on the rear of the housing from the side and clean
-

Every 2 months



CAUTION!

Risk of damage.

The air filter must only be fitted when dry.

- If required, clean air filter using dry compressed air or by washing it.

-
- Every 6 months**
- Dismantle device side panels and clean inside of device with dry reduced compressed air

NOTE!

Risk of damage to electronic components.

Do not bring air nozzle too close to electronic components.

- If a lot of dust has accumulated, clean the cooling air ducts.

-
- Disposal**
- Dispose of in accordance with the applicable national and local regulations.

Technical data

Special voltages For devices designed for special voltages, the technical data on the rating plate applies.

For all machines with a permitted mains voltage of up to 460 V: The standard mains plug allows the user to operate with a mains voltage of up to 400 V. For mains voltages up to 460 V fit a mains plug permitted for such use or install the mains supply directly.

Explanation of the term "duty cycle"

Duty cycle (D.C.) is the proportion of time in a 10-minute cycle at which the device may be operated at its rated output without overheating.


NOTE!

The D.

C. values specified on the rating plate are based on an ambient temperature of 40°C. If the ambient temperature is higher, either the D.C. or output must be reduced accordingly.

Example: Welding at 150 A at 60% D.C.

- Welding phase = 60% of 10 minutes = 6 minutes
- Cooling phase = remaining time = 4 minutes
- After the cooling phase, the cycle begins anew.



If the device is to be continuously operated without stopping:

- 1 look in the technical data for a D.C. value of 100% for the reigning ambient temperature.
- 2 Reduce the output or amperage in line with this value so that the device can remain in use without observing a cooling phase.

TSt 2500c

| | | | | |
|--|-----------------------|--|--------|-------|
| Mains voltage (U_1) | 3 x | 380 V | 400 V | 460 V |
| Max. effective primary current ($I_{1\text{eff}}$) | | 7 A | 6.7 A | 5.6 A |
| Max. primary current ($I_{1\text{max}}$) | | 11.8 A | 11.2 A | 9.7 A |
| Mains fuse | | 16 A slow-blow | | |
| Mains voltage tolerance | | -15 / +15% | | |
| Mains frequency | | 50 / 60 Hz | | |
| Max. permitted mains impedance Z_{max} on PCC ¹⁾ | | 136 mOhm | | |
| Welding current range (I_2) | | | | |
| MIG / MAG | | 10 - 250 A | | |
| Rod electrode | | 10 - 250 A | | |
| Welding current at | 10 min / 40°C (104°F) | 40% | 60% | 100% |
| | | 250 A | 210 A | 170 A |
| Output voltage range according to standard characteristic (U_2) | | | | |
| MIG / MAG | | 14.5 - 34.5 V | | |
| Rod electrode | | 20.4 - 30.0 V | | |
| Open circuit voltage (U_0 peak / U_0 r.m.s) | | 41 V | | |
| Apparent power | at 400 V AC | 7,76 kVA | | |
| Protection class | | IP 23 | | |
| Insulation class | | B | | |
| Overvoltage category | | III | | |
| Pollution level according to IEC60664 | | 3 | | |
| Safety symbols | | S, CE, CSA | | |
| Efficiency at 170 A and 22.5 V | | 88% | | |
| Dimensions l x w x h | | 687 x 276 x 445 mm 27.1 x 10.9 x 17.5 in. | | |
| Weight | | 30 kg 66.1 lb. | | |
| Max. shielding gas pressure | | 7 bar 101.49 psi | | |
| Wire feed speed | | 1 - 25 m/min 40 - 980 ipm | | |
| Wire drive | | 4-roller drive | | |
| Wire diameter | | 0.8 - 1.6 mm 0.03 - 0.06 in. | | |
| Wirespool diameter | | max. 300 mm max. 11.81 in. | | |
| Wirespool weight | | max. 19.0 kg max. 41.9 lb. | | |

1) Interface to a 230 / 400 V, 50 Hz public grid

TSt 2500c MV

| | | | | |
|---|-----------------------|-------------------|----------|---------------|
| Mains voltage (U_1) | 3 x | 200 V | 230 V | |
| Max. effective primary current ($I_{1\text{eff}}$) | | 16.8 A | 14.5 A | |
| Max. primary current ($I_{1\text{max}}$) | | 26.0 A | 22.4 A | |
| Mains fuse protection (slow-blow) | | | 25 A | |
| Mains voltage (U_1) | 3 x | 380 V | 400 V | 460 V |
| Max. effective primary current ($I_{1\text{eff}}$) | | 8.6 A | 8.2 A | 7.1 A |
| Max. primary current ($I_{1\text{max}}$) | | 13.2 A | 12.6 A | 10.9 A |
| Mains fuse protection (slow-blow) | | | | 15 A |
| Mains voltage (U_1) | 1 x | 230 V | 240 V | 240 V |
| Max. effective primary current ($I_{1\text{eff}}$) | | 16.0 A | 15.0 A | 18.1 A |
| Max. primary current ($I_{1\text{max}}$) | | 22.3 A | 23.9 A | 28.1 A |
| Mains fuse protection (slow-blow) | | 16 A | 15 A | 20 A |
| Apparent power | | 5.13 kVA | 5.74 kVA | 5.98 kVA |
| Mains voltage tolerance | | | | -10 / +15 % |
| Mains frequency | | | | 50 / 60 Hz |
| Max. permitted mains impedance Z_{max} on PCC ¹⁾ | | | | 142 mOhm |
| Welding current range (I_2) | | | | |
| MIG / MAG | | | | 10 - 250 A |
| Rod electrode | | | | 10 - 250 A |
| Welding current range (I_2) in single-phase operation | | | | |
| MIG / MAG | | | | 10 - 220 A |
| Rod electrode | | | | 10 - 180 A |
| Welding current at | 10 min / 40°C (104°F) | 40% | 60% | 100% |
| $U_1 = 200 - 230$ V: | | 250 A | 200 A | 170 A |
| $U_1 = 380 - 460$ V: | | 250 A | 200 A | 170 A |
| Welding current in single-phase operation at | 10 min / 40°C (104°F) | 15% ²⁾ | | 100% |
| $U_1 = 230$ V: | Fuse 16 A | 180 A | | 145 A |
| Welding current in single-phase operation at | 10 min / 40°C (104°F) | 8% ²⁾ | | 100% |
| $U_1 = 240$ V: | Fuse 15 A | 180 A | | 145 A |
| Welding current in single-phase operation at | 10 min / 40°C (104°F) | 11% ²⁾ | | 100% |
| $U_1 = 240$ V: | Fuse 20 A | 200 A | | 160 A |
| Welding current in single-phase operation at | 10 min / 40°C (104°F) | 40% ²⁾ | | 100% |
| $U_1 = 240$ V: | Fuse 30 A | 220 A | | 160 A |
| Output voltage range according to standard characteristic (U_2) | | | | |
| MIG / MAG | | | | 14.5 - 34.5 V |
| Rod electrode | | | | 20.4 - 30.0 V |
| Output voltage range according to standard characteristic (U_2) in single-phase operation | | | | |

| | |
|--|--|
| MIG / MAG | 14.5- 24 V |
| Rod electrode | 20.4 - 27.2 V |
| Open circuit voltage (U_0 peak / U_0 r.m.s) | 42 V |
| Apparent power at 400 V AC | 7,76 kVA |
| Protection class | IP 23 |
| Insulation class | B |
| Overvoltage category | III |
| Pollution level according to IEC60664 | 3 |
| Safety symbols | S, CE, CSA |
| Efficiency at 220 A and 25.0 V | 87% |
| Dimensions l x w x h | 687 x 276 x 445 mm 27.1 x 10.9 x 17.5 in. |
| Weight | 30 kg 66.1 lb. |
| Max. shielding gas pressure | 7 bar 101.49 psi |
| Wire feed speed | 1 - 25 m/min 40 - 980 ipm. |
| Wire drive | 4-roller drive |
| Wire diameter | 0.8 - 1.6 mm 0.03 - 0.06 in. |
| Wirespool diameter | max. 300 mm max. 11.81 in. |
| Wirespool weight | max. 20.0 kg max. 44.1 lb. |

- 1) Interface to a 230 / 400 V, 50 Hz public grid
- 2) Detailed information concerning the duty cycle in single-phase operation is located in chapter „Installation and commissioning“, section „single-phase operation“

TSt 2700c

| | | | | |
|--|-----------------------|--------|--------|--|
| Mains voltage (U_1) | 3 x | 380 V | 400 V | 460 V |
| Max. effective primary current ($I_{1\text{eff}}$) | | 7 A | 6.6 A | 5.8 A |
| Max. primary current ($I_{1\text{max}}$) | | 13.1 A | 12.5 A | 10.8 A |
| Mains fuse | | | | 16 A slow-blow |
| Mains voltage tolerance | | | | -15 / +15% |
| Mains frequency | | | | 50 / 60 Hz |
| Max. permitted mains impedance Z_{max} on PCC ¹⁾ | | | | 136 mOhm |
| Welding current range (I_2) | | | | |
| MIG / MAG | | | | 10 - 270 A |
| Rod electrode | | | | 10 - 270 A |
| Welding current at | 10 min / 40°C (104°F) | 30% | 60% | 100% |
| | | 270 A | 210 A | 170 A |
| Output voltage range according to standard characteristic (U_2) | | | | |
| MIG / MAG | | | | 14.5 - 34.9 V |
| Rod electrode | | | | 20.4 - 34.9 V |
| Open circuit voltage (U_0 peak / U_0 r.m.s) | | | | 41 V |
| Apparent power | at 400 V AC | | | 8,66 kVA |
| Protection class | | | | IP 23 |
| Insulation class | | | | B |
| Overvoltage category | | | | III |
| Pollution level according to IEC60664 | | | | 3 |
| Safety symbols | | | | S, CE |
| Efficiency at 170 A and 22.5 V | | | | 88% |
| Dimensions l x w x h | | | | 687 x 276 x 445 mm 27.1 x 10.9 x 17.5 in. |
| Weight | | | | 30 kg 66.1 lb. |
| Max. shielding gas pressure | | | | 7 bar 101.49 psi |
| Wire feed speed | | | | 1 - 25 m/min 40 - 980 ipm |
| Wire drive | | | | 4-roller drive |
| Wire diameter | | | | 0.8 - 1.6 mm 0.03 - 0.06 in. |
| Wirespool diameter | | | | max. 300 mm max. 11.81 in. |
| Wirespool weight | | | | max. 19.0 kg max. 41.9 lb. |

1) Interface to a 230 / 400 V, 50 Hz public grid

TSt 2700c MV

| | | | | |
|--|-----------|-------------------|----------|---------------|
| Mains voltage (U_1) | 3 x | 200 V | 230 V | |
| Max. effective primary current ($I_{1\text{eff}}$) | | 13.3 A | 11.6 A | |
| Max. primary current ($I_{1\text{max}}$) | | 25.7 A | 22.41 A | |
| Mains fuse protection (slow-blow) | | | 25 A | |
| Mains voltage (U_1) | 3 x | 380 V | 400 V | 460 V |
| Max. effective primary current ($I_{1\text{eff}}$) | | 7 A | 6.6 A | 5.8 A |
| Max. primary current ($I_{1\text{max}}$) | | 13.1 A | 12.5 A | 10.8 A |
| Mains fuse protection (slow-blow) | | | | 15 A |
| Apparent power at 400 V AC | | | | 8,66 kVA |
| Mains voltage (U_1) | 1 x | 230 V | 240 V | 240 V |
| Max. effective primary current ($I_{1\text{eff}}$) | | 16.0 A | 15.0 A | 18.1 A |
| Max. primary current ($I_{1\text{max}}$) | | 22.3 A | 23.9 A | 28.1 A |
| Mains fuse protection (slow-blow) | | 16 A | 15 A | 20 A |
| Apparent power | | 5.13 kVA | 5.74 kVA | 5.98 kVA |
| Mains voltage tolerance | | | | -10 / +15 % |
| Mains frequency | | | | 50 / 60 Hz |
| Max. permitted mains impedance Z_{max} on PCC ¹⁾ | | | | 142 mOhm |
| Welding current range (I_2) | | | | |
| MIG / MAG | | | | 10 - 270 A |
| Rod electrode | | | | 10 - 270 A |
| Welding current range (I_2) in single-phase operation | | | | |
| MIG / MAG | | | | 10 - 220 A |
| Rod electrode | | | | 10 - 180 A |
| Welding current at 10 min / 40°C (104°F) | | 30% | 60% | 100% |
| $U_1 = 200 - 230$ V: | | 270 A | 200 A | 170 A |
| $U_1 = 380 - 460$ V: | | 270 A | 200 A | 170 A |
| Welding current in single-phase operation at 10 min / 40°C (104°F) | | 15% ²⁾ | | 100% |
| $U_1 = 230$ V: | Fuse 16 A | 180 A | | 145 A |
| Welding current in single-phase operation at 10 min / 40°C (104°F) | | 8% ²⁾ | | 100% |
| $U_1 = 240$ V: | Fuse 15 A | 180 A | | 145 A |
| Welding current in single-phase operation at 10 min / 40°C (104°F) | | 11% ²⁾ | | 100% |
| $U_1 = 240$ V: | Fuse 20 A | 200 A | | 160 A |
| Welding current in single-phase operation at 10 min / 40°C (104°F) | | 40% ²⁾ | | 100% |
| $U_1 = 240$ V: | Fuse 30 A | 220 A | | 160 A |
| Output voltage range according to standard characteristic (U_2) | | | | |
| MIG / MAG | | | | 14.5 - 34.3 V |
| Rod electrode | | | | 20.4 - 34.3 V |

| | |
|---|--|
| Output voltage range according to standard characteristic (U_2) in single-phase operation | |
| MIG / MAG | 14.5- 24 V |
| Rod electrode | 20.4 - 27.2 V |
| Open circuit voltage (U_0 peak / U_0 r.m.s) | |
| | 42 V |
| Protection class | |
| | IP 23 |
| Insulation class | |
| | B |
| Overvoltage category | |
| | III |
| Pollution level according to IEC60664 | |
| | 3 |
| Safety symbols | |
| | S, CE, CSA |
| Efficiency at 220 A and 25.0 V | |
| | 87% |
| Dimensions l x w x h | |
| | 687 x 276 x 445 mm 27.1 x 10.9 x 17.5 in. |
| Weight | |
| | 30 kg 66.1 lb. |
| Max. shielding gas pressure | |
| | 7 bar 101.49 psi |
| Wire feed speed | |
| | 1 - 25 m/min 40 - 980 ipm. |
| Wire drive | |
| | 4-roller drive |
| Wire diameter | |
| | 0.8 - 1.6 mm 0.03 - 0.06 in. |
| Wirespool diameter | |
| | max. 300 mm max. 11.81 in. |
| Wirespool weight | |
| | max. 20.0 kg max. 44.1 lb. |

- 1) Interface to a 230 / 400 V, 50 Hz public grid
- 2) Detailed information concerning the duty cycle in single-phase operation is located in chapter „Installation and commissioning“, section „single-phase operation“

TSt 3500c

| | | | | |
|---|-------------------------|--|--------|--------|
| Mains voltage (U_1) | 3 x | 380 V | 400 V | 460 V |
| Max. effective primary current (I_{1eff}) | | 15.2 A | 14.5 A | 12.7 A |
| Max. primary current (I_{1max}) | | 23.9 A | 23.0 A | 20.1 A |
| Mains fuse | | 35 A slow-blow | | |
| Mains voltage tolerance | | -10 / +15 % | | |
| Mains frequency | | 50/60 Hz | | |
| Cos phi (1) | | 0.99 | | |
| Max. permitted mains impedance Z_{max} at PCC ¹⁾ | | 77 mOhm | | |
| Recommended earth-leakage circuit breaker | | Type B | | |
| Welding current range (I_2) | | | | |
| MIG/MAG | | 10 - 350 A | | |
| Rod electrode | | 10 - 350 A | | |
| Welding current at | 10 min / 40 °C (104 °F) | 40 % | 60 % | 100 % |
| | | 350 A | 300 A | 250 A |
| Output voltage range according to standard characteristic (U_2) | | | | |
| MIG/MAG | | 14.5 - 38.5 V | | |
| Rod electrode | | 20.4 - 35.0 V | | |
| Open circuit voltage (U_0 peak / U_0 r.m.s) | | 60 V | | |
| Apparent power at 400 V AC | | 15.87 kVA | | |
| Degree of protection | | IP 23 | | |
| Type of cooling | | AF | | |
| Insulation class | | B | | |
| Overvoltage category | | III | | |
| Pollution level according to IEC60664 | | 3 | | |
| Safety symbols | | S, CE, CSA | | |
| Dimensions l x w x h | | 747 x 300 x 497 mm 29.4 x 11.8 x 19.6 in. | | |
| Weight | | 36 kg 79.4 lb. | | |
| Max. shielding gas pressure | | 5 bar 72.52 psi | | |
| Coolant | | Original Fronius | | |
| Wire feed speed | | 1 - 25 m/min 40 - 980 ipm | | |
| Wire drive | | 4-roller drive | | |
| Wire diameter | | 0.8 - 1.6 mm 0.03 - 0.06 in. | | |
| Wirespool diameter | | max. 300 mm max. 11.81 in. | | |
| Wirespool weight | | max. 19.0 kg max. 41.9 lb. | | |

| | |
|----------------------------------|-----------|
| Efficiency at 250 A and 26.5 V | 89 % |
| Max. noise emission (L_{WA}) | 72 dB (A) |

- 1) Interface to a 230/400 V, 50 Hz public grid

Quick reference

TransSteel Synergic

Quick Reference: English

1 Selecting the filler metal and shielding gas

| Wire | Steel dynamic | Steel | CO ₂ 100% | Gas |
|------|---------------|-------|-------------------------|-----|
| | Steel root | 0.30 | Ar +-8%CO ₂ | |
| | Flux | 0.35 | Ar +-18%CO ₂ | |
| | Basic Cored | 0.40 | Ar +-4%O ₂ | |
| | Metal Wire | 0.45 | Ar 100% | |
| | Self-shielded | 0.52 | | |
| | | 1/16 | | |
| | | | | |

SP ... Special Program

2 Selecting the process

MANUAL
SYNERGIC
STICK

MANUAL MIG/MAG standard manual
SYNERGIC Standard synergic
STICK Manual metal arc welding

3 Setting the mode

2 T 2-step mode
4 T 4-step mode
S 4 T Special 4-step mode

4 Setting the welding power

Sheet thickness
Welding current
Wire feed speed

- select desired parameter
- set desired parameter

- 1 - 5 Start-up sequence
- Follow operating instructions

5 Correcting parameters

Arc length correction
Welding voltage
Dynamic
Real Energy Input

- select desired parameter
- set desired parameter

Important if external system components are connected, some parameters can be modified on those components. The power source control panel is only for display purposes.

Keylock

activate / deactivate:

- < - press and hold
- < - press
- < - release

activated: „CLO | SEd“ display
deactivated: „OP | En“ display

Important! If the keylock is activated, only the parameter settings can be retrieved, as well as any assigned "Save" button provided that an assigned "Save" button was selected when the keylock was enabled.



Fronius International GmbH, www.fronius.com

01/2013

MIG/MAG - setup

Synergic



- G P r Gas pre-flow time
- G P o Gas post-flow time
- S L Slope (2-step, special 4-step)
- I - 5 Starting current (2-step, special 4-step)
- I - E Final current (2-step, special 4-step)
- E - 5 Starting current duration (2-step)
- E - E Final current duration (2-step)
- F d , Threading speed
- b b c Burn-back effect
- l l o Length of wire before the safety cut-out trips
- F A C Restoring factory setup
- 2 n d 2nd menu level

- C - C Cooling unit control
- C - E Cooling unit watchdog
- S E E Country setting
- r Welding circuit resistance
- L Welding circuit inductivity
- E n E Real Energy Input

Operating points

1 2 3 4 5 "Save" buttons

retrieve:

1 1 6 3

briefly press

save:

1 P r o 1 6 3 1

press and hold release

delete:

1 P r o 1 6 3 C L r 1

press and hold down for several seconds release

Rod electrode - setup



- H C U Hot-start current
- H E , Hot-current time
- A S E Anti-stick
- F A C Restoring factory setup
- 2 n d 2nd menu level
- r Welding circuit resistance
- L Welding circuit inductivity

Setup



e.g.: 1 0 0 4.2 1
firmware version

e.g.: 2 4 9 1
welding program configuration



e.g.: r 2 2 9 0
number of the currently selected welding program

e.g.: 1 F d 0.0
motor current for wire drive in A
The value changes as soon as the motor is running.


e.g.: 6 5 4 3 2.1
Arc burning time

2. Menu level for service engineers

Display service parameters



TSt 2500c / TSt 2700c welding program table




Welding program database:
TSt 2500c / TSt 2700c
VAT ID 3474

| Standard Programs | | | | | | | | | | |
|-------------------|----------------------|------|------------------------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|----|
| Material | | Gas | | Diameter | | | | | | |
| Pos. | | Pos. | | 0,8 mm .030" | 0,9 mm .035" | 1,0 mm .040" | 1,2 mm .045" | 1,4 mm .052" | 1,6 mm 1/16" | SP |
| 1 | Steel | A | 100 % CO ₂ | 2290 | 2300 | 2310 | 2322 | | | |
| 1 | Steel | B | Ar + 8-12 % CO ₂ | 2288 | 2298 | 2308 | 2324 | | | |
| 1 | Steel | C | Ar + 15-25 % CO ₂ | 2485 | 2486 | 2487 | 2488 | | | |
| 1 | Steel | D | Ar + 3-6 % O ₂ | 2285 | 2297 | 2307 | 2323 | | | |
| 1 | Stainless Steel | F | Ar + 2,5 % CO ₂ | 2427 | 2402 | 2426 | 2405 | | | |
| 2 | Steel dynamic | B | Ar + 8-12 % CO ₂ | 2292 | 2302 | 2312 | 2326 | | | |
| 2 | Steel dynamic | C | Ar + 15-25 % CO ₂ | 2293 | 2303 | 2313 | 2327 | | | |
| 2 | Steel dynamic | D | Ar + 3-6 % O ₂ | 2291 | 2301 | 2311 | 2325 | | | |
| 3 | Steel root | A | 100 % CO ₂ | 2502 | 2501 | 2499 | 2500 | | | |
| 3 | Steel root | B | Ar + 8-12 % CO ₂ | 2295 | 2305 | 2315 | 2329 | | | |
| 3 | Steel root | C | Ar + 15-25 % CO ₂ | 2296 | 2306 | 2316 | 2330 | | | |
| 3 | Steel root | D | Ar + 3-6 % O ₂ | 2294 | 2304 | 2314 | 2328 | | | |
| 3 | Stainless Steel root | F | Ar + 2,5 % CO ₂ | 2440 | 2441 | 2442 | 2443 | | | |
| 4 | Rutil FCW | A | 100 % CO ₂ | | 2410 | | 2321 | | | |
| 4 | Rutil FCW | C | Ar + 15-25 % CO ₂ | | 2411 | | 2320 | | | |
| 5 | Basic FCW | A | 100 % CO ₂ | | | | 2317 | | | |
| 5 | Basic FCW | C | Ar + 15-25 % CO ₂ | | | | 2318 | | | |
| 6 | Metal cored | B | Ar + 8-12 % CO ₂ | | 2420 | | 2385 | | | |
| 6 | Metal cored | C | Ar + 15-25 % CO ₂ | | 2421 | | 2536 | | | |
| 7 | Self-shielded | | | | 2350 | | 2349 | | | |

| Special assignment | | | | | | | | | | |
|--------------------|----------------------|------|--|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|----|
| Material | | Gas | | Diameter | | | | | | |
| Pos. | | Pos. | | 0,8 mm .030" | 0,9 mm .035" | 1,0 mm .040" | 1,2 mm .045" | 1,4 mm .052" | 1,6 mm 1/16" | SP |
| 1 | Stainless Steel | F | Ar + 2,5 % CO ₂ | 2427 | 2402 | 2426 | 2405 | | | |
| 3 | Stainless Steel root | F | Ar + 2,5 % CO ₂ | 2440 | 2441 | 2442 | 2443 | | | |
| 8 | FCW Stainless Steel | C | Ar + 18 % CO ₂ | | 2423 | | 2424 | | | |
| 8 | AlMg5 | E | 100 % Ar | | | 3639 | 3643 | | | |
| 1 | AISI5 | E | 100 % Ar | | | 3640 | 3092 | | | |
| 8 | CuSi3 | F | 100 % Ar (Ar + 2,5 % CO ₂) | 2496 | 2495 | 2493 | 2497 | | | |

* Diameter = 1,2 mm (0.45 in.)

**TSt 2500c USA /
TSt 2700c USA
welding program
table**




Welding program database:
TSt 2500c USA / TSt 2700c USA
VAT ID 3475

| Standard Programs | | | | | | | | | | |
|-------------------|----------------------|------|------------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|----|
| Material | | Gas | | Diameter | | | | | | |
| Pos. | | Pos. | | 0,8 mm .030" | 0,9 mm .035" | 1,0 mm .040" | 1,2 mm .045" | 1,4 mm .052" | 1,6 mm 1/16" | SP |
| 1 | Steel | A | 100 % CO2 | 2290 | 2300 | 2310 | 2322 | | | |
| 1 | Steel | B | Ar + 8-12 % CO2 | 2418 | 2370 | 2308 | 2377 | | | |
| 1 | Steel | C | Ar + 15-25 % CO2 | 2419 | 2369 | 2309 | 2376 | | | |
| 1 | Steel | D | Ar + 3-6 % O2 | 2372 | 2371 | 2307 | 2378 | | | |
| 2 | Steel dynamic | B | Ar + 8-12 % CO2 | 2374 | 2367 | 2312 | 2380 | | | |
| 2 | Steel dynamic | C | Ar + 15-25 % CO2 | 2375 | 2366 | 2313 | 2379 | | | |
| 2 | Steel dynamic | D | Ar + 3-6 % O2 | 2373 | 2368 | 2311 | 2381 | | | |
| 2 | Steel dynamic | B | Ar + 8-12 % CO2 | | 2462 | | | | | |
| 3 | Steel root | A | 100 % CO2 | 2502 | 2501 | 2499 | 2500 | | | |
| 3 | Steel root | B | Ar + 8-12 % CO2 | 2295 | 2364 | 2315 | 2383 | | | |
| 3 | Steel root | C | Ar + 15-25 % CO2 | 2296 | 2363 | 2316 | 2382 | | | |
| 3 | Steel root | D | Ar + 3-6 % O2 | 2294 | 2365 | 2314 | 2384 | | | |
| 3 | Stainless Steel root | F | Ar + 2,5 % CO2 | 2440 | 2441 | 2442 | 2443 | | | |
| 4 | Rutil FCW | A | 100 % CO2 | | 2471 | | 2472 | | | |
| 4 | Rutil FCW | C | Ar + 15-25 % CO2 | | 2470 | | 2456 | | | |
| 5 | Basic FCW | A | 100 % CO2 | | | | 2474 | | | |
| 5 | Basic FCW | C | Ar + 15-25 % CO2 | | | | 2473 | | | |
| 6 | Metal cored | B | Ar + 8-12 % CO2 | | 2420 | | 2385 | | | |
| 6 | Metal cored | C | Ar + 15-25 % CO2 | | 2421 | | 2386 | | | |
| 6 | FCW Stainless Steel | F | Ar + 18 % CO2 | | 2423 | | 2424 | | | |
| 7 | Self-shielded | | | | 2350 | | 2349 | | | |

| Special assignment | | | | | | | | | | |
|--------------------|----------------------|------|---------------------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|----|
| Material | | Gas | | Diameter | | | | | | |
| Pos. | | Pos. | | 0,8 mm .030" | 0,9 mm .035" | 1,0 mm .040" | 1,2 mm .045" | 1,4 mm .052" | 1,6 mm 1/16" | SP |
| 3 | Stainless Steel root | F | Ar + 2,5 % CO2 | 2440 | 2441 | 2442 | 2443 | | | |
| 6 | FCW Stainless Steel | F | Ar + 18 % CO2 | | 2423 | | 2424 | | | |
| 8 | Stainless Steel | A | Ar + 90He + 2,5 % CO2 | | 2404 | | 2407 | | | |
| 8 | Stainless Steel | B | Ar + 33He + 1 % CO2 | | 2403 | | 2406 | | | |
| 8 | Stainless Steel | C | Ar + 2,5 % CO2 | 2427 | 2402 | 2426 | 2405 | | | |
| 8 | FCW MAP409Ti | D | Ar + 2 % O2 | | | | 2464 | | | |
| 8 | AlMg5 | E | 100 % Ar | | | 3639 | 3643 | | | |
| 1 | AlSi5 | E | 100 % Ar | | | 3640 | 3092 | | | |
| 8 | CuSi3 | F | 100 % Ar (Ar + 2,5 % CO2) | 2496 | 2495 | 2493 | 2497 | | | |

* Diameter = 1,2 mm (0.45 in.)

**TransSteel 3500
Euro welding pro-
gram tables**




Welding program database:
TransSteel 3500 Euro
VAT ID 3431

| Standard Programs | | | | | | | | | | |
|-------------------|---------------|------|---------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|----|
| Material | | Gas | | Diameter | | | | | | |
| Pos. | | Pos. | | 0,8 mm .030" | 0,9 mm .035" | 1,0 mm .040" | 1,2 mm .045" | 1,4 mm .052" | 1,6 mm 1/16" | SP |
| 1 | Steel | A | 100 % CO2 | 2290 | 2300 | 2310 | 2322 | 2334 | | |
| 1 | Steel | B | Ar + 8 % CO2 | 2288 | 2298 | 2308 | 2324 | 2332 | | |
| 1 | Steel | C | Ar + 18 % CO2 | 2485 | 2486 | 2487 | 2488 | 2489 | | |
| 1 | Steel | D | Ar + 4 % O2 | 2285 | 2297 | 2307 | 2323 | 2331 | | |
| 2 | Steel dynamic | B | Ar + 8 % CO2 | 2292 | 2302 | 2312 | 2326 | 2336 | | |
| 2 | Steel dynamic | C | Ar + 18 % CO2 | 2293 | 2303 | 2313 | 2327 | 2337 | | |
| 2 | Steel dynamic | D | Ar + 4 % O2 | 2291 | 2301 | 2311 | 2325 | 2335 | | |
| 3 | Steel root | A | 100 % CO2 | 2502 | 2501 | 2499 | 2500 | | | |
| 3 | Steel root | B | Ar + 8 % CO2 | 2295 | 2305 | 2315 | 2329 | 2339 | | |
| 3 | Steel root | C | Ar + 18 % CO2 | 2296 | 2306 | 2316 | 2330 | 2340 | | |
| 3 | Steel root | D | Ar + 4 % O2 | 2294 | 2304 | 2314 | 2328 | 2338 | | |
| 4 | Rutil FCW | A | 100 % CO2 | | 2410 | | 2321 | 2391 | 2345 | |
| 4 | Rutil FCW | C | Ar + 18 % CO2 | | 2411 | | 2320 | 2390 | 2344 | |
| 5 | Basic FCW | A | 100 % CO2 | | | | 2317 | 2433 | 2342 | |
| 5 | Basic FCW | C | Ar + 18 % CO2 | | | | 2318 | 2432 | 2341 | |
| 6 | Metal cored | B | Ar + 8 % CO2 | | 2420 | | 2385 | 2387 | 2415 | |
| 6 | Metal cored | C | Ar + 18 % CO2 | | 2421 | | 2536 | 2388 | 2343 | |
| 7 | Self-shielded | | Self-shielded | | 2350 | | 2349 | | 2348 | |

| Special assignment | | | | | | | | | | |
|--------------------|----------------------|------|----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|--------|
| Material | | Gas | | Diameter | | | | | | |
| Pos. | | Pos. | | 0,8 mm .030" | 0,9 mm .035" | 1,0 mm .040" | 1,2 mm .045" | 1,4 mm .052" | 1,6 mm 1/16" | SP |
| 1 | Stainless Steel | F | Ar + 2,5 % CO2 | 2427 | 2402 | 2426 | 2405 | | | |
| 3 | Stainless Steel root | F | Ar + 2,5 % CO2 | 2440 | 2441 | 2442 | 2443 | | | |
| 8 | FCW Stainless Steel | C | Ar + 18 % CO2 | | 2423 | | 2424 | | 2425 | |
| 8 | AlMg 5 | E | 100 % Ar | | | | 2444 | | | |
| 8 | AlSi | E | 100 % Ar | | | | | | | 3092 * |
| 8 | CuSi 3 | F | SP | 2496 | 2495 | 2493 | 2497 | | | |

* Diameter = 1,2 mm (0.45 in.)

**TransSteel 3500
US welding pro-
gram tables**



Welding program database:
TransSteel 3500 US
VAT ID 3431

| Standard Programs | | | | | | | | | | |
|-------------------|---------------|------|---------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|----|
| Material | | Gas | | Diameter | | | | | | |
| Pos. | | Pos. | | 0,8 mm .030" | 0,9 mm .035" | 1,0 mm .040" | 1,2 mm .045" | 1,4 mm .052" | 1,6 mm 1/16" | SP |
| 1 | Steel | A | 100 % CO2 | 2290 | 2300 | 2310 | 2322 | 2334 | | |
| 1 | Steel | B | Ar + 10 % CO2 | 2418 | 2370 | 2308 | 2377 | 2409 | | |
| 1 | Steel | C | Ar + 25 % CO2 | 2419 | 2369 | 2309 | 2376 | 2333 | | |
| 1 | Steel | D | Ar + 5 % O2 | 2372 | 2371 | 2307 | 2378 | 2408 | | |
| 2 | Steel dynamic | B | Ar + 10 % CO2 | 2374 | 2367 | 2312 | 2380 | 2336 | | |
| 2 | Steel dynamic | C | Ar + 25 % CO2 | 2375 | 2366 | 2313 | 2379 | 2337 | | |
| 2 | Steel dynamic | D | Ar + 5 % O2 | 2373 | 2368 | 2311 | 2381 | 2335 | | |
| 2 | Steel dynamic | B | Ar + 10 % CO2 | | 2462 | | | | | |
| 3 | Steel root | A | 100 % CO2 | 2502 | 2501 | 2499 | 2500 | | | |
| 3 | Steel root | B | Ar + 10 % CO2 | 2295 | 2364 | 2315 | 2383 | 2339 | | |
| 3 | Steel root | C | Ar + 25 % CO2 | 2296 | 2363 | 2316 | 2382 | 2340 | | |
| 3 | Steel root | D | Ar + 5 % O2 | 2294 | 2365 | 2314 | 2384 | 2338 | | |
| 4 | Rutil FCW | A | 100 % CO2 | | 2471 | | 2472 | 2467 | 2469 | |
| 4 | Rutil FCW | C | Ar + 25 % CO2 | | 2470 | | 2456 | 2466 | 2468 | |
| 5 | Basic FCW | A | 100 % CO2 | | | | 2474 | 2433 | 2476 | |
| 5 | Basic FCW | C | Ar + 25 % CO2 | | | | 2473 | 2432 | 2475 | |
| 6 | Metal cored | B | Ar + 10 % CO2 | | 2420 | | 2385 | 2387 | 2415 | |
| 6 | Metal cored | C | Ar + 25 % CO2 | | 2421 | | 2386 | 2388 | 2416 | |
| 7 | Self-shielded | | Self-shielded | | 2350 | | 2349 | | 2348 | |

| Special assignment | | | | | | | | | | |
|--------------------|----------------------|------|--------------------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|-------|
| Material | | Gas | | Diameter | | | | | | |
| Pos. | | Pos. | | 0,8 mm .030" | 0,9 mm .035" | 1,0 mm .040" | 1,2 mm .045" | 1,4 mm .052" | 1,6 mm 1/16" | SP |
| 3 | Stainless Steel root | F | Ar + 2,5 % CO2 | 2440 | 2441 | 2442 | 2443 | | | |
| 6 | FCW Stainless Steel | F | Ar + 18 % CO2 | | 2423 | | 2424 | | 2425 | |
| 8 | Stainless Steel | A | Ar + 90 % He + 2,5 % CO2 | | 2404 | | 2407 | | | |
| 8 | Stainless Steel | B | Ar + 33 % He + 1 % CO2 | | 2403 | | 2406 | | | |
| 8 | Stainless Steel | C | Ar + 2,5 % CO2 | 2427 | 2402 | 2426 | 2405 | | | |
| 8 | FCW MAP409Ti | D | Ar + 2 % O2 | | | | 2464 | 2465 | | |
| 8 | AlMg 5 | E | 100 % Ar | | | | 2444 | | | |
| 8 | AlSi | E | 100 % Ar | | | | | | | 3092* |
| 8 | CuSi 3 | F | SP | 2496 | 2495 | 2493 | 2497 | | | |

* Diameter = 1,2 mm (0.45 in.)

FRONIUS INTERNATIONAL GMBH

Froniusstraße 1
A-4643 Pettenbach
AUSTRIA
contact@fronius.com
www.fronius.com

Under **www.fronius.com/contact** you will find the addresses
of all Fronius Sales & Service Partners and locations.



Find your
spareparts online



spareparts.fronius.com