

RisunMotor MQCON Sine-Wave Controller

HCI User Manual(For Bluetooth)



V1.0

Catalogue

1	Soft Installation and Debugging.....	3
1.1	App Installation	3
1.2	Offset angle test	5
1.3	Parameter Setting	10
2	Fault Information	12

1 Soft Installation and Debugging

1.1 App Installation

If the phone system is IOS, pls download the MQCON app from apple store while search"MQCON"

If the phone system is ANDRIOD:

(1). Please download the MQCON app from:

https://cdn.shopify.cn/s/files/1/0040/9223/1778/files/MQCON_v1.20_release.apk?v=1587109516

or ask your sales to send you the app.

(2). You can also scan QR code to install it:



Enable bluethooth on your phone




Figure 1

- (1) Connect bluethooth adapter to the controller usb port.
- (2) Power on the controller.

Caution : to be sure all connection is right before power on.

- (3) Click the icon **MQCON** on the phone desktop.




Figure 2

- (4) The **MQCON** app will open.





Figure 3

Click "Not connected" icon, the bluetooth adapter will be searched, select the right bluetooth as figure 4 showed.

Waiting for about 5 seconds ,the controller will connect the phone scsessfully



Firgue 4



1.2 offset angle test

For MQCON controller ,the most important parameter is"offset angle" .

The parameter is different because hall sensor position is different. same type motors can share same parameter in controller , in the following 2 cases, the offset angle test should be done before driving.

1. The user don't know the right angle in advance.
2. When use the controller to drive a new motor firstly , please test the "hall offset angle" .As the firguer 5 showed,click the debugger icon on the interface .




Figure 5





Figure 6

Before doing the offset angle test ,make sure the motor without any load, then follow the steps as figure 7 showed:



Figure 7

- 1- Set the " Given current " about 10 A to 35A
 - 2- Click ok
 - 3- Click run mode
 - 4- Select "test mode"
 - 5- Enable "hall test"
- Then you will find the motor spin very slowly
- 6- The controller enter "in progress" status
 - 7- After test finish , the motor stop spinning. if test ok, the "offset angle "will be refreshed automatically



8- Save the final succesful "offset angle"

After the step 8 finished , rotate the throttle slowly to run the motor .

Caution:

1 : the value of "**Given current**" should be under 35A. normally 15A is ok,if test failed ,please add the given current and test again.

2 : when angle test failed,you can exchange any two phase wires and match again.

3 : after test , if the motor spin reverse ,just change the "motor dirction" on the app interface as following :

Type 1 at **motor direction** input field. and click **ok**. it will change the spin direction.




Figure 8

- 4 : type the right Pole pair number at the "**motor poles pair**", and click **OK**.
- 5 : Parameters which are modified must be click **OK** and the **parameter store** must be click **OK**, otherwise ,the parameter will not be updated at next time when power on.
- 6: **if you know the motor offset angle in advance ,just enter the right hall angel ,no need to do hall test.**

1.3 parameters setting

Category	Parameter	Remark	Unit	Range
	lack voltage	when battery volt is lower than the value, the controller enter lack volt fault status	V	According the controller type
	Current limit voltage	When the battery volt is lower than the value ,the controller will limit output current	A	It is about 2V higher than the lack voltage

	over voltage	when battery volt is higher than the value, the controller enter over volt fault status	V	According the controller type
	Dc current	Max dc limit current in nomal mode	A	According the controller type
	Boost current	Max dc limit current in boost mode	A	According the controller type
	max phase current	it is corresponding to the max throttle value	A	According the controller type
	protected phase current	When phase current is higher than the value, the controller enter over current fault status	A	According the controller type
	rated phase current	Continuance run phase current	A	According the controller type
FUNC	E-brake	If it is enabled ,the controller enter electric brake status when the brake signal is valid	0 : disable 1 : enable	0,1
	E- brake current	When controller enter electric brake status, the battery is recharged , the value indicate the max charged current	A	0~150
	Boost/ 3 spd	Select the run mode: boost or 3pd and so on		0,3
	reverse speed limit	When motor reverse , the max reverse sped is limited to the value	A	0~100
	flux weaken enable	If it is enable , the flux weakening function is valid	0 : disable 1 : enable	0,1
	flux weaken current	Max flux weaken current	A	0~150
	Regenen enable	If it is enable ,the slide recharge function is valid	0 : disable 1 : enable	0,1
	regen current	When controller enter slide recharge status, the battery is recharged , the value indicate the max charged current	A	0~150
	regen start speed	Only when the motor speed is higher than the speed value ,the controller can enter the slide recharge status if the throttle is zero longer than 1 second	RPM	0~500
THROTTLE	throttle min	Throttle min valid volt	0.1V	0.0~5

	volt			
	throttle max volt	Throttle max valid volt	0.1V	0.0~5
	accelerate time	It adjust the output current accelerate rate	0.1s	1~500
	decelerate time	It adjust the output current decelerate rate	0.1s	1~500
	Throttle mid voltage	It set the mid voltage for the throttle mid positon	v	Normally about 2.5V
	Throttle mid current	It set the output phase current for the mid position of the throttle	A	Nomally about half of the max phase current
Motor	Motor rotation direction	It adjust the motor spin direction		0,1
	Motor pair poles	It is accoroding the motor		
	Speed limit mode	Select speed limit mode		
	Internal speed limit	While select internal speed mode ,this value will decide the max motor speed		0~100
	Low speed limit	It is valid in 3 speed mode		0~100
	Mid speed limit	It is valid in 3 speed mode		0~100

Tips:

1- "throttle min volt" correspond 0 phase current, and "throttle max volt" correspond max phase current.

2- "the max phase current " determine the max output torque ,

3- "the rate phase current" determine the continuous load endurance

4- if motor direction is 0, "accelerate time" determine the response time for the controller to response the throttle output during the **accelerate** process

if motor direction is 1, "accelerate time" determine the response time for the controller to response the throttle output during the **decelerate** process

5- if motor direction is 0, "decelerate time"determine the response time for the controller to response the throttle release during the **decelerate** process

if motor direction is 1, "decelerate time"determine the response time for the controller to response the throttle release during the **accelerate** process

2 Fault Information

You can get the fault information from the app interface, after the controller connected with computer, the fault information will display as following:




Figure 9

Some of faults remark are as following :

Num	Fault Name	Remark
1	Mosfet fault	Hardware fault
2	overVolt	Battery over volt fault
3	lackVolt	Battery lack volt fault
4	resvd	reserved
5	mtOverTemp	Motor temperature is higher than set temperature
6	ctOverTemp	controller temperature is higher than set temperature
8	overCurrent	phase current is higher than over protected ph current
9	overLoad	The timer that phase current is higher than rated phase current exceed the set time
11	Store error	The setting parameter store failed fault
12	HALL test fault	Motor hall fault when matching
13	HALL fault	Motor hall fault
18	overSpeed	The tasks of controller are too many to calculate.
20	Block protect	The block current
21	unInitEeprom	The eeprom of controller is not initialized