



MCK-MRDR-001

Marz Rover

Self Driving Unmanned Ground Vehicle



PRO-LINE
RACING TO BRING YOU THE BEST!

Helpful instructional videos available at: mindsieducation.com

MINDS-i® PRODUCT SAFETY INFORMATION

When safety precautions are followed, your MINDS-i® system will provide years of enjoyment. Use care and good sense at all times when operating this product. Failure to use your system in a safe, sensible manner can result in injury or damage to property. You and you alone must insure that the instructions are carefully followed and all safety precautions are obeyed.

- Water can cause the electronics to short out and can cause permanent damage.
- Always turn on the transmitter before turning on the receiver.
- Fully extend the transmitter antenna before operating your vehicle.
- Before turning on your radio system, check to make sure that no one else is running on the same frequency.



- **CHOKING HAZARD:** Do not allow children under age 3 or any individuals who have a tendency to place objects in their mouths to play with any part of the MINDS-i system, including, but not limited to: connectors, pieces, electronics, radio transmitters, wheels, tires. The system contains small parts which could accidentally be swallowed and cause suffocation.
- When the system is powered and/or in motion, keep fingers, face, tools, loose clothing, hair, and all other body parts away from gears, wheels, etc. Do not wear gloves while operating machinery. Even plastic parts can pinch, cut, or crush.
- The transmitter's antenna could also cause injury if played with violently or pointed towards someone's face.
- Never operate your MINDS-i® system on streets or in any areas where full-size vehicles are.
- Do not pick up your MINDS-i® system when it is in motion.
- Never charge, run or store your MINDS-i® system in a location subject to high temperatures, low temperatures or high humidity.

Do not store in direct sunlight.

- To avoid electronic malfunction, do not allow the vehicle to become wet. Short circuits will produce a very strong electrical current. Should your MINDS-i® system become wet, stop using it immediately.



- **WARNING! Electrocutation Hazard.** Do not use the materials provided for other than its intended purpose.
- Do not put it into fire.
- Always use recommended batteries. If improper batteries are used, they may become hot, leak and may rupture.
- Do not attempt to recharge non-rechargeable batteries.
- Only batteries of the same equivalent type as recommended are to be used. Do not mix old and new batteries.
- Exhausted batteries are to be removed from the system and replaced with new ones. Recycle all used batteries.
- Do not lick batteries. If battery appears to be leaking or has a crystalline deposit on the outside, dispose of it immediately (wear gloves when handling, preferably nitrile or other non-reactive material).
- Do not run a wire between battery terminals, as wire will get very hot, can be irreparably damaged or explode.
- Make sure the batteries are installed with the correct polarity as shown. Do not disassemble your batteries. Never allow them to become hot or to burn. To avoid short-circuits, avoid getting them wet. Do not short circuit batteries.
- If liquid from inside the batteries contacts your skin or clothes, wash them with water. If leaked battery fluid gets into your eyes, flush them immediately with cool water and seek medical attention. Do not rub eyes.
- Always wear safety glasses to protect your eyes. Note that normal glasses, while usually made of impact-resistant plastic, will not afford sufficient protection from shrapnel or flying debris.
- Always wear close-toed shoes to protect your feet from heavy or sharp objects, which might be dropped.
- If you have long hair, keep it tied back or under a hat to avoid it becoming caught in moving parts.
- The MINDS-i® system contains small parts. Do not ingest. Do not insert into any orifice (e.g. nostrils, ears, etc).
- The system contains metal parts. Cutting or bending can cause parts to break; resulting in sharp edges which can cut skin.
- Battery disposal. Do not throw batteries into the trash, especially rechargeable batteries. Contact your local waste disposal office for information on battery disposal. Batteries should be stored as directed by your local hazardous materials disposal office until pickup (usually in a hard sided waterproof, non-conductive container, e.g. a plastic bucket).



WARNING! IMPORTANT! RESPONSIBLE ADULT SUPERVISION IS REQUIRED FOR CHILDREN UNDER THE AGE OF 14. THIS PRODUCT IS NOT DESIGNED FOR UNSUPERVISED USE BY CHILDREN YOUNGER THAN 14 YEARS OLD.

All pictures descriptions and specifications found in this instruction manual are subject to change without notice.

MINDS-i® maintains no responsibility for inadvertent errors in this manual. Visit www.mymindsi.com for the latest updates and information.

MINDS-i® is a high-performance Construction/RC/Robotics System, which is NOT intended for use on the public roads or congested areas where its operation may conflict with or disrupt pedestrian or vehicular traffic. Read all enclosed information before operating. Fully illustrated, step-by-step instructions describe adjustment, operation, and required maintenance procedures. MINDS-i® should not be operated in a crowd, or without adequate space. In an effort to continually upgrade our products, MINDS-i® reserves the right to make improvements and modifications to this system, which may not be reflected in the photographs and specifications printed on this box. PROPOSITION 65 WARNING: This product contains chemicals known to the State of California to cause cancer and/or birth defects or other reproductive harm.

Terms & Conditions: All orders placed with MINDS-i, Inc (phone, fax, mail, internet/web & email) constitute the acknowledgment and acceptance of all conditions listed below. All purchases remain the property of MINDS-i®, Inc until paid for in full. All orders shipped to a Washington State address must pay sales tax as required by the Washington State Department of Revenue. In the event that an order placed on our web-site does not calculate sales tax and the order is being shipped to a Washington State address, MINDS-i® will calculate the sales tax when the order is processed and call or email the customer with the new amount. All prices, materials, design, color, contents included with a product and product specifications are subject to change without notice. Some product images may be shown with optional items that are sold separately. Depending on the products ordered and the destination of the order, certain shipping services may not be available. MINDS-i® will not be responsible for pricing errors and may cancel the order. Orders will not be shipped until all Credit Card information is verified and matched. All other orders (check or money order) will not be shipped until payment has been received in full. All unpaid orders will be canceled after 30 calendar days. All weights shown for products are used for shipping calculation only and may not reflect actual weight of the product.

Product Warranty: MINDS-i® warrants to the original buyer that our products are free from defects in materials and workmanship for a period of 120 days from the original date of purchase (original purchase receipt required). This warranty does not cover abuse, misuse, incorrect wiring, modifications, alterations, connector damage, wear and tear or robot competition damage. If the Product is determined to be defective within the warranty period, MINDS-i® or its authorized service provider will, at our sole option, repair or replace any defective parts free of charge, or refund the purchase price. What you must do: Return the Product in its original packaging or packaging affording equal protection, freight prepaid, with proof of purchase, to an authorized MINDS-i® service provider. You are responsible for all shipping charges. For more information, contact MINDS-i® at (509) 252-5767 or info@my minds i. com.

Shipping Errors and Defective Products: Claims for shipping shortages, errors, or defective materials must be in writing and received by MINDS-i® within ten (10) days after receipt of shipment by buyer. Failure to make such claim within the stated period shall constitute an irrevocable acceptance of the goods and an admission that the goods fully comply with all the terms and conditions of the buyer's order.

MINDS-i® is Designed and Manufactured in the United States
Some components are manufactured in China and the Philippines.

Patents US 7,517,270; US 7,410,225; US 7,736,211; US 7,841,923; MX 288350; CN ZL 200680044576.1; Additional Patents Pending.
Trademarks 3,420,137 and 3,487,694
Copyright © 2014 MINDS-i Inc. All rights reserved.

MINDS-i, Inc
22819 East Appleway Avenue
Liberty Lake, WA 99019
USA



CONNECTOR ASSEMBLY AND USAGE

HELPFUL INSTRUCTIONAL VIDEOS AVAILABLE AT: www.mindsieducation.com



1.5-LOCK



2-LOCK



3-LOCK




PANEL-LOCK




2-ROTATE




3-ROTATE




02




03




04




05



06



07



MARZ ROVER & LUNAR ROVER BUILD STEPS

UAV AIRFRAME BUILD-----	9
MOTOR POD ASSEMBLY-----	10
CHOOSE YOUR FRAME-----	12
MOUNTING YOUR FLIGHT ELECTRONICS-----	19
WIRING THE FLIGHT CONTROLLER -----	20
UAV WIRING DIAGRAM-----	21
UAV COMPETITION KIT JUMPER-----	24
FLIGHT CONTROLLER PROGRAMMING-----	25
CALIBRATING SENSORS-----	28
CALIBRATING ESC'S-----	30
UPLOAD UAV CODE-----	31
PID TEST RACK-----	32
CONNECTING TO THE DASHBOARD-----	34
SERVO REVERSING / TRANSMITTER BINDING-----	35
MINDS-I DASHBOARD-----	37
DASHBOARD FEATURES AND FUNCTIONS-----	39
WAYPOINT PANEL-----	40
CONFIGURATION PANEL-----	41
TELEMETRY-----	42
GRAPHING-----	43
EVENT LOG-----	44
DATA PANEL-----	45
FLIGHT MODES-----	46
CONNECTION / TERMINAL-----	47
MAP VIEW-----	48
TOGGLING MODES / LOG FILES-----	49
FINAL ASSEMBLY-----	51
ON RACK PRE-FLIGHT CHECK-----	53
FLIGHT AND SAFETY CHECKLIST-----	54

PART IDENTIFICATION REFERENCE

Due to variance in manufacture some parts may differ in shape and color from those pictured in this manual.


WIRES

For a 2 or 3 wire plug the lightest wire is the signal and the darkest wire is the ground. Colors may NOT match those pictured in the diagrams. Possible variations include:




WIRING GUIDE FOR ELECTRONICS

USE FOR STEPS: 07-09 & 17 - 21



6x6



MOTOR CASE ASSEMBLY



(Without Encoder)

01



x1
MOTOR CASE A



x1
MOTOR CASE B



x2
6x12x4mm BEARING




02

x1
MOTOR SHAFT




x1
58T 32P SPUR GEAR




x3
#4-40 x 3/8" SCREW



x3
#4-40 NUT



03



04

Be sure to align the set screw with the flat spot on the motor shaft.

Then, tighten the pinion set screw.


x1
5,000 RPM MOTOR



x1
10T 32P PINION GEAR



x1
PINION SET SCREW




Mount the pinion gear flush with the end of the motor shaft.

05

x1
M3x6mm SCREW



x2
M3 WASHER



DO NOT TIGHTEN!

06


x4
#4-40 x 3/4" SCREW



x4
#4-40 NUT





x4
#4 WASHER




07




Adjust motor screws until gears mesh smoothly, then tighten.



Tighten both screws after gears mesh.



Check that the gears mesh.



The motor case with the encoder is pre-assembled.

DIFFERENTIAL ASSEMBLY



x2



x1
RING GEAR



x1
DIFFERENTIAL CARRI



x1
CARRIER SHAFT




x4
CARRIER SCREW



x2
OUTPUT GEAR SHAFT



x2
SPIDER GEAR




02

x1
PINION GEAR



x2
6x12x4mm BEA




03

x2
DIFFERENTIAL CASE



x2
10x15x4mm BEARING



04



05

PUT THE SCREW HEADS ON THE SAME SIDE AS THE RING GEAR TO MARK IT.


x2
#4-40 x 3/4" SCREW



x2
#4 WASHER



x2
#4-40 NUT



Repeat steps 1 - 5: x2

CENTER DIFFERENTIAL ASSEMBLY



x1
RING GEAR



x1
DIFFERENTIAL CARRIER



x1
CARRIER SHAFT




x4
CARRIER SCREW



x2
OUTPUT GEAR SHAFT



x2
SPIDER GEAR



02

x2
PINION GEAR



x4
6x12x4mm BEARING




03

x2
CENTER DIFFERENTIAL CASE



x2
10x15x4mm BEARING



04

MARK THE SIDE THE RING GEAR IS ON FOR FUTURE REFERENCE.



05

PUT THE SCREW HEADS ON THE SAME SIDE AS THE RING GEAR TO MARK IT.

x4
#4-40 x 3/4" SCREW




x4
#4 WASHER



x4
#4-40 NUT



FRONT AXLE



02


x1
AXLE HOUSING



x1
STEERING BRACKET



x4
1.5-LOCK



03


x1
STEERING BAR



x1
STEERING PLATE



x4
#4-40 x 3/8" SCREW



04

x1
AXLE HOUSING



x2
SERVO MOUNT



x2
TRANSITION




x4
3-LOCK




RING GEAR IS ON THIS SIDE

SIDE VIEW



TOP VIEW

SCREW HEAD



05


x1
HS-485HB SERVO



x4
SERVO BUSHING




x4
SERVO BUSHING SLEEVE




06

x4
#2-32 x 5/8" SCREW



x4
#2 WASHER





07

x4
12-BEAM



x2
90mm SHOCK




x2
#4-40 x 1-3/8" SCREW



x2
#4 WASHER



x2
ROD END BALL




x6
CLEARANCE THREAD ADAPTER




x2
INTERFERENCE THREAD ADAPTER



INSERT THE ROD END BALL FIRST



x2



08

x4
12-BEAM



x2
FRONT WHEEL HUB



x2
FRONT WHEEL KNUCKL



x4
3-ROTATE



x4
6x12x4mm BEARING



ASSEMBLE THE ENDS
FIRST



x2




09




10

x4
3-ROTATE



11

x5
3/16" BALL STUD



12


x2
#4-40 x 3-3/4" THREAD ROD




x4
23mm BALL CUP



x2




13



14

x1
#4-40 x 1" THREAD ROD

x2
18mm BALL CUP



15

x1
STEERING SERVO HORN

x1
3/16" BALL STUD





16



POSITION OF SERVO HORN ON
SERVO WILL BE SET AFTER
SERVO IS POWERED.

17

x1
SERVO HORN SCREW




DO NOT TIGHTEN. SERVO
WILL CHANGE POSITION
AFTER IT IS POWERED ON
FOR THE FIRST TIME.

18

x2
DUAL TRANSITION



x4
1.5-LOCK


19

x2
14mm WHEEL NUT


x2
2.5x10mm DOWEL PIN

REAR AXLE



x2
6-DRIVELINE

A small, black, cylindrical component with a flange on one end and a threaded section on the other.

x2
M5 WHEEL END SHAFT

A small, black, cylindrical component with a threaded section on one end.

x4
U-JOINT SET SCREW

A small, silver, cylindrical component with a threaded section on one end.

02


x1
AXLE HOUSING



x1
STEERING BRACKET



x4
1.5-LOCK



03


x1
STEERING BAR



x1
STEERING PLATE



x4
#4-40 x 3/8" SCREW



04

x1
AXLE HOUSING



x2
SERVO MOUNT



x2
TRANSITION




x4
3-LOCK



SIDE VIEW



TOP VIEW



05


x1
HS-485HB SERVO



x4
SERVO BUSHING




x4
SERVO BUSHING SLEEVE




06

x4
#2-32 x 5/8" SCREW



x4
#2 WASHER





07

x4
12-BEAM



x2
90mm SHOCK




x2
#4-40 x 1-3/8" SCREW



x2
#4 WASHER



x2
ROD END BALL




x6
CLEARANCE THREAD ADAPTER




x2
INTERFERENCE THREAD ADAPTER



INSERT THE ROD END BALL FIRST



x2



08

x4
12-BEAM



x2
FRONT WHEEL HUB



x2
FRONT WHEEL KNUCKL




x4
3-ROTATE



x4
6x12x4mm BEARING



ASSEMBLE THE ENDS
FIRST



x2




09




10

x4
3-ROTATE



11

x5
3/16" BALL STUD



12


x2
#4-40 x 3-3/4" THREAD ROD




x4
23mm BALL CUP



x2




13



14

x1
#4-40 x 1" THREAD ROD

x2
18mm BALL CUP



15

x1
STEERING SERVO HORN

x1
3/16" BALL STUD





16



POSITION OF SERVO HORN ON
SERVO WILL BE SET AFTER
SERVO IS POWERED.

17

x1
SERVO HORN SCREW




DO NOT TIGHTEN. SERVO
WILL CHANGE POSITION
AFTER IT IS POWERED ON
FOR THE FIRST TIME.

18

x2
DUAL TRANSITION



x4
1.5-LOCK

19

x2
14mm WHEEL NUT


x2
2.5x10mm DOWEL PIN

MIDDLE AXLE



02

x2
AXLE HOUSING



x2
TRANSITION



x2
2-BEAM



x4
3-LOCK



03

x4
12-BEAM



x2
90mm SHOCK



x2
#4-40 x 1-3/8" SCREW



x2
#4 WASHER



x2
ROD END BALL




x6
CLEARANCE THREAD
ADAPTER




x2
INTERFERENCE THREAD
ADAPTER



INSERT THE ROD END
BALL FIRST



x2



04

ASSEMBLE THE ENDS
FIRST

x4
12-BEAM





x2
REAR WHEEL HUB



x4
3-ROTATE



x4
6x12x4mm BEARING




05



06

x4
3-ROTATE




07

x4
DUAL TRANSITION



x8
1.5-LOCK




08

x2
14mm WHEEL NUT



x2
2.5x10mm DOWEL PIN




DIFFERENTIAL ORIENTATION

THE DIFFERENTIALS MUST BE ORIENTED PROPERLY OR THE WHEELS WILL NOT SPIN IN THE CORRECT DIRECTION.

REFER TO THE DIAGRAM BELOW WHEN ATTACHING THE AXLES. **THE FRONT AND REAR AXLES ARE NOT EXCHANGEABLE. NOTE THE DIRECTION OF THE SCREW HEADS.**

CHECK THE ROTATION OF THE DRIVE TRAIN BY SPINNING IT BY HAND BEFORE INSTALLING THE ELECTRONICS. BOTH AXLES SHOULD SPIN IN THE SAME DIRECTION WHEN THE DIFFERENTIAL INPUTS ARE TWISTED CLOCKWISE.

IF THE DIFFERENTIALS ORIENTATION IS WRONG THE FRONT AND REAR WHEELS WILL SPIN IN OPPOSITE DIRECTIONS; SEE THE TROUBLESHOOTING GUIDE.



01

x2
15-BEAM




x4
13-BEAM



x4
12-BEAM




x8
2-LOCK



02

x6
2-LOCK




03

x8
9-BEAM


x8
DUAL TRANSITION


x16
2-LOCK

04

x12
11-BEAM


x4
9-BEAM



x8
3-LOCK


x16
2-LOCK




05

x16
2-LOCK



06


x16
SUPPORT ARM



x16
2-LOCK



x16
2-ROTATE




07

USE ONE MOTOR ASSEMBLY WITH ENCODER

x4
2-45 BEAM


x4
3-LOCK



08

x8
TRANSITION

x4
3-LOCK




09

USE THE OTHER WITHOUT ENCODER

x4
2-45 BEAM


x4
3-LOCK



10

x8
TRANSITION

x4
3-LOCK



11

CONNECT THE MOTOR WIRES TO THE MOTORS. IF THE WIRES ARE ATTACHED TO EACHOTHER PULL THE ENDS APPART SLIGHTLY.


x2
MOTOR WIRE - BLACK



x2
MOTOR WIRE - RED



SEE THAT THE RED WIRE IS CONNECTED NEXT TO THE RED DOT.





x2



12

CONNECT THE MOTOR ENCODER CABLE TO THE ENCODER PLUG. THE CABLE ONLY FITS IF THE ORIENTATION IS CORRECT.

x1
ENCODER CABLE



THICK SIDE

MAKE CERTAIN THE PLUG IS ORIENTED CORRECTLY.



13

x1
3-DRIVELINE




x8
U-JOINT SET SCREW



x2
1-DRIVELINE




x1
0-DRIVELINE



14

x8
2-LOCK



15

x6
15-BEAM



x4
12-BEAM



x8
2-LOCK



16


x2
BATTERY CAP



x4
TRANSITION



x4
2-LOCK



17

x4
3-LOCK




18

x8
3-LOCK



x20
2-LOCK



19

x12
3-45 BEAM



x12
3-LOCK




20

x12
TRANSITION


x12
3-LOCK

21

x6

13-BEAM



x6

#4-40 x 1-3/8" SCREW



x6

#4 WASHER



x6

SHOCK MOUNT




x18

CLEARANCE THREAD
ADAPTER



x6

INTERFERENCE THREAD
ADAPTER



22

x12

2-LOCK



23

x6
BADLANDS 2.2" TIRE & DESPERADO WHEEL




x6
M5 WASHER



x6
M5 NUT



5-PIN SENSOR ARRAY



x1

13-BEAM



x2

5-BEAM




x2

TRANSITION



x4

2-LOCK




02

x2
6-BEAM


x1
5-BEAM


x2
TRANSITION


x2
3-ROTATE


03

x2
8-BEAM


x2
6-BEAM


x2
3-ROTATE


x4
2-ROTATE

04

x5
4-BEAM


x5
2-45 BEAM

x5
PING))) SENSOR

x10
#4-40 x 3/4" SCREW

x20
CLEARANCE THREAD
ADAPTER


x10
INTERFERENCE THREAD
ADAPTER



05

x10
TRANSITION


x10
2-LOCK



06

x2
3-BEAM



x4
3-LOCK

07

x2
3-LOCK


x4
2-LOCK

08

x1
15-BEAM



x2
9-BEAM



x1
7-BEAM



x2
4-BEAM



x2
3-BEAM



x6
3-LOCK



09

x5
TRANSITION



x1
3-LOCK



x4
2-LOCK



10


x4
2-LOCK



11

x2
3-LOCK

x4
2-LOCK



4X4 SUPER CRAWLER



MOTOR CASE ASSEMBLY



(Without Encoder)

01



x1
MOTOR CASE A



x1
MOTOR CASE B



x2
6x12x4mm BEARING



02

x1
MOTOR SHAFT




x1
58T 32P SPUR GEAR




x3
#4-40 x 3/8" SCREW



x3
#4-40 NUT



03



04

Be sure to align the set screw with the flat spot on the motor shaft.

Then, tighten the pinion set screw.


x1
5,000 RPM MOTOR



x1
10T 32P PINION GEAR



x1
PINION SET SCREW




Mount the pinion gear flush with the end of the motor shaft.

05

x1
M3x6mm SCREW



x2
M3 WASHER



DO NOT TIGHTEN!

06


x4
#4-40 x 3/4" SCREW



x4
#4-40 NUT





x4
#4 WASHER




07




Adjust motor screws until gears mesh smoothly, then tighten.



Tighten both screws after gears mesh.



Check that gears mesh.



The motor case with the encoder is pre-assembled.

DIFFERENTIAL ASSEMBLY




x1
RING GEAR



x1
DIFFERENTIAL SPOOL



x4
CARRIER SCREW




02

x1
PINION GEAR



x2
6x12x4mm BEA




03

x2
DIFFERENTIAL CASE




x2
10x15x4mm BEARING



04

MARK THE SIDE THE RING GEAR IS ON FOR FUTURE REFERENCE.



05

PUT THE SCREW HEADS ON THE SAME SIDE AS THE RING GEAR TO MARK IT.


x2
#4-40 x 3/4" SCREW



x2
#4 WASHER




x2
#4-40 NUT



Repeat steps 1- 5: x2

REAR AXLE



02


x1
AXLE HOUSING



x1
STEERING BRACKET



x4
1.5-LOCK



03


x1
STEERING BAR



x1
STEERING PLATE



x4
#4-40 x 3/8" SCREW



04

x1
AXLE HOUSING



x2
SERVO MOUNT



x2
2-BEAM




x4
3-LOCK




RING GEAR IS ON THIS SIDE

SIDE VIEW



TOP VIEW

SCREW HEAD



05


x1
HS-485HB SERVO



x4
SERVO BUSHING



x4
SERVO BUSHING SLEEVE




06

x4
#2-32 x 5/8" SCREW



x4
#4 WASHER



07

x8
9-BEAM



x2
FRONT WHEEL HUB



x2
FRONT WHEEL KNUCKLE




x4
3-LOCK



x4
6x12x4mm BEARING



ASSEMBLE WHEEL HUB FIRST




08



09

x4
3-LOCK



10


x2
3-45 BEAM

x2
TRANSITION

x2
3-LOCK


x2
2-LOCK

ASSEMBLE FIRST



11

x5
3/16" BALL STUD



12

x2
#4-40 x 2-3/4" THREAD ROD



x4
23mm BALL CUP




x2



=




13



14

x1
#4-40 x 1" THREAD ROD

x2
18mm BALL CUP




15

x1
STEERING SERVO HORN

x1
3/16" BALL STUD





16



POSITION OF SERVO HORN ON
SERVO WILL BE SET AFTER
RADIO IS SETUP.

17

x1
SERVO HORN SCREW




DO NOT TIGHTEN. SERVO
WILL CHANGE POSITION
AFTER IT IS POWERED ON
FOR THE FIRST TIME.

18


x2
14mm WHEEL NUT



x2
2.5x10mm DOWEL PIN



FRONT AXLE



02


x1
AXLE HOUSING



x1
STEERING BRACKET



x4
1.5-LOCK



03


x1
STEERING BAR



x1
STEERING PLATE



x4
#4-40 x 3/8" SCREW



04

x1
AXLE HOUSING




x2
SERVO MOUNT




x2
2-BEAM



x4
3-LOCK



TOP VIEW



05


x1
HS-485HB SERVO



x4
SERVO BUSHING



x4
SERVO BUSHING SLEEVE




06

x4
#2-32 x 5/8" SCREW



x4
#4 WASHER



07

x8
9-BEAM



x2
FRONT WHEEL HUB



x2
FRONT WHEEL KNUCKLE




x4
3-LOCK



x4
6x12x4mm BEARING



ASSEMBLE WHEEL HUB FIRST




08



09

x4
3-LOCK



10


x2
3-45 BEAM

x2
TRANSITION

x2
3-LOCK


x2
2-LOCK

ASSEMBLE FIRST



11

x5
3/16" BALL STUD



12

x2
#4-40 x 2-3/4" THREAD ROD



x4
23mm BALL CUP




x2



=




13



14

x1
#4-40 x 1" THREAD ROD

x2
18mm BALL CUP




15

x1
STEERING SERVO HORN

x1
3/16" BALL STUD





16



POSITION OF SERVO HORN ON
SERVO WILL BE SET AFTER
RADIO IS SETUP.

17

x1
SERVO HORN SCREW




DO NOT TIGHTEN. SERVO
WILL CHANGE POSITION
AFTER IT IS POWERED ON
FOR THE FIRST TIME.

18


x2
14mm WHEEL NUT



x2
2.5x10mm DOWEL PIN



AXLE CONNECTORS



x2
DUAL TRANSITION



x1
#4-40 x 1-3/8" SCREW



x1
#4 WASHER



x3
CLEARANCE THREAD
ADAPTER



x1
INTERFERENCE THREAD
ADAPTER




02

x1
8-BEAM


x1
2-LOCK



x2
CLEARANCE THREAD
ADAPTER

03

x1
DUAL TRANSITION


x2
2-LOCK

Repeat steps 1 - 3: x4

**Add page showing
differentials for 4
wheeler**

01

USE ONE MOTOR ASSEMBLY WITH ENCODER


x2
2-45 BEAM

x2
DUAL TRANSITION

x2
TRANSITION

x2
3-LOCK

x4
2-LOCK



02

USE THE OTHER WITHOUT ENCODER


x2
2-45 BEAM

x2
DUAL TRANSITION

x2
TRANSITION

x2
3-LOCK

x4
2-LOCK



03

CONNECT THE MOTOR WIRES TO THE MOTORS. IF THE WIRES ARE ATTACHED TO EACHOTHER PULL THE ENDS APPART SLIGHTLY.


x2
MOTOR WIRE - BLACK




x2
MOTOR WIRE - RED



SEE THAT THE RED WIRE IS CONNECTED NEXT TO THE RED DOT.





x2



04

CONNECT THE MOTOR ENCODER CABLE TO THE ENCODER PLUG. THE CABLE ONLY FITS IF THE ORIENTATION IS CORRECT.

x1
ENCODER CABLE



THICK SIDE

MAKE CERTAIN THE PLUG IS ORIENTED CORRECTLY.



04

x8
4.8" FOUR LINK ARM

x16
ROD END



x16
ROD END BALL



x16



x8

05

x4
11-BEAM



x4
7-BEAM



x4
3-LOCK



x4
#4-40 x 1-3/8" SCREW




x4
#4 WASHER



x12
CLEARANCE THREAD
ADAPTER



x4
INTERFERENCE
THREAD
ADAPTER



x2

06


x2
7-BEAM



x8
CLEARANCE THREAD
ADAPTER



x2




07

x4
3-LOCK



x4
2-LOCK



08

x2
13-BEAM




x2
BATTERY CAP



x4
TRANSITION



x6
2-LOCK

09


x4
11-BEAM



x4
10-BEAM



x4
90mm SHOCK



x2
2.0" THREAD COLLAR



x4
#4-40 x 1-3/8" SCREW



x4
SHOCK MOUNT



x4
ROD END BALL





x4
#4 WASHER



x16
CLEARANCE THREAD ADAPTER



INSERT THE ROD END BALL FIRST



10

x2
11-BEAM



x8
3-LOCK



11


x4
2-LOCK



12

x4
3-LOCK


x4
2-LOCK



13

x4
8-45 BEAM


x8
2-LOCK



14

x2
1.2" THREAD COLLAR

x4
#4-40 x 1-3/8" SCREW




15

x2
1.2" THREAD COLLAR

x4
#4-40 x 1" SCREW

x4
#4 WASHER



16

x2
13-BEAM



x4
9-BEAM



x4
2-LOCK



17

x4
3-45 BEAM



x4
TRANSITION



x4
3-LOCK



x2



18

x2
11-BEAM



x4
2-LOCK




19

x4
3-LOCK




x4
2-LOCK




20

x8
1.5-LOCK




21

x16
2-LOCK



22

x4
2-LOCK




23

x2
7-DRIVELINE



x4
U-JOINT SET SCREW



24


x4
BADLANDS 2.2" TIRE & DESPERADO WHEEL




x4
M5 WASHER



x4
M5 NUT




5-PING SENSOR ARRAY




x1
13-BEAM



x2
4-BEAM



x2
2-LOCK



02

x2
6-BEAM




x1
5-BEAM



x2
TRANSITION



x2
3-ROTATE



03

x2
8-BEAM




x2
6-BEAM



x2
3-ROTATE



x4
2-ROTATE



04

x5
4-BEAM


x5
2-45 BEAM

x5
PING))) SENSOR

x10
#4-40 x 3/4" SCREW

x20
CLEARANCE THREAD
ADAPTER


x10
INTERFERENCE THREAD
ADAPTER



05

x10
TRANSITION

x10
2-LOCK




06

x2
3-BEAM



x4
3-LOCK




07

x2
3-LOCK



x4
2-LOCK




08

x2
TRANSITION



x2
2-LOCK



09

x1
15-BEAM



x2
9-BEAM



x2
3-BEAM



x3
TRANSITION



x5
3-LOCK



10

x1
11-45 BEAM



x1
TRANSITION



x2
2-LOCK




11

x2
TRANSITION



x2
2-LOCK



12


x4
2-LOCK




13

x2
3-LOCK

x2
2-LOCK



Electronics Wiring




01

Wire Control Box on Robot

01

Connect the ESC's to the Motors. (The red & black motor wires should already be attached to the motors).


x2
ESC



02

Connect the Y-Harnes to the ESCs.

x1
Y-Harness




03

Connect the ESCs to the Power Module through the Power Y.


x1
Power Module

x1
ESC to Power Y





04 Connect the Power module to the flight controller box.

x1
Flight Controller Box



05 Connect the ESCs through the Y-Harness to Pin 1 on the flight controller box.



Make certain that the lightest wire is on the inside and the darkest is on the outside.



Plug into socket for Pin 1, the farthest to the left.

06 Connect the servos on the front and rear axles into pins 2 and 3 respectively on the flight controller box.

Make certain that the lightest wire is on the inside and the darkest is on the outside.




The front servo goes into Pin 2 and the rear servo goes into Pin 3.



07

Connect the two plugs coming from the encoder (already mounted in one of the motor assemblies) to pins 6 and 7 on the flight controller box. The orientation of the plugs is as pictured.

The plug with the wires spread goes into pin 6.





The plug with the wires close together goes into pin 7.



08



Connect the ping array to pins 0 through 4 from left to right.

x5
3-PIN CABLE FLAT TO LATCH



Match this plug orientation.

Make certain that the lightest wire is on the inside and the darkest is on the outside.




09 Connect the radio receiver to Input pins 1 and 2 using the male to male servo cable.


x1
Radio Receiver





x2
SERVO CABLE MALE TO MALE



Ch1 is connected to pin 2 and Ch2 is connected to pin 1.




The lightest wire is to the inside and the darkest on the outside for both connections.



10 Attach the optional parts: telemetry radio and gps / compass module.
TO USE THE INTERNAL COMPASS ON THE FLIGHT CONTROLLER INSTEAD OF THE COMPASS ON THE GPS SEE PG ? OF APPENDEX ?.


Plug the 5 pin plug from the telemetry radio into the port marked "telem" on the flight controller. Make certain the orientation is correct.



The gps / compass module has two plugs: a 5 pin and a 4 pin. Both plugs need to plug into the flight controller module. These plugs go into the two sockets labeled "GPS".

The 5 pin goes into the top face above the "GPS" label. The 4 pin plug goes into the side face below the "GPS" label as shown below. Make certain the plug orientation is correct.

TO GPS ←



Flight Controller Programming & Radio Control Setup



01

Introduction


The following steps will cover programming the flight controller and setting up the radio. There are three parts to this:

- Calibrating the sensors
- Loading the drive program on the controller box.
- Setting up the radio
- Connecting the steering servos

Data is saved in the electronics after the sensor calibration and the radio setup. **DO NOT OMIT!** Both of these steps must be performed for software in the controller box to function.

01

Plug the flight controller into the computer using the usb cable. **LEAVE THE BATTERY UNPLUGGED.**



02

Open the arduino program loaded on the computer.

For more information on installing and working with arduino see the “Arduino Users Guide” included with this kit.


02

Calibrate Sensors


01 In arduino, open the program: CalibrateSensors

OPEN: libraries > MINDS-i-Drone > CalibrateSensors


Click the open icon



02 Check that the correct board (mega 2560) and port are selected as shown:




03 Upload the calibrate sensors code onto the flight controller box:



Upload the code:

Wait until the upload completes:



04

Once the upload is complete, open the serial monitor:

Click the serial monitor icon.

Wait until a message is displayed in the serial monitor.




05


Once the message is displayed answer yes to the prompt.

Enter 'y' in the top bar.

Hit send.



Lines of scrolling text will appear with labels for the axes: x,y and z. Each axis will have two columns, one for its positive direction and one for its negative direction.




'ok' : Axis calibration is complete.

' * ' : Axis is being calibrated.

06

Calibrate the accelerometer chip for each of the six possible orientations as shown below.


For each orientation hold the controller box as steady as possible until the indicator beside the orientation label changes from “NA” to “ok”.



Once the accelerometer has been calibrated for all axes, the scrolling will stop.

07

Once the scrolling stops answer the prompt with ‘y’.




Another screen with scrolling values will appear. Unplug the controller box from the computer


03

Load Control Program


01 In arduino, open the program: RoboMagellan6x6



OPEN: libraries > MINDS-i-Drone > RoboMagellan6x6



02 Check under the “tools” drop down menu, that the correct board (mega 2560) and port are selected as shown before:



03

Upload the code:



Wait until the upload completes:

03

Unplug the USB cable from the Flight Controller.





Setup The Transmitter

TURNIGY TGY-I6S

Transmitter Operation Reference:

01 Turing the transmitter on:



HOLD BOTH BUTTONS AT THE SAME TIME UNTIL IT TURNS ON

02 Turn the transmitter off by pressing and holding both buttons simultaneously until it turns off.



HOLD BOTH BUTTONS AT THE SAME TIME UNTIL IT TURNS OFF


01 To get into the configuration menu press: "Setup".



02 Once in a menu, to save changes and/or exit back to the main screen, press the back icon as many times as necessary.



03 If a prompt appears, answer "Y" to save changes.




Additional operations are discussed in the appendix.

04


Bind the transmitter to the receiver on the robot.

This step allow the transmitter unit to control a specific drone. **MAKE CERTAIN THE BATTERY IS NOT PLUGGED INTO THE ROBOT.**


01 From the main screen of the transmitter press: 



02 Scroll down to "rx bind" and press it.



03 Connect the bind cable to the: "B/VCC" port on the receiver.



04 Make certain the transmitter is plugged into the flight controller. Plug the flight controller into the computer.



05 Wait for the led on the receiver to stop flashing.



06 When the led turns solid **REMOVE THE BIND CABLE.**




07 Press  to finish and return to the main screen.

If the bind was successful the battery icon to the left of "RX" should be partially filled instead of showing a question mark.




08 The usb power cable may now be unplugged from the robot.



05

Connect the Steering Servos


01 Disconnect the servo horns from the servos on the front & rear axles.



02 Turn the transmitter on



03 Turn on BOTH ESC's




04 Plug the battery into the robot using the adapter.

x1
Adapter Plug




x1
Battery




After the flight controller is powered the servos will usually move slightly to their centered positions.

04

Align the wheels of the vehicle so that they are straight.

**05**


Connect the servo horns by gently pushing them back onto the servos. If the horn does not go on easily, twist it very slightly and push again. The teeth on the servo horn must slide between the teeth on the servo.



If the servo horn still does not slide on use the screw to push it onto the servo.

Be careful not to twist the servo or the wheels when connecting the servo horn.

If the servo is twisted by accident: unplug the battery; disconnect the servo from the horn; plug the battery back in; straighten the wheels; then connect the servo.





Use zip ties and velcro to secure the electronic components to the robot's frame.

Operation

01

Checklist



Wear Safety Glasses if driving over loose material or outdoors.



Make certain that the battery is the correct voltage. Only use a 7.2V NiMH. Do NOT connect a battery without the adapter plug.



Make certain nothing is broken, no wires are loose and the battery, and other parts, are firmly secured.



Make certain the wheels can turn freely. Check for hair and other obstructions.



NEVER DRIVE THE ROBOT INTO PEOPLE, INCLUDING OPERATOR!!!

02


RC Operation

01 Follow the "Checklist"

02 Turn the transmitter on, then turn the ESC's on.

03 Plug the battery into the robot.

Controls:



D R O N E S

MINDS-i

STEM INTEGRATED ROBOTICS

MINDS-i Dashboard

The screenshot displays the MINDS-i dashboard interface. At the top, there are 'Refresh' and 'Connect' buttons. The main area features a satellite map of North America. On the left, a configuration panel includes buttons for 'Configuration', 'elevation', 'Telemetry', 'Graph', and 'Event Log'. Below these are robot selection controls with 'Robot' text and left/right arrows, and input fields for 'Lat: 0.0', 'Lng: 0.0', and 'Alt: 0.0'. Further down are 'New', 'Enter', 'Save', 'Load', 'Set Target', and 'Looping On' buttons. On the right side, there are several data readouts: a sensor status panel with 'RAW: 0.0', 'Gyro: 0.0', 'GPS: 0.0', 'Acc: 0.0', 'Rot: 0.0', 'MPH: 0.0', and 'Vcc: 0.0'; a panel showing 'Alt: 0', 'Sea: 0', 'Mph: 0.0', and 'Vcc: 0.0'; four circular icons representing different robot types (two-wheeled, four-wheeled, and two-wheeled with a camera); a panel with a blue-to-brown gradient bar; and a 'Radio Status' panel with a yellow bar and two small maps. A 'Welcome!' message is visible at the bottom center.

Dashboard Features & Functions

Waypoint Panel

Connection Panel


The screenshot displays the MINDS-i dashboard interface. The main area is a map of Liberty Lake, showing landmarks like Pumphouse Park and Meadow Golf Course. The interface includes several panels:

- Waypoint Panel (Left):** A vertical sidebar with buttons for Configuration, satellite, Telemetry, Graph, and Event Log. It also features a 'Robot' selection area with left and right arrows, and input fields for Lat: 0.0, Lng: 0.0, and Alt: 0.0. Below these are buttons for New, Enter, Save, Load, Set Target, and Looping On.
- Connection Panel (Top Center):** A box containing 'Refresh' and 'Connect' buttons.
- Data Panel (Right):** A vertical stack of widgets. At the top, a digital display shows Alt: 0, Sea: 0, Mph: 0.0, and Vcc: 0.0. Below this is a circular drone icon, a battery level indicator, and a 'Radio Status' section with two status indicators.
- Terminal (Bottom Center):** A small window displaying the text 'Welcome!'.

Data Panel

Terminal

Waypoint Panel:



- ① Configuration: Opens a pop up window with the Telemetry Radio Configuration tool.
- ② View Button: This button switches the map between satellite and elevation views.
- ③ Navigation: Zoom in and out.
- ④ Telemetry: Opens a window allowing you to select the information that will be recorded in the log as well as all of the adjustable settings for the vehicle.
- ⑤ Graph: Opens a pop up window with a live data graphing function.
- ⑥ Event Log: Opens up the log for the active session.
- ⑦ Waypoint selector: moves the selection up and down the list of waypoints.
- ⑧ Waypoint entry: Will be filled with the latitude, longitude and altitude (MultiRotor) or speed (UGV) of selected waypoint. You can also edit the waypoint location information.
- ⑨ New & Enter, Save & Load: Used to create save and load the GPS waypoint list as a .gpx file.
- ⑩ "Set target": Click set target to redirect the robot to the selected waypoint.
- ⑪ Looping Button: Toggles whether or not the robot will stop when it reaches the last waypoint or if it will loop around and drive to the first and on from there.

Configuration:

The screenshot shows the 'Configuration' window of the MINDS-i Dashboard. At the top, there are two drone icons with callout 1 pointing to the 'Toggle ground/air mode' button and callout 2 pointing to the 'Launch driver installer' button. Below these are buttons for 'Refresh' (callout 3), a 'COM' dropdown menu (callout 4), a 'Baud Rate' dropdown menu (callout 5), and a 'Connect' button (callout 6). A table with columns 'ID', 'Name', and 'Value' is shown below, with callout 7 pointing to its empty body. At the bottom of the window are 'Import Defaults' (callout 8) and 'Save Changes' (callout 9) buttons. The footer of the window displays 'MINDS-i Dashboard | Version 1.0.0 | 2016-12-28' and copyright information.

1. Toggle ground/air mode: Switches between ground and air mode.
2. Driver Installer: Launches the installer for the radio driver.
3. Refresh: Refreshes the serial port list.
4. Com Port List: Shows the open com ports.
5. Baud Rate: Used to set the communication speed.
6. Connect: Connects to the telemetry radio to adjust the settings.
7. Settings Window: Shows all of the radio settings.
8. Import Defaults: Allows you to set all of the options back to default.
9. Save Changes: Saves any settings you have changed.



Telemetry:

Configuration
elevation
+ -
Telemetry
Graph
Event Log
< Robot >
Lat: 0.0
Lng: 0.0
MPH: 0.0
New Enter
Save Load
Set Target
Looping On

The screenshot shows the Telemetry software interface. At the top, there is a 'Set logging period (ms)' input field with a value of 250. Below this is a table with two sections. The first section has columns 'name' and 'Value'. The second section has columns 'name' and 'Setting'. Below the tables, there is a text area with setting limits and a description.

name	Value
Latitude	0.0
Longitude	0.0
Yaw/Direction	0.0
Pitch	0.0
Roll	0.0
Ground Speed	0.0
Voltage	0.0


name	Setting
Output Period	0.0
Accel Gain	0.0
Mag Gain	0.0
Att P Term	0.0
Att I Term	0.0
Att D Term	0.0
Att VP Term	0.0
Att VI Term	0.0
Att VD Term	0.0
Yaw P Term	0.0
Yaw I Term	0.0
Yaw D Term	0.0
Yaw VP Term	0.0
Yaw VI Term	0.0
Yaw VD Term	0.0
Hover Throttle	0.0
Throttle Linearity	0.0

min: 5000.0 max: 10000.0 default: 6666.0
Period in milliseconds between reading the imu, calculating orientation, and sending a signal to the ESC's
This value should be between 5000 (200Hz) and 10000(100Hz)
Higher speeds will decrease the processing time left for other tasks, but could lead to a more stable flight

1. Data Log Window: The data log opens in a new window.
2. ID Column: Lists the names of the preset data to be logged as well as the open slots.
3. Value Column: Includes the value for each row of data.
4. Data Log Interval: Period of time between saving data.
5. Setting Names
6. Setting Value: Used definable settings, used to adjust performance
7. Setting limits: Shows operator the minimum, maximum and default value for each setting.
8. Setting Description: Describes what each setting adjusts.

Graph:

Configuration
elevation
+ -
Telemetry
Graph
Event Log
< Robot >
Lat: 0.0
Lng: 0.0
MPH: 0.0
New Enter
Save Load
Set Target
Looping On




#	Data Name	Graph?
	Latitude	<input type="checkbox"/>
	Longitude	<input type="checkbox"/>
	Yaw/Direction	<input type="checkbox"/>
	Pitch	<input type="checkbox"/>
	Roll	<input type="checkbox"/>
	Ground Speed	<input type="checkbox"/>
	Voltage	<input type="checkbox"/>
	Amperage	<input type="checkbox"/>

1. Configure: Opens Graph Configuration.
2. Anti Alias: Used to smooth jagged edges on curved lines and diagonals.
3. Scaling: Adjusts the scale of the graph.
4. Data Name
5. Check Box: User input for the data to be graphed.
6. Color Settings: User selected color for each row of data selected.

Select the check box in the row of the data desired to be graphed then select the color you would like the line to be on the graph, repeat for each row of data.


Event Log:

Configuration
elevation
+ -
Telemetry
Graph
Event Log
< Robot >
Lat: 0.0
Lng: 0.0
MPH: 0.0
New Enter
Save Load
Set Target
Looping On



1. Event Log: Lists all attempts of communication between the vehicle and the Dashboard software (successful or not).


Data Panel:



Data from the robot will populate this panel when connected. A lack of data when connected could indicate a failing connection to the robot, possibly from distance or obstacles blocking the signal.

- ①. Altitude (Above Ground), Altitude (Sea Level), Speed (MPH), Battery Voltage (Vcc).
- ②. Vehicle Direction (compass heading)
- ③. Vehicle Pitch & Roll (front to back tilt & side to side tilt)
- ④. Radio Status (current position of control sticks)

Flight Modes:



Magnetic Declination	0.0
GPS assist	0.0
Auto Descent Rate	0.0
#33	0.0
#34	0.0

min: 0.0 max: 1.0 default: 1.0

Set to 1 to enable gps loitering when flying in assisted mode with the pitch/roll commands centered. Set to 0 to disable gps loitering; the pilot retains complete control of pitch and roll when in assisted mode, with the processor only stabilizing the altitude autonomously

3

1. Stick Movements: This will show you how the inputs from the radio are being received by the arduino code. You will want to make sure that the stick movements of your controller match the movements of the orange dots. If their movements don't match you will need to either reverse the channel or double check that you have correctly connected the radio receiver to the flight controller.

2. Flight Mode Indicator: This will toggle between the left and right boxes to indicate if the MultiRotor is in Stabilize or Altitude Hold. The box highlighted orange indicates the current flight mode.

A. Stabilize: Maintains level flight only.



A



B. Altitude Hold: Maintains level flight and holds altitude.




B




3. GPS Assist (Loiter Mode): Setting this value to 1 will replace Altitude Hold with Loiter Mode. The MultiRotor will hold latitude and longitude while you aren't moving the right stick on the remote.

C. Loiter Mode: Maintains level flight, holds altitude and GPS position.




Connection Panel:




1. The refresh button will repopulate the drop down menu with the currently available serial ports
2. To connect, select the appropriate serial port in the drop down and press connect.
3. When a connection has been established, the “Connect” button will change to say “Disconnect”





Terminal:



- The terminal will display status updates of the communication messages.
- If the dash is forced to give up on a message it will inform you which message did not make it to the robot.
- Malformed or misunderstood messages coming from the robot are signs of a failing connection but not themselves cause for worry.

Map View:



-  The rover will automatically be placed on the map where the GPS indicates it is located
- Click and drag on the map to pan your view
- Scroll on the map or click the   to zoom
- Click on any empty part of the map to add a waypoint to the end of the current path
- Click on any waypoint to select it. The current waypoint will be green 
- Click on a path to “break” it and add a waypoint in the middle
- Right click on a waypoint to remove it from the path
- Click a waypoint and drag to reposition it
- The Yellow line is the direct path from the Drones current location to the next waypoint.

Switching Between Ground and Air Mode

To switch the dashboard between ground drone and air drone mode, Open the configuration window, press “Toggle ground/air mode”, and then restart the dashboard

Artificial Horizon

When in air mode, the artificial horizon widget can be clicked on to open a full size window with altitude and heading overlaid on the right and top edge respectively.

Waypoint Targeting

When in ground mode, clicking the map will place a GPS waypoint at that location that a connected rover will attempt to drive to. To add a waypoint at the end of the path, click on the map. Click on an existing path’s line to “break” it and add a new point in-between. Right click on a point to delete that waypoint

Log Files

The dashboard makes a .log and a .telem file in the log directory each time its run.

.log files contain a record of errors, warnings, and messages received from the robot while its running.

.telem files contain the robots telemetry data storing in CSV format with the first column containing the timestamp that data was stored at, and the remaining columns being each index of telemetry in order.

The frequency that received telemetry is logged can be changed in the telemetry window, accessible from the left navigation box in the dashboard.



®

*injection-molded
plastic*

For technical questions or to place an order:

Phone: (509) 252 - 5767

Fax: (509) 924 - 2219

Email us at:

info@mymindsi.com

Write to:

ATTN: MINDS-i Inc.

22819 East Appleway Avenue

Liberty Lake, Washington 99019

For the latest from MINDS-i visit:

mindsieducation.com

For technical questions with programming email:

code@mymindsi.com