



SCREAMIN' WATER SLIDE

Ages: 5-14
Weight Limit: 140 lbs
B4A.149 Water Slide

Kit Contains:


- (1) 30 ft. Water slide
- (5) Stakes
- (1) Repair kit


BE SAFE! ALWAYS FOLLOW THESE SAFETY RULES


- ADULT SUPERVISION IS REQUIRED AT ALL TIMES!
- Not recommended for children under 5 years of age and over 14 years of age.
- Maximum weight - 140 lbs
- Review the rules with children each time slide is used.
- Instruct and supervise children so that only one child is allowed on the slide at a time.
- Instruct and supervise children to slide so their arms and stomach contact the slide first. Children should be crouched down and be close to the slide and fully extend their bodies. No flipping, tumbling or other rough play on the slide.
- DO NOT DIVE HEAD FIRST WITHOUT HAVING YOUR ARMS EXTENDED FORWARD AND HEAD UP IN ORDER TO SEE AHEAD OF YOU.
- Instruct and supervise children so that they do NOT attempt to slide on knees
- Instruct and supervise children so that they do NOT attempt to slide feet first
- Instruct and supervise children to get bathing suits or clothing wet first before using the slide.
- Instruct children to remove all hard or sharp objects from person and pockets, including, but not limited to: toys, buckles, keys, jewelry, watches, etc.
- Never use slide when there is lightning or thunder in the area.
- Move slide after a long period of play to another area or strip due to ground getting hard packed.
- Because of their larger size, older children and adults risk spine, neck, head, or other life-threatening injuries from using this slide.
- Use common sense and avoid taking risks.
- Reckless use, misuse or abuse of this slide may cause serious, even fatal injury. Read instructions and safety rules before using. USE ONLY AS INSTRUCTED!



 **WARNING!**
ADULT ASSEMBLY AND SUPERVISION REQUIRED.
Children must be instructed on and follow the safety rules at all times.

 **WARNING!**
Failure to read and follow the instructions and safety rules could lead to serious injury, paralysis or death. Use only as instructed

 **WARNING!**
Not for adult use. Not for use by children over 14 or under 5 years of age. NOT FOR USE BY ANYONE OVER 140 LBS (63 KG)

 **IMPORTANT PRODUCT DISCLAIMER AND NOTICE**
Poor site selection and set up, inadequate user instruction, poor adult supervision or improper use can result in severe injury or death. The buyer and user(s) of this product assume all risk and accept all responsibility for any damage or injury, including death that may arise from the use of the SCREAMIN' WATER SLIDE.





***SCREAMIN'* WATER SLIDE**

1. SITE SELECTION AND SET-UP

- SCREAMIN' WATER SLIDE must be properly setup and installed by an adult.
- ADULT SUPERVISION REQUIRED AT ALL TIMES.
- Choose a clear runway for the slide on a flat, healthy lawn surface free of depressions or high spots. The lawn must be a soft, shock absorbing surface, not a hard packed or high traffic area.
- Do not use on pavement, sidewalks, patios, driveways or other hard surfaces.
- Allow a minimum of 10 feet (3 m) additional runway space before the slide.
- Before set-up, check under and around the slide for sharp objects, rocks, sticks, lawn sprinklers or other objects that could cause injury to users or damage the slide.
- Place slide down with inflatable bumper side up. Walk off 10 feet (3 m) away on all sides of the slide and make sure the 10-foot area on each side is free from concrete, sidewalks, trees, walls, holes, rocks, garden equipment, fences, pools and other sharp objects that could injure users.
- Inspect slide for rips, tears or punctures. Do not use a damaged slide.
- Use repair patches included for small tears and punctures. Clean the damaged area thoroughly, press patch firmly over puncture, then wait 30 minutes to inflate.
- Inflate the two long slide bumpers and half circle splash pool bumper.
- Inflate the launch pad. Inflate ALL bumpers and launch pad to moderately firm- DO NOT OVER INFLATE OR DAMAGE MAY RESULT.
- Wet the entire slide before connecting hose to slide. Connect hose to spray section.
- Adjust spray height by using your home faucet/spigot handle. Spray MUST land on the slide section for proper sliding operation and safety.
- TIP: If side panel rolls over, use a towel to align/adjust your sprayers so that water from the sprayers lands on the sliding section. Note: towels under outside of inflatable bumpers only. Do not place under the sliding section.



2. BEFORE EACH USE

- Check your slide for tears, leaks or any signs of damage. Use the included repair patches for small tears and punctures. See instructions on back of patch for directions.
- Too big a tear to repair? Contact b4Adventure for ordering information: 1-844-834-4334 or info@b4Adventure.com.
- Do not add or use other products with the SCREAMIN' WATER SLIDE as injury may result.
- Review ALL safety instructions with children before letting them use the slide

3. AFTER EACH USE

- Detach garden hose. Carefully deflate the slide bumpers and pad by pinching the valve with your fingers. Tip: Have a friend work their way towards you while pushing the air from the bumpers and pad.
- Clean your slide of any dirt, grass or debris. Use a mild dish soap solution. Do not use caustic or harsh chemicals as they may damage the slide material.
- Rinse the slide completely, dry and roll up. Store Slide and Surf water slide indoors or in closed container only after the slide is completely dry (to avoid mold/mildew).
- Store slide in a secure place, away from children, to prevent suffocation or unsupervised use.

for more detailed information on how to repair your water slide visit:
<https://www.b4adventure.com/waterslide-repair/>

