


ED1100 /1100F SERIES RIM EXIT DEVICE

INSTALLATION INSTRUCTIONS




1100 SERIES RIM EXIT DEVICE






DOOR PREPARATION CHART




TEMPLATE APPLICATION CHART




FUNCTION	RHR	LHR
01	A+E	A+E
02	A+E+G	A+B+E
08	A+C+E+G	A+F+E+B
09	A+D+E	A+D+E

DRAW HORIZONTAL DEVICE AND STRIKE CENTERLINE.




centerline to outside face of door if trim is using) Close door, mark horizontal centerline on inside face of door and on lock side door stop 39-5/8" from finished floor as shown(continue horizontal

2 align strike on horizontal 3 install strike and shim. 4 position template and on $\mathfrak L$ TWO(2) SLOTTED HOLES.




and drill / tap holes as required. centerline on door stop and door. Mark centers centerline on strike lines up with the horizontal and against inside face of door, so the horizontal Use strike as template and place on door stop




through each slot. Prepare two(2) holes and install a screw

AND MARK DOOR




indicated on the template. Mark centers and drill/tap the required holes as template line up with centerlines on the door. using) to the door so that the centerlines on the Tape "TEMPLATE A" (and trim template if trim is




5 PREPARE DOOR FOR DEVICE AND TRIM.

of door. Use extra care if edge of door is beveled. Be sure X-X vertical centerline is parallel to edge Locate same vertical centerline for both sides. See trim instructions for outside door preparation.



See "DOOR PREPARATION CHART" on page 3 for drill, tap and cut-out information.


$oldsymbol{6}$ DETERMINE USE OF NL DRIVE SCREW.



NL driver screw is factory assembled in cam on back of device center case, when the NL drive screw is left in back of center case, the outside cylinder will function only as a Night Latch

- NOTE: 1. DO NOT remove NL drive screw for Pull Plate or when installing trim that has a functional lever Escutcheon with night latch cylinder
- 2. **REMOVE** NL drive screw from back of center case lock and unlock the trim. knob, or thumb piece AND an outside cylinder to

$m{7}$ INSTALL TRIM (IF USING) AND SECURE DEVICE CENTER CASE TO DOOR.




Screws Cente Case

- 1. DEVICE WITH TRIM See "Trim Instructions".


 2. CYLINDER ONLY Install cylinder with cylinder back plate as shown. Make sure the tailpiece is extending 1/2" from the inside face of door. Insert tailpiece into cam in the center case and mount it to the door with six(6) center case screws
- . EXIT ONLY Mount center case to the door with six(6) center case screws.

For FIRE EXIT DEVICES:


mount devices with machine screws. has an alternate mounting method. Fire doors with steel reinforcement, hollow metal doors without reinforcement unless door manufacturer (wood, plastic and steel covered), wood core, sheet metal and Two(2) sex bolts and support screws are required for composite



8 INSTALL MOUNTING BRACKET AND END CAP




1. Remove cover plate, insert end cap bracket into Level device, mark and drill two(2) holes for #10 sheet push bar assembly against mechanism case Fasten end cap bracket screws to door metal screws or #10-24 machine screws.




2. Insert cover plate, slide anti-rattle clip in position (2" minimum from end), and attach end cap with two(2) end cap screws.


9 ADJUST AND SECURE STRIKE.

10 INSTALL COVER.



Fasten strike to frame and adjust strike so that the device latches tightly without binding, apply third center screw once adjustment is complete.






Attach cover to center case with two(2) center case screws.


OPTIONAL DOGGING

CYLINDER DOGGING




Slide cover plate in position in the mechanism case.

DOGGING CHECK




Depress push bar and turn hex wrench or key one full turn for dogging check.


DOUBLE CYLINDER INSTALLATION




1. Remove cover.



 Mount rim cylinder to cylinder spacer and bracket and attach assembly to center case with two(2) cylinder screws through cylinder back plate as shown.




3. Install center case and trim with center case screws. **NOTE:** See "Trim Instructions" to install trim cylinder.




4. Cut off tailpiece if necessary for different door ranges and various cylinder lengths.


CAUTION! If tailpiece is too far into cylinder cam may interfere both cylinders' operation.




To remove standard cam and replaced with extension cam.

CUT DEVICE (IF REQUIRED)





1. With anti-rattle clip removed, tape and mark area being cut.



Cut off device and deburr.

NOTE: Device must be cut square for proper end cap fit.

