



ENERGY FLEX MOTORIZED TREADMILL

SF-T7724

USER MANUAL



IMPORTANT! Please retain owner's manual for maintenance and adjustment instructions. Your satisfaction is very important to us, **PLEASE DO NOT RETURN UNTIL YOU HAVE CONTACTED US:** support@sunnyhealthfitness.com or 1- 877 - 90SUNNY (877-907-8669).

IMPORTANT SAFETY INFORMATION

We thank you for choosing our product. To ensure your safety and health, please use this equipment correctly. It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained, and used properly. It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.


1. Before starting any exercise program, you should consult your physician to determine if you have any medical or physical conditions that could put your health and safety at risk or prevent you from using the equipment properly. Your physician's advice is essential if you are taking medication that affects your heart rate, blood pressure, or cholesterol level.
2. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, shortness of breath, lightheadedness, dizziness, or feelings of nausea. If you do experience any of these conditions, you should consult your physician before continuing with your exercise program.
3. Keep children and pets away from the equipment. The equipment is designed for adult use only.
4. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 8 feet (240 CM) of free space behind it and 2 feet (60 CM) on each side. Do not place the treadmill on any surface that blocks air openings. To protect the floor or carpet from damage, place a mat under the treadmill.
5. Ensure that all nuts and bolts are securely tightened before using the equipment. The safety of the equipment can only be maintained if it is regularly examined for damage and/or wear and tear.
6. Always use the equipment as indicated. If you find any defective components while assembling or checking the equipment, or if you hear any unusual noises coming from the equipment during exercise, discontinue use of the equipment immediately and do not use until the problem has been rectified.
7. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may become entangled in the equipment.
8. Do not place fingers or objects into the moving parts of the equipment.
9. The maximum weight capacity of this unit is 240 pounds (110 KG).
10. The equipment is not suitable for therapeutic use.
11. To avoid bodily injury and/or damage to the product or property, proper lifting and moving is required.
12. Your product is intended for use in cool, dry conditions. You should avoid storage in extreme cold, hot or damp areas as this may lead to corrosion and other related problems.
13. This equipment is designed for indoor and home use only, it is not intended for commercial use!



IMPORTANT NOTE:

The belt must be lubricated before the first use! Please see Page 8 for instructions on how to properly apply lubricant.

EXPLODED DIAGRAM



ASSEMBLY CONTENTS

WHEN YOU OPEN THE CARTON, YOU WILL FIND THE FOLLOWING PARTS:

Main Frame (No. 2) 	Safety Key (No. 76) 	MP3 Wire (No. 77) 	Half-roundhead Hex Bolt (No. 55) – 4pcs
Serrated Gasket (No. 56) - 6pcs 	Half-roundhead Hex Bolt (No. 38) - 2pcs 	Silicone Oil (No. 81) 	Allen Wrench (No. 82)
Allen Wrench (No. 83) 			

HARDWARE PACKAGE

#38 M8*45 2PCS	#55 M8*15 4PCS
#56 D8 6PCS	
#83 S6 1PC	#82 S5 1PC

PARTS LIST

No.	Description	Spec.	Qty.
1	Base Frame		1
2	Main Frame		1
3	Left Support Tube		1
4	Right Support Tube		1
5	Computer Bracket		1
6	Incline Bracket		1
7	Side Rail Support		10
8	Retainer Plate		2
9	Computer Upper Cover	755*537*115	1
10	Computer Bottom Cover	755*559*138	1
11	Computer Panel	429*337*20	1
12	Left Handrail Bushing	323*97*54	1
13	Right Handrail Bushing	323*97*54	1
14	Motor Cover	607*396*123	1
15	End Cap (L)	133*96*91	1
16	End Cap (R)	133*96*91	1
17	Side Rail	1215*70*17	2
18	Motor Bottom Cover	605*345*22	1
19	Transportation Wheel	Ø45* Ø8.2*22	2
20	Moving Wheel	Ø51* Ø8.2*20	2
21	Cable Protector	Ø24* Ø18*9	1
22	Flat Foot Pad	Ø31* Ø6*16	4
23	Cushion	Ø30*32*M8	4
24	Round Cushion	Ø20*Ø16*17.	2
25	Transportation Wheel Cover	60*30*18.8	2
26	Front Roller	46*558	1
27	Rear Roller	46*550	1
28	Running Board	1210*480*18	1

No.	Description	Spec.	Qty.
29	Running Belt	2785*460*1.6	1
30	Motor Belt	210-J6	1
31	Cylinder	610*260-35kg	1
32	Incline Bushing	Ø15* Ø10*9	4
33	Flat Washer	Ø20* Ø 10.5*2	6
34	Flat Washer	Ø16* Ø 8.5*1.2	14
35	Cross Recessed with Washer Head Self-tapping Screw	ST4.2*13	24
36	Cross Recessed Pan Head Tapping Screw	ST4.2*16	29
37	Cross Recessed Pan Head Tapping Screw	ST4.2*45	4
38	Half-roundhead Hex Bolt	M8*45	8
39	Half-roundhead Hex Bolt	M8*35	2
40	Roundhead Hex Bolt	M8*50	1
41	Roundhead Hex Bolt	M8*55	2
42	Roundhead Hex Bolt	M8*15	9
43	Cross Recessed Pan Head Tapping Screw	ST4.2*8	10
44	Half-roundhead Hex Bolt	M8*25	1
45	Half-roundhead Hex Bolt	M8*45	1
46	Half-roundhead Hex Bolt	M10*25	4
47	Half-roundhead Hex Bolt	M10*45	1
48	Half-roundhead Hex Bolt	M10*60	1
49	Cross Recessed Round Head Screw	M5*15	9
50	Cross Recessed Sunk Head Screw	M8*30	6
51	Lock Nut	M10	6
52	Lock Nut	M6	12
53	Lock Nut	M8	16
54	Cross Recessed Pan Head Self-drilling Tapping Screw	ST4.2*19	2
55	Half-roundhead Hex Bolt	M8*15	4
56	Serrated Gasket	D8	6

No.	Description	Spec.	Qty.
57	Spring Washer	M8	6
58	DC Motor		1
59	Incline Motor		1
60	Power Line	2100mm	1
61	Power Line Plug	6N-3	1
62	Power Switch	250V/16A	1
63	Overload Protector	250V/16A	1
64	Single Blue Wire	250mm	1
65	Single Blue Wire	100mm	1
66	Single Brown Wire	250mm	1
67	Safety Key Sensor		1
68	Computer Chip		1
69	Controller		1
70	Button Board		1
71	Overlay		1

No.	Description	Spec.	Qty.
72	Key Panel Sticker		1
73	Incline Hand Pulse		1
74	Speed Hand Pulse		1
75	Speaker		2
76	Safety Key		1
77	MP3 Wire		1
78	Upper Computer Wire		1
79	Middle Computer Wire		1
80	Lower Computer Wire		1
81	Silicone Oil		1
82	Allen Wrench	S5	1
83	Allen Wrench	S6	1
84	Top Console		1
85	Cushion	Ø20*20*M6	2

Ordering Replacement Parts (U.S. and Canadian Customers only)


Please provide the following information in order for us to accurately identify the part(s) needed:

- ✓ The model number (found on cover of manual)
- ✓ The product name (found on cover of manual)
- ✓ The part number found on the “EXPLODED DIAGRAM” and “PARTS LIST” (found near the front of the manual)

Please contact us at support@sunnyhealthfitness.com or 1- 877 - 90SUNNY (877-907-8669).

ASSEMBLY INSTRUCTIONS

We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at support@sunnyhealthfitness.com or 1-877-90SUNNY (877-907-8669).




STEP 1:

Open the carton and remove all contents. Place the **Main Frame (No. 2)** on level ground and ensure that you have a clean, adequate work space. Follow the diagram on the left to lift the top console upright.

NOTE: Be careful not to puncture the wires when folding!

STEP 2:


Secure the **Left & Right Support Tubes (No. 3 & No. 4)** to the base frame using 2 **Half-roundhead Hex Bolts (No. 55)**, 2 **Half-roundhead Hex Bolts (No. 38)**, and 4 **Serrated Gaskets (No. 56)**. Tighten and secure with **Allen Wrench (No. 82)**.



We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at support@sunnyhealthfitness.com or 1-877-90SUNNY (877-907-8669).

STEP 3:

Secure the **Top Console (No. 84)** to both support tubes using 2 **Half-roundhead Hex Bolts (No. 55)** and 2 **Serrated Gaskets (No. 56)**. Tighten and secure with **Allen Wrench (No. 82)**.




STEP 4:

You may now remove the packing belt. Next, insert the **Safety Key (No. 76)** into the console.

NOTE: The belt must be lubricated before the first use! Please see Page 8 for instructions on how to properly apply lubricant.

The assembly is complete!



LUBRICATING THE TREADMILL

IMPORTANT NOTE:

You will need to lubricate your treadmill before the first use!


RUNNING BELTS & TREADMILL LUBRICANT:

Lubricating the **Running Belt (No. 29)** & **Running Board (No. 28)** is essential as the friction between the two affects the life span and operations on the treadmill. Inspect the running **Running Belt (No. 29)** regularly. If you find any wear on the **Running Board (No. 28)**, please contact us at support@sunnyhealthfitness.com.

⚠ WARNING: Always unplug the treadmill from the electrical outlet before cleaning, lubricating, or repairing the unit.

The following time table is recommended:

- | | |
|--|-----------------------|
| ● Light user (less than 3 hours/ week) | <i>every 2 months</i> |
| ● Medium user (3-5 hours/ week) | <i>every 45 days</i> |
| ● Heavy user (more than 5 hours/ week) | <i>every month</i> |



NOTE:

To better maintain the treadmill and prolong its life, it is suggested that the treadmill be powered off for 10 minutes every 2 hours and fully powered off when not in use.

A loose **Running Belt (No. 29)** will result in the runner sliding off when in use, while too tight of a **Running Belt (No. 29)** will result in decrease to the motors performance and create more friction between the roller and **Running Belt (No. 29)**. The most suitable tightness for the **Running Belt (No. 29)** is pulled out 50-75mm from the **Running Board (No. 28)**.


MAINTENANCE GUIDE

General cleaning will help to prolong the life and improve performance of your treadmill. Keep the unit clean and maintained by dusting the components on a regular basis, cleaning the two exposed sides of the **Running Belt (No. 29)** will prevent dust from accumulating underneath. Keep your running shoes clean so that dirt from the shoes does not wear the **Running Board (No. 28)** and **Running Belt (No. 29)**. Clean the surface of the **Running Belt (No. 29)** using a clean, damp cloth. Keep liquids away from electrical parts and the **Running Belt (No. 29)**.


ADJUSTING THE RUNNING BELT

Place the treadmill on level ground and set it at 3.5-5 MPH to check and see if the **Running Belt (No. 29)** drifts from the center. Adjust the **Running Belt (No. 29)** according to below instructions with **Allen Wrench (No. 83)**


1. If the **Running Belt (No. 29)** drifts to the right, turn the adjusting bolt on the right side $\frac{1}{4}$ turn **clockwise**, then turn the left adjusting bolt $\frac{1}{4}$ turn **counter-clockwise**. If the **Running Belt (No. 29)** does not move, repeat this step until it centers. Refer to image A.



2. If the **Running Belt (No. 29)** drifts to the left, turn the adjusting bolt on the left side $\frac{1}{4}$ turn **clockwise**, then turn the right adjusting bolt $\frac{1}{4}$ turn **counter-clockwise**. If the **Running Belt (No. 29)** does not move, repeat this step until it centers. Refer to image B.



3. Over time, the **Running Belt (No. 29)** will loosen. To tighten the **Running Belt (No. 29)**, turn both the left & right side adjusting bolts one full turn **clockwise**. Check the tension of the **Running Belt (No. 29)**. Continue this process until **Running Belt (No. 29)** is at the correct tension. Make sure to adjust both sides equally to ensure even alignment. Refer to image C.




FOLDING INSTRUCTIONS



NOTE: Please make sure the incline is at ZERO when folding and unfolding.

FOLDING:

To fold the treadmill, place your hands at the end of the running board and lift the running board all the way up until you hear the safety lock 'Click' from the safety cylinder.




UNFOLDING:

To unfold the treadmill, simply give the safety cylinder a light kick and pull down the running board at the same time. With its soft drop system, the machine will unfold slowly.

(Please keep everyone and all pets away from the machine when unfolding the treadmill).

INCLINE INSTRUCTIONS




Console Keys   and **+ - INCLINE Handrail Keys** are used to control the incline level. Increase or decrease the incline level by pressing the incline buttons once per level or holding an incline key down to skip through to the desired level.

INCLINE LEVELS

(0%)	= 1.75°
(1%)	= 1.90°
(2%)	= 2.2°
(3%)	= 2.5°
(4%)	= 2.85°
(5%)	= 3.15°
(6%)	= 3.5°
(7%)	= 3.75°
(8%)	= 4.10°
(9%)	= 4.40°
(10%)	= 4.75°
(11%)	= 5.05°
(12%)	= 5.40°
(13%)	= 5.70°
(14%)	= 6.00°
(15%)	= 6.25°


Quick 3%, 6%, 9%, 12%, 13%, 14%, 15% INCLINE Keys give you the ability to instantly program a specific incline level with the push of a button.

HOW TO MOVE THE TREADMILL



Before attempting to move the treadmill, make sure that it has been properly folded. Then, unplug the power cord.

To tilt, start by placing one hand at position "P" to support the top end of the treadmill. Next, place one foot at position "K" to hold the bottom end of the treadmill steady. With your foot at "K", slowly tilt the top of the treadmill downward towards the ground. Once the Main Frame "P" reaches a low enough point, the wheels of the treadmill will touch the ground.




To transport, hold the treadmill from position "P" and tilt until the wheel's "K" are able to move on the ground.

IMPORTANT ELECTRICAL INFORMATION

IMPORTANT NOTE: This treadmill requires a power source of **110 Volts** in order to properly operate. For your safety, as well as the safety of others, please verify that the power source is correct before powering the equipment. Any power supply source above or below this level could cause significant damage to the equipment and/or user.

GROUNDING METHODS:

This product must be grounded. Should the treadmill malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a plug that has an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.




CAUTION:

Improper connection of the equipment can result in risk of electric shock. Check with a qualified electrician or serviceman if you are unsure whether the product has been properly grounded. Do not modify the plug provided with this product. If it will not fit the outlet, have a proper outlet installed by a qualified electrician. Ensure that the product is connected to an outlet with the same configuration as the plug. Do not use an adaptor for this product.

WARNING!

1. **NEVER** use a ground fault circuit interrupt (GFCI) outlet with this treadmill. Route the power cord away from all moving parts of the treadmill, including the Air Pressure Cylinder and transportation wheels.
2. **NEVER** operate the treadmill using a generator or UPS power supply.
3. **NEVER** remove any cover on this treadmill without first disconnecting the power cord.
4. **NEVER** expose the treadmill to rain or moisture. This treadmill is not designed for outdoor use or use in any high humidity environment.

THE DISPLAY CONSOLE



WINDOW DISPLAY

The treadmill will start after a 3 second countdown.

1. **PROGRAM:** In addition to manual mode, there are 16 preset programs (P1-P16) and 3 user programs (U1-U3).
2. **SPEED:** The speed range is 0.6-10 MPH. The initial default speed is 0.6 MPH.
3. **TIME:** Displays the elapsed running time or countdown time (0:00~99:59MIN). Once the time has elapsed past 99:59 MINS, you may press the + key to reset it back to 0:00.
4. **DISTANCE:** Displays the total distance traveled or distance countdown (0.0-99.9MILES).
5. **CALORIES:** Displays total calories burned or calories countdown (0.0-999 CAL).
6. **INCLINE:** Displays the current incline (0-15% INCLINE).
7. **PULSE:** Displays your pulse data when hands are placed on the sensors (50-200 BPM).
8. **SAFETY KEY:** The safety key lock acts as an emergency stop function. In case of emergency, simply remove the **Safety Key (No. 76)** from the console and the console will beep twice and bring the running belt to a complete stop.

FUNCTION KEYS/MANUAL MODE

1. **START/STOP:** Insert the **Safety Key (No. 76)** into the console and press START to start the treadmill. The treadmill will initiate at the default running speed of **0.6 MPH**. Press STOP to bring the running belt to a stop.

2. **PAUSE:** Press to pause your current workout session.

NOTE: Pressing STOP once will stop the treadmill. Current workout data is retained. You can press START to continue the workout or press STOP again to clear current workout data.

3. **SPEED +/- KEYS:** During use, use these +/- keys to increase or decrease your speed. The speed will adjust 0.1 MPH at a time.

4. **PROG (PROGRAM) BUTTON:** Press the PROG button while the treadmill is not running to manually cycle through and choose a program. Programs range from P1-P16, and 3 personalized user programs U1-U3.

5. **MODE:** Press this button to choose which *Countdown Mode* to preset before starting the treadmill. H-1 is the TIME Countdown, H-2 is the DISTANCE Countdown, and H-3 is the CALORIES Countdown. Press the SPEED +/- keys to increase or decrease from the set data and/or press the START button to start this exercise.

6. **2MPH, 4MPH, 6MPH, 8MPH (QUICK SPEED KEYS):** Use these quick speed keys to instantly bring the running belt to the desired speed of 2MPH, 4MPH, 6MPH or 8MPH.

7. **3%, 6%, 9%, 12% (QUICK INCLINE KEYS):** Use these quick incline keys to instantly bring the treadmill to an incline of 3%, 6%, 9%, or 12%.

8. **USB CHARGER:** Connect the USB input to charge your mobile device.

COUNTDOWN MODE

1. Press the MODE key to select **H-1** (TIME), **H-2** (DISTANCE), or **H-3** (CALORIES) Countdown.
2. Set the desired TIME, DISTANCE, or CALORIES setting to countdown from.
3. Press START to begin this exercise.

H-1 (TIME): Countdown is set at the initial time setting of 30:00 MINS. You may increase or decrease the set time by pressing the SPEED +/- keys. The TIME setting range is from 5:00-99:00 MINS.

H-2 (DISTANCE): Countdown is set at the initial distance setting of 1.0 MILES. You may increase or decrease the set distance by pressing the SPEED +/- keys. The DISTANCE setting range is from 1.0-99.9 MILES.

H-3 (CALORIES): Countdown is set at the initial calories setting of 50 KCAL. You may increase or decrease the set calories by pressing the SPEED +/- keys. The CALORIES setting range is from 20-990 KCAL.

NOTE: Once completed with a Countdown Mode program, the treadmill will stop, then return to Manual Mode.

PROGRAMS

Each program is divided into 16 exercise segments in an equal time division.

TIME MODE		SET TIME/16															
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
P1	SPEED	1.2	3.1	3.1	3.1	6.2	6.2	3.1	3.1	3.1	1.9	1.9	1.2	3.1	3.1	1.9	1.2
	INCLINE	0	0	1	1	1	1	2	2	2	2	3	3	3	2	2	0
P2	SPEED	1.2	1.2	4.3	1.2	1.2	4.3	4.3	7.5	2.5	2.5	7.5	2.5	2.5	7.5	2.5	1.2
	INCLINE	0	1	2	2	3	3	2	2	3	3	2	2	3	2	2	0
P3	SPEED	1.2	2.5	5.6	5.6	2.5	2.5	5	5	6.2	6.2	7.5	2.5	2.5	5	2.5	1.2
	INCLINE	0	1	2	3	4	5	4	5	4	2	1	2	3	2	1	0
P4	SPEED	1.2	3.7	3.7	3.7	7.5	7.5	7.5	7.5	3.7	3.7	1.9	1.9	1.9	3.1	3.1	1.2
	INCLINE	0	1	2	3	4	5	6	7	6	6	5	4	3	2	1	0
P5	SPEED	1.2	2.5	3.7	7.5	7.5	7.5	1.9	1.9	1.9	1.9	7.5	7.5	7.5	3.7	2.5	1.2
	INCLINE	0	2	4	6	4	2	1	0	1	1	2	2	2	2	3	0
P6	SPEED	1.2	2.5	3.1	3.1	3.7	3.7	5	5	3.7	3.7	5	5	3.7	5.6	3.7	1.2
	INCLINE	0	1	3	4	4	3	3	1	2	1	2	1	2	1	2	0
P7	SPEED	1.2	4.3	4.3	5.6	5.6	2.5	2.5	7.5	7.5	2.5	2.5	5	5	2.5	2.5	1.2
	INCLINE	0	1	1	2	2	3	3	4	4	3	3	2	2	1	1	0
P8	SPEED	1.2	1.2	3.7	3.7	3.7	5	5.6	6.2	6.8	7.5	5.6	3.1	3.1	3.1	1.9	1.2
	INCLINE	0	1	2	4	2	1	2	4	2	1	2	4	2	1	2	0
P9	SPEED	1.2	2.5	5	6.2	1.2	2.5	5	6.2	1.2	2.5	6.2	1.2	2.5	6.2	2.5	1.2
	INCLINE	0	1	2	3	4	5	6	7	8	9	8	6	4	2	1	0
P10	SPEED	1.2	3.1	3.7	4.3	5	5.6	6.2	6.8	6.2	5.6	5	3.7	4.3	3.1	2.5	1.2
	INCLINE	0	1	2	4	6	6	6	4	4	4	2	2	2	1	1	0
P11	SPEED	1.2	3.1	3.7	4.3	5.6	5.6	3.7	5.6	3.7	5.6	3.7	6.2	3.7	6.2	4.3	1.2
	INCLINE	0	2	2	2	3	3	3	4	4	4	5	5	5	4	4	0
P12	SPEED	1.2	3.7	5	6.2	5	3.7	2.5	3.7	5	7.5	5	3.7	5	7.5	7.5	1.2
	INCLINE	0	1	1	3	3	5	5	7	7	5	5	3	3	1	1	0
P13	SPEED	1.2	7.5	2.5	7.5	2.5	7.5	2.5	7.5	2.5	7.5	2.5	7.5	2.5	7.5	2.5	1.2
	INCLINE	0	8	10	13	4	8	10	13	4	8	10	13	4	8	10	0
P14	SPEED	1.2	5	6.2	7.5	2.5	5	6.2	7.5	2.5	5	6.2	7.5	2.5	5	6.2	1.2
	INCLINE	0	8	12	13	4	8	12	13	4	8	12	13	4	8	12	0
P15	SPEED	1.2	7.5	6.2	5	7.5	7.5	6.2	5	7.5	7.5	6.2	5	7.5	7.5	6.2	1.2
	INCLINE	0	3	4	5	6	8	7	8	8	7	7	6	5	4	3	0
P16	SPEED	1.2	7.5	2.5	7.5	2.5	7.5	2.5	7.5	2.5	7.5	2.5	7.5	2.5	7.5	2.5	1.2
	INCLINE	0	4	5	6	2	4	5	6	2	4	5	6	2	4	5	0

USER PROGRAMS (U1-U3):

Each program is made up of 16 segments. User Programs allow you to personalize each segment of your exercise program by programming each individual segment's time duration, desired speed, and incline.

To begin, press the PROG button to select U1, U2, or U3 then press MODE to enter the setting mode and set the TIME of the 1st segment. Next, set the desired SPEED of the 1st segment by pressing the SPEED +/- keys and set the INCLINE by pressing the INCLINE +/- keys. Press MODE and your 1st segment is set.

The next workout segment will flash. Repeat the instructions above until you've completed programming all 10 segments.

BODY MASS INDEX (BMI) CALCULATION:

Press the PROGRAM button until the window displays FAT. Press MODE to enter your (F1) Gender (F2) Age (F3) Height (F4) Weight. Press the SPEED +/- keys to set the data accordingly. After you've set up F1~F4, F5 will display on the screen. Hold the handle pulse sensors and the BMI calculator will display your BMI.

NOTE: Average Body Mass Index score is 20-25%

Underweight Below 19.0

Normal 20.0 – 25.0

Overweight 26.0 – 29.0

Obesity 30.0 – and above

BODY MASS INDEX CHART:

F-1	Sex	1 MALE	2 FEMALE
F-2	Age	10 to 99 YEARS OLD	
F-3	Height	40---80 INCHES	
F-4	Weight	44----330 LBS	
F-5	BMI	≤19	Underweight
	BMI	=(20---25)	Normal Weight
	BMI	=(26---29)	Overweight
	BMI	≥30	Obesity

BLUETOOTH INSTRUCTIONS

The SF-T7724 ENERGY FLEX MOTORIZED TREADMILL is designed to provide you with the most efficient workout. Syncing your treadmill with Bluetooth would enable you to listen to your favorite tunes on your music app from your treadmill. Don't worry about getting distracted with a phone call while on the treadmill. The SF-T7724 ENERGY FLEX MOTORIZED TREADMILL allows you to answer your calls without having to interrupt your exercise!

NOTE: When syncing your treadmill with Bluetooth, please unplug the **MP3 Wire (No. 77)**.

HOW TO SYNC TREADMILL TO BLUETOOTH:

1. From your mobile device, go to the main menu and open your SETTINGS.
2. From SETTINGS, turn on your Bluetooth and the found compatible devices should automatically list.
3. Select the BLUETOOTH USER ID listed on your treadmill (e.g.T7724-000001)
4. You will hear a tone to indicate that your treadmill is now synced to your mobile device! You may play music from your favorite music app and listen through your treadmill speakers.

MUSIC FUNCTIONS:

1.  Press this button to PLAY or PAUSE the music.
2.   For song selection, press these buttons to return to a previous song or skip to the next song.
3.   Press these buttons to decrease or increase the volume.

PHONE CALL FUNCTIONS:

1.  When a phone call comes in, simply press the phone button once to answer the call. To hang up, hold down the phone button.

NOTE: The music will automatically pause when a call comes in.

EXERCISE INSTRUCTIONS

GETTING STARTED:

Before starting any exercise programs, you should consult your physician to determine if you have any medical or physical conditions that could put your health and safety at risk or prevent you from using the treadmill properly. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising immediately if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, extreme shortness of breath, lightheadedness, dizziness, or feelings of nausea.

Turn on the power switch located next to the power cord. Get to know your treadmill. Before attempting to use the treadmill take some time to stand alongside it and familiarize yourself with the controls. Once you feel comfortable to get on, you can stand with your feet on the foot rails and balance yourself by putting your hands on the handrails.

Next, attach the clip end of the **Safety Key (No. 76)** to your clothing and insert the magnetic end of the key into the console. Press the START button to start the treadmill. The treadmill will start at the default speed of 0.5MPH. Once you feel comfortable, you may slowly increase the speed. When you are finished with your exercise, press the STOP button or remove the magnetic end of **Safety Key (No. 76)** to stop the treadmill.

SAFETY LOCK:

Remove the **Safety Key (No. 76)** from the console to stop the treadmill immediately. Once the treadmill reaches a full stop, the window display on the computer will show "---" and the treadmill will beep. To start the treadmill again, insert the magnetic end of **Safety Key (No. 76)** into the console and press START.

POWER SAVE FUNCTION:

Once the treadmill has been inactive for 10 minutes, it will adjust to *Power Saving Mode*. When the treadmill is in *Power Saving Mode*, the window display on the computer will shut off. To reactivate, press any key.

POWER OFF:

Power to the treadmill can be turned off at any time without risk during or after an exercise.

CAUTION!

1. We recommend that you maintain a slow speed at the beginning of a session and hold the handrails until you become comfortable and familiar with the treadmill.
2. Insert the magnetic end of the safety key into the computer and attach the opposite end with the safety clip to your clothing before beginning your workout. To end your workout, press the STOP button or remove the safety key. The treadmill will stop immediately.

TROUBLESHOOTING

Code	Description	How to Troubleshoot
-----	Safety key fault.	1. Insert the safety key properly. 2. Replace the safety key sensor or safety key. If there's still a problem, replace the console.
E01	Communication abnormality: no communication from the console to the control board.	Possible Reasons: Communication obstructed between control board and console, please check to make sure the wires are connected properly, and the wires are without any punctures or damage. If this does not resolve the issue, check the control board and PCB IC to see if there's any damage. Replace if necessary.
E02	Motor fault or control board fault.	1. Check if the motor cable is well connected. Reconnect the wire and restart. 2. Check the motor or the control board for any damage. Replace if necessary.
E04	Incline failure: the incline wire is damaged or the wire for the incline motor is not properly connected.	Check incline motor sensor wire and AC wire to see if they are properly connected. Make sure the incline motor wire does not have any punctures or damage.
E05	Current overload protection.	Possible Reasons: Excessive current load, the incoming voltage is too low or too high. The control board is damaged. A moving part of the treadmill is stuck, and the motor is unable to function properly. Try to restart the treadmill. Also, check if there's any burnt odors around the motor and control board. Make sure the power and voltage comply with the standard. Inspect moving parts to ensure they are operating correctly. Listen for unfamiliar noises from the motor.
E06	Burst clash protection.	Possible Reasons: The power voltage is less than normal by 50% or the controller has problems. Make sure the motor wires are connected. Check the control board for any damage or burnt odors. Replace if necessary.
No display in console	Control board abnormality.	1. Check if the overload button switch is off, if so, press it to turn it on. 2. Check the wire on the power switch, overload button, and control board to see if it is connected properly. 3. Check the console wires and all cables between the console and control board. 4. Check the transformer and replace if necessary.