



Airdopes 172

True Wireless Ear-buds

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 172. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual. Also, you may refer to the same at times when you face any sort of difficulty.

Package Contents

- 1 1x boAt Airdopes 172
- 2 1x Charging Case
- 3 1x Type-C Charging Cable
- 4 2x Pairs of Additional Earmuffs (Small & Large)
- 5 1x User Manual
- 6 1x Warranty Card
- 7 1x Catalogue
- 8 1x Read Me Card
- 9 1x FAQ Card

Overview

- 1 CTC (Capacitive Touch Control) / Power Button



Power On:

Step 1: To switch the earbuds on (Smart Power On) simply open the lid of the charging case (when earbuds are inside). Courtesy our IWP™ (Insta Wake N' Pair) technology, the earbuds power on automatically, get connected and enter the connection mode

OR

Long touch the CTC (Capacitive Touch Control) on both earbuds for 3 seconds to manually power on the earbuds.

Step 2: After powering on, the earbuds enter the Connection Mode, indicated by alternate red and blue LED flashes on primary earbud and blue LED flashes once every 5 seconds on the secondary earbud.



Connection Mode:

Step 3: Turn on the Bluetooth functionality on your phone/media device & scan

Step 4: Search for 'Airdopes 172' and pair accordingly.

Congratulations! Your earbuds are now connected successfully via Bluetooth

Note:

- Pairing mode lasts for 5 minutes. If the pairing time is missed, then you will need to reconnect the earbuds and follow the above-mentioned procedure.
- Airdopes 172 remembers previously connected devices; once switched on, the earbuds automatically reconnect to the previously connected devices in working range.



Quick Guide on Functionalities

- 3 Seconds: Long touch left CTC for 3 seconds to activate voice assistant
- 3 Seconds: Long touch both CTCs for 3 seconds to manually power on
- 5 Seconds: Long touch both CTCs for 5 seconds to manually power off
- 10 Seconds: Long press the Reset button for 10 seconds to perform factory reset



Single Earbud Usage

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud

Step 2: The selected earbud automatically enters the connection mode indicated by red and blue LED flashes

Step 3: Turn on Bluetooth on your phone/media device and search for 'Airdopes 172' to connect

Notes:

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage
- You cannot skip tracks or return to the previous tracks in Mono (single-earbud) mode



Charge the Earbuds:

- Step 1:** Please insert the earbuds back inside the charging case in correct orientation and close the lid
- Step 2:** During charging, the indicator on the earbuds stays solid red
- Step 3:** Once the earbuds get fully charged, the charging case automatically switches off to save power, and the earbuds' indicator turns off

Note:
• Before using the earbuds for the first time, it is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.

Charge The Case:

Step: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc.

Remaining Case Battery LED Indications		
Case	Normal State	Charging State
Low Battery	Red LED blinks thrice upon opening the case lid	First shows the normal state then goes into slow breathing red LED
30%-70% Battery	White LED blinks thrice upon opening the case lid	First shows the normal state then goes into slow breathing white LED
70%-99% Battery	Green LED blinks thrice upon opening the case lid	First shows the normal state then goes into slow breathing green LED
Fully charged	LED stays off	Solid green LED

Case LED indication when Earbuds are charging from the case
This is to indicate the earbud getting charged from the case (when case lid gets closed):
• CYAN for 5 seconds to indicate LEFT bud is charging from the Case
• PURPLE for 5 seconds to indicate RIGHT bud is charging from the Case
• If both are properly charged, BLUE for 5 seconds

Basic Functions:

- Voice Assistant: Long touch the left CTC for 3 seconds to activate the voice assistant
- Answer: Single tap the CTC on either earbud to answer an incoming call
- Hang Up / Reject Call: Double tap the CTC on either earbud to end / reject call
- Play/Pause Music: Single tap either earbud's CTC to play or pause music
- Next Track: When playing music, double tap the right earbud's CTC to skip to the next song
- Previous Track: When playing music, double tap the left earbud's CTC to return to the previous song

Note:
• Volume can only be controlled via the media device




Voice Assistant:

- Step 1:** Long touch the CTC on left earbud for 3 seconds to activate the smart voice assistant
- Step 2:** The respective voice assistant screen pops up and you may place your commands at ease

Tips: You may try the following commands,

- What is the weather?
- Play a song
- Set a reminder

Note: If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device settings.



BEAST™ Mode

Long touch the right CTC for 3 seconds to switch to Low Latency mode, also known as the BEAST™ Mode. Once switched on, it gets notified via a sound prompt. Long touch the right CTC for 3 seconds once again, to turn it off and return to Music Mode.

Made for the Gamers - By Gamers, BEAST™ Mode reduces the latency significantly and improves the overall gaming experience.

ENx™ Tech

Our ENx™ tech algorithm cancels out the background noise so that you can be heard crystal clear via voice calls. One need not activate ENx™ as the mics are equipped with the same and activated by default.

Deliver your voice without interruptions anywhere – traffic, railway stations, airports, work space; literally anywhere!

Smart Power Off

- Step 1:** After usage, remove both the earbuds from your ears
- Step 2:** Place the earbuds back into the charging case in correct orientation and close the lid. The earbuds automatically switch off (and enter charging mode).

Manual Power Off

- Step 1:** Long touch both CTCs for 5 seconds to manually power off the earbuds.
- Step 2:** Once the earbuds get turned off, place them back inside the case and close the lid.

Factory Reset:

Perform the factory reset in case you feel any difficulty while operating your Airdopes.

*NOTE: Before performing reset, clear "Airdopes 172" from pairing device history by forgetting device.


Step 1: Place both the earbuds inside the case in their correct orientations and let the lid remain open

Step 2: Long press the Reset button on the case for 10 seconds to perform reset

Step 3: The case LED flashes blue 5 times to indicate a successful factory reset

Step 4: Take out the earbuds from the case and perform a fresh connection

Congratulations! Your Airdopes 172 has been Reset



Specifications

Headphone Type	TWS
Bluetooth Version	V5.2
Music Playtime	Up to 10HRS per charge; Up to 25HRS additional with Case (at 60% volume)
Standby Time	375 days
Transmission Range	10m
Driver Size	11mm*2
ENx™	Yes
BEAST™ Mode	Yes
Frequency	20HZ-20KHZ
Battery	300mAh (Case) ; 40mAh*2 (Earbuds)
Charging Time	50min (Earbuds) ; 1.5H (Case)
Charging Interface	USB Type C
Water Resistance	IPX4

Charging norms & Precautionary Guidelines: -

- 1) Charger/Brick/Adapter : 5V 2A
- 2) Cable/Wire : Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

Troubleshooting

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset
If Touch Controls don't seem to respond	After long usage, residual stains & perspiration can affect the touch control area, please use a clean cloth to wipe those areas softly

Warning:

- Please follow the instructions to operate
- Please don't use the earbuds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life

Advisable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the phone / media device