



Scuderia Instruction Manual

www.gevril.com

Setting the time and date

- Date/time on the watch:
Present date / time: 17 1:25 AM
04 10:39 PM

- Pull out the crown to position II (watch continues to run).
- Turn the crown until yesterday's date appears 03.
- Pull out the crown to position III (the second hand stops. The display changes from alarm time to reference time.)
- Turn the crown until the correct date 04 appears.
- Continue to turn the crown until the current time 10:39 PM appears.
- Push the crown back into position I (the display changes from reference to alarm time).

Please note:
Resetting the time also requires the identical correction of the reference time.
Please refer to «**setting the reference time**».

* Please observe the AM/PM clock rhythm.

05

Setting the alarm time

Please note:
The alarm cannot be used as long as the chronograph is in operation.

- Activate the setting mode**
Press the push-button B for at least 2 seconds. As soon as the small minute hand jumps forward 1 minute, this mode is active.
- Setting**
Short pressing (less than 1 second): the alarm time is moved forward by the minute.
Long pressing (longer than 2 seconds): the alarm time is moved forward until the push-button is released.

Please note:
If the push-button B is not activated for 10 seconds, the setting mode of the alarm time deactivates itself. At the same time, 2 beeps are emitted to indicate that the alarm is switched on.

06

Switching the alarm on / off

- The alarm is switched on/off by briefly pressing the push-button B:
2 beeps → alarm switched on
1 beep → alarm switched off

Please note:
The alarm can be set maximum 12 hours before the desired alarm time.

Once the set alarm time has been reached, a signal is emitted for 20 seconds. This signal is repeated after two minutes. Following brief pressing of the push-button B, the signal is immediately switched off.

07

Setting the reference time

- Pull out the crown to position III (second hand stops. The display changes from alarm time to reference time.)
- Activating the setting mode**
Press the push-button B for at least 2 seconds. As soon as the small minute hand jumps forwards one minute, this mode is active.
- Short pressing** (less than 1 second): the reference time is moved forwards by the minute.
Medium pressing (1-2 seconds): the reference time is moved forwards by the hour.
Long pressing (longer than 2 seconds): the reference time is moved forwards until the push-button is released.
- Push the crown back into position I (the display changes from reference time to alarm time). A 1 beep signal indicates that the alarm is switched off.

Please note:
The reference time must display the same time as the current time. This means that resetting the current time also requires the identical correction of the reference time. Afterwards, the alarm time has to be reset.

What is the reference time?
The current time is displayed by means of the hour and minute hand. Parallel to the current time, the reference time runs in the background: the alarm time refers itself to this reference time. Thus, resetting the time also requires the identical correction of the reference time. If the reference time is not synchronised with the current time, this results in the alarm signal being emitted at a different time to the set alarm time.

08