

mPower™ Edge Intelligence

MTR Software Guide



mPower Edge Intelligence Software Guide

Model: MTR-LNA7, MTR-LEU7, MTR-MNG2

Part Number: S000720 Version: 6.0

Copyright

This publication may not be reproduced, in whole or in part, without the specific and express prior written permission signed by an executive officer of Multi-Tech Systems, Inc. All rights reserved. **Copyright © 2022 by Multi-Tech Systems, Inc.**

Multi-Tech Systems, Inc. makes no representations or warranties, whether express, implied or by estoppels, with respect to the content, information, material and recommendations herein and specifically disclaims any implied warranties of merchantability, fitness for any particular purpose and non-infringement.

Multi-Tech Systems, Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Multi-Tech Systems, Inc. to notify any person or organization of such revisions or changes.

Legal Notices

The MultiTech products are not designed, manufactured or intended for use, and should not be used, or sold or re-sold for use, in connection with applications requiring fail-safe performance or in applications where the failure of the products would reasonably be expected to result in personal injury or death, significant property damage, or serious physical or environmental damage. Examples of such use include life support machines or other life preserving medical devices or systems, air traffic control or aircraft navigation or communications systems, control equipment for nuclear facilities, or missile, nuclear, biological or chemical weapons or other military applications (“Restricted Applications”). Use of the products in such Restricted Applications is at the user’s sole risk and liability.

MULTITECH DOES NOT WARRANT THAT THE TRANSMISSION OF DATA BY A PRODUCT OVER A CELLULAR COMMUNICATIONS NETWORK WILL BE UNINTERRUPTED, TIMELY, SECURE OR ERROR FREE, NOR DOES MULTITECH WARRANT ANY CONNECTION OR ACCESSIBILITY TO ANY CELLULAR COMMUNICATIONS NETWORK. MULTITECH WILL HAVE NO LIABILITY FOR ANY LOSSES, DAMAGES, OBLIGATIONS, PENALTIES, DEFICIENCIES, LIABILITIES, COSTS OR EXPENSES (INCLUDING WITHOUT LIMITATION REASONABLE ATTORNEYS FEES) RELATED TO TEMPORARY INABILITY TO ACCESS A CELLULAR COMMUNICATIONS NETWORK USING THE PRODUCTS.

Trademarks and Registered Trademarks

MultiTech, the MultiTech logo, DeviceHQ, and MultiConnect and Conduit are registered trademarks and mPower is trademarks of Multi-Tech Systems, Inc. All other products and technologies are the trademarks or registered trademarks of their respective holders.

Contacting MultiTech

| Country | Sales | | Support | |
|------------------------------|-----------------------|----------------------------------|-------------------------|----------------------------------|
| Europe, Middle East, Africa: | sales@multitech.co.uk | +(44) 118 959 7774 | support@multitech.co.uk | +(44) 118 959 7774 |
| U.S., Canada, all others: | sales@multitech.com | (800) 328-9717 or (763) 785-3500 | support@multitech.com | (800) 972-2439 or (763) 717-5863 |

Website

www.multitech.com

Knowledge Base

For immediate access to support information and resolutions for MultiTech products, visit <http://www.multitech.com/kb.go>.

Support Portal

To create an account and submit a support case directly to our technical support team, visit: <https://support.multitech.com>.

Warranty

To read the warranty statement for your product, visit <https://www.multitech.com/legal/warranty>.

World Headquarters

Multi-Tech Systems, Inc.
2205 Woodale Drive, Mounds View, MN 55112

Contents

| | |
|---|-----------|
| Chapter 1 – Product Overview | 7 |
| About mPower Edge Intelligence..... | 7 |
| Chapter 2 – Using the Wizard to Configure Your Device..... | 8 |
| First-Time Setup | 8 |
| Chapter 3 – Home..... | 13 |
| Device Information | 13 |
| Chapter 4 – Setup | 16 |
| Network Interfaces | 16 |
| Global DNS | 22 |
| Unavailable Services in PPP-IP Passthrough and Serial Modem Modes..... | 22 |
| WAN Setup..... | 23 |
| Editing Failover Configuration..... | 23 |
| Failover Configuration Fields | 23 |
| Configuring IP Address for LAN | 24 |
| Configuring Dynamic Domain Naming System (DDNS) | 24 |
| Entering authentication information | 25 |
| Forcing a DDNS server update | 25 |
| Configuring Dynamic Host Configuration Protocol (DHCP) Server | 25 |
| Assigning Fixed Addresses | 26 |
| Configuring SNMP..... | 26 |
| Configuring the Global Positioning System (GPS)..... | 28 |
| GPS Server Configuration..... | 28 |
| Dumping NMEA Sentence Information to the Device's TCP Server Port | 29 |
| Sending GPS information to a remote server | 29 |
| Configuring NMEA Sentences | 29 |
| SMTP Settings | 30 |
| Configuring the Serial Port in Serial IP Mode | 30 |
| Configuring Device to Act as Client for Serial IP | 31 |
| Configuring Device to Act as Server for Serial IP | 32 |
| Unavailable Services in PPP-IP Passthrough and Serial Modem Modes..... | 33 |
| Time Configuration | 33 |
| Setting the Date and Time | 33 |
| Configuring SNTP Client to Update Date and Time | 34 |
| Chapter 5 – Wireless..... | 35 |
| Setting Up Wi-Fi Access Point..... | 35 |
| Setting Security Options | 35 |
| Viewing Information About Wi-Fi Clients Using Your Wireless Network | 36 |

| | |
|--|-----------|
| Setting Up Wi-Fi as WAN | 36 |
| Setting up Bluetooth | 37 |
| IP Pipe in TCP/UDP Server mode | 37 |
| To configure the IP Pipe in TCP/UDP Client mode..... | 37 |
| Chapter 6 – Firewall | 39 |
| Normal Firewall Settings | 39 |
| Prerouting Rule | 39 |
| Input Filter Rules | 40 |
| Forward Filter Rules | 40 |
| Output Filter Rules | 41 |
| Postrouting Rule..... | 42 |
| Adding Port Forwarding Rules | 43 |
| Trusted IP | 43 |
| Firewall Status | 44 |
| Setting up Static Routes | 44 |
| Legacy Firewall Settings | 45 |
| Chapter 7 – Cellular | 46 |
| Configuring Cellular..... | 46 |
| Cellular Configuration Fields | 46 |
| Unavailable Services in PPP-IP Passthrough and Serial Modem Modes..... | 49 |
| Configuring Wake Up On Call..... | 49 |
| Wake Up On Call Method Settings | 49 |
| Wake Up On Call General Configurations | 50 |
| Radio Status | 51 |
| Cellular Radio Firmware Upgrade | 52 |
| Upgrading Cellular Firmware Using DeviceHQ (Remote Management)..... | 52 |
| Upgrading Cellular Firmware using UI only | 53 |
| Chapter 8 – SMS | 54 |
| Configuring SMS..... | 54 |
| SMS Field Descriptions..... | 54 |
| SMS Commands | 54 |
| Sending an SMS Message..... | 56 |
| Viewing Received SMS Messages | 56 |
| Viewing Sent SMS Messages..... | 57 |
| Chapter 9 – Tunnels | 58 |
| Setting Up GRE Tunnels | 58 |
| IPsec Tunnels..... | 58 |
| IPsec Tunnel Configuration Field Descriptions | 60 |
| OpenVPN Tunnels | 63 |
| Unavailable Services in PPP-IP Passthrough and Serial Modem Modes..... | 71 |

| | |
|--|-----------|
| Chapter 10 – Administration | 72 |
| User Accounts | 72 |
| Password Complexity | 73 |
| Self-Diagnostics | 74 |
| Configuring Device Access | 75 |
| HTTP Redirect to HTTPS | 75 |
| HTTPS | 75 |
| HTTPS Security | 76 |
| SSH | 77 |
| Reverse SSH Tunnel | 77 |
| SSH Security | 78 |
| ICMP | 78 |
| Node-RED | 78 |
| SNMP | 79 |
| Modbus Slave | 79 |
| IP Defense | 79 |
| RADIUS Configuration | 81 |
| Unavailable Services in PPP-IP Passthrough and Serial Modem Modes..... | 82 |
| Generating a New Certificate..... | 82 |
| Importing a Certificate | 83 |
| Uploading CA Certificate | 83 |
| Setting up the Remote Management | 83 |
| Managing Your Device Remotely | 84 |
| Unavailable Services in PPP-IP Passthrough and Serial Modem Modes..... | 85 |
| Notifications | 85 |
| Customizing the User Interface | 89 |
| Customizing Support Information | 89 |
| Specifying Device Settings | 90 |
| Upgrading Firmware | 90 |
| Saving and Restoring Settings | 91 |
| Using the Debugging Options | 94 |
| Automatically rebooting the device..... | 94 |
| Configuring Remote Syslog | 94 |
| Statistics Settings | 95 |
| Statistics Configuration Fields..... | 95 |
| Ping and Reset Options..... | 95 |
| Usage Policy | 96 |
| Chapter 11 – Status & Logs | 98 |
| Viewing Device Statistics | 98 |
| Service Statistics..... | 99 |
| Mail Log..... | 99 |

| | |
|-------------------------------|------------|
| Mail Queue..... | 99 |
| Notifications Sent..... | 100 |
| Chapter 12 – Apps..... | 101 |
| Manage Apps | 101 |

Chapter 1 – Product Overview

About mPower Edge Intelligence

This guide reviews the mPower Edge Intelligence software for MTR devices.

For hardware details, refer to the appropriate hardware guide. Use your device to provide secure data communication between many types of devices that use legacy and the latest communication technologies.

Some device models support (varies with model-refer to your specific hardware guide for details):

- Bluetooth communication to devices with this technology
- Wi-Fi communication to devices with this technology
- GPS capability
- Diversity

What's New in This Release

| Manual version | Update description |
|----------------|---|
| 5.2 | Reboot Optimization, Save and Apply w/o Reboot , and PDP context |
| 5.3 | Upgrades of Yocto, OpenSSL, and TLS (security improvements), Radio Firmware Upgrade (delta files), and Device Firmware Upgrade (differential files) |
| 6.0 | Upgrade of Yocto, IP Masquerading, 802.1X Authentication, Modbus update, Ping updates (adjust size) |

Chapter 2 – Using the Wizard to Configure Your Device

First-Time Setup

Setting Up Your Device using Setup Wizard (After Choosing Reset and Factory Default Settings)

If you need to change the mode of your device, this is the only way to do so. This section is not available through the device management software.

Other than when you first power up the device, you must configure the device to factory default settings, reset it and then, access it through the default 192.168.2.1 IP address to see the first-time setup. To reset the device to factory default settings, go to **Administration > Save/Restore > Reset to Factory Default Configuration** and click the **Reset** button. This wizard helps you configure the main features of your device for initial setup.

Depending on the mode, your proceeding options and fields differ (see **For Network Router Mode** , **For PPP-IP Passthrough Mode**, or **For Serial Modem Mode** below for the mode's proceeding steps).

Here are the steps for first-time setup:

1. Upon power up for the first time or after you set factory default settings, the device goes into commissioning mode. The system requires you to set up an admin user. Enter your desired username and click **OK**.
2. Enter a desired password for the admin user and click **OK**. This password must be of sufficient length and strength (with a mix of character classes such as letters, numbers, and symbols). Enter the password again to confirm. Click **OK**.
3. Log into your device using your new username and password.
4. On the first page, the system allows you set up the device as a **Network Router** , **PPP-IP Passthrough**, or **Serial Modem** device.
 - a. The default mode establishes the device as a cellular **Network Router**.
 - b. In the **PPP-IP Passthrough** mode, the device assigns the IP address it receives from the cellular provider to the Ethernet-attached device. In this mode, the device only allows one DHCP lease.
Note: In this mode, many of the device services described in this help are non-configurable and do not appear in the device configuration menu. All IP traffic is passed between the Ethernet-attached device and the cellular provider with no firewall functionality.
 - c. The **Serial Modem** mode creates a serial connection to the device which can be configured for speed and flow control. The serial port talks to the cellular radio in order to send and receive commands via the cellular radio.
 - d. Click **Next**.

For Network Router Mode:

1. Set the date, time, and time zone.
 - a. Enter the desired **Date**.
 - b. Enter the desired **Time**.
 - c. Select the **Time Zone** in which the device operates.
 - d. Click **Next**.

2. Configure LAN network interfaces Eth0 and Br0. Enter the device address and network information for Network Router mode only. (**Note:** If you do not accept default settings, after applying changes to **Network Interface Configuration (br0 or eth0)**, the device reboots.):
 - a. In the **Network Interface Configuration – eth0** section, leave the **eth0** assigned to the bridge **br0**, or unassign **eth0** from bridge and enter network settings for the **eth0** interface - **IPv4 Address** and **Mask**.
 - b. In the **Network Interface Configuration – br0** section, enter network settings for the **br0** interface - **IPv4 Address** and **Mask**.
3. Configure your device's **PPP**.
 - a. To use PPP, check **Enable**. When enabled, your device functions as a router.
 - b. Check **Diversity** to enable the use of two cellular antennas for better performance. (For devices that use two antennas, Diversity is enabled by default. See *Installing the Router* in your User Guide for more details).
 - c. To enable the dial-on-demand feature, check **Dial-on-Demand**. This indicates to the device to bring up the PPP connection when there is outgoing IP traffic, and take down the PPP connection after a given idle timeout. **Note:** This field is only available on specific models where the device defaults to PPP instead of WWAN.
 - d. Enter the **APN** (Access Point Name). The APN is assigned by your wireless service provider. (This field is not available on all models.)
 - e. Click **Next**.
4. Set up **PPP Authentication**:
 - a. Select the authentication protocol **Type** used to negotiate with the remote peer: **PAP, CHAP, or PAP-CHAP**. The default value is **NONE**.
 - b. Enter the **Username** with which the remote peer authenticates. Optional. Username is limited to 60 characters.
 - c. Enter the **Password** with which the remote peer authenticates. Optional. Password is limited to 60 characters.
5. Set up **Remote Management**:
 - a. Check **Enabled** to configure the device to check in at the next scheduled check-in time.
 - b. Check **SSL Enabled** to activate SSL on the annex protocol.
 - c. **Server Name** for DeviceHQ is provided.
 - d. **Server Port** for DeviceHQ is provided.
 - e. **App Store URL** for DeviceHQ is provided.
 - f. Enter your **DeviceHQ Account Key**. (**NOTE:** You must already have a DeviceHQ account.)
 - g. Click **Next**.
6. Configure **HTTP/HTTPS Access**.
 - a. In the **HTTP Redirect to HTTPS** panel define how the device handles HTTP traffic. Check **Enabled** to enable HTTP and redirect to HTTPS.
 - b. Configure **HTTP Port**. By default, 80.
 - c. Check **Via LAN** (enabled by default) to allow traffic from local area network.
 - d. Check **Via WAN** (disabled by default) to allow traffic from the wide area network.

- e. In the **HTTPS** panel, define how the device handles secure HTTP traffic.
 - f. Check **Via WAN** to allow traffic from the wide area network. Note: HTTPS traffic via LAN is enabled by default and cannot be changed.
 - g. Configure **HTTPS Port**. By default, 443.
7. Set up **Bootloader Protection** by setting a u-boot password.
 - a. Enter a password and click **Enable**. The password will be set immediately.
 - b. To change the password, enter a new password and click **Change Password**.
 - c. To disable the password, click **Disable**.
8. Click **Finish**.
9. To save your changes, click **Save and Apply**.

Note: The **Bootloader Protection** settings depend on the previous u-boot configuration and are preserved when device is reset to factory defaults.

For PPP-IP Passthrough Mode:

1. Set the date, time, and time zone.
 - a. Enter the desired **Date**.
 - b. Enter the desired **Time**.
 - c. Select the **Time Zone** in which the device operates.
 - d. Click **Next**.
2. Enter the device address and network information (the fields shown vary based on the selected internet protocol):
 - a. In the **Protocol Support** field, choose the internet protocol from the drop-down (select from IPv4 and IPv6).
 - b. In the **IPv4/IPv6 Address** field, type the device's IP address.
 - c. In the **Mask** field, enter the IP mask (default: 255.255.255.255 for mask 32, 255.255.255.0 for mask 24))
 - d. In the **IPv4/IPv6 Primary DNS** field, type the address of the primary DNS (optional).
Note: This is an optional value that can be used if you use a DNS server other than the servers received from your carrier.
 - e. In the **PublicIPv4 Mask** field, select the public mask from the drop-down either 32 or 24.
 - f. Click **Next**.
3. Configure your device's **PPP**.
 - a. To use PPP, check **Enable**. When enabled, your device functions as a router.
 - b. Check **Diversity** to enable the use of two cellular antennas for better performance. (For devices that use two antennas, Diversity is enabled by default. See *Installing the Router* in your User Guide for more details).
 - c. To enable the dial-on-demand feature, check **Dial-on-Demand**. This indicates to the device to bring up the PPP connection when there is outgoing IP traffic, and take down the PPP connection after a given idle timeout.

- d. Enter the **APN** (Access Point Name). The APN is assigned by your wireless service provider. (This field is not available on all models.)
 - e. Click **Next**.
4. Set up **PPP Authentication**:
 - a. Select the authentication protocol **Type** used to negotiate with the remote peer: **PAP, CHAP, or PAP-CHAP**. The default value is **NONE**.
 - b. To change the password, enter a new password and click **Change Password**.
 - c. To disable the password, click **Disable**.
5. Set up **Bootloader Protection** by setting a u-boot password.
 - a. Enter a password and click **Enable**. The password will be set immediately.
 - b. To change the password, enter a new password and click **Change Password**.
 - c. To disable the password, click **Disable**.
6. Click **Finish**.
7. To save your changes, click **Save and Apply**. After applying those changes, the device reboots.

Note: The **Bootloader Protection** settings depend on the previous u-boot configuration and are preserved when device is reset to factory defaults.

For Serial Modem Mode:

1. Set the date, time, and time zone.
 - a. Enter the desired **Date**.
 - b. Enter the desired **Time**.
 - c. Select the **Time Zone** in which the device operates.
2. Click **Next**.
3. Enter the device address and network information:
 - a. In the **IP Address** field, type the device's IP address.
 - b. In the **Mask** field, type the mask for the network. The default is **255.255.255.0**.
 - c. Click **Next**.
4. In the **Serial Port Configuration** section:
 - a. From **Baud Rate**, select baud rate in BPS for the serial port from the drop-down. Default setting is **115200**.
 - b. In the **Flow Control** field, select the flow control option from the drop-down provided. Choose from **NONE** or **RTS-CTS**.
 - c. In the **Parity** field, select the parity option from the drop-down. Choose from **NONE**, **ODD**, or **EVEN**.
 - d. In the **Data Bits** field, select the data bits option from the drop-down. Choose from **7** or **8**.
 - e. In the **Stop Bits** field, select the stop bit option from the drop-down. Choose from **1** or **2**.
5. Set up **Bootloader Protection** by setting a u-boot password.
 - a. Enter a password and click **Enable**. The password will be set immediately.
 - b. To change the password, enter a new password and click **Change Password**.

- c. To disable the password, click **Disable**.
- 6. Click **Finish**.
- 7. To save your changes, click **Save and Apply**. After applying those changes, the device reboots.

Note: The **Bootloader Protection** settings depend on the previous u-boot configuration and are preserved when device is reset to factory defaults.

Chapter 3 – Home

Device Information

The Home page (dashboard) displays a summary of the configuration settings for the device. The following settings, where applicable, include the area of the user interface where they can be accessed and changed.

Click **Home** to display the following information:

- **Device:**

Model Number: The MTR model ID.

Serial Number: The MultiTech device ID.

IMEI: International Mobile Station Equipment Identity.

Note: Not applicable for the MTR-C2 or MTR-EV3 models.

Firmware: mPower Edge Intelligence firmware version.

Current Time: Current date and time of the device. For information on setting the date and time, go to **Setup > Time Configuration**.

Up Time: Amount of time the device has been continuously operating.

WAN Transport: Current transport for IP traffic leaving the LAN. If two WAN interfaces are configured for use (Wi-Fi and cellular), the current WAN will be set based on the WAN configurations at **Setup > WAN Configuration**.

Current DNS: the actual DNS IP addresses that are used by the current WAN.

GeoPosition: the GPS coordinates of the device (provided a GPS satellite fix is acquired)

- **LAN**(LAN network interfaces, br0, eth0 and wlan1):

Bridge (br0)

MAC Address: Media Access Control Address used to uniquely identify the devices LAN Ethernet interface.

IPv4 Address: IP address of this device. To configure the IP address, go to **Setup > Network Interfaces Configuration**.

Mask: Network mask of the bridge (**br0**). To configure the network mask, go to **Setup > Network Interfaces Configuration**.

DHCP State: Current state of the DHCP server configured for the bridge (br0). To configure, go to **Setup > DHCP Configuration**.

Lease Range: Current DHCP lease range of the interface DHCP server. To configure, go to **Setup > DHCP Configuration**.

Interfaces: lists all the interfaces added to the bridge (**br0**).

Ethernet (eth0):

Mode: IP Mode, Static or DHCP Client.

Bridge: specifies if the network interface is added into the bridge (**br0**).

MAC Address: Media Access Control Address used to uniquely identify the devices LAN Ethernet interface.

IPv4 Address: LAN IP address of the **eth0** interface. To configure the IP address, go **Setup > Network Interfaces Configuration**.

Mask: Network mask of the **eth0** interface. To configure the network mask, go to **Setup > Network Interfaces Configuration**.

DHCP State: Current state of this device's DHCP server. To configure, go to **Setup > DHCP Configuration**.

Lease Range: Current DHCP lease range of the **eth0** interface DHCP server. To configure, go to **Setup > DHCP Configuration**.

Wi-Fi Access Point (wlan1):

State: Current state of the Access Point. To configure go to **Wireless > Wi-Fi Access Point**.

Bridge: specifies if the network interface is added into the bridge (**br0**)

MAC Address: Media Access Control Address used to uniquely identify the devices LAN Ethernet interface.

IPv4 Address: LAN IP address of the **eth0** interface. To configure the IP address, go **Setup > Network Interfaces Configuration**.

Mask: Network mask of the bridge (**br0**). To configure the network mask, go to **Setup > Network Interfaces Configuration**.

DHCP State: Current state of this device's DHCP server. To configure, go to **Setup > DHCP Configuration**.

SSID: the Service Set Identifier (SSID) for this device's Wi-Fi Access Point. For configuration go to **Wireless > Wi-Fi Access Point**.

Security: the current security protocol of this device's Wi-Fi Access Point. To configure go to **Wireless > Wi-Fi Access Point**.

■ **Bluetooth**

State: Current state of the Bluetooth link. To configure go to **Wireless > Bluetooth-IP**.

MAC Address: Media Access Control Address used to uniquely identify the Bluetooth interface.

Device Name: Name of Bluetooth device configured to link to. For configuration go to **Wireless > Bluetooth-IP**.

Device MAC: Media Access Control Address of the Bluetooth device configured to link to. To configure go to **Wireless > Bluetooth-IP**.

■ **WAN (WAN network interfaces, ppp0, wlan0 and eth0):**

Cellular (ppp0)

State: Current state of the cellular PPP link.

Connection Mode: PPP or WWAN (only visible on LTE devices)

Cellular Mode: LTE, 3G, or 2G.

Mode: IP Mode, PPP or PPP-Addresses Only.

Protocol Support (only available when you choose PPP-IP Passthrough): Choose from IPv4 or IPv6. If you choose IPv6, also enter the Connect Timeout.

Signal: Current signal strength of the cellular link. Mouse hover provides dBm value.

Ec/Io: Signal to Noise Ratio (used to calculate RSSI in 3G devices).

RSCP: Received Signal Code Power (used to calculate RSSI in 3G devices)

RSRP: Reference Signal Received Power (used to calculate RSSI in LTE devices)

RSRQ: Reference Signal Received Quality (used to calculate RSSI in LTE devices)

Connected: Total time connected for the current PPP session.

IPv4 Address: Current cellular WAN IP address issued to this device by the cellular carrier.

DNS: DNS IP addresses retrieved from the cellular network or configured by user in the **Setup > Network Interfaces Configuration**.

Roaming: Indicates whether or not this device's cellular link is currently connected to its home network.

Phone number: Device's cellular phone number also known as Mobile Directory Number (MDN). This field is blank if the MDN is not stored in the SIM card.

Tower: Tower ID of the cellular tower currently providing cellular service to this device.

Wi-Fi (wlan0):

State: Current state of the Wi-Fi.

Mode: **IP Mode, DHCP Client** or **DHCP Client – Addresses Only**

MAC Address: Media Access Control Address used to uniquely identify the Wi-Fi interface.

IPv4 Address: The IP address that is obtained from the Wi-Fi network to which the device is currently connected.

Mask: Network mask of the Wi-Fi network to which the device is currently connected.

Gateway: Gateway IP address that is retrieved from the Wi-Fi network to which the device is currently connected.

DNS: DNS IP addresses retrieved from the cellular network or configured by user in the **Setup > Network Interfaces Configuration**.

Chapter 4 – Setup

Network Interfaces

For configuration management of network interfaces, go to **Setup > Network Interfaces > Network Interfaces Configuration**. This section displays the list of network interfaces. Click on the pencil icon to the right of a particular interface in order to edit its configuration. Refer to possible configurations in the table below.

Bridge

This section allows you to create a bridge between network interfaces. All LAN network interfaces are added into the bridge (br0) by default.

Just LAN interfaces are allowed under bridge including **eth0** and **wlan1** (Wi-Fi Access Point). With this bridge interface added, it is possible to assign any number of LAN interfaces (of both **Ethernet** and **Wi-Fi AP** types) to a specified bridge. Only one bridge interface is supported. **IPv6** support is also available under the bridge using **Static** IP mode.

Slave Interfaces

Slave interfaces such as **Ethernet (eth0)** or **Wi-Fi AP (wlan1)** do not have their own IP addresses and are not configured as DHCP clients by default. Static IP address mode is implemented on the bridge level.

Ethernet Interface

The Ethernet interface can be configured as either **LAN** or **WAN**. Ethernet interface as **LAN** can be set to use static pre-set IPv4 or IPv6 addresses or dynamically obtain an IPv4/IPv6 address over DHCP in DHCP client mode. When configured as **WAN**, only IPv4 is available.

PPP interface

The **PPP** interface is only allowed to be **WAN**. The **PPP** interface listed in the **Network Interfaces** page can only have its mode changed. Options are **PPP** and **PPP addresses-only** modes. IPv6 WAN support is also an option with the PPP interface (configurable fields vary with network carrier).

Wi-Fi integration (depends on model)

Wi-Fi integration is enabled by adding two network interfaces: **wlan0** (used exclusively for **Wi-Fi as WAN (STATION)** mode) and **wlan1** (used exclusively for **AP** mode). The Web UI as well as API back-end has been modified to add support and validation rules in order to assign **LAN** interface(s) to a bridge, and removing them from under the bridge. **NOTE:** Wi-Fi availability depends on model. Consult the appropriate manual for details.

IP Masquerading (for WAN interfaces only)

IP masquerading is a type of network address translation that allows all of the hosts on a private network (LAN) to use the internet at the price of a single IP address. IP Masquerading is available under **Setup > Network Interfaces > Network Interface Configuration > IPv4 Settings**. When this feature is enabled (box is checked), the device performs IP address translation of client network traffic to the corresponding WAN interface. IP Masquerading is available for WAN interfaces only. This capability is enabled by default. When the IP Masquerading feature is disabled, the device passes client network requests unchanged to the corresponding WAN interface.

802.1X Authentication

802.1X Authentication is available for Ethernet network interfaces (**eth0**) if it is not on the Bridge (**br0**). For other network interfaces, including the Bridge (**br0**) this feature is not available. The 802.1X Authentication settings depend on the Authentication method selected. By default, the Authentication Method is **NONE**.

The system supports the following authentication methods:

- **EAP-PWD**
- **EAP-TLS**
- **EAP-TTLS**
- **EAP-PEAP**

The following table explains the settings available for 802.1X Authentication:

| Method | User-name | Pass-word | Anon-ymous ID | CA Certifi-cate | Domain Match | Subject Match | Client Certifi-cate | Private Key | PK Pass-word | Phase 2 Auth. Method | PEAP Version |
|----------------|-----------|-----------|---------------|-----------------|--------------|---------------|---------------------|-------------|--------------|----------------------|--------------|
| NONE - default | N/A | N/A | N/A | N/A | N/A | N/A | N/A | N/A | N/A | N/A | N/A |
| EAP-PWD | Yes | Yes | No | No | No | No | No | No | No | No | No |
| EAP-TLS | Yes | No | Yes | Yes | Option | Option | Yes | Yes | Yes | No | No |
| EAP-TTLS | Yes | Yes | Yes | Yes | Option | No | No | No | No | Yes | No |
| EAP-PEAP | Yes | Yes | Yes | Yes | Option | No | No | No | No | Yes | Yes |

Network configurations

Refer to the following table for the possible network configurations:

| Interface | Direction | Type | IP Mode | Bridge Mode | IPv4/IPv6 Support |
|-----------|-----------|--------------|------------------------------|-------------|-------------------|
| Br0 | N/A | BRIDGE | STATIC | Br0 | Both |
| Eth0 | LAN | Ethernet | STATIC | N/A | Both |
| Eth0 | LAN | Ethernet | DHCP Client | N/A | Both |
| Eth0 | LAN | Ethernet | N/A | Br0 | N/A |
| Eth0 | WAN | Ethernet | STATIC | N/A | IPv4 only |
| Eth0 | WAN | Ethernet | DHCP Client | N/A | IPv4 only |
| Eth0 | WAN | Ethernet | DHCP Client - Addresses Only | N/A | IPv4 only |
| Wlan0 | WAN | Wi-Fi as WAN | DHCP Client | N/A | IPv4 only |


| | | | | | |
|-------|-----|--------------|------------------------------|-----|-----------|
| Wlan0 | WAN | Wi-Fi as WAN | DHCP Client - Addresses Only | N/A | IPv4 only |
| Wlan0 | WAN | Wi-Fi as WAN | STATIC | N/A | IPv4 only |
| Wlan1 | LAN | Wi-Fi AP | STATIC | N/A | IPv4 only |
| Wlan1 | LAN | Wi-Fi AP | N/A | Br0 | IPv4 only |
| ppp0 | WAN | Cellular | PPP | N/A | Both |
| ppp0 | WAN | Cellular | PPP - Addresses Only | N/A | Both |

IPv6 Example Configurations

Configuration Example #1: Cellular WAN, Delegated LAN

This example is the most typical configuration. The admin user enables IPv6 on the Cellular Configuration, configures the bridge interface on the device in Delegated Prefix mode and, configures all LAN interfaces that will perform IPv6 as slaves of the bridge interface. The LAN networks “under” the bridge will all have the whole 64 bit prefix delegated to them. The bridge and Cellular WAN interfaces will have the same IPv6 address. In this manner, the router will act as the gateway to the Internet for all the LAN devices that have delegated addresses.


- WAN interface is configured in Automatic Client IPv6 Mode.
- All LAN interfaces are connected to the bridge interface.
- The bridge interface is configured in the Delegated Prefix mode.
- The whole /64 prefix is delegated to the LAN network.
- The Bridge interface and Cellular WAN interface have the same IPv6 address.



Configuration Example #2: No IPv6 WAN, Static LAN

This example is essentially the same as the old mode where IPv6 was not supported. The devices have Internet access via IPv4, but not via IPv6. On the LAN side, the admin user assigns a static IPv6 address to the br0 (bridge) interface and all the IPv6 addresses on the LAN side will be assigned by the user. In this case, the device may be managed through the LAN interface over IPv6.


- IPv6 support disabled on WAN interface or IPv6 is not supported on cellular provider.
- Devices in LAN1 will see each other.
- Devices in LAN1 will not have Internet access over IPv6.



Configuration Example #3: Cellular WAN, Static LAN with valid addresses

This example is typically the second most widely used IPv6 scenario since not all ISPs support prefix delegation automatically. In this case, the cellular provider or ISP provides the admin user with global address of the device and the IPv6 prefix that needs to be assigned to the LAN devices. The LAN devices are all programmed with a valid IPv6 address statically by the admin user with the knowledge of what IPv6 prefix to use provided by the Cellular Provider / ISP. All the LAN devices can access the Internet via IPv6 if they have a global IPv6 address configured.


- It is known exactly what IPv6 subnet is assigned to the device by the cellular provider/ISP.
- All devices in LAN1 will have IPv6 Internet access.



Configuration Example #4: Cellular WAN, Static LAN with user-selected addresses

For this example, the LAN has IPv6 addresses, but they're not in the recognized range of addresses the cellular provider/ISP have specified with a prefix. The LAN devices will network with each other over IPv6, but do not have Internet access via IPv6. The device can ping IPv6 addresses on the Cellular WAN. However, since the LAN devices don't have globally routable addresses recognized by the cellular provider/ISP, they get their packets dropped on the WAN link.


- LAN subnet is outside of the range of addresses provided by the cellular provider/ISP.
- Devices in LAN can see each other via IPv6.
- Devices in LAN do not have Internet access via IPv6.
- The router can ping IPv6 addresses.
- All packets with invalid IPv6 addresses are dropped on the WAN link.



Configuration Example #5: Cellular WAN, Static LAN, Delegated Prefix LAN

This scenario is a combination of examples #1 and #3. The difference is the Static LAN2 does not have Internet access because the prefix for the statically assigned addresses on that LAN do not match the delegated prefix from the cellular provider/ISP. The devices on LAN1 got their IPv6 addresses from the router that is using the delegated prefix from the cellular provider/ISP, so those devices have Internet access via IPv6. This example demonstrates the difference in behavior for the LAN networks based on the prefix delegation.


- User configured LAN1 in Delegated Prefix IPv6 mode.
- User configured LAN2 in Static IPv6 mode with user-selected addresses
- Devices in LAN2 will see each other.
- Devices in LAN1 will have Internet access via IPv6.
- Devices in LAN2 will not have Internet access via IPv6.



Configuration Example #6: No IPv6 WAN, Static LAN

For this example, IPv6 is enabled on the LAN interface but disabled on the WAN side or not supported by the cellular provider/ISP. The delegation fails. This results in LAN1 not receiving delegated IPv6 addresses as it should, but only link-local IPv6 addresses. LAN2 has statically defined IPv6 addresses, but does not have Internet access since the device does not have an established IPv6 connection.

- IPv6 support disabled on WAN interface or IPv6 is not supported by cellular provider/ISP.
- Delegation fails.
- Devices in LAN1 will not get any IPv6 addresses (except link-local).
- Devices in LAN2 will see each other and have IPv6 addresses.
- No IPv6 Internet access.



Global DNS

The **Global DNS** Configuration page allows the user to set user-defined DNS servers. User-defined DNS servers in this page are always used to resolve hostnames regardless of what the WAN settings are and what WAN interface is being used. If the **Global DNS** primary and secondary servers are not configured here, the DNS servers used default to the servers configured for the current WAN.

Here are the key configuration scenarios for both **Global DNS** and forwarding server and their results (the device refers to a MultiTech device):

- If you do not configure **Global DNS** and enable forwarding, the device acts as a proxy server for any devices on the LAN network(s). In this mode, the device uses WAN DNS settings. Client settings: On the client, you must configure the device as the default gateway and DNS server. The easiest way to accomplish this is by using the DHCP server on the device.
- If you configure **Global DNS** and enable forwarding, DNS requests are forwarded to servers configured in the **Global DNS** settings. The device still acts as a proxy. Client settings: Clients must be configured the same as in the previous case above.
- If you configure **Global DNS** and disable forwarding, the default gateway and DHCP server on clients should point to the device and the DNS servers on the client must use the same DNS as the **Global DNS** settings. Client settings: The client device uses the device as default gateway and the DHCP server, but must have DNS servers configured to what options you plan to use.
- If neither item is configured/enabled, make sure to configure your device properly to forward DNS.

To configure **Global DNS**:

1. Click **Setup > Global DNS**.
2. Under **Global DNS Configuration**, leave **Enable Forwarding Server** unchecked. (If you check this, the forwarding server is active and global DNS is not configured).
3. To set global DNS servers, enter IP addresses for the both **Primary** and **Secondary Servers**. (These servers override any DNS servers specified elsewhere in the UI. If none are entered, the system defaults to servers configured for the current WAN.)
4. Under **Hostname Configuration**, enter the **Hostname** for your device.
5. Click **Submit**.
6. Click **Save and Apply** to save your changes **OR** click **Reset to Default** to return to default settings.

Hostname Configuration allows the user to change the hostname of the device to distinguish the device from other devices on the network.

To modify the default hostname:

1. Under **Hostname Configuration**, enter the **Hostname** for your device.
2. Click **Save and Apply** to save your changes **OR** click **Reset to Default** to return to default settings.

Unavailable Services in PPP-IP Passthrough and Serial Modem Modes

In both **PPP-IP Passthrough** and **Serial Modem** modes, many rCell services described in this document are either limited, or non-configurable and therefore do not appear in the device configuration menu. If you choose one of these modes, all sections between this and the next note on this subject are limited, or typically not available.

WAN Setup

Configuring WAN Failover Priority

Failover mode regulates which WAN is used for the Internet connection and switches the WAN if a connectivity failure is detected.

Failover mode enables the WAN with the highest priority as displayed on the **WAN Configuration** page. If the WAN with priority 1 is disabled or a connection failure is detected, the WAN with priority 2 is automatically selected for establishing connection to the Internet.

Ethernet (eth0) is priority 1 by default.

If Ethernet is used as WAN, the DHCP server must be disabled.

1. Click **Setup > WAN Configuration**.
2. Under **Options**, click the up and down arrows to change the priority of the appropriate WAN.
3. Click **Save and Apply** to save the change.

For field descriptions see [Failover Configuration Fields](#)

For information on editing WAN Failover see [Editing Failover Configuration](#)

Editing Failover Configuration

The device can use the active or passive mode to monitor the Internet availability in WAN. The default condition is active mode.

Active mode can be type ICMP (ping) or TCP. ICMP periodically pings the designated host at the specified interval. TCP tries to make a connection to the designated host at the interval specified.

For both ICMP and TCP, if a response is not received, the device switches to the WAN with lower priority. The device continues to ping the designated host at the interval specified for WAN with the higher priority and switches back when the ping is successful. When passive mode is enabled, the device switches the WANs when the network interface is down. The currently active WAN is displayed on the home page under the label WAN Transport.

To edit failover configuration:

1. Click **Setup > WAN Configuration**.
2. Under the **Options** column at the right, click the pencil icon (edit) for the selected WAN. The **Failover Configuration** page is displayed.
3. Make the desired changes. Refer to [Failover Configuration Fields](#) for details.
4. Click **Finish**.
5. If you are finished making changes, click **Save and Apply**.

Failover Configuration Fields

| Field | Description |
|------------------------|--|
| Monitoring Mode | Use the drop-down list to select the mode to connect to the host: PASSIVE or ACTIVE. |
| Interval | Enter the number of seconds between each check. Default is 60 seconds. |

| Field | Description |
|------------------|--|
| Host Name | Enter the host name or IP address to use for the check. Default is www.google.com. |
| Mode Type | Use the drop-down list to select the mode type: ICMP or TCP. Default is ICMP. (Active Monitoring Mode) |
| TCP Port | Enter the TCP Port number to connect to the host. (Mode TCP) |
| ICMP Port | Enter the number of ICMP pings to be sent to the specified host. Default is 10. (Mode ICMP) |

Configuring IP Address for LAN

Your device manages traffic for your local area network (LAN). To change the IP address and DNS configuration:

1. Go to **Setup > Network Interfaces > br0** and click the **pencil icon** to edit.
2. To configure the address LAN information:
In the **IP Address** field, type the device's IP address. The default is 192.168.2.1.
In the **Mask** field, type the mask for the network. The default is 255.255.255.0.
3. To resolve domain names, configure domain name server information (DNS), go to **Setup > Global DNS** and refer to the [Global DNS](#) section (WAN DNS) for options and instructions on how to properly configure this feature.
4. Click **Submit**.
5. To save your changes, click **Save and Apply**.

Configuring Dynamic Domain Naming System (DDNS)

This feature allows your router to use a DDNS service to associate a hosted server's domain name with a dynamically changing internet address. To configure your router to use DDNS:

1. From **Setup**, select **DDNS Configuration**.
2. In the **Configuration** group, check **Enabled**.
3. In the **Service** drop-down list, select a DDNS service. To define a service that isn't listed choose **Custom**.
 - a. For custom DDNS service, in the **Service** field, type the DDNS server's URL.
 - b. For custom DDNS service, in the **Port** field, type the DDNS server's port.
4. In the **Domain** field, type the registered Domain name.
5. In the **Update Interval** field, type the days that can pass with no IP Address change. At the end of this interval, the existing IP Address is updated on the server so that the address does not expire. The range of the interval you can enter is between 1 and 99 days. The default is 28 days.
6. Check **Use Check IP**, if you want to query the server to determine the IP address before the DDNS update. The IP address is still assigned by the wireless provider and the DDNS is updated based on the address returned by Check IP Server. If disabled, the DDNS update uses the IP address from the PPP link. The default is **Use Check IP**.
7. In the **Check IP Server** field, type the name to which the IP Address change is registered. Example: checkip.dyndns.org
8. In the **Check IP Port** field, type the port number of the Check IP Server. The default is 80.
9. Click **Submit**.

10. To save your changes, click **Save and Restart**.

Entering authentication information

Your DDNS server requires you to identify yourself before you can make changes.

1. In the **Username** field, type the name that can access the DDNS Server. The default is NULL. You receive your name when you register with the DDNS service.
2. In the **Password** field, type the password that can access the DDNS Server. The default is NULL. You receive your password when you register with the DDNS service.
3. Click **Submit**. If you are finished making changes click **Save and Apply**.

Forcing a DDNS server update

To update the DDNS server with your IP address, click **Update**.

Configuring Dynamic Host Configuration Protocol (DHCP) Server

To view, add, or edit DHCP servers, see the **IPv4 DHCP Servers** (IPv4 support) or **DHCPv6 and Router Advertisement** (for IPv6 support) list under **Setup > DHCP Configuration**.

You can configure multiple DHCP servers. Only one DHCP server can be created per LAN network interface. You can configure your device to function as a DHCP server that supplies network configuration information, such as IP address, subnet mask, and broadcast address, to devices on the network.

By default, the DHCP server is configured and enabled for Bridge (**br0**) network interface. If a LAN network interface is NOT under the bridge, DHCP server can be configured and enabled for it..

DHCP Server is disabled automatically if you modify the network interface under **Setup > Network Interface** including:

- changes to the interface subnet
- adding network interface under the bridge
- changing the interface from LAN to WAN (Ethernet interface only)
- removing all LANs from under the bridge (DHCP for **br0** will be disabled in this case)

DHCP Server cannot be enabled if the network interface is under the bridge, or is not enabled or configured properly (for example, when **eth0** is configured as WAN, or Wi-Fi Access Point is disabled).

To edit the configuration of an existing IPv4 DHCP server or add a new one:

1. Go to **Setup > DHCP Configuration**. See the **IPv4 DHCP Servers** list.
2. To edit a **DHCP Server**, click the pencil icon (edit) for the selected interface, **OR** to add a **DHCP Server**, click the **Add IPv4 DHCP Server** button.
3. The **DHCP Configuration** fields appear. To use the **DHCP** feature, check **Enabled**.
4. In the **Interface** field, select the network interface. Note: The Interface field is read-only when you edit DHCP Server.
5. The **Subnet** field displays the subnet address.
6. The **Mask** field displays the network's subnet mask.
7. In the **Gateway** field, type the gateway address.
8. In the **Domain** field, type your network domain, if any.

9. In the **Lease Time** field, enter the DHCP lease time. Lease time is set in days, hours, and minutes (dd-hh-mm). A Lease Time of 00-00-00 is an infinite lease time.
10. In the **Lease Range Start** field and in the **Lease Range End** field, type the range of IP addresses to be assigned by DHCP.
11. Click **Submit**. If you are finished making changes, click **Save and Apply**.

To edit the configuration of an existing DHCPv6 and Router Advertisement server or add a new one:

1. Go to **Setup > DHCP Configuration**. See the **DHCPv6 and Router Advertisement** list.
2. To edit a **DHCP Server**, click the pencil icon (edit) for the selected interface, **OR** to add a **DHCP Server**, click the **Add DHCPv6/RA** button.
3. The **DHCP Configuration** fields appear. To use the **DHCP** feature, check **Enabled**.
4. In the **Interface** field, select the network interface from the drop-down including **eth0** and **wlan1**. **Note:** Interface field is read-only when you edit DHCP Server.
5. In the **Router Advertisement Mode**, select from the drop-down the DHCP IPv6 mode including **SLAAC** or **Stateless DHCP**.
6. In the **Lease Time** field, type the DHCP lease time. Lease time is set in days, hours, and minutes (dd-hh-mm). A Lease Time of 00-00-00 is an infinite lease time.
7. Click **Submit**. If you are finished making changes, click **Save and Apply**.

To add fixed addresses for the DHCP server, see **Assigning Fixed Addresses**.

Assigning Fixed Addresses

To add fixed addresses for the DHCP server make the changes under the **Fixed Addresses** section on the **DCHP Configuration** page:

1. In the **MAC Address** field, type the MAC address to which the specified IP address binds.
2. In the **IP Address** field, type the fixed IP address to be assigned.
3. Click **Add**.
4. To save your changes, click **Save and Apply**.

Configuring SNMP

The device offers Simple Network Management Protocol (SNMP) which is used for collecting information from network devices on an IP network.

You also have the option to configure SNMP traps which are alerts sent from SNMP-enabled devices to an SNMP agent or manager typically providing device status or condition information.

You can also access the **MIB** file which is a management information base. This file is a formal description of a set of network objects managed using the Simple Network Management Protocol (SNMP). The format of the **MIB** is defined as part of the SNMP. (All other **MIBs** are extensions of this basic management information base.)

Click **Download MIB**, to download the MIB file.

To configure SNMP:

1. Go to **Setup > SNMP Configuration**.
2. Under **SNMP Server Configuration**, check **Enabled** to activate the SNMP server. Click **Submit**.
3. If needed, click **Add** under **Allowed IP Addresses** for **SNMP v1/v2c**.

4. Click **Add Server Configuration**.
 - a. Make sure that **Enabled** is checked.
 - b. Under **Version**, select from the drop-down either **SNMP v1/v2c** or **SNMP v3**.
 - c. For **SNMP v1** and **SNMP v2c**:
 - i. Enter the **Configuration Name** for your SNMP configuration.
 - ii. Enter **Community String** which is a read-only string used to authenticate incoming SNMP requests.
 - d. For **SNMP v3**:
 - i. Enter the **Authentication Protocol** from the drop-down, including **NONE**, **MD5**, or **SHA1**.
 - ii. Enter the **Security Name** which is a username used to authenticate incoming SNMP v3 requests. If you selected **MD5** or **SHA1** for Authentication Protocol:
 - Enter the **Authentication Password**, which is a password used to authenticate incoming SNMPv3 requests.
 - Confirm the password.
 - iii. Enter the **Encryption Protocol** for SNMPv3 messages from the drop-down, including **NONE**, **DES** or **AES-128**. If you selected **DES** or **AES-128** for **Encryption Protocol**:
 - Enter the **Encryption Password**.
 - Confirm the password.
 - e. Click **Submit**.
5. The **SNMP Configuration** list displays your recently added SNMP Server Configuration. To edit the configuration, click the pencil icon under **Options**.
6. To delete an existing configuration, click the trash can icon under **Options**.
7. To save your changes, click **Save and Apply**. Or continue to **SNMP Trap Destinations** and **Add Trap Destinations**.

To configure SNMP Traps:

1. Go to **Setup > SNMP Configuration > SNMP Trap Configuration**, check **Enabled** to enable sending SNMP traps on the device..
2. The engine ID displays to the right of **Enabled**. Modify the engine ID or use the default value.
3. Click **Submit**.
4. Click **Add Trap Destination**.
 - a. Make sure that **Enabled** box is checked.
 - b. Enter the **Destination Name**.
 - c. Select from the drop-down the **Version** of SNMP (**SNMP v1/v2c** or **SNMP v3**).
 - d. For **SNMP v1** or **SNMP v2c**
 - i. Enter the **Destination IP Address**.
 - ii. Enter the **Community String**.
 - e. For **SNMPv3**:
 - i. Enter the **Destination IP Address**.

3. In the **Port** field, type the port number on which the TCP server is listening for connections. The default is **5445**. You can use up to five digits. Each digit itself must be between **0** and **9**. Numbers above **65,535** are illegal as the port identification fields are 16 bits long in the TCP header.
4. Enter **Password** and confirm **Password**.
5. Click **Submit**.
6. To save your changes, click **Save and Apply**.

Dumping NMEA Sentence Information to the Device's TCP Server Port

To configure the TCP server port where you can send the NMEA sentences:

1. Complete the steps under **GPS Server Configuration**.
2. To use the serial port for GPS, you must disable the serial port client/server. Go to **Setup > Serial IP Configuration > Serial Port Settings** and uncheck **Enabled**.
3. Then, under **Local Configuration**, check **Serial Port Dump**.
4. **Submit**.
5. To save your changes, click **Save and Apply**.

Sending GPS information to a remote server

The **Client Configuration** allows the device to connect to a remote server using the IP and port information for uploading GPS data.

1. To allow the device to connect, go to **Setup > GPS Configuration > Client Configuration**.
2. Check **TCP/UDP Client**.
3. From the **Protocol** drop-down list, select the protocol of the client (**TCP** or **UDP**).
4. In the **Remote Host** field, type the IP address of the remote host.
5. In the **Port**, field type the port number of the remote host.
6. If your remote host requests a password, type that password in the **Password** field. The password is sent to the server in response.
7. Click **Submit**.
8. To save your changes, click **Save and Apply**.

Configuring NMEA Sentences

To configure the time interval, additional prefix or ID information, and which NMEA sentences that can be sent:

1. Go to **Setup > GPS Configuration > NMEA Configuration**.
2. If **Enable NMEA Mode** exists (disabled by default), check to enable. **NOTE:** GLL and VTG sentences cannot be enabled when NMEA Mode is disabled.
3. In the **Interval** field, type the amount of time, in seconds, that passes before the NMEA information is sent. The default is **10** seconds. The range is **1** to **255** seconds.
4. You can further identify the device, also called a remote asset, that is collecting and sending the GPS information. To do so:

Add ID: The ID is an unique remote asset identification string. The ID string can be any length up to 20 characters. The **&** and **\$** are invalid characters. The ID must follow the standard NMEA sentence structure. Refer to the [Universal IP AT Commands Reference Guide](#) for sentence structure.

To add more information to the beginning of the ID, in the Add ID Prefix field, type the information.

- For devices that do not have **Enable NMEA Mode**, you can select which NMEA sentence types you want to send. Check any combination of the available options: **GGA**, **GSA**, **GSV**, **GLL**, **RMC**, and **VTG**.

SMTP Settings

The following table lists the configuration fields in the SMTP window.

| Field | Description |
|---------------------------|--|
| SMTP Configuration | |
| Enabled | Click to use the SMTP feature. |
| Server | Enter the SMTP server address. |
| Port | Enter the port number that the SMTP server uses. |
| Email | Enter the sender email address. This address will be added as the sender email address to the sent emails. |
| Username | Enter the name that can access the SMTP server. |
| Password | Enter the password that can access the SMTP server. |
| Mail Log Settings | |
| Entries to Keep | Enter the desired number of mail log entries that are to be stored in the device. The range of values is 10 to 1000 . If you click Submit , this setting is not applied to the emails that are in progress or deferred. Note that logs are not saved on the device. Also, logs do not persist through power cycles. |
| Send a Test Email | |
| Address | To make sure that the SMTP is configured properly, enter a destination email address, then click Send Test Email . |

Configuring the Serial Port in Serial IP Mode

To configure the serial terminal connected to the RS-232 connector on the device:

- Go to **Setup > Serial Port Configuration**.
- Under **General Configuration**, select the **Mode** from the drop-down including **Disabled** (default), **Serial IP**, or **Modbus RTU/TCP Gateway*** **Disabled** means that **Serial-IP** and **Modbus Gateway** are both disabled. However, you can configure the serial port which can be used by other features like GPS. **NOTE:** If you want to use **Modbus Gateway**, you may have the TCP connection encrypted with TLS. Make sure to check **Protocol** under **IP Pipe** and select **SSL/TLS**.
- From the **Baud Rate** drop-down list, select the baud-rate at which the serial terminal communicates. The default is **115200**.
- From the **Flow Control** drop-down list, select the flow control for the serial port. The options are **NONE** or **RTS-CTS**. The default is **NONE**.
- From the **Parity** drop-down list, select the parity for the serial port. The options are **NONE**, **EVEN**, or **ODD**. The default is **NONE**.
- From the **Data Bits** drop-down list, select the data bits for the serial port. Data bit options are **7** or **8**. The default is **8**.

7. From the **Stop Bits** drop-down list, select the stop bits for the serial port. The options are **1** or **2**. The default is **1**.
8. Click **Submit**.
9. To save your changes, click **Save and Apply**. If the device is set to **Serial Modem Mode**, the device reboots after applying any changes.

***Note on Modbus RTU/TCP Gateway:** This feature was developed for a specific application/use case where a Modbus RTU slave is connected to the Serial Port and a remote Modbus TCP Master. The Modbus Gateway application works as a translator between Modbus RTU (slave) and Modbus-TCP (master) devices. Without Modbus Gateway enabled, the Serial-IP feature simply passes raw data between the serial DB9 interface and the socket representing the TCP connection in the system to a configured remote device. When the Modbus Gateway is enabled, its application runs in the system. The application works as a translator converting between the Modbus-TCP and Modbus RTU protocols. The Modbus Gateway passes data between an RTU connected to the serial port and a Modbus TCP remote client/server. The Modbus Gateway and the Serial-IP features cannot work simultaneously.

Configuring Device to Act as Client for Serial IP

You can set up the device to act as a client.

The TCP, UDP, SSL/TLS client feature enables the device to act as a proxy TCP, UDP, or SSL/TLS client to the serial terminal connected to the RS-232 port on the device. This helps the serial terminal access any TCP, UDP, or SSL/TLS server on the LAN/WAN allowing two-way traffic between the serial device and the remote server.

To use this function, you must first check **Enabled** under **Serial Port Settings**. To configure the IP Pipe in TCP, UDP, or SSL/TLS client mode:

1. Go to **Setup > Serial-IP Configuration > Serial Port Settings > IP Pipe** group.
2. From the **Mode** drop-down list, select **CLIENT**.
3. From the **Protocol** drop-down list, select the desired protocol: **TCP**, **UDP**, or **SSL/TLS**.
4. In the **Server IP Address** field, enter the address of the far-end TCP, UDP, or SSL/TLS server.
5. In the **Server Port** field, enter the port value used by the far-end TCP, UDP, or SSL/TLS server.
6. If the primary server is unavailable, in the **Secondary IP Address** field, enter the address of the alternate TCP, UDP, or SSL/TLS server.
7. If the primary server is unavailable, in the **Secondary Port** field, enter port number value of the alternate TCP, UDP, or SSL/TLS server.
8. From the **Connection Activation** drop-down list, select a connection method. Options are:
 - ALWAYS-ON.**
 - DTR-ASSERT.** When the DTR signal is asserted, the connection is established.
 - CR.** Three carriage returns must be received before the TCP, UDP, or SSL/TLS connection is established to the remote server.
 - ON-DEMAND.** Set the connection as available on-demand.
9. From the **Connection Termination** drop-down list, select a disconnect method for the IP pipe. Options are:
 - ALWAYS-ON.**
 - TIMEOUT.** The IP pipe connection disconnects if the configured timer expires with no data sent or received. In the **Timeout** field, enter the desired number of seconds for this timeout. The valid timeout

range is from **0 to 900 seconds**. Timeout of zero seconds disables the timeout and it is equivalent to **ALWAYS-ON**.

SEQUENCE. A sequence of received characters disconnects the IP pipe.

DTR-TOGGLE. When the DTR control signal is toggled, the IP pipe disconnects.

10. In the **Buffer Timeout** field, enter the timeout after which data is sent to the network if the buffer is not full (in milliseconds).
11. In the **Buffer Size** field, enter the size of the buffer for reading data from the serial port and sending to the network (in bytes). Data is sent when the buffer is full.
12. Click **Submit**.
13. To save your changes, click **Save and Apply**. If the device is set to **Serial Modem Mode**, the device reboots after applying any changes.

To configure security settings:

1. Make sure you select **SSL/TLS** under **Protocol**.
2. Under **Security Settings**, click the **Show** to the right.
3. Select any TLS version. Check **TLSv1.3**, **TLSv1.2** and/or **TLSv1.1 (deprecated)**. Default: **TLSv1.3** and **TLSv1.2** are enabled.
4. Check any preferred Cipher Suite from the following list: **TLS_AES_256_GCM_SHA384**, **TLS_CHACHA20_POLY1305_SHA256**, **TLS_AES_128_GCM_SHA256**, **ECDHE-RSA-AES256-GCM-SHA384**, **ECDHE-RSA-AES128-GCM-SHA256**, **TLS_AES_128_GCM_SHA256**, and also including the following deprecated ciphers: **ECDHE-RSA-AES256-GCM-SHA384**, **ECDHE-RSA-AES256-SHA**, **DHE-RSA-AES256-GCM-SHA384**, **AES256-SHA**, **ECDHE-RSA-AES128-GCM-SHA256**, **ECDHE-RSA-AES128-SHA**, **DHE-RSA-AES128-GCM-SHA256**, **DHE-RSA-AES128-SHA**, and/or **AES128-SHA**. Default: **All**. (You can also set the priority order of the ciphers).
5. Click **Submit**.
6. To save your settings, click **Save and Apply**.

Configuring Device to Act as Server for Serial IP

You can set up the device to act as a server.

The TCP, UDP, SSL/TLS server feature enables a TCP, UDP, SSL/TLS client on the Ethernet network to connect to the remote serial terminal that is connected to the RS-232 port on the device. The device acts as a TCP, UDP, SSL/TLS server which allows two-way traffic between the TCP, UDP, SSL/TLS client and the remote terminal on the serial port.

To use this function, you must first check **Enabled** under **Serial Port Settings**. To configure the IP Pipe in TCP, UDP, SSL/TLS server mode:

1. Go to **Setup > Serial-IP Configuration > Serial Port Settings > IP Pipe** group.
2. In the **Mode** drop-down list, select **SERVER**.
3. From the **Protocol** drop-down list, select the desired protocol: **TCP**, **UDP**, or **SSL/TLS**.
4. In the **Buffer Timeout** field, enter the timeout after which data is sent to the network if the buffer is not full (in milliseconds).
5. In the **Server Port** field, type the desired port value in the range **1 to 65535**.

6. In the **Buffer Size** field, enter the size of the buffer for reading data from the serial port and sending to the network (in bytes). Data is sent when the buffer is full.
7. From the **Connection Termination** drop-down list, select a disconnect method for the IP pipe. Options are:
 - ALWAYS-ON.**
 - TIMEOUT.** The IP pipe connection disconnects if the configured timer expires with no data sent or received. In the **Timeout** field, enter the desired number of seconds for this timeout. The valid timeout range is from **0 to 900 seconds**. Timeout of zero seconds disables the timeout and it is equivalent to ALWAYS-ON.
 - SEQUENCE.** A sequence of received characters disconnects the IP pipe.
 - DTR-TOGGLE.** When the DTR control signal is toggled, the IP pipe disconnects.
8. Click **Submit**.
9. To save your changes, click **Save and Apply**. If the device is set to **Serial Modem Mode**, the device reboots after applying any changes.

To configure security settings:

1. Make sure you select **SSL/TLS** under **Protocol**.
2. Under **Security Settings**, click the **Show** to the right.
3. Select any **TLS version**. Check **TLSv1.3**, **TLSv1.2** and/or **TLSv1.1 (deprecated)**. Default: **TLSv1.3** and **TLSv1.2** are enabled.
4. Check any **Cipher Suite** from the following list: **TLS_AES_256_GCM_SHA384**, **TLS_CHACHA20_POLY1305_SHA256**, **TLS_AES_128_GCM_SHA256**, **ECDHE-RSA-AES256-GCM-SHA384**, **ECDHE-RSA-AES128-GCM-SHA256**, **TLS_AES_128_GCM_SHA256**, and also including the following deprecated ciphers: **ECDHE-RSA-AES256-GCM-SHA384**, **ECDHE-RSA-AES256-SHA**, **DHE-RSA-AES256-GCM-SHA384**, **AES256-SHA**, **ECDHE-RSA-AES128-GCM-SHA256**, **ECDHE-RSA-AES128-SHA**, **DHE-RSA-AES128-GCM-SHA256**, **DHE-RSA-AES128-SHA**, and/or **AES128-SHA**. Default: **All**.
5. Click **Submit**.
6. To save your settings, click **Save and Apply**.

Unavailable Services in PPP-IP Passthrough and Serial Modem Modes

In both **PPP-IP Passthrough** and **Serial Modem** modes, many rCell services described in this document are either limited, or non-configurable and therefore do not appear in the device configuration menu. If you choose one of these modes, all sections between this and the previous note on this subject are limited, or typically not available.

Time Configuration

You can configure how your device manages the setting of time on its domain of systems. The system date and time display in these formats: **MM/DD/YYYY HH:MM**. You can set the date and time manually, or you can configure the device to get this information from an SNTP server.

Setting the Date and Time

To set the device's date and time:

1. From **Setup**, select **Time Configuration**.
2. In the **Date** field, select today's date from the pop-up calendar that opens.
3. In the **Time** field, type the time (24-hour).
4. From the **Time Zone** drop-down list, select your time zone. The default selection is UTC (Universal Coordinated Time, Universal Time).

Note: To learn more about time zones, visit the following website :
<http://www.https://greenwichmeantime.com/time-zone/>

5. Click **Submit**.
6. To save your changes, click **Save and Apply**.

Configuring SNTP Client to Update Date and Time

To configure the server from which the SNTP date and time information is taken, and how often:

1. To enable SNTP to update the date and time, check **Enabled**.
2. In the **Polling Time** field, type the time that passes (in minutes), after which the SNTP client requests the server to update the time. Default is 120 minutes.
3. In the **Server** field, type the SNTP server name or IP address that is contacted to update the time.
4. In the **Backup Server 1 - 4** fields, you may enter the SNTP server name or IP address of up to four backup SNTP servers. These fields are optional.
5. Click **Submit**.
6. To save your changes, click **Save and Apply**.

Chapter 5 – Wireless

Setting Up Wi-Fi Access Point

If you ordered a device with Wi-Fi capability, it can be configured as a wireless access point (AP). This allows Wi-Fi enabled devices to connect to your device using Wi-Fi. The Wi-Fi access point can have up to 5 clients at a time. To set up your device as an access point:

1. Go to **Wireless > Wi-Fi Access Point**.
2. To enable Wi-Fi Access Point mode, check **Enabled**.
3. To set the SSID (service set identifier) for the access point supported by your device, in the **SSID** field, type the name. The Wi-Fi devices look for this ID in order to join the wireless network. All wireless devices on a WLAN must use the same SSID in order to communicate with the access point.
4. To specify the data rates supported, in the **Network Mode** drop-down list, select the desired option. Possible values are B/G/N-Mixed, B/G-Mixed, B-Only, and N-Only.
5. From the **Channel** drop-down list, select the channel on which the device operates. Channels 1-11 are available.
6. In the **Beacon Interval** field, enter the period of time, in milliseconds, when the access point sends a beacon packet. Beacons help synchronize a wireless network. For most applications, the default value of 100 provides good performance.
7. In the **DTIM Interval** field, enter how often a beacon frame includes a Delivery Traffic Indication Message, and this number is included in each beacon frame. It is generated within the periodic beacon at a frequency specified by the DTIM Interval. A delivery traffic indication message is a kind of traffic indication message (TIM) which informs the clients about the presence of buffered multicast/broadcast data on the access point. The default value of 1 provides good performance for most applications. You might want to increase this value when using battery powered Wi-Fi devices, which can sleep (at reduced power consumption) during the longer DTIM interval period. You must balance the power savings from increasing the DTIM interval against possible reduced communication throughput.
8. In the **RTS Threshold** field, type the frame size at which the AP transmissions must use the RTS/CTS protocol. This is often used to solve hidden node problems. Using a small value causes RTS packets to be sent more often, consuming more of the available bandwidth. However, the more RTS packets that are sent, the quicker the system can recover from interference or collisions.

For related information, see [Setting Security Options](#) and [Viewing Information About Wi-Fi Clients Using Your Wireless Network](#).

Setting Security Options

Specify the security protocol that your device uses to secure the communications from it to the connected devices under **Security Options**.

1. From the **Mode** drop-down list, select the security protocol you want to use. Options include:
 - None
 - WEP**: Use Wired Equivalent Privacy protocol to allow a group of devices on the network to exchange coded messages.
 - WPA-PSK**: Use Wi-Fi protected access to secure data exchanged on your network.
 - WPA2-PSK**: Use Wi-Fi protected access version 2 to secure data exchanged on your network.
 - WPA/WPA2-PSK**: Use Wi-Fi protected access version 1 and 2 to secure data exchanged on your network.

2. To select **WEP** mode:
 - a. From the **Encryption** drop-down list, select the encryption to be used. Choose from **64 bit 10 hex digits** or **128 bit 26 hex digits**.
 - b. To generate a key from a phrase, in the **Passphrase** field, type a phrase. Click **Generate**.
 - c. To manually enter keys, type the keys in the Key 1, Key 2, Key 3 or Key 4 fields.
3. To select **WPA-PSK**, **WPA2-PSK** or **WPA-PSK/WPA2-PSK** modes:
 - a. Select the WPA Algorithm from the drop-down list. Choose from **TKIP**, **AES** or **TKIP+AES**.
 - b. In the **Shared Key** field, type the key that is used for encrypting and decrypting the data.
 - c. To remove the mask characters, thereby making the Shared Key visible, check **Unmask**.
4. When done, click **Submit**.
5. To save your changes, click **Save and Apply**.

Viewing Information About Wi-Fi Clients Using Your Wireless Network

To view information about clients (such as computers, tablets, and smart phones) that are connected to your device's Wi-Fi access point:

1. The Clients group displays a list of clients using your device's Wi-Fi.
2. To update the list, click **Refresh**.

Setting Up Wi-Fi as WAN

To setup the device's Wi-Fi as WAN:

1. Go to **Wireless > Wi-Fi as WAN**.
2. To enable Wi-Fi as WAN mode, check **Enabled**. (**Note:** After you enable or disable **Wi-Fi as WAN** and apply that change, the device reboots.)
3. Click **Save and Apply**. **Note:** **Save and Apply** the device to get a list of available Wi-Fi Networks.
4. Go to **Wireless > Wi-Fi as WAN**.
5. Searching for available Wi-Fi networks starts automatically. After 30 to 60 seconds, a list of detected Wi-Fi Access Points appears in the **Available Networks** group.
6. In the **Available Wi-Fi Networks** group, click the SSID for the Wi-Fi access point you want to use. The **Add Saved Network** window opens. Here are the available fields to enter information:

Network Name

Hidden Network(only check if your target network is currently hidden)

SSID

Security Mode: None, WEP, WPA, WPA-PSK, WPA-2, or WPA-2-PSK

Username

Password

Unmask (Check, Uncheck)

WPA Algorithm: TKIP, +AES, TKIP, or AES

Shared Key

Key Index: 0 - 3

Network Key

IEEE 802.1x

7. Review the information, enter any required security info, then click **Finish**. The Wi-Fi access point you just added appears in the **Saved Wi-Fi Networks** group.
8. If desired, add additional access points to the list of Saved Networks. The device tries to connect to **Saved Wi-Fi Networks** in the order they are listed. You can change the order by clicking the up or down arrows shown under **Options**.
9. When finished, click **Save and Apply**. The Status field displays "Connected" if you have successfully connected to the Wi-Fi access point.

Note: You cannot edit the network name and you cannot delete a network if it is used in another configuration.

Setting up Bluetooth

The Bluetooth-IP feature allows a data connection between a remote TCP/UDP client or server and a local Bluetooth device. To set up the Bluetooth connection:

1. Go to **Wireless > Bluetooth-IP**
2. To enable the feature, check **Enabled**. Click **Submit**.
3. Confirm that the far-end Bluetooth device is powered on and waiting for a connection.
4. In the **Available Devices** group, click **Refresh**. A list of detected Bluetooth devices appears.
5. Click the name of the Bluetooth device that you want to use. The name and MAC address appear under the **Selected Device**.
6. To add a device, click **Add Device** and enter the device name and the **MAC address**.
7. Click **Finish**.
8. To save your changes, click **Save and Apply**.

Note: You cannot edit the network name and you cannot delete a network if it is used in another configuration.

IP Pipe in TCP/UDP Server mode

1. In the **IP Pipe** group, from the **Mode** drop-down list, select **SERVER**.
2. From the **Protocol** drop-down list, select the desired protocol, either **TCP** or **UDP**.
3. In the **Server Port** field, type the desired port value in the range **1** to **65535**.
4. From the **Connection Termination** drop-down list, select a disconnect method for the IP pipe. Options are:
 - **ALWAYS-ON**
 - **SEQUENCE:** A sequence of characters received from the Bluetooth side used to disconnect the IP pipe.
 - **TIMEOUT:** The IP pipe connection disconnects if the configured timer expires with no data sent or received. A timeout of zero seconds disables the timeout, it is equivalent to **ALWAYS-ON**.

To configure the IP Pipe in TCP/UDP Client mode

1. In the **IP Pipe** group, from the **Mode** drop down list, select **CLIENT**.
2. From the **Protocol** drop-down list, select the desired protocol, either **TCP** or **UDP**.
3. In the **Server IP Address** field, type the address of the far-end TCP-UDP server.
4. In the **Server Port** field, type the port value used by the far-end TCP/UDP Server.
5. In case the primary server is unavailable, in the **Secondary IP Address** field and in the **Secondary Port** field, type the IP address and port number, respectively, of the alternate TCP/UDP server.

6. From the **Connection Activation** drop-down list, select a connection method. Options are:
 - **ALWAYS-ON**
 - **ON-DEMAND**
 - **CR:** Three carriage returns must be received from the Bluetooth side before TCP/UDP connection is established to the remote server.
7. From the **Connection Termination** drop-down list select a disconnect method for the IP pipe. Options are:
 - **ALWAYS-ON:**
 - **TIMEOUT:** The IP pipe connection disconnects if the configured timer expires with no data sent or received. A timeout of zero seconds disables the timeout, it is equivalent to **ALWAYS-ON**.
 - **SEQUENCE:** A sequence of characters received from the Bluetooth side used to disconnect the IP pipe.
8. Click **Submit**.
9. To save your changes, click **Save and Apply**.
 - The device immediately connects to the local Bluetooth device. If successful the **Status** field displays **Connected**. If **IP Pipe** is configured for **SERVER**, the IP connection is initiated by the far-end TCP/UDP client.
 - If **Mode** is set to **CLIENT**, the device initiates connections for the far-end TCP/UDP server based on the configured **Connection Activation** conditions are met.

To configure security settings:

1. Make sure you select **SSL/TLS** under **Protocol**.
2. Under **Security Settings**, click the **Show** to the right.
3. Select any TLS version. Check **TLSv1.3**, **TLSv1.2** and/or **TLSv1.1 (deprecated)**. Default: **TLSv1.3** and **TLSv1.2** are enabled.
4. Check any preferred Cipher Suite from the following list: **TLS_AES_256_GCM_SHA384**, **TLS_CHACHA20_POLY1305_SHA256**, **TLS_AES_128_GCM_SHA256**, **ECDHE-RSA-AES256-GCM-SHA384**, **ECDHE-RSA-AES128-GCM-SHA256**, **TLS_AES_128_GCM_SHA256**, and also including the following deprecated ciphers: **ECDHE-RSA-AES256-GCM-SHA384**, **ECDHE-RSA-AES256-SHA**, **DHE-RSA-AES256-GCM-SHA384**, **AES256-SHA**, **ECDHE-RSA-AES128-GCM-SHA256**, **ECDHE-RSA-AES128-SHA**, **DHE-RSA-AES128-GCM-SHA256**, **DHE-RSA-AES128-SHA**, and/or **AES128-SHA**. Default: **All**.
5. Click **Submit**.
6. To save your settings, click **Save and Apply**.

Chapter 6 – Firewall

Normal Firewall Settings

The device's firewall enforces a set of rules that determine how incoming and outgoing packets are handled. By default, all outbound traffic originating from the LAN is allowed to pass through the firewall, and all inbound traffic originating from external networks is dropped. This effectively creates a protective barrier between the LAN and all other networks.

Go to **Firewall > Settings** to see the current firewall configuration. The firewall's **Normal Settings** mode (default) lets you manipulate and add **DNAT**, **SNAT**, and **Filter** rules directly. **DNAT** rules can manipulate the destination address and port of a packet; similarly **SNAT** rules can manipulate the source address and port of a packet. We recommend using these normal settings. Filter rules apply an **ACCEPT**, **REJECT**, **DROP**, or **LOG** action to a packet. **DNAT**, **SNAT**, and **Filter** rules can be associated if they are named the same.

The firewall is built on top of iptables. The different rule groups correspond to their respective chains in iptables.

Note: As a best security practice, the device employs minimum firewall rules by default. This means by default the device allows all outbound traffic from it in the **Output Filter Rules**. (Traffic through the device is handled by the **Port Forwarding Rules**.) But all traffic to the device via WAN interfaces is blocked by default in the Input Filter Rules. Users may create their own specific and targeted input filter rules to allow certain traffic to the device based on their specific needs.

- [Adding Prerouting Rules](#)
- [Input Filter Rules](#)
- [Forward Filter Rules](#)
- [Output Filter Rules](#)
- [Adding Postrouting Rules](#)
- [Legacy Settings](#)

Prerouting Rule

Add a DNAT rule

To add prerouting or DNAT rule to your firewall:

1. Go to **Firewall > Settings** to display the **Firewall** window.
2. In the **Prerouting Rules** group, click **Add DNAT Rule**.
3. In the **Filter Rule** section, enter a name for the rule and optionally, a description.
4. In the **Destination IP** field, enter the destination IP address that applies to this rule.
5. In the **Destination Port** field, enter the destination port that applies to this rule. If there is a range of ports, the ending port is automatically set.
6. In the **Destination Mask** field, enter the subnet mask of the destination that applies to this rule.
7. In the **Destination Interface** field, select the interface used by the destination that applies to this rule from the drop-down menu. Select from **ANY**, **LAN**, **WAN**, **ETHERNET**, **CELLULAR**, **WI-FI WAN**, **WI-FI AP**, or **OPENVPN**.
8. In the **Source IP** field, enter the source IP address that applies to this rule.
9. In the **Source Port** field, enter the source port that applies to this rule.
10. In the **SourceMask** field, enter source subnet mask that applies to this rule.

11. In the **SourceMAC** field, enter the source MAC address for the device that applies to this rule.
12. In the **SourceInterface** field, select the source interface that applies to this rule from the drop-down menu. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
13. In the **Protocol** drop-down list, select the protocol of the messages that apply to this rule. Select from **TCP/UDP, TCP, UDP, or ANY**.
14. In the **NAT IP** field, enter the local IP address for the Network Address Translation.
15. In the **NAT Port** field, enter the port used for the Network Address Translation.
16. **Check Enable NAT Loopback if you want to redirect LAN packets destined for the WAN's public IP address.**
17. Click **Submit**.
18. To save your changes, click **Save and Apply**.

Input Filter Rules

To add an input filter rule to your firewall:

1. Go to **Firewall > Settings** to display the **Firewall** window.
2. In the **Input Filter Rules** group, click **Add Rule**.
3. In the **Filter Rule** section, enter a name for the rule and optionally, a description.
4. In the **Destination IP** field, enter the destination IP address that applies to this rule.
5. In the **Destination Port** field, enter the destination port that applies to this rule. If there is a range of ports, the ending port is automatically set.
6. In the **Destination Mask** field, enter the subnet mask of the destination that applies to this rule.
7. In the **Destination Interface** field, select the interface used by the destination that applies to this rule from the drop-down menu. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
8. In the **Source IP** field, enter the source IP address that applies to this rule.
9. In the **Source Ports** field, enter the source port range that applies to this rule.
10. In the **Source Mask** field, enter source subnet mask that applies to this rule.
11. In the **Source MAC** field, enter the source MAC address for the device that applies to this rule.
12. In the **Source Interface** field, select the source interface that applies to this rule from the drop-down menu. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
13. In the **Protocol** drop-down list, select the protocol of the messages that apply to this rule. Select from **TCP/UDP, TCP, UDP, or ANY**.
14. In the **Chain** field, select the grouping based on the type of traffic affected by the rule from the drop-down menu. Select from **INPUT, FORWARD, or OUTPUT**.
15. In the **Target** field, select the desired action of the firewall based on this rule from the drop-down menu. Choose from **ACCEPT, REJECT, DROP, or LOG**.
16. Click **Submit**.
17. To save your changes, click **Save and Apply**.

Forward Filter Rules

This page defines rules for forward filtering of connections and data.

1. Go to **Firewall > Settings** to display the **Firewall** window.
2. Click **Add Rule** in the **Forward Filter Rules** section.

3. Enter a name for the rule and optionally, a description.
4. In the **Destination IP** field, type the IP address of the device or network that packets are to be sent to. Type **ANY** if the destination address does not matter.
5. In the **Destination Port** field, type the port packets are destined for. Common destination ports are listed in the Destination Port field's attached drop-down list. Type **ANY** if the destination port does not matter.
6. In the **Destination Mask** field, type the network mask of the destination network.
7. In the **Destination Interface** field, select the interface used by the destination that applies to this rule from the drop-down menu. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
8. In the **Source IP** field, type the IP address of the device or network that the traffic originates from. Type **ANY** if the source address does not matter.
9. In the **Source Port** field, type the port that is the origin of the traffic. Type **ANY** if the source port does not matter.
10. In the **Source Mask** field, type a network mask for the origin of the traffic.
11. In the **Source MAC** field, enter the source MAC address for the device that applies to this rule.
12. In the **Source Interface** field, select the source interface that applies to this rule from the drop-down menu. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
13. In the **Protocol** drop-down list, select the protocol of the messages that apply to this rule. Select from **TCP/UDP, TCP, UDP, or ANY**.
14. In the **Chain** field, this parameter is the grouping based on the type of traffic affected by the rule from the drop-down menu. Keep this field as **FORWARD**.
15. In the **Target** field, select the desired action of the firewall based on this rule from the drop-down menu. Choose from **ACCEPT, REJECT, DROP, or LOG**.
16. Click **Submit**.
17. To save your changes, click **Save and Apply**.

Output Filter Rules

To prevent a device within the LAN from communicating with a device in an external network, you must establish a firewall rule to drop packets destined to the external device.

1. Go to **Firewall > Settings** to display the **Firewall** window.
2. Click **Add Rule** in the **Output Filter Rules** section.
3. Enter a **Name** for the rule and optionally, a **Description**.
4. In the **Destination IP** field, type the IP address of the device or network that packets are to be sent to. Type **ANY** if the destination address does not matter.
5. In the **Destination Port** field, type the port for which that the packets are destined. Common destination ports are listed in the Destination Port field's attached drop-down. Type **ANY** if the destination port does not matter.
6. In the **Destination Mask** field, type the network mask of the destination network.
7. In the **Destination Interface** field, select the interface used by the destination that applies to this rule from the drop-down. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
8. In the **Source IP** field, type the IP address of the device or network that the traffic originates from. Type **ANY** if the source address does not matter.

9. In the **Source Port** field, type the port that is the origin of the traffic. Type **ANY** if the source port does not matter.
10. In the **Source Mask** field, type a network mask for the origin of the traffic.
11. In the **SourceMAC** field, enter the source MAC address for the device that applies to this rule.
12. In the **Source Interface** field, select the source interface that applies to this rule from the drop-down. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
13. From the **Protocol** drop-down, select the protocol of the messages that apply to this rule. Choose from **TCP/UDP, TCP, UDP, or ANY**.
14. In the **Chain** field, select the grouping based on the type of traffic affected by the rule from the drop-down. Select from **INPUT, FORWARD, or OUTPUT**.
15. In the **Target** field, select the desired action of the firewall based on this rule from the drop-down. Choose from **ACCEPT, REJECT, DROP, or LOG**.
16. Click **Submit**.
17. To save your changes, click **Save and Apply**.

Postrouting Rule

Add a SNAT rule

To add postrouting or SNAT rule to your firewall:

1. Go to **Firewall > Settings** to display the **Firewall** window.
2. In the **Postrouting Rules** group, click **Add SNAT Rule**.
3. In the **Postrouting Rule** section, enter a name for the rule and optionally, a description.
4. In the **Destination IP** field, enter the destination IP address that applies to this rule.
5. In the **Destination Port** field, enter the destination port that applies to this rule. If there is a range of ports, the ending port is automatically set.
6. In the **Destination Mask** field, enter the subnet mask of the destination that applies to this rule.
7. In the **Destination Interface** field, select the interface used by the destination that applies to this rule from the drop-down menu. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
8. In the **Source IP** field, enter the source IP address that applies to this rule.
9. In the **Source Port** field, enter the source port that applies to this rule.
10. In the **SourceMask** field, enter source subnet mask that applies to this rule.
11. In the **SourceInterface** field, select the source interface that applies to this rule from the drop-down menu. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
12. In the **Protocol** drop-down list, select the protocol of the messages that apply to this rule. Select from **TCP/UDP, TCP, UDP, or ANY**.
13. In the **NAT IP** field, enter the public IP address for the Network Address Translation.
14. In the **Target** field, select the desired action of the firewall based on this rule from the drop-down menu. Choose from **SNAT or MASQUERADE**.
15. In the **NAT Port** field, enter the port used publicly for the Network Address Translation.
16. Click **Submit**.
17. To save your changes, click **Save and Apply**.

Adding Port Forwarding Rules

For a device within the LAN to be visible from the internet or from an outside network, create a forwarding rule to allow incoming packets to reach the device.

1. Go to **Firewall > Settings** to display the **Firewall** window.
2. In the **Port Forwarding** group, click **Add Rule**.
3. In the **Filter Rule** section, enter a name for the rule and optionally, a description.
4. In the **Destination IP** field, enter the destination IP address that applies to this rule.
5. In the **Destination Port** field, enter the destination port that applies to this rule. If there is a range of ports, the ending port is automatically set.
6. In the **Destination Mask** field, enter the subnet mask of the destination that applies to this rule.
7. In the **Destination Interface** field, select the interface used by the destination that applies to this rule from the drop-down menu. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
8. In the **Source IP** field, enter the source IP address that applies to this rule.
9. In the **Source Ports** field, enter the source port range that applies to this rule.
10. In the **Source Mask** field, enter source subnet mask that applies to this rule.
11. In the **Source MAC** field, enter the source MAC address for the device that applies to this rule.
12. In the **Source Interface** field, select the source interface that applies to this rule from the drop-down menu. Select from **ANY, LAN, WAN, ETHERNET, CELLULAR, WI-FI WAN, WI-FI AP, or OPENVPN**.
13. In the **Protocol** drop-down list, select the protocol of the messages that apply to this rule. Select from **TCP/UDP, TCP, UDP, or ANY**.
14. In the **Chain** field, select the grouping based on the type of traffic affected by the rule from the drop-down menu. Select from **INPUT, FORWARD, or OUTPUT**.
15. In the **Target** field, select the desired action of the firewall based on this rule from the drop-down menu. Choose from **ACCEPT, REJECT, DROP, or LOG**.
16. Click **Submit**.
17. To save your changes, click **Save and Apply**.

A default filter allowing forwarded packets through the firewall is automatically created. If desired, you can use the **Advanced Settings** mode of the Port Forwarding configuration to further restrict packets based on source address and source ports using the **Inbound Filter Rule**. In most cases, this is not necessary.

Trusted IP

Trusted IP is a simplified interface to create iptables rules to allow or block specific IPs, IP ranges, or subnets. This feature allows users to create whitelists (which are allowed or trusted IPs) or black lists (which are blocked or unwanted IPs). You can add, edit, and delete IP addresses as needed.

If you select **White List** as **Trusted IP Mode** and you do not set any IP range, no traffic will be allowed. If you select **Black List** as **Trusted IP Mode** and you do not set any IP range, all traffic will be allowed.

To set up a Trusted IP range:

1. Go to **Firewall > Trusted IP**.
2. Check the **Enabled** box to turn on Trusted IP.
3. Select the **Trusted IP Mode** from the drop-down, either **White List** or **Black List**. (**NOTE:** Be aware of the behavior of each list and its consequences based on your specific configuration. For example, if you select

White List as Trusted IP Mode, you should include the device **IP Address Range** or **IP Address** and **Subnet Mask** to maintain your local device LAN access.)

4. To add IP addresses, click **Add IP Range** in the upper right corner.
5. Under the **Add IP Range**, enter or select the following parameters:
 - a. **Name**
 - b. Mode from drop-down, either **Subnet** or **IP Range**.
 - c. For **Subnet**:
 - i. **IP Address**
 - ii. **Subnet Mask**
 - d. For **IP Range**:
 - i. **IP Address Start**
 - ii. **IP Address End**
 - e. **Destination Port** (default: **ANY**)
 - f. **Protocol** from drop-down including **ANY, TCP/UDP, TCP, or UDP**
 - g. Click **Finish**.
6. The system displays your recently added and existing IP ranges in a list. The list includes the relevant details. You may edit any IP ranges by clicking on the pencil icon under **Options**.
7. You may delete any IP ranges by clicking on the trash can icon under **Options**.
8. If you want to revert back to default settings (where **Trusted IP** is disabled and all IP ranges are removed), click the **Reset to Default** button in the lower right corner
9. Click **Submit**.
10. To save your changes, click **Save and Apply**.

Firewall Status

The firewall status page allows you to view the current state of the Filter Rules, NAT tables, and iptables-save command output. You may also download an archive that contains log files showing the same output from each view.

To view the status for each firewall section as currently configured in the UI:

1. Go to **Firewall > Status** and view the **Firewall Status** page. You may change the display by clicking **Show** or **Hide** for each section.
2. The system displays the output view for each section including: **Filter Rules, NAT Rules, and IP Tables Dump**.
3. Click **Refresh** to update the views.
4. To download the archive file containing the same output shown in all three views, click **Download**. You can save or open the file from your browser. This archive contains three log files: iptables-filter.log, iptables-nat.log, and iptables-save.log.

Setting up Static Routes

To set up a manually configured mapping of an IP address to a next-hop destination for data packets:

1. Go to **Firewall > Static Routes**.

2. In the **Static Routes** window, click **Add Route**.
3. In the **Name** field of the **Add Route** dialog box, type the name of the route.
4. In the **IP Address** field, type the remote network IP address of the remote location.
5. In the **IP Mask** field, type the network mask that is assigned on the remote location.
6. In the **Gateway** field, type the IP address of the routing device that supports the remote IP Network.
7. Click **Finish**.
8. To save your changes, click **Save and Apply**.

Legacy Firewall Settings

The device's firewall enforces a set of rules that determine how incoming and outgoing packets are handled. By default, all outbound traffic originating from the LAN is allowed to pass through the firewall, and all inbound traffic originating from external networks is dropped. This effectively creates a protective barrier between the LAN and all other networks.

The firewall is built on top of iptables. The different rule groups correspond to their respective chains in iptables.

The Legacy Firewall Settings provide the older version of the firewall software interface. These settings include Port Forwarding, Input Filter Rules, and Output Filter Rules. We recommend using the Normal Settings by clicking on the Normal button. For additional information, see:

- [Adding Port Forwarding Rules](#)
- [Adding Input Filter Rules](#)
- [Adding Output Filter Rules](#)
- [Normal Settings](#)

Chapter 7 – Cellular

Configuring Cellular

To configure how cellular is used on your device:

1. Go to **Cellular > Cellular Configuration** to display the **Cellular Configuration** window.
2. Check **Enabled**.
3. Check and change the Cellular Configuration fields as desired. For field descriptions, see [Cellular Configuration Fields](#).
4. Click **Submit**.
5. To save your changes, click **Save and Apply**.

Cellular Configuration Fields

| Field | Description |
|------------------------------------|--|
| General Configuration | |
| Enabled | Allows the device to establish a cellular PPP or WWAN connection. After you enable or disable PPP and apply that change, the device reboots. |
| Mode (varies with model) | Choose from either PPP or WWAN for the cellular connection mode. (NOTE: For some models, this field is not available and the device defaults to PPP. Some fields described here are not used in WWAN mode.) |
| Protocol Support | Select the IP protocol from the drop-down (either IPv4 or IPv6). |
| Dial-on-Demand ^{1 2} | Enables the Dial-on-Demand feature. If enabled, the device brings up and maintains a cellular connection while network activity on the LAN requires WAN access. The device brings down the cellular connection when outgoing network traffic ceases for the given Idle Timeout duration. Enable this feature when Wakeup-on-Call is enabled to allow the device to "sleep" after it has been "woken up." See Configuring Wakeup-on-Call for more information. |
| Diversity ^{2 3} | Allows the use of two antennas to increase receive signal quality. Not all models support diversity. If diversity is enabled, connect a second cellular antenna to the AUX port on the device. Otherwise, the cellular performance of the device may degrade. |
| Connect Timeout ^{2 3} | The time (in seconds) that the device waits before it deems that the connection attempt has failed. The value used is the amount of time that elapses between each dialing retry. |
| Dialing Max Retries ^{2 3} | Number of dialing retries allowed; the default is zero, which means an infinite number is allowed. |
| Cellular Mode (varies with model) | Select the Cellular Mode from the drop-down based on the cellular radio module in your device including: Auto (default) , LTE Only , LTE prefer , 2G only , 3G only , or 3G prefer . NOTE: Values vary based on model. For some models, this field is not available. |
| IPv4/IPv6 Address | The IP address of the device. |

| Field | Description |
|---|---|
| IPv4/IPv6 Primary DNS ³ | The IP address of the primary DNS server (optional). |
| Public IPv4 Mask | The public mask for IPv4 (either 32 or 24). |
| Packet Size Settings | |
| MTU | Specifies the maximum transmit unit. The value must be between 128 and 16834 (default: 1500). |
| MRU | Specifies the maximum receive unit. The value must be between 128 and 16834 (default: 1500). |
| Modem Configuration | |
| Firmware Image (Only available for specific models) | Only available for specific radio models including -L4N1, -LNA3, or -MNG2. Allows user to switch from one network carrier to another. Select from the drop-down either AT&T Compatible (default), or Verizon for -L4N1. Select from the drop-down either Auto (default), AT&T Compatible , or Verizon for -LNA3. Select from Auto (default), AT&T Compatible , Verizon , or World-Wide for -MNG2. The Auto option automatically detects your SIM and configures the device for the appropriate carrier. |
| Dial Number ² | The modem dial string is: <ul style="list-style-type: none"> ■ *99***1# for GSM/GPRS/non-Verizon LTE devices <p>If the Dial Number is empty, the system uses the dial string based on the detected provider (AUTO).</p> |
| Connect String ² | The modem response to initiate a PPP connection, usually CONNECT . |
| Dial Prefix ² | The modem AT command that initiates a PPP connection, usually ATDT or ATD . |
| SIM Pin | The pin used to unlock the SIM for use (only required if the SIM is locked). This does not apply to CDMA radios. |
| PDP Context Mode | A value used to establish a cellular connection. Value is determined automatically and depends on the carrier. Select from drop-down either: AUTO (default), IP , IPV4V6 , or IPV6 . |
| APN ² | The Access Point Name assigned by the wireless service provider (carrier specific). |
| Init String# ² | Optional fields to apply additional AT commands that execute just before every PPP connection attempt. Use these fields to expand functionality and to troubleshoot. |
| Authentication | |
| Authentication Type | The type of authentication to use when establishing a PPP connection: NONE , PAP , CHAP , or PAP-CHAP (either). Authentication may not be required by the cellular service provider. After you select and apply that change, the device reboots. |
| Username | Name of the user that the remote PPP peer uses to authenticate. |
| Password | Password that the remote PPP peer uses to authenticate. |

| Field | Description |
|--|---|
| Keep Alive¹ | |
| Used to periodically check if the cellular link is up; if not, the device tries to establish the link. | |
| ICMP/TCP Check¹ | |
| An active check that provides the most reliable and reactive diagnosis of the cellular link, but requires sending data through the cellular link. | |
| Enabled ¹ | Enables the Active Keep Alive check. Depending on the plan type and data usage, this may result in additional data charges. |
| Keep Alive Type ¹ | Protocol type for active keep alive, either TCP or ICMP . ICMP periodically pings the designated host at the specified interval. TCP tries to make a connection to the designated host at the interval specified. |
| Interval ¹ | Time in seconds between active checking of the cellular link. |
| Hostname ¹ | Host name or IP address for the keep alive check. |
| TCP Port ¹ | TCP port number to connect with the TCP server (only visible when Keep Alive Type TCP is selected). |
| ICMP Count ¹ | Number of sequential, unsuccessful ping attempts to the specified host to declare that the link needs to be re-established (only visible when Keep Alive Type ICMP is selected). |
| Packet Size | Specifies the packet size/how much data to be sent from 0 to 64 (in bytes), default = 56. |
| Data Receive Monitor | |
| A passive check that observes the absence of packets received over a given amount of time. This check cannot reliably determine if the link is down; no network traffic may cause the monitor to signal to shutdown and re-establish the cellular link even though the link was in a good state. | |
| Enabled | Enable or disable the passive monitoring of the cellular link. |
| Window | The amount of time that can pass without receiving network traffic before the cellular link is torn down and re-established. |
| Network Registration Reset Timeout | |
| Checks for the network registration every 10 seconds, and if no network registration occurs during the set interval, the radio modem is reset. | |
| Enabled | If enabled, radio will reset if no network registration occurs before the timeout period has elapsed. |
| Timeout (minutes) | Amount of time (in minutes) that passes before the radio is reset in case the modem is not registered in a network. |

¹If you choose **PPP-IP Passthrough** and **Serial Modem** mode, this field is not available.

²If you choose **WWAN** mode, this field is not available.

³ If the device is set to **PPP-IP Passthrough Mode**, the device reboots after applying changes except for this field.

Unavailable Services in PPP-IP Passthrough and Serial Modem Modes

In both **PPP-IP Passthrough** and **Serial Modem** modes, many rCell services described in this document are either limited, or non-configurable and therefore do not appear in the device configuration menu . If you choose one of these modes, all sections between this and the next note on this subject are limited, or typically not available.

Configuring Wake Up On Call

This feature allows the device to wake up and initiate a cellular connection when there is an incoming call, SMS, or LAN activity.

The Wake Up on Call function is not available for the LVW2 or Cat M1 devices (even though you can access those settings in the device software.)

1. Go to **Cellular > Wake Up On Call** to display the configurations.
2. Check the **Wake Up On Call** box.
3. Select a Wake Up setting. For wakeup methods, see [Wake Up On Call Method Settings](#).
4. Click **Submit**.
5. To save your changes, click **Save and Apply**.

Note: This feature only defines when the device brings up its cellular link, not when the device takes it down. See the **Dial on Demand** option on the **Cellular Configuration** page at **Cellular > Cellular Configuration** to configure the criteria for bringing the cellular link down.

Wake Up On Call Method Settings

The triggers that wake up the device to re-establish the cellular link are:

- On Ring:*
 - Any incoming call will bring up the cellular link.
 - Enabled:** Check to allow any incoming call to wake up the device.
 - Message:** The expected response from the integrated cellular modem to an incoming call.
- On Caller ID:*
 - Only incoming calls in the caller ID list will bring up the cellular link.
 - Enabled:** Check to allow a specific caller to wake up the device.
 - Caller ID:** Field to specify a caller ID. Enter the ID then click **Add** to add the caller to the approved caller ID trigger list.
- On SMS (not available if you enabled SMS through **SMS > General Configuration**):
 - Only specific SMS messages will bring up the cellular link.
 - Enabled:** Check to allow specific SMS messages to wake up the device.
 - Message:** Field to specify the SMS message contents. Click **Add** to add the SMS message to the approved SMS trigger list.

***Note:** For AT&T users, these triggers are not available as voice support is disabled.

For Wake-Up-On-Call field descriptions, see [Wake Up On Call General Configurations](#).

Wake Up On Call General Configurations

| Field | Description |
|---------------------------------|--|
| Wake Up on Call check box | Enables the Wake Up On Call feature. |
| Dial On Demand LAN | When checked, the device allows network activity on the LAN that needs WAN access to trigger the Wake Up and establish the cellular link. If this configuration is not checked, the device will only establish a cellular connection when the selected Wake Up method is triggered via incoming call, caller ID, and/or short message service (SMS). |
| Time Delay | Time that passes between a receiving call and initiating the Wake Up On Call connection. |
| Acknowledgment String to Caller | String used to acknowledge to the delivering SMSC (short message service center) the receipt of an SMS. |
| Init String Number | Device initialization strings specific to the integrated cellular modem required for the Wake Up On Call feature. |

Radio Status

| Field | Description |
|----------------------------|--|
| Module Information | |
| IMEI | International Mobile Station Equipment Identifier |
| IMSI | International Mobile Subscriber Identifier. |
| Manufacturer | Company that developed the cellular module. |
| Model | Cellular module model number. |
| Hardware Revision | Module's hardware revision. |
| MDN (Phone Number) | Mobile Directory Number. In some SIM/carriers, the value may not be present and therefore not displayed. |
| MSID | Mobile Station ID. Some SIM/carriers do not contain this value and therefore the value is not displayed. |
| Firmware Version | Module's firmware version. |
| Service Information | |
| Home Network | Cellular service provider associated with the module's data account. |
| Current Network | Current cellular service operator (Not available for C2 or EV3 models). |
| RSSI | Received Signal Strength Indication (RSSI is pure wide band power including intracell power, interference, and noise): $RSSI [dBm] = RSCP[dBm] - Ec/Io[dB]$. |
| Service | Cellular service connection type. |
| Roaming | Indicates whether or not the current service is provided by the Home Network carrier. |
| Engineering Details | |
| Tx Pwr | Transmit Power. |
| PCS | 3G Service. |
| Ec/Io | Signal to Noise Ratio (used to calculate RSSI in 3G devices). |
| RSCP | Received Signal Code Power (used to calculate RSSI in 3G devices). |
| RSRP | Reference Signal Received Power (used to calculate RSSI in LTE devices). |
| RSRQ | Reference Signal Received Quality (used to calculate RSSI in LTE devices): $RSRQ = (N * RSRP) / RSSI$ where N is the number of Physical Resource Blocks (BRBs) over which RSSI is measured, typically equal to system bandwidth. |
| DRX | Discontinuous Reception. |
| Mobility Management State | State of cellular radio. |
| Radio Service State | On/off status of cellular radio. |
| Network Operator Mode | Cellular provider's Network Operation Mode. |
| Block Error Rate | Number of erroneous blocks / total number of received blocks. |

| Field | Description |
|-----------------------|---|
| Service Domain | Network Domain/Service Area. |
| Update Options | |
| MDN (Phone Number) | Update the cellular module's phone number. This number is updated only on the device. The MDN that the carrier has associated with this device does not change. |

Cellular Radio Firmware Upgrade

Applies to specific models only

NOTE: When the device is set to PPP-IP Passthrough or Serial Modem Modes, this page is available under the Setup menu.

Your device can perform a **Delta Firmware Upgrade** of the cellular radio firmware: When applied, the current firmware image is updated with the differences between it and the new version, and effectively becomes the new version of firmware. Due to space restrictions, full firmware image upgrades are not available on your device. The delta upgrade file contains **DELTA** in the upgrade filename.

Those models that support delta upgrades only include: **LNA7, LEU7** and **L4G1**.

Refer to your product model number on the product label usually found on the bottom or back of your device or also at the top of the page of the device UI.

There are two methods for updating the cellular firmware offered: 1) Upgrading using DeviceHQ® and 2) Upgrading using the device UI only.

Upgrading Cellular Firmware Using DeviceHQ (Remote Management)

DeviceHQ can manage the Radio Firmware upgrade to your device when annex-client checks in. **NOTE:** You must first enable and properly configure Remote Management in the device UI (refer to [Managing Your Device Remotely](#)).

1. Open **DeviceHQ**.
2. Select **Device > Your Device Name > Schedule > Upgrade Radio Firmware**.
3. **DeviceHQ** provides a list of eligible Telit and Quectel module firmware that a particular device can queue for download and install. Select the appropriate firmware.
4. The device checks in, downloads the firmware, automatically verifies the MD5 sum of the firmware to check the integrity of the upgrade file, and applies it to the modem module.
Note: Allow at least 10 minutes after the device has downloaded the firmware file before taking any action. The system should reboot on its own after a successful download. Otherwise, after 10 minutes, you may reboot the device manually.
5. Once you have refreshed or the device checks in again, verify that the cellular radio firmware has been updated in DeviceHQ.

In the device UI, you can also check that the cellular radio firmware has been updated. Refer to the **Current Radio Firmware** on the **Radio Firmware Upgrade** page (see step 1 of Upgrading Cellular Firmware Using UI only) or also see the firmware version on the **Radio Status** page under **Cellular**.

Upgrading Cellular Firmware using UI only

You can also use the device UI to upgrade your radio firmware. You must first obtain the appropriate binary upgrade file for the cellular radio in your device.

NOTE: If you use the firmware upgrade via Cellular using the UI and you get a timeout failure, first try to boost the signal strength and attempt it again. Otherwise, update via an Ethernet connection or use **DeviceHQ**.

1. Open the **Cellular Radio Firmware Upgrade** page under **Cellular**.
2. Enter the MD5 Check Sum or hash under **File MD5**.
3. Place the downloaded binary or delta file on your local computer. Browse for the file and select it.
4. Click **Start Upgrade**. The system should reboot automatically after a successful download. Otherwise, after ten minutes, you may reboot the device manually.
5. Check that the cellular radio firmware has been updated. Refer to the **Current Radio Firmware** on the **Cellular Radio Firmware Upgrade** page (see step 1 of Upgrading Cellular Firmware Using UI only) or also see the firmware version on the **Radio Status** page under **Cellular**.

Chapter 8 – SMS

Configuring SMS

This function is not available if you enable SMS through **Cellular > Wake Up On Call**. To enable short message service (SMS) via the Web Management interface or API:

1. From the Web Management interface, go to **SMS > SMS Configuration > SMS Settings**.
2. Check **Enabled**.
3. In the **Sent SMS to Keep** field, enter the total number of sent SMS messages to keep in the device's history.
4. In the **Received SMS to Keep** field, enter the total number of received SMS messages to keep in the device's history.
5. In the **Resend Failed SMS** field, enter the total number of resend attempts for SMS messages that failed to send.
6. Set messages to keep and resend options.
7. Click **Submit**.
8. To save your changes, click **Save and Apply**.

For field descriptions see [SMS Field Descriptions](#).

SMS Field Descriptions

| Field | Description |
|----------------------|--|
| Enabled | Enables the SMS utilities required to send SMS via API and the Web Management interface. |
| Sent SMS to Keep | The total number of sent SMS messages to keep in the device's history. |
| Received SMS to Keep | The total number of received SMS messages to keep in the device's history. |
| Resend Failed SMS | The total number of resend attempts for SMS messages that failed to send. |

SMS Commands

SMS commands are disabled by default.

First, make sure to enable SMS under **SMS > SMS Configuration > SMS Settings**.

To enable these available commands (for status and debugging purposes) and set security filters:

1. Go to **SMS > SMS Configuration > SMS Commands**, check the SMS commands you wish to enable. Refer to the table of [SMS Command Descriptions](#) for details on available commands.
2. Check the security filters, you wish to use (can be one or both):
 - **Password:** If enabled, SMS commands will require **p password** in the syntax. For example: **p 123456 #serial** where 123456 is your password.

Use the **default password** (last six digits of the radio's IMEI or last six digits of the MEID).

Or click on **Use custom password** and enter your own password.

You can also toggle the eye icon to make the password visible or hidden.

- **Whitelist:** If enabled, SMS commands can only be received from a number in the whitelist (you must enter a phone number).

Enter the phone number and click **Add Number**.

Note: Due to differences between service providers, for every US number you add to the **Whitelist**, create two separate entries: 1) one using the **phone number** and 2) the other using **1 + phone number**. Tip: Since the number format varies with provider, you can send your device an SMS message from the number in question and see what format is used.

3. Refer to the **Required SMS Command Format** field to see the format based on your chosen settings.
4. Click **Submit**.
5. To save your changes, click **Save and Apply**.

Here is an example SMS Command (#serial – Server mode):

```
Serial-IP Port Status:
Mode: Server
Protocol: SSL/TLS
Port: 3000
TX Bytes: 1234567
RX Bytes: 123456789
DCD Status: ON
2016-11-20 19:22
```

The response message to all SMS commands includes a time stamp. The time stamp format is **YYYY-MM-DD HH:MM**.

The system adds the time stamp to the existing commands at the end of the SMS message. In case the message exceeds the 160 character limit, the device information and the occurred event are not truncated. Only the time stamp is lost.

SMS Command Descriptions

The following table describes available SMS Commands under **SMS Configuration > SMS Commands**. All SMS Commands are disabled by default. Check to enable.

| SMS Command | Description |
|---------------------------------------|--|
| #reboot | reboot the device |
| #checkin | check in to DeviceHQ |
| #rm <enable disable> <AccountKey> | enable or disable remote management using DeviceHQ (You must specify AccountKey when enabling Remote Management if not previously configured.) |
| #setcellular <enable disable> [<APN>] | enable or disable Cellular and allows setting of the APN |

| SMS Command | Description |
|---|---|
| #ping [<interface>] [<count>] <address> | ping IP address <count> times (range: 1-20, default = 4) through <interface> (choose from cellular, wifi, and ethernet or if not specified, the default gateway interface is used) |
| #apn | get APN string |
| #cellular | get cellular connection status |
| #radio | get radio status |
| #ethernet | get Ethernet interface configuration |
| #wan | get actual WAN transport and WAN priority configuration |
| #serial | get serial details: Mode (Server or Client), RX bytes, TX bytes, DCD Status, Protocol, Port (Server mode only), Server IP Address (Client mode only), and Server Port (Client Mode only) |
| #wifi | get Wi-Fi details: Date and time in format YYYY-MM-DD HH:MM, mode (WAN or Access Point), MAC address, status (for WAN mode only), SSID, Security settings (for Access Point only, None, WEP, WPA, WPA2-PSK, and WPA/WPA2-PSK) |
| #geoposition | get GPS coordinates, latitude and longitude (only available on devices with a GPS module acquiring sufficient GPS signal) |

Note: Arguments in square brackets [] are optional. Those in angle brackets < > are values.

Sending an SMS Message

To send an SMS message from the device:

1. Go to **SMS > Send SMS** to display the **Send SMS** window.
2. In the **Recipient** field, enter a phone number and click **Add**. You can add up to 100 phone numbers.
3. In the **Message** field, enter a text message up to 160 characters long.
4. Click **Send**. The system displays a confirmation indicating whether the message has been successfully sent or not.

Viewing Received SMS Messages

To view received SMS messages from the device:

1. Go to **SMS > Received** to display the **Received SMS** window. The messages are sorted by date with the most recent messages on top. The table shows up to 30 characters for each message.
2. To view the full message, click the **eye** icon to the right of the message entry.
3. To delete an SMS message, click the **trash can** icon under **Options** to the right of the message. A dialog box asks you to confirm that you want to delete the SMS message. Click **OK**.

4. To delete all the received SMS messages, click **Delete All**. A dialog box asks you to confirm that you want to delete all SMS messages. Click **OK**.
5. To configure, the receive list to automatically update, check the **Auto Refresh** box in the upper right corner.

Viewing Sent SMS Messages

To view sent SMS messages from the device:

1. Go to **SMS > Sent** to display the **Sent SMS** window. The messages are sorted by date with the most recent messages on top. The table shows up to 30 characters for each message.
2. To view a full message, click the **eye** icon to the right of the message entry.
3. To delete a sent SMS message, click the **trash can** icon to the right of the message entry. A dialog box asks you to confirm that you want to delete the SMS message. Click **OK**.
4. To delete all the sent SMS messages, click **Delete All**. A dialog box asks you to confirm that you want to delete all the SMS messages. Click **OK**.
5. To configure, the receive list to automatically update, check the **Auto Refresh** box in the upper right corner.

Chapter 9 – Tunnels

Setting Up GRE Tunnels

Tunneling allows the use of a public network to convey data on behalf of two remote private networks. It is also a way to transform data frames to allow them to pass networks with incompatible address spaces or even incompatible protocols. Generic Routing Encapsulation (GRE) is a tunneling mechanism that uses IP as the transport protocol and can be used for carrying many different passenger protocols.

The tunnels behave as virtual point-to-point links that have two endpoints identified by the tunnel source and tunnel destination addresses at each endpoint. Configuring a GRE tunnel involves creating a tunnel interface, which is a logical interface, then configuring the tunnel endpoints for the tunnel interface. To set up GRE tunnels:

1. Go to **Tunnels > GRE Tunnels > GRE Tunnels Configuration**.
2. Click **Add Tunnel**.
3. In the **Tunnel Name** field, enter a name for the new tunnel.
4. (Optional) In the **Description** field, you can enter a description that helps you further identify the tunnel.
5. In the **GRE Tunnel Settings** section:
 - a. In the **Remote WAN IP** field, type the IP address of the gateway to which you want to connect.
 - b. Click **Add** in the **Remote Network Routes** table.
 - c. In the **Remote Network Route** field, type the IP address of the network that is routed through the tunnel.
 - d. In the **Remote Network Mask** field, type the mask of the network.
 - e. Click **Add**. The defined **Remote Network Route** is added and appears in the **Network Routes** list.
6. In the **Interface IP Address**, specify the IP address of the virtual GRE network interface. It should be equal to the IP address of the LAN interface that is used for establishing the Tunnel connection.
7. In the **Interface Network Mask**, specify the network mask of the virtual GRE network interface.
8. (Optional) In the **Checking period (minutes)** specify the interval to resolve the Remote WAN hostname by DynDNS. Recommended for hostnames that have dynamic IP addresses.
9. Click **Submit**.
10. The defined GRE tunnel configuration is added and appears in the **GRE Tunnels list**.
11. To update an existing tunnel, click the pencil icon under **Options** to the right of the desired tunnel in the displayed list.
12. Under **Edit Tunnel**, make your desired changes. This includes the option to enable or disable the tunnel by checking or unchecking **Enabled**.
13. Click **Submit**.
14. To save your changes, click **Save and Apply**.

IPsec Tunnels

Configuring Network-to-Network Virtual Private Networks (VPNs)

The device supports site-to-site VPNs via IPsec tunnels for secure network-to-network communication. Both tunnel endpoints should have static public IP addresses and must be able to agree on the encryption and authentication methods to use. Setting up an IPsec tunnel is a two-stage negotiation process. The first stage negotiates how the key exchange is protected. The second stage negotiates how the data passing through the tunnel is protected. For

endpoints that do not have public static IP addresses, additional options may help such as **NAT Traversal** and **Aggressive Mode**.

By default, based on the encryption method chosen, the device negotiates ISAKMP hash and group policies from a default set of secure algorithms with no known vulnerabilities. This allows flexibility in establishing connections with remote endpoints. There is an **ADVANCED** mode that provides a way to specify a strict set of algorithms to use per phase, limiting the remote endpoint's negotiation options.

The default Encryption Method is: **AES-128**.

The default set of DH Group Algorithms is: **DH2(1024-bit), DH5(1536-bit), DH14(2048-bit), DH15(3072-bit), DH16(4096-bit), DH17(6144-bit), DH18(8192-bit), DH22(1024-bit), DH23(2048-bit), and DH24(2048-bit)**.

You have the option to add multiple local and remote networks. These additional subnets can provide more complexity, flexibility, efficiency, and redundancy to your VPN. Using multiple networks allows different endpoints in different LAN subnets to securely communicate through the same tunnel. Users don't have to configure an additional tunnel for those subnets saving time and effort.

To set up a Network-to-Network VPN tunnel on your device:

1. From the Web Management interface, go to **Tunnels > IPsec Tunnels**.
2. Click **Add Tunnel** in upper right.
3. Enter a **Name** for the tunnel and an optional **Description**.
4. In the **Remote WAN IP** field, enter the external IP address of the remote endpoint.
5. Choose **Tunnel Type** from the drop-down. Values are **IKE** and **IKEv2**.
6. If you wish to allow all traffic through the tunnel, click on the checkbox for **Allow All Traffic**. This feature is disabled by default. In this case, you need to add explicit rules manually to allow traffic. This scenario is the best security practice.
7. Click **Add** under **Local Networks** to add a local network of the device that is used to establish the tunnel connection (leftsubnet). You can enter multiple networks
 - a. Enter the **IP Address** and **Mask** under **Add Local Network**.
 - b. Click **OK**. The network displays in the network list.
8. Click **Add** under **Remote Networks** to add a local network of the remote device at the other end of the tunnel connection (rightsubnet). You can enter multiple networks.
 - a. Enter the **IP Address** and **Mask** under **Add Remote Network**.
 - b. Click **OK**. The network displays in the network list.
9. The public IP address and LAN of this device do not need to be configured because they are already known by this device.
10. Select the **Authentication Method** from the drop-down either **Pre-Shared Key** or **RSA Signatures**. Authentication is performed using secret pre-shared keys and hashing algorithms (like SHA1 MD5) or RSA signatures.
11. If you select **Pre-Shared Key**, then enter the **Secret**. This key needs to be the same on both endpoints.
12. If you select **RSA Signatures**, enter the following (in .pem format):
 - a. **CA Certificate**
 - b. **Local RSA Certificate**
 - c. **Local RSA Private Key**

13. Select the **Encryption Method** from the drop-down including **AES-128**, **AES-192**, **AES-256** or **ADVANCED**. The encryption method needs to be the same on both endpoints. IKE encryption algorithm is used for the connection (**phase 1** - ISAKMP SA). Based off of **Phase 1**, a secure set of defaults are used for phase 2, unless the **Advanced** option is used, in which case, you must specify all components of both **phases 1** and **2** including **Encryption**, **Authentication**, and **Key Group**. When you choose **Advanced** Encryption Method, you select the following (see [IPsec Fields](#) for field values) :
 - a. **Phase 1 Encryption**
 - b. **Phase 1 Authentication**
 - c. **Phase 1 Key Group**
 - d. **Phase 2 Encryption**
 - e. **Phase 2 Authentication**
 - f. **Phase 2 Key Group**

NOTE: For mPower 5.3 and above, deprecated encryption and hash algorithms are not available for creating new tunnels. But old tunnels that were created in 5.2 or lower will retain the deprecated settings unless changed. Those deprecated settings include: **3DES**, **ANY**, **MD5**, and **SHA-1**.

14. If the remote endpoint is set up with unique IDs, check the **Enable UID** box, and enter the **Local** and **Remote IDs**.
15. Click **Show** for **IPsec Tunnel: Advanced** features that limit the remote endpoint's negotiation options.
16. In the **IKE Lifetime** field, enter the duration in which ISAKMP SA lasts (in hours).
17. In the **Max Retries** field, enter the number of retries for the IPsec Tunnel. Enter zero for unlimited retries.
18. In the **Key Life** field, duration in which the IPsec SA lasts (in hours).
19. In the **Checking Period** field, enter the timeout interval (in minutes).
20. Check **Compression** to enable IPComp (compression algorithm).
21. Check **Aggressive Mode** to enable exchange identification in plain text (unencrypted for faster negotiation). **NOTE:** This mode is less secure and prone to dictionary and brute force attacks.
22. The defined IPsec tunnel configuration is added and appears in the **IPsec Tunnel** list.
23. To update an existing tunnel, click the pencil icon under **Options** to the right of the desired tunnel in the displayed list.
24. Under **Edit Tunnel**, make your desired changes. This includes the option to enable or disable the tunnel by checking or unchecking **Enabled**.
25. Click **Submit**.
26. To save your changes, click **Save and Apply**.

For field descriptions, see [IPsec Tunnel Configuration Field Descriptions](#).

IPsec Tunnel Configuration Field Descriptions

| Field | Description |
|-------------------------------------|---|
| IPsec Tunnel | |
| Name | Name used to identify the IPsec tunnel in configurations and logs. |
| Description | Optional text to describe the IPsec tunnel. This description shows up in the UI while hovering over the summary of an IPsec tunnel. |
| IPsec Remote Tunnel Endpoint | |

| Field | Description |
|------------------------------|---|
| Remote WAN IP | External IP address of the remote tunnel endpoint. The remote device is typically a router. |
| Remote Network Route | This field is used in conjunction with the Remote Network Mask field and describes the remote endpoint's subnet. This is used to identify packets that are routed over the tunnel to the remote network. |
| Remote Network Mask | This field is used in conjunction with the Remote Network Route field, to describe the remote endpoint's subnet. It identifies packets that are routed over the tunnel to the remote network. |
| Tunnel Type | Internet Key Exchange (IKE) for host-to-host, host-to-subnet, or subnet-to-subnet tunnels. Choose from IKE or IKEv2 . |
| IPsec Tunnel: IKE | |
| Authentication Method | Choose between Pre-Shared Key or RSA Signatures . Authentication is performed using secret pre-shared keys and hashing algorithms (like SHA1 MD5) or RSA signatures (you provide the CA Certificate , Local RSA Certificate , and Local RSA Private Key in .pem format). If you check Enable UID , then Local ID and Remote ID become available as options. |
| Pre-Shared Key | Authentication is performed using a secret pre-shared key and hashing algorithms on both sides. |
| Secret | Secret key that is known by both endpoints. |
| Encryption Method | IKE encryption algorithm used for the connection (phase 1 - ISAKMP SA). Based off of phase 1, a secure set of defaults are used for phase 2, unless the Advanced option is used, in which case, all components of both phases 1 and 2 are specified by the user. |
| RSA Signatures | Authentication is performed using digital RSA signatures. |
| CA Certificate | Certificate Authority certificate used to verify the remote endpoint's certificate. |
| Local RSA Certificate | Certificate the local endpoint uses during Phase 1 Authentication . |
| Local RSA Private Key | The private key that the local endpoint uses during Phase 1 Authentication. |
| Encryption Method* | Choose an Encryption Method from the following list: AES-128 , AES-192 , AES-256 , or ADVANCED . IKE encryption algorithm is used for the connection (phase 1 - ISAKMP SA). Based off of phase 1, a secure set of defaults are used for phase 2, unless the Advanced option is used, in which case, all components of both phases 1 and 2 are specified by the user. |
| Phase 1 Encryption* | If Advanced is selected for Encryption Method , select Phase 1 Encryption from the drop-down: AES-128 , AES-192 , AES-256 , or ANY AES . |

| Field | Description |
|-------------------------------|--|
| Phase 1 Authentication* | If Advanced is selected for Encryption Method , select Phase 1 Authentication from the drop-down: SHA-2, SHA2-256, SHA2-384, SHA2-512, or ANY. |
| Phase 1 Key Group* | If Advanced is selected for Encryption Method , select the Phase 1 Key Group from the drop-down: DH2 (1024-bit), DH5 (1536-bit), D14 (2048-bit), DH15 (3072-bit), DH16 (4096-bit), DH17 (6144-bit), DH18 (8192-bit), DH22 (1024-bit), DH23 (2048-bit), DH24 (2048-bit), and ANY. |
| Phase 2 Encryption* | If Advanced is selected for Encryption Method , select Phase 2 Encryption from the drop-down: AES-128, AES-192, AES-256, ANY AES, or ANY. |
| Phase 2 Authentication* | If Advanced is selected for Encryption Method , select Phase 2 Authentication from the drop-down: SHA-2, SHA2-256, SHA2-384, SHA2-512, or ANY. |
| Phase 2 Key Group* | If Advanced is selected for Encryption Method , select the Phase 2 Key Group from the drop-down: DH2 (1024-bit), DH5 (1536-bit), D14 (2048-bit), DH15 (3072-bit), DH16 (4096-bit), DH17 (6144-bit), DH18 (8192-bit), DH22 (1024-bit), DH23 (2048-bit), DH24 (2048-bit), and ANY. |
| Enable UID | Unique Identifier String to enable the Local ID and Remote ID fields. |
| Local ID | String Identifier for the local security gateway (optional) |
| Remote ID | String Identifier for the remote security gateway (optional) |
| IPSec Tunnel: Advanced | |
| IKE Lifetime | Duration for which the ISAKMP SA exists from successful negotiation to expiration. |
| Key Life | Duration for which the IPsec SA exists from successful negotiation to expiration. |
| Max Retries | Number of retry attempts for establishing the IPsec tunnel. Enter zero for unlimited retries. |
| Checking Period | Timeout interval in minutes. If Remote WAN IP address is a hostname that can be resolved by DynDNS, the hostname will be resolved at the set interval. Recommended for dynamic IP addresses. |
| Compression | Enable IPComp. This protocol increases the overall communication performance by compressing the datagrams. Compression requires greater CPU processing. |

| Field | Description |
|------------------------|--|
| Aggressive Mode | Whether to allow a less secure mode that exchanges identification in plain text. This may be used for establishing tunnels where one or more endpoints have a dynamic public IP address. Although this mode is faster to negotiate phase 1, the authentication hash is transmitted unencrypted. You can capture the hash and start a dictionary or use brute force attacks to recover the PSK. |

***NOTE:** For mPower 5.3 and above, deprecated encryption and hash algorithms are not available for creating new tunnels. But old tunnels that were created in 5.2 or lower will retain the deprecated settings unless changed. Those deprecated settings include: **3DES, ANY, MD5, and SHA-1.**

OpenVPN Tunnels

OpenVPN is an open-source software application that implements virtual private network (VPN) techniques for creating secure point-to-point or site-to-site connections in routed or bridged configurations and remote access facilities. You can use and setup OpenVPN tunnels with this device.

To use OpenVPN, you must first install an OpenVPN application along with an easy-rsa tool and configure OpenVPN on your computer. Then you must also generate the certificates for the OpenVPN server and client before configuring the device.

To configure OpenVPN client and server on this device the following files are required:

- **CA PEM file or CA certificate (.crt)**
- **Diffie Hellman PEM file (.pem)**
- **Server Certificate to be used by the device endpoint (.crt)**
- **Server/Client Key to be used by the device endpoint (.key)**

Note 1: When you configure OpenVPN server and client make sure both sides use the same settings, and certificates.

Note 2: For mPower 5.3 and above, some encryption and hash configurations are deprecated and not available for creating new tunnels. But old tunnels that were created in 5.2 or lower will retain the deprecated settings unless changed. Deprecated settings for hash algorithms include: **MD4, MD5, RSA-MD4, RSA-MD5, and SHA-1.**

Deprecated settings for encryptions ciphers include: **BF-CBC, CAST5-CBC, DES-CBC, DES-EDE-CBC, DES-EDE3-CBC, DESX-CBC, IDEA-CBC, RC2-40-CBC, RC2-64-CBC, and RC2-CBC.** Deprecated setting for Minimum TLS version is **1.1.**

Note 3: Some encryption and hash configurations are too weak and NOT supported at all in mPower 5.3 or higher. These settings do not function when performing an upgrade to mPower 5.3. The system provides a warning message during upgrade and replaces them with **Default.** The following TLS cipher suites are not supported: **TLS-DHE-RSA-WITH-CAMELLIA-256-CBC-SHA** and **TLS-DHE-RSA-WITH-CAMELLIA-128-CBC-SHA.** Also, the following hash algorithms are not supported: **DSA, DSA-SHA, DSA-SHA1, DSA-SHA1-old, ECDSA-with-SHA1, RSA-SHA, RSA-SHA1-2, and SHA.**

Existing OpenVPN tunnels are displayed in the OpenVPN tunnel list under **OpenVPN Configuration.** To update an existing tunnel:

1. Click the pencil icon under **Options** to the right of the desired tunnel in the displayed list.
2. Under **Edit Tunnel**, make your desired changes. This includes the option to enable or disable the tunnel by checking or unchecking **Enabled.**

3. Click **Submit**.
4. To save your changes, click **Save and Apply**.

Configuration 1: OpenVPN Tunnel with TLS Authorization Mode (Device only)

This first configuration establishes the OpenVPN Tunnel connection from a device client to a device server using TLS as Authorization Mode. This involves adding and configuring both OpenVPN Server and Client sides within the device UI.

To add an **OpenVPN Server using TLS**:

1. Go to **Tunnels > OpenVPN Tunnels > OpenVPN Tunnel Configuration**.
2. Click **Add Tunnel**.
3. Enter the **Name**.
4. Select the **Type** as **SERVER** from the drop-down.
5. You can also enter an optional **Description**.
6. Under OpenVPN Tunnel Configuration, enter the following fields (using **TLS** as **Authorization Mode**):
 - a. **Interface Type** as **TUN** from the drop-down.
 - b. **Authorization Mode** as **TLS** from the drop-down.
 - c. **Protocol** as **UDP**.
 - d. **VPN Subnet**.
 - e. **Port** number.
 - f. **VPN Netmask**.
 - g. **LZO Compression** as **ADAPTIVE** from the drop-down.
 - h. **Hash Algorithm** as **DEFAULT**.
 - i. **NCP (Negotiable Crypto Parameters)** as **DEFAULT**.
 - j. **Min. TLS Version** as **1.2**.
 - k. **TLS Cipher Suite** as **DEFAULT**.
 - l. Enter the contents of the following files generated from the easy-rsa tool. You can copy and paste this content from the certificate files after opening from a text editor like Notepad. (all required):
 - i. **CA PEM (.crt)**
 - ii. **Diffie Hellman PEM (.pem)**
 - iii. **Server Certificate PEM (.crt)**
 - iv. **Server Key PEM (.key)**

Note: Use the same **CA PEM** certificate and parameters as the server for the OpenVPN clients .

7. **Remote Network Routes** create a route from the server network to the client network. This allows the server to get access to the client's network. In the **OpenVPN Tunnel Network Routes**, click **Add**:
 - a. Enter the **Remote Network Route** (should be the client subnet). For example, if the client IP address is 192.168.3.1, enter 192.168.3.0.
 - b. Enter the **Remote Network Mask** (usually 255.255.255.0).
 - c. You may enter **Gateway** (optional).
 - d. Click **Add**.

8. The system displays your recently-added **Push Route** with the client subnet (remote network route + mask).
9. **Push Routes** create a route from client's network to the server's network. This allows clients to get access to the server's network. Under **Push Routes**:
 - a. Click **Client To Client** box if you want this optional feature (this establishes a connection between multiple clients that are connected to the server).
 - b. In the **Push Network Route**, click **Add**.
 - c. In the dialog box, enter the **Remote Network Route** (same address as the server subnet above).
 - d. Enter the **Remote Network Mask** (same as above).
 - e. You may enter **Gateway** (optional).
 - f. Click **Add**.
Note: If you use **Static Key Authorization Mode**, the **Push Routes** do not work.
10. The system displays your recently-added **Push Route** with the client subnet (remote network route + mask).
11. Click **Preview** to view the tunnel configuration.
12. Click **Submit**.
13. Click **Save and Apply** to save your changes

To add an **OpenVPN Client using TLS**:

1. Go to **Tunnels > OpenVPN Tunnels > OpenVPN Tunnel Configuration**.
2. Click **Add Tunnel**.
3. Enter the **Name** of the tunnel.
4. Select the **Type** as **CLIENT** from the drop-down.
5. You can also enter an optional **Description**.
6. Under OpenVPN Tunnel Configuration, enter the following fields (using **TLS** as **Authorization Mode**):
 - a. **Interface Type** as **TUN** from the drop-down.
 - b. **Authorization Mode** as **TLS** from the drop-down.
 - c. **Protocol** as **UDP**.
 - d. **Remote Host** (server public IP address).
 - e. **Remote Port** number.
 - f. **LZO Compression** as **ADAPTIVE** from the drop-down.
 - g. **Hash Algorithm** as **DEFAULT**.
 - h. **NCP (Negotiable Crypto Parameters)** as **DEFAULT**.
 - i. **Min. TLS Version** as **1.2**.
 - j. **TLS Cipher Suite** as **DEFAULT**.
 - k. Enter the contents of the following files generated from the easy-rsa tool. You can copy and paste this content from the certificate files after opening from a text editor like Notepad. (all required):
 - i. **CA PEM (.crt)**
 - ii. **Client Certificate PEM (.crt)**
 - iii. **Client Key PEM (.key)**

7. If you use **TLS** as **Authorization Mode**, you do not need configure or add **Remote Network Routes**. The server adds the routes if the server's **Push Routes** are already configured. If you use **Static Key** as **Authorization Mode**, you must add and configure **Remote Network Routes**.
8. Click **Preview** to view the tunnel configuration.
9. Click **Submit**.
10. Click **Save and Apply** to save your changes.

Now the device client can access the device server subnet. You can ping the IP address of the device server subnet from the client console to test this.

Note: The PC connected to the device does not have access to the device server subnet.

Configuration 2: OpenVPN Tunnel with TLS Authorization Mode (Device and Connected PC)

This second configuration provides access between a device server and its subnet and device client and its subnet. An additional configuration is needed on the device server side. This also allows your PC to connect with the device server and ultimately to the device client through that server.

1. Configure the device server as shown under how to add an **OpenVPN Server using TLS**.
2. Open device console, go to `/var/config/ovpnccd/openVPNServerName`. Create the folder if not present in the device.
3. Create a file that has the client certificate name with the following information:
 - a. `iroute [Client_Subnet] [Mask]`
 - b. `example -- echo "iroute 192.168.3.0 255.255.255.0" > mtrClient1`
4. For each client, you must create a separate file in the folder `/var/config/ovpnccd/yourserverName`.
Note: Make the file name the same as the Common Name value used to create the certificate.
5. Configure device client as shown under how to add an **OpenVPN Client**.

Once properly configured, you should have a connection between the device server and device client and their subnets. Your PC can also connect with the device server and thus the device client through that server.

Configuration 3: OpenVPN Tunnel with Static Key Authorization Mode (device server and client)

This third configuration establishes the OpenVPN Tunnel connection from a device client to a device server using Static Key as Authorization Mode. This involves adding and configuring both OpenVPN Server and Client sides within the device UI.

When using Static Key, the OpenVPN tunnel is created between only two end-points, the client and server. You cannot connect more than one client to the server in this mode. Remote Network Route must be specified in both configurations, client and server, in order to establish the connection between subnets.

To add an **OpenVPN Server using Static Key**:

1. Go to **Tunnels > OpenVPN Tunnels > OpenVPN Tunnel Configuration**.
2. Click **Add Tunnel**.
3. Enter the **Name**.
4. Select the **Type** as **SERVER** from the drop-down.
5. You can also enter an optional **Description**.
6. Enter the following fields (using **STATIC KEY** as **Authorization Mode**):

- a. **Interface Type** as **TUN** from the drop-down.
- b. **Authorization Mode** as **STATIC KEY** from the drop-down.
- c. **Protocol** as **UDP**.
- d. **Local Address** as **DEFAULT**.
- e. **Port** number.
- f. **Remote Address** as **DEFAULT**.
- g. **LZO Compression** as **ADAPTIVE** from the drop-down.
- h. **Hash Algorithm** as **DEFAULT**.
- i. **NCP (Negotiable Crypto Parameters)** as **DEFAULT**.
- j. Generate and enter the **Static Key PEM** (required). Both server and client must use the same static key. See example below:

```
-----BEGIN OpenVPN Static key V1-----
```

```
3f4c9113b2ec15a421cfe21a5af015bb967059021c1fd6f66ecfd00533d967237875215e20e80a2d59efd
79148d6acdea9358dcafe0efdbb54003ff376c71432dd9d16f55e7d8917a32bfe07d61591b7bbb43c7ba
d214482b8547ec9dca8910f514d9f4270ccaef1a79852ae27c1c307c9dc3c836d1c380bece3c70fd2104
e1968ed29b6c3388719226f959f69f9be43688ed27bc3a4dbc83f640370524b47bb871816af79586d07
08781fad384480d0609b11c31d27baa6e902d29277a474e3e2785a8410d595c0f9c75312375b4bd098
76e1a47a598e114749a09c35f098e9123015c2795c702e4a346a8bccd00305c7cb30beef66ad33f43dac
c2e662128
```

```
-----END OpenVPN Static key V1-----
```

7. **Remote Network Routes** create a route from the server network to the client network. This allows the server to get access to the client's network. In the **OpenVPN Tunnel Network Routes**, click **Add**:
 - a. Enter the **Remote Network Route** (should be the client subnet). For example, if the client IP address is 192.168.3.1, enter 192.168.3.0.
 - b. Enter the **Remote Network Mask** (usually 255.255.255.0).
 - c. Click **Add**.
8. The system displays your recently-added **Remote Network Route** with the client subnet (remote network route + mask).
Note: **Push Routes are not required with Static Key as Authorization Mode**.
9. Click **Preview** to view the tunnel configuration.
10. Click **Submit**.
11. Click **Save and Apply** to save your changes.

To add an **OpenVPN Client using Static Key**:

1. Go to **Tunnels > OpenVPN Tunnels > OpenVPN Tunnel Configuration**.
2. Click **Add Tunnel**.
3. Enter the **Name**.
4. Select the **Type** as **CLIENT** from the drop-down.
5. You can also enter an optional **Description**.
6. Enter the following fields (using **STATIC KEY** as **Authorization Mode**):
 - a. **Interface Type** as **TUN** from the drop-down.
 - b. **Authorization Mode** as **STATIC KEY** from the drop-down.

- c. **Protocol** as **UDP**.
- d. **Local Address** as **DEFAULT**.
- e. **Remote Host**.
- f. **Remote Address** as **DEFAULT**.
- g. **Remote Port** number.
- h. **LZO Compression** as **ADAPTIVE** from the drop-down.
- i. Select the **NCP (Negotiable Crypto Parameters)** as **DEFAULT** from drop-down.
- j. Select the **Hash Algorithm** as **DEFAULT** from drop-down.
- k. **Min. TLS Version** as **1.2**.
- l. **TLS Cipher Suite** as **DEFAULT**.
- m. Enter the **Static Key PEM** (required). Both server and client must use the same static key. See example below:

```
-----BEGIN OpenVPN Static key V1-----
```

```
3f4c9113b2ec15a421cfe21a5af015bb967059021c1fd6f66ecfd00533d967237875215e20e80a2d59efd
79148d6acdea9358dcafe0efdbb54003ff376c71432dd9d16f55e7d8917a32bfe07d61591b7bbb43c7ba
d214482b8547ec9dca8910f514d9f4270ccaef1a79852ae27c1c307c9dc3c836d1c380bece3c70fd2104
e1968ed29b6c3388719226f959f69f9be43688ed27bc3a4dbc83f640370524b47bb871816af79586d07
08781fad384480d0609b11c31d27baa6e902d29277a474e3e2785a8410d595c0f9c75312375b4bd098
76e1a47a598e114749a09c35f098e9123015c2795c702e4a346a8bccd00305c7cb30beef66ad33f43dac
c2e662128
```

```
-----END OpenVPN Static key V1-----.
```

- 7. **Remote Network Routes** create a route from the server network to the client network. This allows the server to get access to the client's network. In the **OpenVPN Tunnel Network Routes**, click **Add**:
 - a. Enter the **Remote Network Route** (should be the client subnet). For example, if the client IP address is 192.168.3.1, enter 192.168.3.0.
 - b. Enter the **Remote Network Mask** (usually 255.255.255.0).
 - c. Click **Add**.
- 8. The system displays your recently-added **Remote Network Route** with the client subnet (remote network route + mask).
Note: **Push Routes** are not required with **Static Key** as **Authorization Mode**.
- 9. Click **Preview** to view the tunnel configuration.
- 10. Click **Submit**.
- 11. Click **Save and Apply** to save your changes.

Configuration 4: OpenVPN Tunnel with Static Key Authorization Mode and TCP

This fourth configuration establishes the OpenVPN Tunnel connection from a device client to a device server using Static Key as Authorization Mode and TCP protocol (instead of UDP for the third configuration). This involves adding and configuring both OpenVPN Server and Client sides within the device UI.

To add an **OpenVPN Server using Static Key and TCP**:

- 1. Go to **Tunnels > OpenVPN Tunnels > OpenVPN Tunnel Configuration**.
- 2. Click **Add Tunnel**.
- 3. Enter the **Name**.

4. Select the **Type** as **SERVER** from the drop-down.
5. You can also enter an optional **Description**.
6. Enter the following fields (using **STATIC KEY** as **Authorization Mode**):
 - a. **Interface Type** as **TUN** from the drop-down.
 - b. **Authorization Mode** as **STATIC KEY** from the drop-down.
 - c. **Protocol** as **TCP**.
 - d. **Local Address** as **DEFAULT**.
 - e. **Remote Host**.
 - f. **Remote Address** as **DEFAULT**.
 - g. **Remote Port** number.
 - h. **Hash Algorithm** as **RSA-SHA1**.
 - i. **LZO Compression** as **ADAPTIVE** from the drop-down.
 - j. **NCP (Negotiable Crypto Parameters)** as **CAMELLIA-256-CBC**.
 - k. **Min. TLS Version** as **NONE**.
 - l. **TLS Cipher Suite** as **DEFAULT**.
 - m. Generate and enter the **Static Key PEM** (required). Both server and client must use the same static key. See example below:


```
-----BEGIN OpenVPN Static key V1-----
3f4c9113b2ec15a421cfe21a5af015bb967059021c1fd6f6ecfd00533d967237875215e20e80a2d59efd
79148d6acdea9358dcafe0efdbb54003ff376c71432dd9d16f55e7d8917a32bfe07d61591b7bbb43c7ba
d214482b8547ec9dca8910f514d9f4270ccaef1a79852ae27c1c307c9dc3c836d1c380bece3c70fd2104
e1968ed29b6c3388719226f959f69f9be43688ed27bc3a4dbc83f640370524b47bb871816af79586d07
08781fad384480d0609b11c31d27baa6e902d29277a474e3e2785a8410d595c0f9c75312375b4bd098
76e1a47a598e114749a09c35f098e9123015c2795c702e4a346a8bccd00305c7cb30beef66ad33f43dac
c2e662128
-----END OpenVPN Static key V1-----
```
7. Click **Next**.
8. **Remote Network Routes** create a route from the server network to the client network. This allows the server to get access to the client's network. In the **OpenVPN Tunnel Network Routes**, click **Add**:
 - a. Enter the **Remote Network Route** (should be the client subnet). For example, if the client IP address is 192.168.3.1, enter 192.168.3.0.
 - b. Enter the **Remote Network Mask** (usually 255.255.255.0).
 - c. Click **Add**.
9. The system displays your recently-added **Remote Network Route** with the client subnet (remote network route + mask).

Note: **Push Routes are not required with Static Key as Authorization Mode.**
10. Click **Preview** to view the tunnel configuration.
11. Click **Submit**.
12. Click **Save and Apply** to save your changes.

To add an **OpenVPN Client using Static Key and TCP**:

1. Go to **Tunnels > OpenVPN Tunnels > OpenVPN Tunnel Configuration**.

2. Click **Add Tunnel**.
3. Enter the **Name**.
4. Select the **Type** as **CLIENT** from the drop-down.
5. You can also enter an optional **Description**.
6. Enter the following fields (using **STATIC KEY** as **Authorization Mode**):
 - a. **Interface Type** as **TUN** from the drop-down.
 - b. **Authorization Mode** as **STATIC KEY** from the drop-down.
 - c. **Protocol** as **TCP**.
 - d. **Local Address** as **DEFAULT**.
 - e. **Remote Host**.
 - f. **Remote Address** as **DEFAULT**.
 - g. **Remote Port** number.
 - h. **Hash Algorithm** as **RSA-SHA1**.
 - i. **LZO Compression** as **ADAPTIVE** from the drop-down.
 - j. **NCP (Negotiable Crypto Parameters)** as **CAMELLIA-256-CBC**.
 - k. **Min. TLS Version** as **NONE**.
 - l. **TLS Cipher Suite** as **DEFAULT**.
 - m. Generate and enter the **Static Key PEM** (required). Both server and client must use the same static key. See example below:

```
-----BEGIN OpenVPN Static key V1-----
3f4c9113b2ec15a421cfe21a5af015bb967059021c1fd6f66ecfd00533d967237875215e20e80a2d59efd
79148d6acdea9358dcafe0efdbb54003ff376c71432dd9d16f55e7d8917a32bfe07d61591b7bbb43c7ba
d214482b8547ec9dca8910f514d9f4270ccaeff1a79852ae27c1c307c9dc3c836d1c380bece3c70fd2104
e1968ed29b6c3388719226f959f69f9be43688ed27bc3a4dbc83f640370524b47bb871816af79586d07
08781fad384480d0609b11c31d27baa6e902d29277a474e3e2785a8410d595c0f9c75312375b4bd098
76e1a47a598e114749a09c35f098e9123015c2795c702e4a346a8bccd00305c7cb30beef66ad33f43dac
c2e662128
-----END OpenVPN Static key V1-----
```
7. Click **Next**.
8. **Remote Network Routes** create a route from the server network to the client network. This allows the server to get access to the client's network. In the **OpenVPN Tunnel Network Routes**, click **Add**:
 - a. Enter the **Remote Network Route** (should be the client subnet). For example, if the client IP address is 192.168.3.1, enter 192.168.3.0.
 - b. Enter the **Remote Network Mask** (usually 255.255.255.0).
 - c. Click **Add**.
9. The system displays your recently-added **Remote Network Route** with the client subnet (remote network route + mask).

Note: **Push Routes are not required with Static Key as Authorization Mode.**
10. Click **Preview** to view the tunnel configuration.
11. Click **Submit**.
12. Click **Save and Apply** to save your changes.

Unavailable Services in PPP-IP Passthrough and Serial Modem Modes

In both **PPP-IP Passthrough** and **Serial Modem** modes, many rCell services described in this document are either limited, or non-configurable and therefore do not appear in the device configuration menu. If you choose one of these modes, all sections between this and the previous note on this subject are limited, or typically not available.

Chapter 10 – Administration

User Accounts

Use this feature to add user accounts or change the password.

The system offers three roles or user types: administrator, engineer, and monitor. Administrators have full rights and permissions including change settings on the device. Engineers have read/write privileges and some access to controls on the device. Monitors have read-only access. Note: the system automatically checks for a strong password and tells you how to improve it.

Username requirements include:

- Must be unique.
- Is case-sensitive (for example, admin and ADMIN are treated as two different usernames).
- Acceptable characters: uppercase alphabetic, lowercase alphabetic, numeric, and non-alphanumeric (symbols like #).
- A hyphen (-) should not be used as the first character.

Password requirements include:

- User account is disabled if password is not set up.
- Must be at least eight characters in length.
- Contains three or more different types of characters such as: uppercase alphabetic, lowercase alphabetic, numeric, and non-alphanumeric (symbols like #).

Administrator details:

- Able to delete any local users. (Engineer and Monitor cannot delete any users.)
- Able to modify any other user details, except username.
- Can not modify another administrator user account if it is the only enabled local administrator user on the device.
- Able to modify own account details except Role, Username, and Enabled values.
- Able to disable and enable any local users except their own account. Also, not able to disable local user account if this is only local administrator.
- Able to change own password and other user passwords.

Engineer and Monitor details:

- Able to view and modify own user account details except Role, Username, and Enabled values.
- Access to only their own user account.
- Not able to delete users.
- Able to change own password.

To add new users:

1. Go to **Administration > User Accounts**.
2. Click **Add New User**.
3. Under **User Details**, enter the following fields:

- a. Username (required)
 - b. Role (required). Select the user role from the drop-down menu including **administrator**, **engineer**, or **monitor**.
 - c. First Name
 - d. Last Name
 - e. Title
 - f. Division
 - g. Employee Identification
4. Under **Contact Information**, enter the following fields:
 - a. Email
 - b. Address
 - c. City
 - d. State
 - e. Country
 - f. Postal Code
 - g. Work Phone
 - h. Mobile Phone
 5. Click **Submit**.
 6. The **Change Password** page opens. Enter **New Password**. Click **Submit**.
 7. The **Change Password** page opens. Enter **New Password**. Click **Submit**.

If the password is not set up for the new user, the user is disabled until the password is set.

Password Complexity

Password Complexity Rules allow an administrative user to choose rules and limitations on user passwords. You can determine various password parameters such as the minimum length of passwords, upper and lower case requirements, and characters not permitted.

Before choosing your options, you must first select between two different complexity modes: **Default** or **Credit**.

Default mode uses a minimum character length and may require a specific number of characters from each class. But requiring specific classes of characters actually makes brute force attacks easier because it reduces the search space.

For this reason, we recommend using **Credit** mode. This mode grants one credit per password character plus one extra credit for certain character classes up to their respective extra credit cap. You can still specify a minimum number of classes, but the strongest passwords come from their length.

In either mode, you should use longer passwords for increased security.

1. Go to **Administration > User Accounts**.
2. Click **Change Password Complexity Rules** button.
3. Under the **Change Password Complexity Rules** window, select from the drop-down between **Default** or **Credit** mode.
4. For **Default** mode, you may enter the following:

- a. **Minimum Password Length** (default = 8)
 - b. **Minimum Upper Case Characters** (default = 0)
 - c. **Minimum Lower Case Characters** (default = 0)
 - d. **Minimum Numeric Characters** (default = 0)
 - e. **Minimum Special Characters** (default = 0)
 - f. **Maximum Password Length** (default = 64)*
 - g. **Characters Not Permitted** (enter restricted characters in any order with no separators)
5. For **Credit** mode, you may enter the following:
- a. **Minimum Password Credits** (default = 8)
 - b. **Minimum Character Classes** (default = 3)
 - c. **Upper Case Extra Credit Cap** (default = 0)
 - d. **Lower Case Extra Credit Cap** (default = 0)
 - e. **Numeral Extra Credit Cap** (default = 0)
 - f. **Special Extra Credit Cap** (default = 0)
 - g. **Maximum Password Length** in number of characters (default = 64)*
 - h. **Characters Not Permitted** (enter restricted characters in any order with no separators)

* **Note:** Entering a value of 0 indicates no maximum.

Self-Diagnostics

The device offers self-diagnostics or periodic monitoring of certain issues such as memory errors or leaks, and security violations by applications. The following self-diagnostic features are available with this device (varies with model) :

- Security Violation
- Flash Memory Violation
- Resource Overuse

This monitoring is intended detect corruption, or help prevent malicious activity. After an event is detected, the system disables the cellular radio module, sends an alarm or notification, logs the event, and sends a record of it via SMS, Email, or to the SNMP server. To receive notifications for specific diagnostic features, configure them under **Administration > Notifications**.

For the self-diagnostic features, go to **Administration > Self-Diagnostics** and refer to the following sections.

To turn on the **Resource Overuse** diagnostic that detects memory leaks or errors:

1. Check **Enabled** under **Resource Overuse**.
2. If you want the system to reboot the device after a **Resource Overuse** is detected, check **Reboot the device** under **Actions**.

To turn on the **Security Violation** diagnostic that detects security rule violations by applications:

1. Check **Enabled** under **Security Violation**.
2. If you want the system to disable WAN interfaces after a **Security Violation** is detected, check **Disable WAN Interfaces** under **Actions**.

3. If you want the system to disable user-defined firewall rules after a **Security Violation** is detected, check **Disable User-Defined Firewall Rules** under **Actions**.

To turn on the **Flash Memory Violation** diagnostic that performs a flash memory checksum check to protect the integrity of device firmware:

1. Check **Enabled** under **Flash Memory Violation**.
2. Enter the **Flash Memory Check Interval** (ranging between 4-24 hours). Default is 24.
3. If you want the system to disable WAN interfaces after a **Flash Memory Violation** is detected, check **Disable WAN Interfaces** under **Actions**.
4. If you want the system to disable user-defined firewall rules after a **Flash Memory Violation** is detected, check **Disable User-Defined Firewall Rules** under **Actions**.

After you completed your **Self-Diagnostic** configuration (selecting any or all of the above):

1. Click **Submit**.
2. To save changes, click **Save and Apply**.

If at any time you want to return the device to the default setting, click the **Reset to Default** button in the bottom right corner. (This disables or removes all enabled **Self-Diagnostic** features.)

Configuring Device Access

This section contains configurations that determine how the device can be accessed as well as security features that decrease susceptibility to malicious activity.

To display the **Access Configuration** window containing the fields described below, go to **Administration > Access Configuration**.

HTTP Redirect to HTTPS

The device allows only secure access to its Web UI. This set of rules automatically redirects HTTP requests to the device's secure HTTPS port.

| Field | Description |
|-------------------------|---|
| Enabled | Enables HTTP to HTTPS redirect which automatically redirects users trying to access the device via HTTP to HTTPS. |
| Port | The port on which the device listens for HTTP requests to redirect. |
| Via LAN/Ethernet | If checked, the device listens and redirects HTTP requests to HTTPS from the LAN. |
| Via WAN/Cellular | If checked, the device listens and redirects HTTP requests to HTTPS from the WAN. |

HTTPS

The device provides secure Web UI access to modify its configurations and execute actions.

| Field | Description |
|--|---|
| Port | The port on which the device will listen for HTTPS requests. |
| Via WAN/Cellular | If checked, the device will listen and respond to HTTPS requests from the WAN. This increases susceptibility to malicious activity. |
| Session Timeout (under Authorization) | Amount of time a user's session can remain dormant before automatically being logged out (minutes). Note: Changing this item requires the device to reboot. |

HTTPS Security

Configure the HTTPS security settings (like version and cipher suite). Click the **Show** link to the right under **HTTPS Security**. To enable the Web server to authenticate the client via the client's public key certificate, check **Client Authentication** under the **Authentication** section.

Note: Enabling **Client Authentication** can prevent users from accessing the Web UI. When **Client Authentication** is enabled it is required that a web browser has a valid client certificate that is signed by a CA that the server can verify. The CA certificate needs to be uploaded to the device using the upload feature at **Administration > X.509 CA Certificates**. Configure TLS version and cipher suites under the **TLS Settings** section.

NOTE: For mPower 5.3 and above, deprecated encryption and ciphers are not available for creating new tunnels. But old tunnels that were created in 5.2 or lower will retain the deprecated settings unless changed.

| Field | Description |
|---|---|
| Authentication | |
| Client Authentication | Requires web browsers to have a valid client certificate that is signed by a Certifying Authority (CA) that the server can verify. Otherwise, user access to the UI is blocked. NOTE: You must first upload a CA certificate at Administration > X.509 CA Certificates . |
| TLS Settings | |
| TLSv1.3, TLSv1.2, and/or TLSv1.1 | Check any version of the TLS protocol you want to use: TLSv1.3, TLSv1.2, and/or TLSv1.1 (Deprecated) . Default: TLSv1.3 and TLSv1.2 |

| Field | Description |
|--------------------------|---|
| Cipher Suite Name | Check any preferred Cipher Suite from the following: TLS_AES_256_GCM_SHA384 , TLS_CHACHA20_POLY1305_SHA256 , TLS_AES_128_GCM_SHA256 , ECDHE-RSA-AES256-GCM-SHA384 , ECDHE-RSA-AES128-GCM-SHA256 , TLS_AES_128_GCM_SHA256 , and also including the following deprecated ciphers: ECDHE-RSA-AES256-GCM-SHA384 , ECDHE-RSA-AES256-SHA , DHE-RSA-AES256-GCM-SHA384 , AES256-SHA , ECDHE-RSA-AES128-GCM-SHA256 , ECDHE-RSA-AES128-SHA , DHE-RSA-AES128-GCM-SHA256 , DHE-RSA-AES128-SHA , and/or AES128-SHA . Default: All . (You can also set the priority order of the ciphers). |

SSH

The device's internal system can be accessed securely via SSH. This is intended for advanced troubleshooting and/or custom deployment solutions.

| Field | Description |
|-------------------------|---|
| Enabled | Enables SSH redirect which automatically redirects users trying to access the device via SSH (disabled by default). |
| Port | The port on which the device listens for SSH requests. |
| Via LAN/Ethernet | If checked, the device listens and responds to SSH requests from the LAN. |
| Via WAN/Cellular | If checked, the device listens and respond to SSH requests from the WAN. |

Reverse SSH Tunnel

Enable and configure a reverse SSH tunnel.

| Field | Description |
|------------------------------|--|
| Enabled | Enable Reverse SSH tunnel to get SSH access to the device with a public IP address. |
| Server | Remote SSH server IP address or hostname to which the reverse SSH tunnel connection is established. |
| Remote Port | Tunnel remote port that opens on the remote end of the reverse SSH tunnel connection (2222 by default). |
| Username | Remote SSH server username. |
| Authentication Method | Defines Authentication method to use for Reverse SSH Tunnel . Select from drop-down including Password , Public Key , or Private Key . |
| Password | User's password on the remote SSH server (when you select Password for Authentication Method). |

| Field | Description |
|--------------------|--|
| Public Key | The public key that the Remote SSH server uses to authorize your device and establish the tunnel connection (when you select Public Key for Authentication Method). |
| Private Key | The private key provided by the remote SSH server (when you select Private Key for Authentication Method). |

SSH Security

Configure the **SSH security settings** (like ciphers and HMAC). Click **Show** to the right under **Security Settings**. Must select **SSL/TLS** under **Protocol**.

NOTE: For mPower 5.3 and above, deprecated hash algorithms are not available for creating new tunnels. But old tunnels that were created in 5.2 or lower will retain the deprecated settings unless changed.

| Field | Description |
|----------------|--|
| Ciphers | Check any Cipher you want to use: CHACHA20-POLY1305@OPENSSH.COM (no HMAC required), AES128-CTR, and/or AES256-CTR. |
| HMAC | Check any hash-based message authentication code, you want to use: SHA1 (deprecated), SHA2-256, and/or SHA2-512. |

ICMP

Internet Control Message Protocol (ICMP) is used by devices to send error messages such as that a requested service is not available or a host or device could not be reached. ICMP can also relay query messages.

| Field | Description |
|------------------------------------|---|
| Enabled | Enables ICMP responses. |
| Respond to LAN/Via Ethernet | If checked, the device will respond to ICMP traffic from the LAN, such as ping requests. |
| Respond to WAN/Via Cellular | If checked, the device will respond to ICMP traffic from the WAN, such as ping requests. This increases susceptibility to malicious activity. |

Node-RED

The device can be configured to accept connections to the Node-RED browser editor to either/both LAN and/or WAN.

| Field | Description |
|----------------|--|
| Via LAN | If checked, the device allows connection to Node-RED from the LAN. |

| Field | Description |
|---------|--|
| Via WAN | If checked, the device allows connection to Node-RED from the WAN. This may increase susceptibility to malicious activity. |

NOTE: Support for Node-RED/Node.js on Multitech AT91SAM9G25-based products has been discontinued.

SNMP

The device offers Simple Network Management Protocol (SNMP) which is used for collecting information from, and configuring network devices on an IP network. For more details, refer to [Configuring SNMP](#).

| Field | Description |
|---------|--|
| Via LAN | If checked, the device allows access to the SNMP server via LAN. |
| Via WAN | If checked, the device allows access to the SNMP server via WAN. |

Modbus Slave

The Modbus feature allows the user to enable the Modbus query server. You can query this server over Modbus-TCP for status information.

| Field | Description |
|--------------------------------------|---|
| Enabled (under Modbus Slave) | Enables the Modbus Query Server. |
| Via LAN | If checked, the device can query the Modbus server via LAN. |
| Port | Port number configured for Modbus. |

For Modbus query information, refer to the MTR Modbus Information page on our Developer Resources website (on .net) for details: <http://www.multitech.net/developer/software/mtr-software/mtr-modbus-information/>

IP Defense

A set of rules that decreases susceptibility to malicious activity. If these settings are configured too strictly, they may interfere with non-malicious activity.

Go to **Administration > Access Configuration > IP Defense** to find these features.

DoS Prevention

This area of the Access Configuration window engages a set of rules at the firewall that prevents Denial-of-Service attacks by limiting the amount of new connection requests to the device.

| Field | Description |
|------------|---|
| Enabled | Enables DoS prevention (enabled by default). |
| Per Minute | Allowed number of new connections per minute until burst points are consumed. For example, if 60 new connections are received in a minute, decrement one burst point. If no more burst points, drop the packet. |

| Field | Description |
|--------------|---|
| Burst | Number of allowed burst for traffic spikes. A burst occurs when the Per Minute limit is reached. On a period where the Per Minute limit is not reached, one burst point is regained, up to the maximum. |

Ping Limit

This area of the Access Configuration window engages a set of rules at the firewall that aims to prevent ping flood attacks by limiting the number of ICMP requests to the device. These rules that mitigate the effects of a ping DoS on your device do not apply if ICMP is disabled.

| Field | Description |
|-------------------|---|
| Enabled | Enables the Ping Limit feature (enabled by default). |
| Per Second | Allowed number of pings per second before burst points are consumed. Once burst points run out, ICMP packets will be dropped. |
| Burst | Number of burst points. On a period where the Per Second limit is not reached, one burst point is regained, up to this maximum. |

Brute Force Protection

This feature tracks login attempts at the RESTFUL API level. Its purpose is to prevent Dictionary attacks that attempt to brute force the user's password. The device reboots after applying changes in this section.

| Field | Description |
|------------------------|---|
| Enabled | Enables the Brute Force Prevention feature (enabled by default). |
| Attempts | The number of failed attempts allowed before the user's account is locked out. |
| Lockout Minutes | The number of minutes an account is locked out before a new login attempt will be accepted. |

Bootloader Protection

To see or set these features, go to **Administration > Access Configuration > Bootloader Protection** and click **Show**.

Bootloader Password

This feature enables password authentication to access the device bootloader. It is disabled by default.

| Field | Description |
|-----------------|---|
| Enable | Enables the Bootloader Password feature to the right of Authentication Status (enabled by default). |
| Password | Enter password to access the device bootloader. |
| Confirm | Enter the password again to confirm. |

Debug Console

This feature allows the customer to run **Silent Mode** which turns off the output to the **Debug Console**. The console output is enabled by default (i.e. **Silent Mode** is disabled).

When **Silent Mode** is enabled, **Debug Console** is turned off. (**NOTE:** During boot, the device does not output any information after the notice that the Linux Kernel is being decompressed including no login prompt, etc.)

| Field | Description |
|---------------|---|
| Enable | Enables Silent Mode which turns off output to the Debug Console (disabled by default meaning Debug Console output is on). |

After making all your desired changes, click **Submit**, then click **Save and Apply**. (Changes to specific sections may require reboot.)

RADIUS Configuration

The RADIUS protocol supports authentication, user session accounting, and authorization of users to the device. This authentication, accounting, and authorization is independent of the local users created on the device. The user can enable Authentication, Accounting, or both options.

RADIUS user details:

- Access to device if role is one of those in the provided list (Administrator, Engineer, or Monitor).
- All RADIUS users do not have SSH access to the device.
- RADIUS creates a temporary session instead of a local account like local users.
- RADIUS uses shared key encryption.
- Local users shall take priority over RADIUS user (if a RADIUS user has the same username as a local user, the RADIUS user cannot log in even if the local user is disabled).
- RADIUS user with Administrator role can view and modify all local users (but cannot delete a local Administrator if it is the only local admin user on the device).
- RADIUS users with Engineer and Monitor role cannot view or modify user details. They do not have access to the **User Accounts** page.
- RADIUS users cannot change their own password in the Web UI.

To set up the RADIUS server configuration:

1. Go to **Administration > RADIUS Configuration**.
2. To enable authentication, check **Enable Authentication**.
3. To enable accounting, check **Enable Accounting**.
4. Enter the following fields for **RADIUS configuration**:
 - a. Primary Server
 - b. Authentication Port (for Primary Server)
 - c. Accounting Port (for Primary Server)
 - d. Secondary Server
 - e. Authentication Port (for Secondary Server)
 - f. Accounting Port (for Secondary Server)
5. Under **Options**, enter the following fields:

- a. **Shared Secret Key** value is used to: 1) encrypt packets between the RADIUS Server and device, 2) encrypt RADIUS attributes such as user password, and 3) verify that RADIUS messages have not been modified in transit. This value must be equal to the shared secret that is set up in RADIUS server. The Shared Secret Key can be up to 128 characters long. You can click the eye icon to hide the key.
 - b. Authentication Protocol: select from drop-down list including **PAP**, **EAP-PEAPv0/MSCHAPv2**, or **EAP-TTLS/PAPv0**
 - c. Timeout is the interval in seconds between tries to connect to RADIUS server in case of communication failure. Maximum is 10 seconds.
 - d. Retries is the number of tries to connect to RADIUS server in case of communication failure.
6. Advanced Options are used when Authentication Protocol is EAP-PEAPv0/MSCHAPv2 or EAP-TTLS/PAPv0. If Protocol is PAP, these settings are ignored:
- a. Check **Use Anonymous ID** if you want to enable identity privacy. The device does not send its identity in plain text before the device has authenticated the RADIUS server.
 - b. Anonymous ID is a name or value that the device will use in the identity response when “Use Anonymous ID” is enabled.
 - c. Check **Check Server Certificate Hostname** to allow the server certificate CN (common name) to be validated by the device.
7. Click **Submit**.
8. To save your changes, click **Save and Apply**.

Unavailable Services in PPP-IP Passthrough and Serial Modem Modes

In both **PPP-IP Passthrough** and **Serial Modem** modes, many rCell services described in this document are either limited, or non-configurable and therefore do not appear in the device configuration menu . If you choose one of these modes, all sections between this and the next note on this subject are limited, or typically not available.

Generating a New Certificate

Because the device uses a self-signed website certificate, your browser shows a certificate error or warning. Ignore the warning and add an exception or add your device address to the trusted sites.

To generate a new certificate:

1. Go to **Administration > X.509 Certificate**. The **X.509 Certificate** window displays the details of the certificate that is currently used.
2. Click **Generate** to open the **Generate Certificate** window.
3. In the **Common Name** field, enter the name, hostname, or IP address, depending on what you use to connect to the device. The web browser uses this field to check for a valid certificate.
4. In the **Days** field, enter the amount of days before the certificate will expire.
5. In the **Country** field, enter the 2-letter code for the country name.
6. In the **State/Province** field, enter the state or province for which the certificate is valid.
7. In the **Locality/City** field, enter the locality or the city for which the certificate is valid.
8. In the **Organization** field, enter the organization name for which the certificate is valid.
9. In the **Email Address** field, enter the email address of the person responsible for the device. Typically this is the administrator. This field may be left blank.

10. Click **Generate**. Wait until the certificate is generated. You may have to reboot to complete the operation.
11. If you are finished making changes, click **Save and Apply**. The device reboots after applying those changes.

Importing a Certificate

To import a certificate (in **.pem** format):

1. Go to **Administration > X.509 Certificate**. The Certificate window displays the details of the certificate that is currently used.
NOTE: A certificate with a key size greater than 2048 bits causes a delay accessing the Web UI after the device starts. A certificate with a key size less than 2048 bits is not recommended since it is less secure and may become breakable in the near future.
2. Click **Import** to open **Upload Certificate** window.
3. Click **Browse** to select a valid certificate to be uploaded. Check that your certificate file format is **.pem**.
4. Click **Upload**. Wait until the file is uploaded.
5. To save your changes, click **Save and Apply**. The device reboots after applying those changes.

NOTE: Your certificate file must be in **.pem** format.

Uploading CA Certificate

This page allows a user to upload an X.509 CA (Certifying Authority) Certificate. This is also where you upload root CA certificates for the on-premises Device HQ server to the device.

To upload a CA certificate:

1. Go to **Administration > X.509 CA Certificates**.
2. Click **Choose File** and browse for your CA certificate file.
3. Click **Open**.
4. Once your file is selected, click **Import**.
5. Click **Save and Apply** to save your changes. The device reboots.
6. Your CA certificate file displays in the certificate list along with relevant details.
7. You may delete or remove a certificate by clicking the trash can icon to the right under **Options**.

Note: Both add and remove functions may take up to two minutes to update. Once updated, the changes are applied immediately. There is no need to restart the device after CA certificate is added or removed. For bi-directional certificate authentication or client authentication, go to **Device Administration > Access Configuration > HTTPS Security > Authentication** and check **Client Authentication**. See **HTTPS Security** on the [Access Configuration](#) page for more details.

Setting up the Remote Management

To modify DeviceHQ automatic update settings, go to options under **Auto-Update Settings** and refer to [Managing Your Device Remotely](#).

1. Go to **Administration > Remote Management > Remote Server**. To allow the device to connect to the Remote Management Server, check **Enabled**.
2. If you want the device to use a secure connection, check **SSL Enabled**.

3. The **Server Name** field is pre-populated with the address of the Remote Management Server.
4. The **Server Port** field is pre-populated with the port the Remote Management Server listens on. You likely do not need to change this.
5. In the **Account Key** field, type the account key received from the Remote Management administrator. The device is not allowed to connect to the Remote Management Server without a valid account key.
6. Click **Submit**.
7. To save your changes, click **Save and Apply**.

Managing Your Device Remotely

DeviceHQ® can monitor devices, reboot devices, and perform remote software and configuration updates.

NOTE: Reboot the device before performing any firmware updates.

To configure your device to use DeviceHQ:

1. Go to **Administration > Remote Management** and check **Enabled**.
2. Go to options under **DeviceHQ Check-In Settings**.
3. Enable the **Intervals** check box to check in to DeviceHQ periodically at the specified interval. **If you do not select **Intervals**, certain DeviceHQ features will NOT be available. See note at the end for this topic for details.*
 - a. To define how often the device connects to DeviceHQ to check in and request any pending updates, set the **Check-In Interval** field to the desired number of minutes between 240-10080 (240 minutes to 1 week). **Note:**The minimum check-in interval is 4 hours. If you set a device's check-in interval to less than 4 hours, the change is ignored.
 - b. To define how often the device connects to DeviceHQ to send GPS data, set the **GPS Data Interval** field to the desired number of minutes, between 240-10080 (240 minutes to 1 week). **Note:** Some MTR models do not have GPS. Then this field does not display.
4. Enable **Single Check-In** to configure your device to check-in to DeviceHQ at the specific date and time. If you enable **Single Check-In**, click the **Date** field to select the date from the calendar picker, and then enter the **Time** (HH:MM) for your device to check-in.
5. Enable **Repeatable** to check-in to DeviceHQ periodically at the specified time daily or at the specific days of the week.
 - a. Select **Daily** from the **Repeat** drop-down to check in to DeviceHQ every day, and enter the **Time** (HH:MM) for your device to check-in.
 - b. Select **Custom** from the **Repeat** drop-down, then specify the days of the week, and enter the **Time** (HH:MM) for your device to check-in.
6. Go to options under **Update Settings**
7. If **Sync with Dial-On-Demand** is checked and cellular dial-on-demand is enabled, the connection is not dialed solely for the purpose of connecting to DeviceHQ. The device will connect to DeviceHQ only when other traffic brings up the link.
8. Check **Allow Firmware Upgrade** if you want DeviceHQ to make automatic updates of your firmware.
9. Check **Allow Configuration Upgrade** if you want DeviceHQ to make automatic updates of your configuration software.
10. Check **Allow Radio Firmware Upgrade** if you want DeviceHQ to make automatic updates of your cellular radio firmware.

11. Click **Submit**.
12. Click **Save and Apply** to save your changes.

***NOTE:** If you do not select **Intervals**, certain DeviceHQ features will NOT be available including:

- missed check-in alerts
- device rebooted alerts
- automatically scheduled device log uploads
- home page notices for rebooted or missed check-in devices

Unavailable Services in PPP-IP Passthrough and Serial Modem Modes

In both **PPP-IP Passthrough** and **Serial Modem** modes, many rCell services described in this document are either limited, or non-configurable and therefore do not appear in the device configuration menu. If you choose one of these modes, all sections between this and the previous note on this subject are limited, or typically not available.

Notifications

The device can send alerts via email, SMS, and/or SNMP. To use these options, enable SMTP (see [SMTP Settings](#) for details), SMS (see [Configuring SMS](#) for details), and SNMP Traps (see [Configuring SNMP](#) for details).

A time stamp is added to the actual notifications. The format is **YYYY-MM-DD HH:MM**.

To setup notifications:

1. Go to **Administration > Notifications > Configuration**.
2. Under **Recipient Group**, click **Add Group** (you must add a group before you can edit/save your alert).
3. In the **Create Recipient Group** window, enter your **Group Name**.
4. Enter the person's **Name** and **Phone Number**. Click **Add Phone**.
5. Enter the person's **Name** and **Email**. Click **Add Email**.
6. Add name, phone number and email for each person in your group. When done, click **Submit**.
7. Click **Save and Apply** if you have no additional changes. Otherwise, skip to step 9.
8. See the list of available alerts:
 - **High Data Usage**
 - **Low Signal Strength**
 - **Device Reboots**
 - **Ethernet Interface Failure**
 - **Cellular Interface Failure**
 - **Ethernet Data Traffic**
 - **Cellular Data Traffic**
 - **WAN Interface Failover**
 - **Ping Failure**
 - **Security Violation**
 - **Flash Memory Violation**
 - **Resource Overuse**

- **Wi-Fi Interface Failure***
- **Wi-Fi Data Traffic***

*Only available on models with Wi-Fi capabilities

9. Click on the pencil icon under the **Edit** column for the alert you want to use and configure. The **Edit** dialog box appears for your chosen alert.

For **High Data Usage**:

1. Check **Enabled**.
2. Under **Data Plan Details**, select the **Plan Type** from the drop down menu which includes **Monthly** or **Custom Interval**.
3. If you choose **Custom Interval**, enter the **Interval** length in days.
4. Select the **Start Date** from the calendar picker.
5. Enter the **Limit** in **MB** for data usage.
6. In **Notify At**, enter the percentage of the limit that triggers notification to be sent.
7. Select alert recipients from **Recipient Group**.
8. Select how you want to send alerts by clicking **Email**, **SMS**, or **SNMP**.
9. Click **OK**.
10. To save your changes, click **Save and Apply**.

For **Low Signal Strength**:

1. Check **Enabled**.
2. Enter the **Signal Threshold** in **dBm**.
3. Enter the **Duration** in seconds.
4. Under **Alerts**, select the recipients under **Recipient Group**.
5. In **Notify**, enter the frequency of notification (in hours). Default is **24**.
6. Select how you want to send alerts by clicking **Email**, **SMS**, or **SNMP**.
7. Click **OK**.
8. To save your changes, click **Save and Apply**.

For **Device Reboots**:

1. Check **Enabled**.
2. Under **Alerts**, select the recipients under **Recipient Group**.
3. In **Notify**, the field for frequency of notification is shown. The predefined value is **Always** and cannot be modified by the user.
4. Select how you want to send alerts by clicking **Email**, **SMS**, or **SNMP**.
5. Click **OK**.
6. To save your changes, click **Save and Apply**.

For **Ethernet Interface Failure**:

1. Check **Enabled**.
2. Enter the **Duration** in seconds.
3. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
4. In **Notify**, enter the frequency of notification (in hours). Default is **24**.

5. Select how you want to send alerts by clicking **Email, SMS** or **SNMP**.
6. Click **OK**.
7. To save your changes, click **Save and Apply**.

For **Cellular Interface Failure**:

1. Check **Enabled**.
2. Enter the **Duration** in seconds.
3. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
4. In **Notify**, enter the frequency of notification (in hours). Default is **24**.
5. Select how you want to send alerts by clicking **Email, SMS** or **SNMP**.
6. Click **OK**.
7. To save your changes, click **Save and Apply**.

For **Ethernet Data Traffic**:

1. Check **Enabled**.
2. Enter **Interval** in hours when alert is sent.
3. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
4. In **Notify**, the constant value is **Always**.
5. Select how you want to send alerts by clicking **Email, SMS** or **both**.
6. Click **OK**.
7. To save your changes, click **Save and Apply**.

For **Cellular Data Traffic**:

1. Check **Enabled**.
2. Enter **Interval** in hours when alert is sent.
3. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
4. In **Notify**, the constant value is **Always**.
5. Select how you want to send alerts by clicking **Email, SMS** or **both**.
6. Click **OK**.
7. To save your changes, click **Save and Apply**.

For **WAN Interface Failover**:

1. Check **Enabled**.
2. Enter the **Timeout** in seconds.
3. Select what to **Notify On** from the drop-down.
4. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
5. In **Notify**, the constant value is **Always**.
6. Select how you want to send alerts by clicking **Email, SMS** or **SNMP**.
7. Click **OK**.
8. To save your changes, click **Save and Apply**.

For **Ping Failure**:

1. Check **Enabled**.

2. Under **Ping Details**, select the **Network Interface** from the drop-down.
3. Enter the **IP Address** or **URL** that you want to ping.
4. Enter the **Count**.
5. Enter the **Failure Threshold**.
6. Enter the **Ping Interval**.
7. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
8. In **Notify**, the constant value is **Always**.
9. Select how you want to send alerts by clicking **Email**, **SMS** or **SNMP**.
10. Click **OK**.
11. To save your changes, click **Save and Apply**.

For **Security Violation**:

1. Check **Enabled**.
2. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
3. In **Notify**, the constant value is **Always**.
4. Select how you want to send alerts by clicking **Email**, **SMS** , or **SNMP**.
5. Click **OK**.

For **Flash Memory Violation**:

1. Check **Enabled**.
2. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
3. In **Notify**, the constant value is **Always**.
4. Select how you want to send alerts by clicking **Email**, **SMS** , or **SNMP**.
5. Click **OK**.

For **Resource Overuse**:

1. Check **Enabled**.
2. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
3. In **Notify**, the constant value is **Always**.
4. Select how you want to send alerts by clicking **Email**, **SMS** , or **SNMP**.
5. Click **OK**.

The following notifications are only available on models with Wi-Fi capabilities:

For **Wi-Fi Interface Failure**:

1. Check **Enabled**.
2. Enter the **Duration** in seconds.
3. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
4. In **Notify**, enter the frequency of notification (in hours). Default is **24**.
5. Select how you want to send alerts by clicking **Email**, **SMS** or **SNMP**.
6. Click **OK**.
7. To save your changes, click **Save and Apply**.

For **Wi-Fi Data Traffic**:

1. Check **Enabled**.
2. Enter **Interval** in hours when alert is sent.
3. Under **Notification Options**, select the recipients from the drop-down in **Recipient Group**.
4. In **Notify**, the constant value is **Always**.
5. Select how you want to send alerts by clicking **Email** or **SMS**.
6. Click **OK**.
7. To save your changes, click **Save and Apply**.

Customizing the User Interface

You can change how the user interface on your device appears. To change the interface:

1. From the Navigation pane, select **Administration > Web UI Customization**.
2. To define what information appears on the **Administration: Support** page, use the Support group. See [Customizing Support Information](#).
3. To define other settings, use the **Device Settings** group. See [Specifying Device Settings](#).

Customizing Support Information

To customize the interface displaying information that can be used to support users:

1. To enable display of the custom support information, go to **Administration > Web UI Customization > Support Information** and check **Show Custom Info**.
2. Type the desired information into the optional fields including:
 - **Company Name**
 - **Country**
 - **Fax**
 - **Address 1**
 - **Address 2**
 - **City**
 - **State/ Prv**
 - **Zip Code**
 - **City**
3. To add a phone number:
 - a. Click **Add Phone**.
 - b. A label can appear next to the phone number, for example **Fax** or **Phone** or **International**. In the **Label** field, enter text that describes the phone number.
 - c. In the **Number** field, type the phone number.
4. To add a link to a website, click **Add Link**.
 - a. To label the website, type label text in **Label** field.
 - b. In the **URL** field, type the website's link.
 - c. To add further descriptive text about the site, type the information in the **Text** field.
5. To add an image, click **Upload Image:**

- a. Click **Browse**, go to the location of the image, and select the image.
 - b. Click **OK**.
6. To delete an existing image, click **Remove Image**.
7. Click **Submit**.
8. To save your changes, click **Save and Apply**.

Specifying Device Settings

To define other custom settings for devices:

1. Go to **Administration > Web UI Customization > Device Settings**.
2. Enter desired information in the optional fields including:
 - **Device Name**
 - **Custom ID**
 - **Button Color**
 - **Button Font Color**
 - **Highlight Color**
 - **Highlight Font Color**

Note: To define color fields, use **#rrggbb** format.

3. To add a favorite icon, also known as a shortcut icon or bookmark icon, in the **Custom Favicon** field, click **Browse** to find where the Favicon file resides, select the desired file, and click **Upload Icon**.
4. To remove an existing favorite icon, click **Remove Icon**.
5. To add a custom logo, next to the **Custom Logo** field, click **Browse** to find where the logo file resides, select the desired file, and click **Upload Logo**.
6. To remove an existing logo, click **Remove Logo**.
7. Click **Submit**.
8. To save your changes, click **Save and Apply**.

Upgrading Firmware

Before upgrading: reboot the device.

Upgrade the device's firmware to the latest version. You can download firmware upgrades from the MultiTech website or update your firmware automatically through MultiTech's DeviceHQ™ system.

For added security, Signed Firmware Validation is automatically used once it's enabled after upgrading from version 5.1 and higher. This authentication method prevents attempts to load invalid or damaged firmware files in order to defeat possible tampering. The module does not load any firmware that MultiTech did not digitally sign.

First, check your firmware version. Refer to the top of your configuration software window. To upgrade the firmware on your device:

There are two types of device firmware upgrades based on the upgrade file:

1. **Full Firmware Image Upgrade:** When applied, the full firmware update replaces the current firmware image with the new image of the new version.

2. **Differential Firmware Upgrade:** When applied, the current firmware image is updated with the differences between it and the new version, and effectively becomes the new version of firmware. **NOTE:** This type is only available in mPower 5.3 or later.
NOTE: When selecting the appropriate file, the differential upgrade files use diff in the filename. Full upgrade files do not contain diff in the filename.

To upgrade the firmware locally on your device:

1. Before you upgrade your firmware, save your present configuration as a backup. Otherwise, see [DeviceHQ](#).
2. Go to the MultiTech website, locate the firmware upgrade file you want for your device, and download this file to a known location.
3. Select **Administration > Firmware Upgrade**. The Administration: Firmware Upgrade pane opens.
4. Click the **Choose Firmware Upgrade File** button:
 - a. Click **Browse** to find where the firmware file resides that you want to apply.
 - b. Select the file and click **Open**. The file name appears next to the **Choose Firmware Upgrade File** button. Make sure you select the correct BIN file; otherwise, your device can become inoperable.
5. Click **Start Upgrade**.
6. A message about time needed to upgrade appears. Click **OK**. A progress bar appears indicating the status of the upgrade. When upgrade is completed, your device reboots.
7. After the firmware upgrade is complete, verify your configuration to make sure it is what you expected.

Note:

- The new firmware is written into flash memory.
- It may take up to 10 minutes to upgrade the firmware. Do not interfere with the devices's power or press the reset button during this time.
- The DeviceHQ is a cloud platform that provides the ability to remotely manage and upgrade devices. Please see the **Remote Management** section or visit www.devicehq.com for more information.

Saving and Restoring Settings

Before using these settings and features, we recommend you clearly understand their behaviors and effects.

To restore previous configuration settings to your device, to restore settings to their factory or user-defined defaults, or to save the current configuration, see the following.

User-defined Default Settings

When you reset your device to user-defined default settings, the following actions occur:

- Your device restarts, then it restores custom apps if they are present in the configuration, and it reboots the system again
- All settings modified by the user (not saved in the user-defined default configuration) are removed/returned to user-defined default settings
- var/persistent is not erased
- Installed packages are not included in user-defined default configurations but are not deleted (when you reset to user-defined default configuration, they are not restored this way)

Factory Default Settings

When you reset your device to factory default settings, the following actions occur:

- Your device restarts
- User-defined default configuration is deleted (if set)
- All settings modified by the user are removed/returned to factory default settings
- All custom applications are deleted
- All Node-RED applications are deleted
- All installed packages are deleted
- Customer images, favicons, and logos are deleted
- CA certificates are deleted and new certificates are generated
- Your web server's SSL certificate is deleted and a new certificate is generated
- SSH certificates are removed and new certificates are generated

Save and Restore Configuration

1. From the navigation bar, go to **Administration > Save/Restore > Save and Restore Configuration**.
2. To restore a configuration from a previously saved file:
 - a. Next to the **Restore Configuration** field, click **Browse**.
 - b. Navigate to the location where the configuration file is stored and select the desired file.
 - c. Click **Restore**. The device reboots.
3. To save your current configuration to a file:
 - a. Next to the **Save Configuration to File**, click **Save**.
 - b. Navigate to the location where you wish to save the file and select location.

Factory Default

To reset the device's configuration to the factory default settings:

1. Click **Reset**.
2. A dialog box appears prompting you to confirm that you want to restore to factory default settings.
3. Click **OK**.

User-Defined Default

To restore the device to user-defined default settings, you must first set a current configuration as user-defined default.

1. To set deployment-specific default settings as user-defined defaults, under **Set Current Configuration As User-Defined Default**:
 - a. Click **Set**.
 - b. A dialog box appears prompting you to confirm that you want to save the current configuration as user-defined settings.
 - c. Click **OK**.
2. To restore the device's configuration to the user-defined configuration settings, go to **Reset to User-Defined Configuration** under **User-Defined Default**:

- a. Click **Restore**.
 - b. A dialog box appears prompting you to confirm that you want to restore to a set of user-defined settings.
 - c. Click **OK**. The device reboots.
3. To clear user-defined defaults, under **Clear User-Defined Defaults**:
- a. Click **Clear**.
 - b. A dialog box appears asking you if you want to clear user-defined defaults.
 - c. Click **OK**.

Reset Button Configuration

To enable reset to factory default settings:

1. Check **Enable Reset to Factory Default** under **Reset Button Configuration** (enabled by default).
2. Click **Submit**.
3. Then click **Save and Apply** to save your changes. No restart required.

When you enable this option and press the reset button on the device for 5 seconds or more, the device will reset to factory default settings.

To enable reset to user-defined default settings:

1. Check **Enable Reset to User-Defined Default** under **Reset Button Configuration** (disabled by default).
2. Click **Submit**.
3. Then click **Save and Apply** to save your changes. No restart required.

When you enable this option and press the reset button on the device 5 seconds or more, the device will reset to user-defined default settings.

To enable reset of **BOTH** factory default and user-defined default settings:

1. Check both options, **Enable Reset to Factory Default** and **Enable Reset to User-Defined Default** under **Reset Button Configuration**.
2. Click **Submit**.
3. Then click **Save and Apply** to save your changes. No restart required.

To **Reset to User-Defined Configuration**:

When you enable both options and press the reset button on the device for 5 seconds or more, the device will reset to user-defined default settings.

To **Reset to Factory Default Configuration**:

To override user-defined default configurations and restore the device to factory default settings, press and hold the reset button on the device for more than 30 seconds.

To disable **BOTH** factory default and user-defined default settings:

1. Uncheck both options, **Enable Reset to Factory Default** and **Enable Reset to User-Defined Default** under **Reset Button Configuration**.
2. Click **Submit**.
3. Then click **Save and Apply** to save your changes. No restart required.

In this case, the reset button on the device only restarts the device and will not restore it to either factory default or user-defined default settings.

NOTE: Disabling factory default settings will mean there is no mechanism to restore the device to commissioning mode. Once the factory default has been disabled, do not lose track of your access credentials or access to the device will be lost.

Using the Debugging Options

The device has utilities to help troubleshoot and solve technical problems. You can set up your device:

- To automatically reboot itself at a particular time of day or use a particular offset in hours from boot.
- To record and report Syslog messages that can help you resolve potential issues with your device.

You can also communicate directly with the device's cellular radio. To do this:

1. From **Administration**, select **Debug Options**.
2. Click the down arrow to the far right of the Radio Terminal screen to view the terminal window.
3. Enter AT commands to the radio.

See other topics for additional Debug Options:

- Auto Reboot Timer (automatically reboot device)
- Remote Syslog (configuring syslog)
- Ping and Reset Options
- Statistics Settings

See also: [Statistics Configuration Fields](#)

Automatically rebooting the device

To choose a specific time to reboot daily, the amount of time that passes before the device automatically reboots itself, or to disable this function:

1. Go **Administration > Debug Options > Auto Reboot Timer**, select **DAILY**, **TIMER**, or **DISABLED** from the drop-down under **Auto Reboot**.
2. If you chose **DAILY**, enter the **Time** of day you want device to reboot (in HH:MM format).
3. If you chose **TIMER**, enter the Interval (in hours) for the amount of time that passes before the device automatically reboots itself.
4. If you do NOT want the device to automatically reboot, select **DISABLED** (default).

Configuring Remote Syslog

To enable and configure Remote Syslog to capture and send log data from your device, you must have local syslog software installed.

To set up a log request in DeviceHQ, under **Devices**, select your device. Then click on **Tasks** and select **Request Device Logs**. After the request has been completed, return to the device administration software.

Note: If you change **Debug Log Level**, it does not require reboot. However, you must reboot the system in order for the log level in `/var/log/api.log` to be changed.

1. To activate **Remote Syslog**, go to **Administration > Debug Options > Remote Syslog**, check **Enabled**. The **Hostname** is displayed to the right of the enabled box. (**Hostname** can be modified in the **Hostname Configuration** pane under **Setup > Global DNS** page.)

2. To enable a remote server to receive and store the device's log data, under **Remote Syslog**, in the **IP Address** field, type the IP address of the desired server.
3. Select the **Protocol** used to communicate with the remote syslog server from the drop-down including **UDP, TCP, or SSL/TLS**.
4. If you select **SSL/TLS** for **Protocol**, then click **Show** to choose from the following **Security Settings**:
 - a. Check to enable **TLS v1.3, TLS v1.2, or both**.
 - b. Select from any or all of the available Cipher Suites based on the version(s) of TLS that you selected. For TLS v1.3: **TLS_AES_256_GCM_SHA384, TLS_CHACHA20_POLY1305_SHA256, and TLS_AES_128_GCM_SHA384**. For TLS v1.2: **ECDHE-RSA-AES256-GCM-SHA384 and ECDHE-RSA-AES128-GCM-SHA256**. You can also click **Select All**.
5. Enter the desired **Port** number that the remote syslog server uses.
6. To determine the amount of log information that is collected, under **Logging**, in the **Debug Log Level**, select the type of information from the values in the dropdown menu which includes: **Minimum, Error, Warning, Info, Debug, and Maximum**. The system will collect the type of information you specify. For example, **Maximum** will collect all the log data available while **Warning** will collect anything that is a warning or above that level.
7. To download syslog information directly from the device, click **Download Logs**.
8. Click **Submit**.
9. To save your changes, click **Save and Apply**.

Statistics Settings

To configure **Statistics**:

1. Go to **Administration > Debug Options > Statistics**.
2. Enter the **Save Timeout** in seconds.
3. Enter the **Save Data Limit** in megabytes.
4. Click **Submit**.
5. To save your settings, click **Save and Apply**.

Statistics Configuration Fields

The device saves the statistics periodically depending on the configured timeout and data limit. By default, the Save Timeout is set to 300 seconds and the Data Limit is set to 5 MB. For the default scenario, the device saves the data if more than 5 minutes has elapsed, or if more than 5 MB has been sent or received from the last check. The device checks these conditions every minute, but the data is saved only if one of the conditions is met.

| Field | Description |
|-----------------|--|
| Save Timeout | The device saves the statistical data when the desired timeout period has elapsed. Default is 300 seconds (5 minutes). |
| Save Data Limit | The device saves the statistical data if the data limit is reached. Default is 5 MB. |

Ping and Reset Options

Perform a Ping Test

Ping allows you to test the IP address or URL to ensure it is operational. This feature is not available in PPP-IP Passthrough mode.

To perform a ping test:

1. Go to **Administration > Debug Options > Ping**.
2. Enter the **IP address or URL** of the site you wish to ping.
3. Enter the **Number of Requests** to set the number of ping requests.
4. To forbid fragmentation, check **Do Not Fragment**. Without fragmentation, the ping fails if the ping packet exceeds MTU size for the network path. By default, the option is disabled.
5. Under **Network Interface**, choose from the available drop-down menu options including: **ANY, BRIDGE, CELLULAR, WI-FI WAN, WI-FI AP, ETHERNET (ETH0)**. (Available interfaces vary with hardware model.)
NOTE: When using Serial Modem Mode, only the following interfaces are available: **ANY, BRIDGE (BR0) and ETHERNET (ETH0)**.
6. Enter the **Packet Size** (in bytes). This specifies the number of data bytes to be sent. The default is 56, which translates into 84 bytes of data when combined with 8 bytes of ICMP header and 20 bytes of IP header. When specifying 0 bytes, the actual packet size is 28 bytes (ICMP header and IP header).
7. Click **Ping**.

Perform a Continuous Ping

Continuous ping is not available in PPP-IP Passthrough or Serial Modem mode. To perform a continuous ping:

1. Enter the IP address or URL of the site you wish to continuous ping.
2. Enter Packet Size (in bytes). This specifies the number of data bytes to be sent.
3. To forbid fragmentation, check **Do Not Fragment**. Without fragmentation, the ping fails if the ping packet exceeds MTU size for the network path. By default, the option is disabled.
4. Under **Network Interface**, choose from the available drop-down menu options including: **ANY, BRIDGE, CELLULAR, WI-FI WAN, WI-FI AP, ETHERNET (ETH0)**. (Available interfaces vary with hardware model.)
5. Click **Start Continuous Ping** to kick off the continuous ping. The system displays a message that ping is in progress.
6. The button changes to **Stop Continuous Ping**. Click the stop button to end the ping. Once done, the system displays the ping results.

Reset Options

For various reset options, go to **Administration > Debug Options > Reset Options**:

- To reset the modem, click **Reset Modem**.
- To reset Wi-Fi, click **Reset Wi-Fi**.
- If you use a Verizon SIM only, click **Reset Class 3 APN (Verizon)** to initiate the OMA DM procedure, retrieve APN settings from Verizon, and apply them automatically to your modem settings.
- To reset Bluetooth, click **Reset Bluetooth**

Usage Policy

The device shall provide a Usage Policy for the system. The default usage policy reads as follows:

This system is for the use of authorized users only. Individuals using this system without authority, or in excess of their authority, are subject to having all their activities on this system monitored and recorded by system personnel.

Anyone using this system expressly consents to such monitoring and is advised that if such monitoring reveals possible evidence of criminal activity, system personnel may provide the evidence of such monitoring to law enforcement officials.

This policy displays on the login page. You may modify or add language to the policy as needed.

To view or modify the **Usage Policy**:

1. Go to **Administration > Usage Policy**.
2. The default language appears. You may edit the language directly in the text box.
3. When completed, click **Submit**.
4. To save your changes, click **Save and Apply**.

If at any time you want to return the device to the default setting, click the **Reset to Default** button in the bottom right corner. (This reverts the **Usage Policy** back to the default language.)

Chapter 11 – Status & Logs

Viewing Device Statistics

The device collects sent/received traffic data for WAN, Cellular, and Ethernet networks. The daily statistical data is stored on the device for a 365-day period. All data that is older than 365 days is automatically deleted.

1. From **Status & Logs** on the left side of the Web Management interface, select **Statistics**.
2. The application categorizes statistics about your device. To see statistics that appear in a particular category, click the appropriate tab.

System

Ethernet

Wi-Fi

Access Point

Cellular

Serial

Bluetooth

GRE

IPSec

OpenVPN

Definitions

A data usage bar chart and a cumulative usage line chart are available for Ethernet, Wi-Fi, and Cellular. The Data Usage bar chart also shows statistics for data sent and data received. The following list includes some definitions to help you understand some of the data. Not all of the available statistics are listed here or shown in every tab.

- **Total:** Total number of sent/received bytes for a 365-day period.
- **Today:** Total number of sent/received bytes for today.
- **Sessions:** Bytes.
- **Packets:** Number of successfully transmitted (TX) and received (RX) packets.
- **Errors:** Number of errors that occurred. Possibly due to connection issues or network congestion.
- **Dropped:** Number of dropped packets. Possibly due to memory constraints.
- **Overruns:** Number of overruns that occurred. Possibly due to processing constraints.
- **Frame:** Number of invalid packets.
- **Carrier:** Number of signal modulation errors that occurred (possibly due to physical connection).
- **Collisions:** Number of packet collisions that occurred due to network congestion.
- **Queue Length:** Length of the transmit queue.
- **MTU (Maximum Transmission Unit):** the maximum size of packet content (Bluetooth only).
- **ACL (Asynchronous Connection-Less):** the typical protocol used for data packets (Bluetooth only).
- **SCO (Synchronous Connection-Oriented):** the typical protocol used for voice (Bluetooth only).
- **Events:** Number of events that occurred on a Bluetooth connection (Bluetooth only).
- **Commands:** Number of commands given to devices on a Bluetooth connection (Bluetooth only).

Cumulative and Daily Usage

Click **Show Cumulative Usage** or **Show Daily Usage** to display the desired view. Default chart view is Daily Usage for 30-day period.

Timeframe of Chart

Change the time frame for the chart by clicking **Start Date** or **End Date** using calendar to set a different date.

Show Log

The associated run-time logs for this section.

Service Statistics

On the Web Management interface side menu, click **Status & Logs > Services** to display the **Service Statistics** window. This window shows the configuration (enabled or disabled) and the status of the following services:

- **DDNS**
- **SNTP**
- **TCP/ICMP Keep Alive**
- **Dial-on-Demand**
- **SMTP**
- **SMS**
- **Failover**
- **SNMP Server**
- **Security Violation**
- **Reverse SSH Tunnel**
- **Remote Management**
- **Continuous Ping**

Mail Log

Mail Log shows the recent email delivery attempts and the mail log details. Mail log entries are sorted by date with the most recent on top. You can select the number of emails to display in the mail log. Possible values are **10, 25, 50, or 100 emails**.

This function is not available if you use **PPP-IP Passthrough** or **Serial Modem** mode.

1. Go to **Status & Logs > Mail Log** to display the **Mail Log** window.
2. To see the delivery details, click the eye icon under **Options** for the desired email entry.
3. To delete all mail log entries, click **Purge Log**.

Note: Logs do not persist through power cycles.

Mail Queue

Mail Queue shows the emails that are waiting to be sent. The most recent email delivery attempts are on top. You can select the number of emails to display in the queue. Possible values are **10, 25, 50, and 100 emails**. **Note:** Logs do not persist through power cycles.

This function is not available if you use **PPP-IP Passthrough** or **Serial Modem** mode.

1. Go to **Status & Logs > Mail Queue** to display the **Mail Queue** window.
2. To view the delivery details for an individual email, click the eye icon under **Options** for the desired email entry.

Notifications Sent

This page displays attempts to send Notifications via email, SMS, or SNMP.

The list includes the following details of each attempted notification: **Date**, **Message**, **Recipient Group**, and the status of the notification under each communication method including **Email**, **SMS**, and **SNMP**. A check indicates success via that method. An **X** means failure. No symbol or a blank space indicates that method was not attempted.

To view **Notifications Sent**:

1. Go to **Status & Logs > Notifications Sent**.
2. In the upper right corner, click **Refresh** to update the list.
3. To the right of **Refresh**, click **Delete All Notifications** if you want to remove all items in the list.

Chapter 12 – Apps

Manage Apps

The **Manage Apps** screen under **Apps** provides information on installed custom applications including the status and version of all the installed applications.

NOTE: For the MTR router, we recommend a maximum application size of up to 4MB. Larger applications may encounter problems on this device.

You must have your MTR router configured for **Network Router Mode** during **First-Time Setup** to use **Apps**. Otherwise, if you have configured your device to either **PPP-IP Passthrough** or **Serial Modem Modes**, **Apps** will not be available.

Custom Apps

Check **Enabled** to enable custom applications.

Uncheck **Backup On Install** if you do not want to backup the currently running application while installing a new version of the application. When checked, the backup is re-installed if the installation of a new version of the app fails.

After you make changes to **Backup On Install** (enable or disable), click **Save and Apply**.

The **Custom Apps** section contains the list of custom applications currently installed on the device. Each listing contains the information for a particular application including the **name, version, status, and info** of the application. The status value can be **Started, Running, Stopped, Failed, Install Failed, and Start Failed**.

Refer to [Creating a Custom Application](#) on the MultiTech Developer Resources website for complete instructions on developing, installing, and deploying custom applications.

The device reboots after enabling or disabling this feature.

To install a new Custom app, click **Add Custom App**:

1. In the **App ID** field, enter Application ID.
2. In the **App Name** field, enter Application Name.
3. Click **Browse**, go to the location of the custom app, and select the file.
4. To install the app, click **Install Custom App**.

After any changes to this section, click **Save and Apply** to apply those changes.