

Trouble Shooting for Mimiuo Pizza Oven

Problem	Possible Cause	Prevention/Solution
Burner will not light	<ol style="list-style-type: none"> 1. No gas flow 2. Coupling nut and regulator not fully connected 3. Obstruction of gas flow 4. Disengagement of burner to valve 5. Incorrect assembly 	<ol style="list-style-type: none"> 1. Check to see if propane tank is empty. 2. Turn the coupling nut about one half to three quarters additional turn until solid stop. Tighten by hand only - do not use tools 3. Clear burner tube. 4. Reengage burner and valve. 5. Check steps in assembly Instructions.
Flame cannot be maintained, once the knob is released, the flame will extinguish	<ol style="list-style-type: none"> 1. Carbon deposits on the surface of thermocouples 2. Excessive distance between the thermocouple affects gas sensing 	<ol style="list-style-type: none"> 1. With the oven cooling down, extend your hand into the oven and gently wipe the thermocouple head with a tissue or small cloth 2. Simply press the thermocouple inside the oven gently to adjust its position as close as possible to a certain outlet on the burner.
Sudden drop in gas flow or low flame	<ol style="list-style-type: none"> 1. Out of gas 	<ol style="list-style-type: none"> 1. Check for gas in propane tank. 2. Turn off gas control knob, wait 30 seconds and light oven. If flames are still low, turn off gas control knob and propane tank valve. Disconnect regulator. Reconnect regulator and leak test. Turn on propane tank valve, wait 30 seconds and then light oven.
Flames blow out	<ol style="list-style-type: none"> 1. High or gusting winds 2. Low on propane gas 	<ol style="list-style-type: none"> 1. Turn front of oven away from Wind. 2. Refill propane tank. 3. Refer to Sudden drop in gas flow Above.
Flare-up	<ol style="list-style-type: none"> 1. Grease build up 2. Excessive fat in meat 3. Excessive cooking temperature 4. Excess flour on the cooking surface 	<ol style="list-style-type: none"> 1. Clean oven. 2. Trim fats from meat before cooking. 3. Adjust (lower) temperature accordingly. 4. Brush remnant flour from cooking surface.

Flashback (fire in burner tube, roaring sound from burner)	<ol style="list-style-type: none"> 1. Burner and/or burner tubes are blocked 2. Pressure drop during ignition 	<ol style="list-style-type: none"> 1. Turn gas control knob off. Clean burner and/or burner tubes. 2. Turn off oven, ensure the tank valve is fully open (if applicable) and relight.
Turntable not working or not rotating smoothly	<ol style="list-style-type: none"> 1. The surface of the shaft is not smooth enough 	<ol style="list-style-type: none"> 1. Add some oil as or lubricant on the shaft, wait for the lubricant to slowly flow down the shaft, and then use it again.