

TROUBLESHOOTING GUIDE

PROBLEM	CAUSE	SOLUTION
<p><u>SAFE IS BEEPING</u></p> <p>Safe won't Stop Beeping, you Can't Press Any Buttons on the Electronic Keypad or Use any Registered Fingerprint on the Biometric Scanner.</p>	<p><u>LOCKOUT MODE</u></p> <p>This is a built in Safety Feature called Lockout Mode that's caused by 4 wrong entry attempts in a row to prevent burglars from guessing your code.</p>	<p><u>WAIT 5 MINUTES</u></p> <p>With power added to safe, wait 5 minutes for beeping to stop. Retry your code/fingerprint or reset your safe back to default settings by holding down registration button.</p>
<p><u>SAFE WON'T OPEN</u></p> <p>Buttons can be pressed, scans fingerprint and clicks to unlock but the safe door doesn't open. Short red flash after entry attempt on keypad or scanner.</p>	<p><u>LOW BATTERY</u></p> <p>This means the battery you have installed in the safe is low and doesn't have enough power to open the door of the safe.</p>	<p><u>REPLACE BATTERY</u></p> <p>You will need to open the safe with the override key or plug in the power cable and enter your code. Then replace the battery with a brand new Duracell Coppertop 9V Battery.</p>
<p><u>OPENS ON ANY FINGERPRINT</u></p> <p>The Safe Opens on ANY Fingerprint placed on the Biometric Scanner.</p>	<p><u>NO REGISTERED FINGERPRINTS</u></p> <p>This is a Default Factory Setting that will allow you to enter the safe for the first time using the biometric scanner.</p>	<p><u>REGISTER FIRST FINGERPRINT</u></p> <p>You need to successfully register your first fingerprint - Press (do NOT hold) the registration button on the inside of the safe & place your finger on biometric scanner.</p>