
Length Adjustment Step 1

HEAVY JUMP ROPE



Disassemble one handle to adjust rope length: Unscrew Handle from Handle Hub by rotating it left. Set aside the Handle to reassemble after adjustment.





Phillips-head

Screw

HEAVY JUMP ROPE

