

Wireless Smart Wrist Receiver/Pager

User Manual

1.Description

The Wireless Wrist Pager can configure multiple call keys (up to 999pcs) to cater for personal, family, hospital, nursing home and communities caregiver alert, And for restaurant waiter / waitress services call alert. And for office alert.

Use Tips

- 1)one call Button be paired multiple receivers at the same time
- 2)the paging system just one-way, for example the customer press the button ,then the waitress will go to know what's they need
- 3)you even can use wireless call system play games at party(like jeopardy),exciting your Imagination fully
- 4)If the wireless signal range is decreased, please replace the battery of call button


2.Component





Key Description:


Short press: Press about 1 second;

Long press: Press about 3 seconds.

[]:Setup Key . Long press to enter the system setting menu in standby; in submenu, short press will be enter next level of the menu.

[]:Up Key . Press to turn up .

[]:Down Key . Press to turn down .


[]: In call state, short press to clears the current call information; in setting state, short press to return to the upper menu.



[USB Port]: USB plug and charge.

[Indicator Light] :In call state, the green light will flash.

3.Operation







Turn On/Off

Turn On: In power off state, long press [] key until the screen light.






Turn Off: In power on state, long press [] key, then press [] .

3.1 Add / Delete buttons

3.1.1 Add buttons




In standby, long press [] key to enter system settings menu, press the [] key to reach to "Add buttons", then press the [] key to enter the button registration. the user can press the [] key to select relevant number to register, long press the [] key to shift the bit . Each number can add one or more buttons, After selecting the number, and the screen display " Trigger buttons", then the user can press the button , this watch will beep after receiving the signal from the button, mean add successfully, press [] key to adjust the number if you want to add the next button.

3.1.2 Delete buttons

In standby, long press [] key to enter system settings menu, and press the [] key to reach to "add buttons", then press the [] key to enter the transmitters registration. Press the [] key to find the number where the button needs to be deleted, and press [] key once to remove the last transmitter you paired. Or use the "Default Set" submenu if you want to delete all transmitters.




3.2 Key Define

Key Define is used to Re-name the key on button which have been paired.





In standby, long press [] key to enter system settings menu, and press the [] key to reach to "Key define", then press the [] key to enter the key define setting . Trigger the key on button when the "call" is displayed in the screen, the "di" sound of the watch and the display of "successfully" means the setting is successful. you can set the "Order, Call, Pay, Cancel, Service, Water, Coffee, Juice, Positive, Negative, Medicine, SOS, Needle, Doctor, Sweep, Bill". In the same way, when the desired name or function is displayed on the screen, trigger the corresponding name or function key of the transmitter.

Note: if you need to set the key function of a transmitter, you must first learn the transmitter before setting the key function of the transmitter.




3.3 Alarm Clock

In standby, long press [] key to enter system settings menu , and press the [] key to reach to "Alarm Clock" submenu, then press the [] key to enter the alarm clock setting.






1. Add Alarm Clock

Press the [] key shows "+add", and press the [] key to move the cursor to hour, minute, week, then press the [] key to adjust the value. Press the [] key to exit. up to 10 groups of timing can be set.






2.Delete Alarm Clock

Press the [] key to move the cursor to a corresponding group to delete, then long press the [] key to delete the selected group of timing. Press the [] key to exit.






3.4 Date & Time

In standby, long press [] key to enter system settings menu , and press the [] key to reach to "Date & time" submenu, then press the [] key to move the cursor to minute, second, year, month, day, press the [] key to adjust the time. Press the [] key to exit.






3.5 Prompt Setting

In standby, long press [] key to enter system settings menu , and Press the [] key to reach to "Prompt mode" submenu, then press the [] key to enter the prompt mode setting. Press the [] key to select the desired prompt mode, press the [] key to exit (total 4 modes: ring + vibration, vibration, ring, mute.)






3.6 Prompt Times

In standby, long press [] key to enter system settings menu , and press the [] key to reach to "Prompt times", then press the [] key to enter the prompt times setting. Press the [] key to select the desired number of prompt times, press the [] key to exit (The default is 9 times).






3.7 Screensaver

In standby, long press [] key to enter system settings menu , and press the [] key to reach to "Screensaver", then press the [] key to enter the screensaver setting. Press the [] key to select the desired screensaver time, press the [] key to exit (The default is 15 seconds).




3.8 Language

In standby, long press [] key to enter system settings menu , and press the [] key to reach to “Language”, then press the [] key to enter the language setting. Press the [] key to select the desired language, then press [] to exit.





3.9 Timer

In standby, long press [] key to enter system settings menu , and press the [] key to reach to “Timer”, then press the [] key to enter the Timer setting . Press the [] key to select timing time, press the [] key to exit.




4.0 Power Timer

In standby, long press [] key to enter system settings menu , and press the [] key to reach to “Power Timer”, then press the [] key to enter the Power Timer setting .






1 . Add Power Timer

Press the [] key shows "+add", and press the [] key to move the cursor to hour, minute, week, and timer on/off, press the [] key to adjust the value. Press the [] key to exit , up to 10 groups of timing can be set.






2 . Delete Power Timer

Press the [] key to move the cursor to a corresponding group to delete, then long press the [] key to delete the selected group of timing. Press the [] key to exit .








4.1 System Number

In standby, long press [] key to enter system settings menu, press the [] key to reach to “System Number” , then press [] to enter the system number setting . Press the [] key to select the desired system number, then press the [] key to exit(The system number will be display in the upper left of the desktop, used to distinguish watches).

4.2 Auto Clear Time









In standby, long press [] key to enter system settings menu, press the [] key to reach to “Auto Clear Time” , then press [] to enter the auto clear time setting . Press the [] key to select the desired automatically clear the call information time, then press the [] key to exit (The default is 0 seconds, not automatically cleared).

4.3 Timeout Prompt








In standby, long press [] key to enter system settings menu, press the [ / ] key to reach to “Timeout Prompt”, then press [] key to enter the timeout prompt time setting . Press the [ / ] key to select the desired timeout prompt time, then press the [] key to exit (The default is 0 seconds, timeout not prompted).

Note: Timeout prompt time means the call information will be prompted again when it exceeds the set time.






4.4 Default Set

In standby, long press [] key to enter system settings menu, and press the [ / ] key to reach to “Default Set”, then press the [] key to enter the default setting . Press the [ / ] button to select the desired default item, press the [] key to select, move the cursor to “ok”, and press the [] key to confirm and start restoring the factory default.

4.5 Call Log

In standby, long press [] key to enter system settings menu , and press the [ / ] key to reach to “Call log”, then press the [] key to enter the Call log. Press the [ / ] key to query the call log, press [] to exit.

4.6 About Me

In standby, long press [] key to enter system settings menu , and press the [ / ] key to reach to “About Me”, then press the [] key to enter the about me setting . Query version, update date, press [] to exit.

Cautions

The host can not receive calls in the Settings state.

Specification of Pager


1. Supply voltage: DC3.7V (Rechargeable battery)
2. Working current: <4mA
3. Standby current: <50μA
4. Working frequency: 433.92MHz

- 5.Call range: 300m (open space)
- 6.Ambient temperature: -20°C — 55°C
- 7.Product size: 61×41×14mm(Not including watch strap)

Specification of Call Button

- 1.button battery: 23A 12V alkaline battery (included)
- 2.button Waterproof Standard: IPX5
- 3.button Size: Diameter 2.4 inch, thickness 0.7 inch
- 4.button with built-in antenna

How to Attach Strap and Replace Battery of Call button



Trouble shooting

Malfunction	Cause	Solution
1. Press the transmitter, the watch does not respond	1.The transmitter is not registered 2.The transmitter is lower battery 3.Airplane mode enabled	1. Add transmitter (refer to Add buttons) 2. Replace the battery of transmitter 3. Disable airplane mode (refer to Airplane Mode)
2.Short range	The transmitter is lower battery	Replace the battery of transmitter
3.No vibrate or no sound when get a in-call	Not setup calling prompt	Enter prompt setting menu to setup (refer to Prompt Mode)
4.Transmitter of other manufacturers does not display function well	Key value does not match	Rematch the key value (refer to Keys define)
5.Automatically shut down	1. Power is too low 2. Setup power timer	1.Please charge 2.Delete unnecessary power timer (refer to Power Timer)