

Safety First: This document provides all the necessary information to allow your Whelen product to be properly and safely installed. Before beginning the installation and/or operation of your new product, the installation technician and operator must read this manual completely. Important information is contained herein that could prevent serious injury or damage.

- Proper installation of this product requires the installer to have a good understanding of automotive electronics, systems and procedures.
- Whelen Engineering requires the use of waterproof butt splices and/or connectors if that connector could be exposed to moisture.
- Failure to use specified installation parts and/or hardware will void the product warranty!
- If mounting this product requires drilling holes, the installer MUST be sure that no vehicle components or other vital parts could be damaged by the drilling process. Check both sides of the mounting surface before drilling begins. Also de-burr any holes and remove any metal shards or remnants. Install grommets into all wire passage holes.
- Do not install this product or route any wires in the deployment area of your air bag. Equipment mounted or located in the air bag deployment area will damage or reduce the effectiveness of the air bag, or become a projectile that could cause serious personal injury or death. Refer to your vehicle owner's manual for the air bag deployment area. The User/Installer assumes full responsibility to determine proper mounting location, based on providing ultimate safety to all passengers inside the vehicle.
- For this product to operate at optimum efficiency, a good electrical connection to chassis ground must be made. The recommended procedure requires the product ground wire to be connected directly to the NEGATIVE (-) battery post.
- If this product uses a remote device to activate or control this product, make sure that this control is located in an area that allows both the vehicle and the control to be operated safely in any driving condition.
- Do not attempt to activate or control this device in a hazardous driving situation.
- This product contains either strobe light(s), halogen light(s), high-intensity LEDs or a combination of these lights. Do not stare directly into these lights. Momentary blindness and/or eye damage could result.
- Use only soap and water to clean the outer lens. Use of other chemicals could result in premature lens cracking (crazing) and discoloration. Lenses in this condition have significantly reduced effectiveness and should be replaced immediately. Inspect and operate this product regularly to confirm its proper operation and mounting condition. Do not use a pressure washer to clean this product.
- **WARNING!** All customer supplied wires that connect to the positive (+) terminal of the battery must be sized to supply at least 125% of the maximum operating current and **FUSED** "at the battery" to carry that load. **DO NOT USE CIRCUIT BREAKERS WITH THIS PRODUCT!**
- **FAILURE TO FOLLOW THESE PRECAUTIONS AND INSTRUCTIONS COULD RESULT IN DAMAGE TO THE PRODUCT OR VEHICLE AND/OR SERIOUS INJURY TO YOU AND YOUR PASSENGERS!**

Mounting

1. Place the unit against the mounting surface.
2. Mark the areas where the mounting holes are to be drilled. Confirm that no vehicle parts could be damaged by the drilling process.
3. Using a bit sized for a #6 sheet metal screw, drill two mounting holes. A 0.375" dia. wire passage hole(s) must also be drilled. Thoroughly de-burr all hole(s).
4. Route the wires through the hole(s) in the gasket and through the wire passage hole(s) in the mounting surface. Secure the lighthouse to the mounting surface using the hardware provided.

Wiring

See illustration below for wiring information

WARNING! All customer supplied wires that connect to the positive terminal of the battery must be sized to supply at least 125% of the maximum operating current and FUSED at the battery to carry the load. DO NOT USE CIRCUIT BREAKERS WITH THIS PRODUCT!

Operation

Scan-Lock™ - Each flash pattern is available in two modes; Phase 1 & Phase 2. The patterns are controlled with the WHT/VIO wire.

To advance to the next pattern, apply +VDC to the WHT/VIO wire for less than 1 second. To cycle backwards, apply +VDC for more than 1 second.

To reset to the factory default pattern, turn off power to the lighthouse and while applying +VDC to the WHT/VIO, turn the lighthouse back on. Continue to apply voltage for 5 seconds.

Waterproof butt splices and/or connectors are required if that connection could be exposed to moisture. Any unused wires must be sealed (waterproofed) to prevent moisture infiltration.

Lighthouses configured to display the Phase 1 mode of a pattern will flash simultaneously. Any lighthouses configured to display the Phase 2 mode will alternate with any Phase 1 lighthouses with the same pattern.

Available Scan-Lock™ Patterns:

SYNC Flash Patterns:

1. SignalAlert™ 75 Phase 1
2. SignalAlert™ 75 Phase 2
3. CometFlash@ 75 Phase 1
4. CometFlash@ 75 Phase 2
5. DoubleFlash 75 Phase 1
6. DoubleFlash 75 Phase 2
7. SingleFlash 75 Phase 1
8. SingleFlash 75 Phase 2
9. ComAlert™ 75 Phase 1
10. ComAlert™ 75 Phase 2
11. LongBurst™ 75 Phase 1
12. LongBurst™ 75 Phase 2
13. PingPong™ 75 Phase 1
14. PingPong™ 75 Phase 2

Regular Flash Patterns:

15. SingleFlash 60
16. SingleFlash 90
17. SingleFlash 120
18. SingleFlash 300
19. DoubleFlash 150
20. ComAlert™ 150
21. ActionFlash™ 1
22. ActionFlash™ 2
23. ModuFlash™
24. ActionScan™
25. Steady

Sync - To sync two lighthouses, configure both lighthouses to display the same Phase 1 pattern. With the power off, connect the GREY wires from each lighthouse together. When the lighthouses are activated, their patterns will be synchronized. To configure the two lighthouses to alternate their patterns, advance the pattern of either lighthouse to the Phase 2 mode of the current pattern.

To understand how to use the sync feature with more than two lighthouses, the principles will be applied to a sample system consisting of 4 lighthouses with 2 mounted on the rear, driver-side and 2 mounted on the rear, passenger-side. With all the wiring complete, turn on all 4 lighthouses. As shipped from factory, the lighthouses will all display SignalAlert™ Phase 1. To configure one side to alternate with the other side, change the pattern for either the passenger or driver side to Phase 2 mode for that pattern.

