
## HPOP to Heads Hoses (see notes)

#1- (2 qty) Straight -06\* (larger)
HPOP o-ring fittings\* (see note
below)
#2- (1qty) Double 90 degree HPO

#2- (1qty) Double 90 degree HPOP to Passenger Side head hose\*\*.
#3- (1qty) Straight + 90 degree HPOP to Drivers Side head hose (reversable if desired as shown)\*\*\*
#4- (2qty) straight -05\*\* (smaller) o-ring fittings for HPOP hose end to head connections



end fittings AFTER
desired fitment is

achieved.

Start threads by hand to prevent cross threading.

Diagram is for general referance only. Avoid tight bends and contact with sharp metal.

\*You need to remove the spring/check valves behind the old fittings from the pump (very common modification)

\*\*Passengers side line will run UNDER most wiring harnesses. Snake hose in a "U" shape to acheive correct mounting configuration. If hose is not lining up DO NOT FORCE.

Reroute it so it mates properly to attaching fittings! Hold in position when tightening.

Crossover hose (If also ordered)


front head ports. ś, #5- Cross up with head fittings. "u" shape and slight #4- (2qty) straight -05 w/ 45 degree crimped Installed on 3rd from o-ring fittings on fittings configured in a slight Note: Hose Assembly 1qty) hose assembly to correctly meet over Line can be

\*\*\*Route hose outside the engine lift eyelet if installed as shown. If not possible on your application, then reverse hose ends and use OEM path.

\*\*HPOP o-ring fittings are slightly larger than the -05 o-ring head fittings.

Use (2) -06 o-ring fittings at pump!!

HPOP Hoses Do not over 28 tighten fittings or damage to threaded parts & sealing surfaces will likely result. Shown Below. Tighten Hose End fittings AFTER attaching to their proper locations.



lighting and patience especially with the Passengers side HPOP hose. Please pay close attention Vehicle" installations will require routing the hoses with the hose end fittings in the picture above. other engine componets H. place. to S the angle of e adequate