



JUICE VORTEX









by ZULAY ✕ KITCHEN



Yes it really juices all this fruit!



CONTENTS

	Safety Information	1
	Product Orientation	2
	Instructions	3
	Juicing Tips	4
	Cleaning & Maintenance	5
	Troubleshooting	6
	Product Specifications	7
	Warranty Information	8



JUICE VORTEX

by ZULAY ✕ KITCHEN



PRODUCT ORIENTATION

This rechargeable juicer takes about 1.5 hours to fully recharge. It is portable and can juice about 25-30 oranges per charge. It can also juice apples, pomegranates, pears, melons, kiwi, and more!

Below is a diagram of your juicer with the name of each part. You can refer to this when studying the rest of this manual.



PRODUCT SPECIFICATIONS

Product Name: Vortex Juicer
Size: 5.5" x 4.3" x 9.3"
Net Weight: 2.1 lbs
Rated Voltage: 7.4V
Rated Current: 6A
Rated Power: 45W
Charge Mode: USB
Charging Requirements: 5V 1A



LIFETIME WARRANTY REGISTRATION



JUST A FEW STEPS AWAY:



Open the Camera App on your phone



Point to the code and focus your camera on the code



Click the notification that pops up*

*If you're having trouble download a QR Code App or go to this link:
ZULAYKITCHEN.COM/WARRANTY

Lifetime Warranty and Satisfaction Guarantee

We believe in our product so much that if for any reason you are not fully satisfied, we will make it right with a replacement or refund without you ever having to go to the post office. To register and for full details, go to: www.zulaykitchen.com/warranty

If you have a question or need support, let us know.

(727) 386-9117 Mon-Fri 9:00 AM - 5:00 PM (EST)

support@zulay.net

Follow us on Social Media

@zulay_kitchen @zulaykitchen Zulay Kitchen

SAFETY INFORMATION

- This product is suitable for personal use.
- Never place the base in the dishwasher or any other body of water, or in a location where it could be exposed to water such as rain. Doing this could destroy the internal electronics and cause electrocution. If you need to clean the base, simply wipe with a damp cloth to remove any mess.
- When the juicer is in operation, do not remove the lid or juice cup. Remove the lid or cup before juicing or after the juicing cycle is complete.
- Clean the cup body, reamer and cover after use to maintain good hygiene. Wash by hand with hot water and soap, rinse with clean water and then dry before storing.
- Empty the juicer once your juice has reached the max line. This is done by simply opening the juice outlet with your cup under the spout. You may then close the spot and continue juicing. Doing this prevents a mess from being created and damage being done to the juicer.
- If the juicer is inactive for five minutes, the machine will turn off automatically. The indicator light around the button will turn off, showing that the machine is now off. To continue juicing simply press the button again.
- If the cover shakes while juicing, do not be concerned. This is normal.

TROUBLESHOOTING

Unit Not Starting: Ensure you are pressing the Power Button for at least 2 seconds to turn it on. If this does not work, either the battery power is exhausted or the unit is not assembled correctly. Check that it is properly assembled. If this does not solve it, recharge the unit fully.

Stops Mid Operation: The fruit could be too big and needs to be cut into smaller pieces. The battery's power could be exhausted and need recharging. Or the fruit is too hard and the machine has become stuck, in which case you will need to turn off the juicer and remove the hard fruit pieces.

Strange Noises in Operation: This could be from the unit not being assembled correctly, or the unit being placed on an uneven surface. Check that the unit is assembled correctly, and that it is on a flat surface.

Juice Spills From Top: This can be caused by too much fruit at one time, or by the top cover not being correctly placed. Make sure the cover is secure, and otherwise reduce the amount of fruit you are juicing at one time.

Flashing Red Indicator Light: When the red indicator light flashes for about 20 seconds, this indicates that the battery is low. Recharge the unit after your current juicing cycle.

Red Indicator Light On for 5 Seconds Then Turns Off: This indicates that the motor is blocked. Remove the fruit that has caused the blockage.

No Indicator Light When Charging: If the indicator light is not turned on when charging, this means that the unit is not connected properly. Simply check the charging cable and make sure it is attached correctly in the USB port on the Juicer and/or the outlet that you are using. If done correctly, the Indicator light should turn on showing that the Juicer is now charging.

INSTRUCTIONS



1. Assemble the unit per the instructions in the ASSEMBLY section.



2. Prepare the fruit for juicing, following the JUICING TIPS section. Put your fruit inside the juicer. Place any fruit that has been cut in half with the cut side facing down. Do not overfill.



3. Secure the cover. Press and hold the Power Button for about 2 seconds to turn on the unit.



4. Press the Power Button to start the juicing process. Once the cycle is done, remove any peels as needed from the juicer and repeat. Do not overfill past the Max Line.



5. Place your glass under the juice outlet and open it, allowing the juice to pour out. Close it when done. Continue making more juice as desired by repeating steps 4 & 5.



6. When done, turn the unit off by pressing and holding the Power Button for 5 seconds. It will also automatically turn off after 5 minutes. Clean and dry the unit before storing.



For smaller fruit like grapes, simply place the small fruit into the top of the juicer. There is no need to cut the fruit into smaller piece, just ensure that the Juicer does not get overloaded and the top can lock into place properly.

For medium-sized fruit like oranges, apples, pears, kiwis, etc., cut in half. Place this with the cut side facing down in the juicer.



For larger fruit such as grapefruit or pomegranates, cut into 4 or more pieces.

For oversized fruit like watermelon, cut into smaller pieces without the rind and place in the juicer.



Clean the unit after use to maintain hygiene.



If the base needs to be cleaned, simply wipe it with a damp cloth to remove any mess.



To clean the other parts (cover, reamer, cup), wash by hand with hot water and mild dish soap. Rinse and dry. Do not use abrasive cleaners or scrubbers. Ensure all parts are fully dry before storing.

If the unit is not used for a longer period, recharge the unit after about 3 months. This will help maintain the battery's life.