

# ZULAY KITCHEN



## ONE YEAR LIMITED WARRANTY

This product is warranted to the original purchaser for one year from the date of purchase, against manufacturer's defects under normal use. Additionally, our top-notch customer service team can help you with any questions or issues. For full details, scan the QR Code.

### JUST A FEW STEPS AWAY:



Open the Camera App on your phone



Point to the code and focus your camera on the code




Click the notification that pops up\*

\*If you're having trouble, download a QR Code App or go to this link:  
<https://www.zulaykitchen.com/warranty>

## We Are Here For You

If you have a question or need support, let us know.

Zulay Kitchen: Clearwater, Florida, USA

 +1(727) 386-9117

 Mon-Fri 9:00 AM - 5:00 PM (EST)

 [support@zulay.net](mailto:support@zulay.net)



## *Instruction Manual*

# CONTENTS

## PAGES

SAFETY INFORMATION .....	.01-02
TECHNICAL SPECIFICATIONS .....	.02
MAIN COMPONENTS .....	.03
CONTROL PANEL .....	.04
LCD SCREEN .....	.05
FEATURES .....	.06
SETTING UP THE UNIT .....	.07
OPERATION GUIDE .....	.08-09
COOKING FUNCTIONS .....	.10
DEFAULT TEMPERATURE & TIME SETTINGS .....	.11
REPLACING THE LIGHT .....	.12
CLEANING & STORAGE .....	.13-14
TROUBLESHOOTING .....	.15-16
NOTES .....	.17-19

### Our Story

Zulay Kitchen is named after my extraordinary mother, Zulay. She was raised in poverty-stricken Venezuela and, against all odds, brought my brother and me to live in the US. As a single mother, she worked extra-long hours but still found time to cook healthy meals for us. At the time, I thought nothing of it. But now that I'm married with children of my own, I see how much of a super-hero mom she really was.

My wife and I created Zulay Kitchen to make shopping easier than ever in today's busy world. We believe that cooking should be fast and easy, so you have more time to enjoy with your loved ones.


*Aaron* Aaron Cordovez, Co-Founder of Zulay Kitchen











**Dark smoke is coming out of the oven:** Food is burning. Press the Stop button, then use mittens to grab the tray and remove the food.

**Food is not evenly cooked:** Please make sure the food are spread out evenly and not stacked or close to each other.

**Food is not crispy after air frying:** The ingredients are too moist. Evenly spraying a small amount of oil on food can increase crispiness.

**Display shows Error Code "E1":** There is a short circuit. Unplug the power cord from the outlet and contact our customer service.

**Display shows Error Code "E2":** The temperature monitor or heaters are inoperative. Unplug the unit and plug it back in after 5 seconds. The oven should resolve this issue but if you are still experiencing problems, please contact customer service.

If you have any questions about the unit or its operation, please call or email customer service.

+1(727)386-9117 support@zulay.net Mon-Fri 9:00 AM - 5:00 PM (EST)



**Oven Rack**  
Used for meat, bread, frozen pizza etc.



**Air Fry Basket**  
Use the Air Fry Basket in conjunction with the Air Fry function to optimize your cooking results. Can be used for fries, chicken, wings, onion rings, etc. It could also function as a dehydrator basket.



**Baking Tray**  
Used for cookies, cake, turkey, etc. It can also hold the drippings from the food or oil when air-frying.

If you have any questions about the unit or its operation, please call or email customer service.

☎ +1(727)386-9117 ✉ support@zulay.net 🕒 Mon-Fri 9:00 AM - 5:00 PM (EST)

**The oven does not work:** The appliance is not plugged in. Make sure the oven is plugged in.

The door is not closed properly. Make sure the door is closed well.

**Steam is coming out from the top of the oven door:** You are cooking high moisture content foods. This is normal. The door is vented to release steam created from high-moisture content foods such as frozen breads.

**White smoke is coming out of the oven:** This is normal for the first use. We strongly recommend setting the oven to the highest temperature and let it run empty for 20 minutes.

This is normal for cooking greasy foods and it will not effect the cooking process.

The Baking Tray, Crumb Tray, or the oven still contains grease or oil residue from previous cooking. Make sure each part is properly cleaned after each use. Please follow the cleaning instructions on pages 13-14.

**Food is not fully cooked:** There is too much food in the oven. Reduce the amount of food in the oven.

Set temperature is too low or time is too short. Adjust the temperature or time.

Please make sure to use the correct function for the type of food that is being cooked.



### FUNCTION KNOB

Rotate the function knob to navigate through the cooking menu.

### TEMP/TIME SELECT BUTTON

This button is used to confirm the cook function you have selected. Additionally, it is used to confirm the time or temp you have selected by using the TEMP/TIME adjustment knob. For more details see page 08.

### TEMP/TIME ADJUSTMENT KNOB

Rotate (left- right+) the TEMP/TIME knob to select the exact desired temperature or time. This is confirmed by pressing the TEMP/TIME SELECT button. Once you are ready to start cooking, press the Start/Stop button.

### START/STOP BUTTON

Press the Start/Stop button to start or stop the cooking process. This button is also used to pause and resume the cooking process.

**Note:** The button will illuminate red when the oven preheats or cooks. If the button is not illuminated, no cooking is taking place.

### PREHEAT


Press the Preheat button to start the preheating process. The smart oven will go to 300 degrees Fahrenheit temperature. Please note that it is not required to press the Start/Stop button to begin the preheat function; it starts immediately once you press the Preheat button.

### LIGHT BUTTON

Press the Light button to turn the oven light on or off. The light will turn off automatically in 5 minutes to save energy.

### STANDBY MODE

When the screen light is not illuminated, simply interact with any of the knobs or buttons. The Smart Oven LCD screen will light up letting you know that the system is now awake and ready for use.



<p>► FRENCH FRIES TOAST GRILL CHICKEN WINGS BROIL PIZZA FROZEN FOOD BAKE COOKIES STEAK BAGEL DEFOST BACON ROAST DEHYDRATE VEGETABLES PROOF SOUS VIDE ROOT VEGETABLES REHEAT KEEP WARM</p>	<p><b>MENU</b> Each dish in the menu has its own default temperature and time settings. Refer to section Default Temperature &amp; Time settings on page 11 for more details.</p>
<p> LIGHT MED DARK</p>	<p><b>TOAST</b> Use to select the desired toast doneness by using TEMP/TIME knob. Choose between Light/Med/Dark.</p>
<p>350°F</p>	<p><b>Display: Temperature</b> Temperature range from 100° F to 450° F.</p>
<p>00:35 <sup>HRS</sup> <sub>MINS</sub></p>	<p><b>Display: Time</b> Your Smart Oven has a 12 hour timer. At the end of a cooking cycle, the Smart Oven will beep and the LCD display will say "End".</p>
<p></p>	<p><b>Preheat</b> This icon will be displayed on the LCD screen when the air fry function is being used as part of the default settings for the cook function you selected.</p>
<p></p>	<p><b>Air fry</b> This icon will be displayed on the LCD screen for dishes that require air frying.</p>
<p></p>	<p><b>Display: Light</b> Pressing the Light button will display this icon on the LCD screen, letting you know that the inside oven light is still on.</p>
<p></p>	<p><b>Cover food</b> The Cover Food icon will display on the LCD screen letting you know that you need to make sure your food is covered, like in the Sous Vide function.</p>

**CLEANING THE CRUMB TRAY**

- After each use, slide out the Crumb Tray and discard the crumbs. Wipe the tray with a soft, damp sponge. A non-abrasive liquid cleaner or mild spray solution may be used to avoid buildup of stains. Apply the cleaner to the sponge, not the tray, before cleaning. Dry thoroughly. Use caution, as the crumb tray may be hot. Let it cool before handling as needed.
- To remove the baked-on grease, soak the tray in warm soapy water, then wash with a soft sponge or soft plastic scouring pad. Rinse and dry thoroughly.
- Always ensure to re-insert the Crumb Tray into the oven after cleaning and prior to inserting the power plug into a power outlet and turning the oven on.

**STORAGE**

- Ensure the oven and all trays are clean and dry.
- Ensure the door is closed.
- Store the appliance in an upright position, standing level and on its supporting legs. Do not store the appliance when wet or hot. Do not store in a wet or hot environment.



**Unplug the unit before cleaning and let it cool to prevent bodily harm.**

### CLEANING THE OUTER BODY AND DOOR

- Wipe the outer body with a soft damp sponge or cleaning cloth. Use a non-abrasive liquid cleaner or mild cleaner solution spray to remove build-up or food stains. Do not spray directly on stove, first spray onto sponge or cloth for best results. We recommend using an Apple Cider Vinegar cleaning solution of 50% part water and 50% Apple Cider Vinegar for all internal and external cleaning.
- To clean the glass door, use a glass cleaner or mild detergent and a soft, damp sponge or soft plastic scouring pad. Do not use an abrasive cleaner or metal scouring pad as these will scratch the oven's surface.
- Wipe the LCD screen with a soft, damp cloth. Do not apply the cleaner directly onto the LCD screen, instead apply it to a cloth. Cleaning the LCD screen surface with a dry cloth and/or abrasive cleaners may produce scratches.



**WARNING:** To prevent electrocution, do not immerse the appliance or power cord into water or any other liquid.

### CLEANING THE INTERIOR

- To clean any mess that may have occurred while cooking, wipe the walls with a soft, damp sponge. A non-abrasive liquid cleaner or mild spray solution may be used to avoid buildup of stains. Apply the cleaner to the sponge, not the interior, before cleaning.



**WARNING:** Use extreme caution when cleaning the heating elements. Unplug the power cord from the wall and allow the oven to cool completely. Use soft, damp sponge or cloth to gently rub the heating elements. Do not use any type of cleaner or cleaning agent. Let all the surfaces dry prior to plugging the oven back in.

### CLEANING THE OVEN RACK, DEHYDRATE RACK, BAKING PAN AND AIR FRY BASKET

- Wash all accessories in warm soapy water with a soft sponge or soft plastic scouring pad. Rinse and dry thoroughly. Do not use abrasive cleaners, metal scouring pads, or metal utensils to clean any of the accessories as damage to the surface may occur.
- To extend the life of your accessories, we do not recommend to clean them in the dishwasher.

By using all-new 360° HOT AIR CIRCULATION technology, The Smart Convection Oven can offer you more delicious and healthier cuisine.



**21 cooking functions**



**Cook modes: Air Fry and Dehydration**



**Time and temperature control**



**Extra large capacity**



**LCD screen**



**Preheat function**




**Interior oven light**



**Door sensor**




**Cord storage**  
Built-in power cord design




1

Remove all packaging around and inside the oven.




2

Place on a stable, level, heat-resistant surface, away from anything that can be damaged by heat. Keep at least 6 inches distance between the electrical outlet and the wall, furniture, etc.




3

Wash all accessories and clean the interior of the Smart Oven. Dry all parts with a clean cloth and place the trays into the oven.



4


Before use, ensure your outlet is rated for the oven. Refer to section Technical Specifications on page 2 for more details.



5


Upon first use, it is necessary to run the oven for 20 minutes at 450°F in order to sterilize and remove any manufacturing odor. The Smart Oven may emit an odor or a little smoke during this cycle, this is totally normal. Once completed, your smart oven is ready to be used. If you have any questions, please contact customer service, see page 2.

**ATTENTION:** Be sure to unplug the Smart Convection Oven and allow it to cool completely before replacing the oven light.




1

Rotate the light cover counterclockwise to remove it.



2


Remove the bulb by pulling it straight out.



3

Insert the new bulb. Always use safety gloves or a soft cloth as they provide additional grip and protection.

Only use a 25W maximum, 120V, Type G9 oven bulb.




4

Rotate the light cover clockwise to tighten it.




The default data is given here for your reference. Please adjust the desired time and temperature as needed.


MENU	DEFAULT TEMPERATURE	DEFAULT TIME	TEMPERATURE RANGE	TIME RANGE
FRENCH FRIES	450° F	25 MINS	100-450° F	Up to 2:00 HRS
CHICKEN WINGS	450° F	20 MINS	100-450° F	Up to 2:00 HRS
FROZEN FOOD	360° F	15 MINS	100-450° F	Up to 2:00 HRS
STEAK	450° F	7 MINS	100-450° F	Up to 2:00 HRS
BACON	450° F	10 MINS	100-450° F	Up to 2:00 HRS
VEGETABLES	450° F	15 MINS	100-450° F	Up to 2:00 HRS
ROOT VEGETABLES	450° F	35 MINS	100-450° F	Up to 2:00 HRS
TOAST	450° F	LIGHT 3 MINS / MED 4 MINS / DARK 5 MINS/	100-450° F	Up to 2:00 HRS
BROIL	400° F	8 MINS	300-450° F	Up to 2:00 HRS
BAKE	350° F	20 MINS	100-450° F	Up to 2:00 HRS
BAGEL	450° F	13 MINS	100-450° F	Up to 2:00 HRS
ROAST	400° F	30 MINS	100-450° F	Up to 2:00 HRS
PROOF	100° F	40 MINS	100-120° F 38-48° C	Up to 2:00 HRS
REHEAT	200° F	5 MINS	100-450° F	Up to 2:00 HRS
GRILL	450° F	10 MINS	100-450° F	Up to 2:00 HRS
PIZZA	400° F	11 MINS	100-450° F	Up to 2:00 HRS
COOKIES	325° F	11 MINS	100-450° F	Up to 2:00 HRS
DEFROST	120° F	20 MINS	100-180° F	Up to 2:00 HRS
DEHYDRATE	120° F	4 HRS	100-180° F 38-82° C	Up to 12:00 HRS
SOUS VIDE	120° F/140° F	45 MINS	120/140° F	Up to 6:00 HRS
KEEP WARM	120° F	4 HRS	100-250° F	Up to 8:00 HRS




Plug your Smart Oven into a properly rated outlet (Refer to section Technical Specifications on page 2 for more details). The Smart Oven will turn on and the LCD screen will illuminate. The time and temperature of the initially selected menu item will be displayed.




Rotate the Function Knob to choose your desired menu item. The LCD screen will display the default temperature and time for the selected item. Press START/STOP button to begin cooking if default temperature and time are applicable. The oven will preheat and start cooking.




In case the temperature and time need to be adjusted, press the TEMP/TIME SELECT button. Temperature will be the first to adjust, simply rotate the TEMP/TIME ADJUSTMENT KNOB (left to decrease, right to increase). Then, press the TEMP/TIME SELECT button to confirm the temperature and go to the cooking time selection. Now, rotate the TEMP/TIME ADJUSTMENT KNOB to select the cooking time. Press TEMP/TIME SELECT to confirm the cooking time. Now press the START/STOP button to begin cooking.




**Preheat:** Press the "PREHEAT" button in order to preheat the Smart Convection Oven. When the internal temperature reaches 300° F, the Smart Oven will beep 5 times and display "Add Food" on the LCD screen. After placing food into the oven press START/STOP button to begin cooking.



Rack Position Diagram



Your Smart Oven has 4 rack positions to choose from. Please refer to the rack position guide above to properly position your rack.



Press the START/STOP button to begin cooking, the button backlight will illuminate red and the LCD screen will begin the selected timer countdown.

Your Smart Oven will beep 5 times and the LCD screen will display "End" once the cooking process is complete.

**Note:** Once cooking is complete, the START/STOP button will no longer be red and the fan will turn on. The oven is cooling itself down. Please make sure that the door is closed for the oven to be able to cool down. The fan will not work with the door open. Please use caution as the oven will be hot after use.

Some moisture may occur on your oven door during the cooking process, this is a normal occurrence. For best results, we recommend you preheat the Smart Convection Oven before cooking.

FUNCTION	PREHEAT	SUGGESTED AMOUNT OF FOOD	SUGGESTED ACCESSORY	SUGGESTED RACK POSITION
FRENCH FRIES	YES	34.5 oz	Air fry Basket	2
CHICKEN WINGS	YES	36.5 oz (21 wings)	Air fry Basket	2
FROZEN FOOD	YES	35.5 oz	Air fry Basket	2
STEAK	YES	6.7 oz	Baking Pan or Oven Rack	2
BACON	YES	8pcs	Air fry Basket	2
TOAST	NO	6pcs	Oven Rack	2 or 3
VEGETABLES	YES	BASED ON THE FOOD YOU SELECT	Baking Pan or Air fry Basket	3
ROOT VEGETABLES	YES		Oven Rack or Air fry Basket	2
BROIL	YES		Baking Pan or Oven Rack	2
BAKE	YES		Baking Pan or Oven Rack	3
BAGEL	YES		Oven Rack or Air fry Basket	2
ROAST	YES		Baking Pan or Oven Rack	4
PROOF	NO		Baking Pan	3
REHEAT	YES		Oven Rack	3
GRILL	YES		Oven Rack or Air fry Basket	1
PIZZA	YES		12 inches	Baking Pan or Oven Rack
COOKIES	YES	BASED ON THE FOOD YOU SELECT	Baking Pan	2
DEFROST	NO		Air fry Basket	2
DEHYDRATE	NO		Air fry Basket	1 or 2 or 3
SOUS VIDE	NO		Baking Pan	4
KEEP WARM	NO		Baking Pan	2