

DIANA®

ACTION

outlaw



EN

Instructions for Use

2 - 11

FR

Instructions d'Utilisation

22 - 31

DE

Gebrauchsanleitung

12 - 21

ES

Instrucciones de Uso

32 - 41

Version 11/2017

INTRODUCTION



DESCRIPTION



SAFETY INSTRUCTIONS



TECHNICAL DATA



HANDLING & OPERATION




CARE & MAINTENANCE

The information provided in this Manual is subject to change without notice. Please check our website www.diana-airguns.de for the latest downloadable version of the Manual, and learn further interesting facts about DIANA and your model.



DESCRIPTION



WARNING

EYE PROTECTION IS REQUIRED! WEAR APPROPRIATE SAFETY GLASSES (SHOOTING GLASSES)!



WARNING

FAILURE TO FOLLOW THE INSTRUCTIONS AND RECOMMENDATIONS IN THIS MANUAL MAY RESULT IN SEVERE BODILY INJURY (INCLUDING FACE INJURY, EYE INJURY, EAR INJURY, BLINDNESS, DEAFNESS) AND EVEN DEATH.



CAUTION

WARRANTY IS VOID IF THE RIFLE IS DISMANTLED WITHOUT AUTHORIZATION. ALL REPAIRS MUST BE MADE BY AUTHORIZED PERSONNEL.

EN

DE

FR

ES



SAFETY INSTRUCTIONS



WARNING

NOT A TOY. ADULT SUPERVISION REQUIRED. MISUSE, ABUSE OR NEGLIGENT USE MAY CAUSE SERIOUS INJURY OR DEATH. MAY BE DANGEROUS UP TO 500 YARDS (460 METERS).

This air rifle is not a toy. Treat it with the same respect you would give a firearm subject to licensing. Always handle it as if it is loaded and ready to shoot. Always carefully follow the safety instructions found in this Manual and keep it in a safe place for future reference.

- The air rifle described in this Manual is a high-powered gun recommended for use by those 18 years of age or older. Be sure to closely read all safety instructions and other information in this Manual before using the air rifle. The purchaser and user of this air rifle must conform to all national, regional and local laws and regulations governing the acquisition of ownership, possession and use of airguns.
- Do not brandish or display the air rifle in public. This may confuse people and may be a crime. Police and others may think this air rifle is a firearm subject to licensing.
- Do not change the coloration and markings to make the air rifle look more like a full-fledged firearm. That is dangerous and may be a crime.
- Airguns differ in design, function and handling, so you are never ready to shoot a gun until you are thoroughly familiar with it. Therefore, please read this Manual carefully before using the air rifle described in it.
- You and any others with or near you **MUST** always wear appropriate safety glasses (shooting glasses) to protect your eyes. If any of you wear vision correcting glasses, contact lenses, or sunglasses, these must be certified for impact resistance by the manufacturer; otherwise, always wear appropriate safety glasses (shooting glasses) over your vision correcting glasses, contact lenses, or sunglasses, as the case may be.
- Always aim in a **SAFE DIRECTION**. Always keep the muzzle of the air rifle pointed in a **SAFE DIRECTION**.
- Always keep your finger off the trigger and out of the trigger guard until you are ready to shoot.
- Never point the air rifle at anything you do not intend to shoot.
- Never point the air rifle at people or animals.
- Always treat the air rifle as though it is loaded and with the same respect you would give a firearm subject to licensing.
- Never look down the barrel of the air rifle.
- Always keep the air rifle uncocked and unloaded with Safety "ON" until you are ready to shoot.

- Always check to see if the air rifle is uncocked and unloaded with safety "ON" when getting it from another person or from storage.
- Never leave a loaded air rifle unattended.
- Use only the proper size and type of projectile as it is marked on the air rifle.
- Never reuse ammunition.
- Do not shoot at hard surfaces or at the surface of water. The projectile may bounce off or ricochet and hit a person or an animal, or hit an object that you had not intended to hit.
- Do not shoot at fragile objects such as windows.
- Place the backstop in a location that will be safe should the backstop fail.
- Check the backstop for wear before and after each use. All backstops are subject to wear and will eventually fail. Replace the backstop if the surface is worn or damaged or if a ricochet occurs.
- Do not attempt to disassemble or tamper with the air rifle. Unauthorized repairs or functional modifications may render it unsafe and will void your warranty. Repairs must only be made by qualified personnel.
- Before you store or transport the air rifle, make sure it is unloaded and uncocked, with safety "ON".
- Always store the air rifle in a secure location out of the reach of unauthorized persons and separate from ammunition.
- Only persons who are thoroughly familiar with the air rifle's function and proper use and who are duly authorized by law may handle the air rifle.
- Always wear appropriate safety glasses (shooting glasses) when shooting or performing maintenance on the air rifle.
- Only shoot where permitted by law.
- Never use alcoholic beverages, drugs or other potentially mind and perception-altering substances before or during shooting sessions.
- Remember to perform inspection and maintenance of the air rifle at regular intervals.
- If the air rifle has been dropped, make sure that its function has not been affected.
- Lead pellets are toxic to humans and animals. Therefore, do not eat, drink or touch your own or someone else's mouth, eyes or nose when handling lead pellets. Do not inhale the dust of lead pellets and do not put them in your mouth. Be sure to wash your hands after handling lead pellets.



TECHNICAL DATA

TECHNICAL DATA

| | cal 4.5 mm (.177) | cal 5.5 mm (.22) | cal 6.35 mm (.25) |
|-----------------------|------------------------------|---------------------------|----------------------------|
| System / Power Source | PCP (pre-charged pneumatic) | | |
| Caliber | cal. 4.5 mm / .177 pellets | cal. 5.5 mm / .22 pellets | cal. 6.35 mm / .25 pellets |
| Magazine | 13 pellets | 11 pellets | 9 pellets |
| Air Capacity | 210 ml • 210 cc | | |
| Max Fill Pressure | 250 bar • 25 MPa • 3,600 PSI | | |
| Energy ¹ | 30 Joule • 22 ft.lbs | 45 Joule • 35 ft.lbs | 60 Joule • 45 ft.lbs |
| Velocity ¹ | 320 m/s • 1,050 fps | 300 m/s • 985 fps | 280 m/s • 920 fps |
| Rail | 11 mm dovetail | | |
| Safety | manual | | |
| Weight | 2,900 g • 6.4 lbs | | |
| Total Length | 1,060 mm • 41.7" | | |
| Barrel Length | 475 mm • 18.7" | | |
| Danger Distance | 640 m (700 yds) | | |

¹ Measured with different lead pellets.



WARNING

NEVER EVER CARRY THE AIR RIFLE WHILE COCKED AND/ OR WHILE LOADED. IT IS BEST TO COCK THE AIR RIFLE ONLY IMMEDIATELY BEFORE SHOOTING.



WARNING

USE ONLY COMPRESSED BREATHING AIR IN THE AIR RIFLE. USE NO OTHER GASES- INCLUDING OXYGEN OR CO₂, WHICH CAN CAUSE A FIRE OR AN EXPLOSION THAT MAY RESULT IN SERIOUS INJURY OR DEATH.




HANDLING & OPERATION


FILLING THE COMPRESSED AIR CYLINDER

CAUTION

- MAKE SURE THE AIR RIFLE IS UNLOADED. POINT THE MUZZLE IN A SAFE DIRECTION. REMOVE THE MAGAZINE AND THE LOADING BASE.
- COCK THE AIR RIFLE BEFORE YOU START FILLING PROCESS: PULL THE BOLT HANDLE BACKWARD TO ITS OPEN POSITION UNTIL A CLICK SOUND IS HEARD. CLOSE AND LOCK THE BOLT BY PUSHING THE BOLT HANDLE FORWARD AND DOWN.



1. Read all instructions about your charging equipment and connect the quick-fill adapter to it. **Please note that your charging equipment must include a pressure gauge (manometer)!**




3. Watch the gauge on the air rifle and charging equipment. We recommend to fill the tank with a pressure of 250 bar. **Do not exceed a filling pressure of 250 bar!**




WARNING

DANGER OF EXPLOSION!



2. Ensure that both, fill adapter and filler, are clean from dirt. Pull back the protective cap and insert the fill adapter into the intake valve and start filling. If you use a scuba tank, fill **slowly** to prevent heat building.



4. **Scuba tank:** BLEED the fill hose COMPLETELY before disconnecting the quick-fill adapter from the air rifle to avoid hose whip and possible injury. Disconnect the quick-fill adapter from the air rifle 1 and the charging equipment 2. To decock, aim in a safe direction and pull the trigger.

EN

DE

FR

ES




HANDLING & OPERATION

EMPTYING THE COMPRESSED AIR CYLINDER (DEGASSING)


Note: This air rifle, like most PCP air rifles, is best stored with some pressure in the air cylinder. This keeps the seals in the air rifle forced against the sealing surface and saves some air for next-time fill or use.

In case you need to depressurize the air rifle, point the unloaded gun in a **SAFE DIRECTION** and repeat cocking and dry-firing until the air cylinder is empty.


LOADING THE MAGAZINE




1. Insert the pellet as shown into the pellet chamber of the magazine **1**.



2. Slightly turn the cylinder to the next pellet chamber. Repeat until all pellet chambers are filled.



3. Pull the bolt handle backward to its open position **3** until a click sound is heard. Now insert the loaded magazine as shown **4**.



4. Close and lock the bolt by pushing the bolt handle forward. **Do not load more than 1 pellet into the barrel. Immediate shooting after cocking is recommended to prevent loading of 2 pellets into the barrel.**



HANDLING & OPERATION


CAUTION

ALWAYS STORE THE MAGAZINE UNLOADED (WITHOUT PELLETS)
TO PREVENT WEAKENING OF THE MAGAZINE SPRING.

SAFETY



SHOOTING



Put the safety "OFF".

To begin shooting, aim at a safe target and pull on the trigger **1**.

For further shooting, load and cock the air rifle again. Pull the bolt handle backward **2** until a click sound is heard and push it forward **3**. Make sure that only one pellet is loaded into the barrel.

WARNING

NEVER POINT THE AIR RIFLE AT ANYTHING YOU DO NOT INTEND TO SHOOT.
NEVER POINT AN AIR RIFLE AT PEOPLE OR ANIMALS.

EN

DE

FR

ES



CARE & MAINTENANCE

BARREL CLEANING

WARNING

IF A PELLET DOES NOT FIRE AFTER YOU HAVE COMPLETED THE OPERATION STEPS DESCRIBED IN THIS MANUAL, THE AIR RIFLE MAY BE JAMMED. AN UNFIRED PROJECTILE IN THE BARREL CAN PRESENT A DANGEROUS SITUATION. TO ELIMINATE THE JAMMING, KEEP THE MUZZLE OF THE AIR RIFLE POINTED IN A SAFE DIRECTION AND REPEAT THE OPERATION STEPS, HOWEVER WITHOUT LOADING ANOTHER PELLET. IF A PROJECTILE STILL DOES NOT FIRE, DO THE FOLLOWING:

1. ENGAGE THE SAFETY AND REMOVE THE MAGAZINE.
2. CLEAR THE BARREL BY RUNNING A CLEANING ROD THROUGH IT FROM THE MUZZLE END.
3. REPEAT THE OPERATION STEPS.

WARNING


UNLOAD THE AIR RIFLE BEFORE CLEANING IT.

CAUTION

- DO NOT FORCE THE ROD INTO THE BARREL AS THIS COULD CAUSE DAMAGE.
- CLEAN THE METAL PARTS ON THE OUTSIDE OF THE RIFLE USING A CLOTH WHICH HAS BEEN SLIGHTLY DAMPENED WITH SOME GUN OIL.
- NEVER ALLOW GUN OIL TO DRIP DIRECTLY INTO THE BARREL.



1. Engage the safety. Attach a piece of cotton fabric to the end of a cleaning rod.



2. Clean the barrel with some gun oil. Insert the rod as shown.




CARE & MAINTENANCE

TRIGGER ADJUSTMENT

WARNING


UNLOAD THE AIR RIFLE BEFORE ADJUSTING THE TRIGGER.

Note: Use a hexagon (Allen) key (SW 1.5) to adjust the trigger.



1. Adjustment of trigger take-up (slack):

In order to reduce trigger slack: Turn adjustment screw **1** clockwise. In order to increase trigger slack: Turn adjustment screw **1** counterclockwise.



2. Adjustment of sear engagement:

When the gun is cocked, the sear engages with the sear lever. By turning the screw, you can adjust sear engagement (and thus trigger creep). In order to reduce sear engagement, turn engagement screw **2** clockwise. In order to increase sear engagement, turn engagement screw **2** counterclockwise.

CAUTION

PLEASE BE AWARE THAT MAJOR ADJUSTMENTS MAY RESTRICT THE FUNCTIONALITY OF THE AIRGUN. IN THIS CASE, THE LEVEL OF ADJUSTMENT MUST BE CORRECTED.

PROBLEM

The safety cannot be activated.

Pulling the trigger does not fire the gun.

The air rifle cannot be cocked.

SOLUTION

Increase trigger slack –
Turn screw 1 counterclockwise.

Sear engagement is too long –
turn engagement screw 2 clockwise.

Sear engagement is too short – turn
engagement screw 2 counterclockwise.

EN

DE

FR

ES