





**DO NOT DISCARD. THIS MANUAL HAS IMPORTANT OPERATING AND MAINTENANCE INSTRUCTIONS. LEAVE WITH THE HOMEOWNER.**

**MODEL:**

**SERIAL #:**



H-Burner



T-Burner

**MODELS**


Models: NG/LP	Description	Models: NG/LP	Description
LOF-2412HAWS-N/P	24" x 12" Fire Pit with H-Burner	LOF-2406TAWS-N/P	24" x 6" Fire Pit with T-Burner
LOF-3012HAWS-N/P	30" x 12" Fire Pit with H-Burner	LOF-3006TAWS-N/P	30" x 6" Fire Pit with T-Burner
LOF-3614HAWS-N/P	36" x 14" Fire Pit with H-Burner	LOF-3606TAWS-N/P	36" x 6" Fire Pit with T-Burner
LOF-4814HAWS-N/P	48" x 14" Fire Pit with H-Burner	LOF-4806TAWS-N/P	48" x 6" Fire Pit with T-Burner
LOF-6016HAWS-N/P	60" x 16" Fire Pit with H-Burner	LOF-6006TAWS-N/P	60" x 6" Fire Pit with T-Burner
LOF-7216HAWS-N/P	72" x 16" Fire Pit with H-Burner	LOF-7206TAWS-N/P	72" x 6" Fire Pit with T-Burner
LOF-8416HAWS-N/P	84" x 16" Fire Pit with H-Burner	LOF-8406TAWS-N/P	84" x 6" Fire Pit with T-Burner
LOF-9616HAWS-N/P	96" x 16" Fire Pit with H-Burner	LOF-9606TAWS-N/P	96" x 6" Fire Pit with T-Burner

**Linear All Weather System (AWS) Fire Pits  
Installation and Operating Instructions**

**IF YOU CANNOT READ OR UNDERSTAND THESE INSTALLATION INSTRUCTIONS DO NOT ATTEMPT TO INSTALL OR OPERATE THIS APPLIANCE**

**INSTALLATION PRECAUTION:**

This fire pit requires a minimum 18-square inches (per side) of cross ventilation. Failure to provide proper ventilation can void the warranty.






**Warning:** For Outdoor Use Only



**NATIONAL FIREPLACE INSTITUTE**  
**NFI**  
**CERTIFIED**  
[www.nficertified.org](http://www.nficertified.org)

We recommend that our gas hearth products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) as NFI Gas Specialists.

 <p><b>DANGER</b></p>	<p align="center"><b>CARBON MONOXIDE HAZARD</b></p> <p>This appliance can produce carbon monoxide which has no odor.</p> <p>Using it in an enclosed area can kill you.</p> <p>Never use this appliance in an enclosed space such as a camper, tent, car or home.</p>
	

 **DANGER**

If you smell gas:

1. Shut off gas to the appliance
2. Extinguish any open flame.
3. If odor continues, keep away from the appliance and immediately call your gas supplier or fire department.

 **WARNING**

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or other appliances.

Any LP cylinder not connected for use shall not be stored in the vicinity of this or other appliances.

**WARNING**

Do not leave unattended during use.  
Do not use for cooking.  
Follow all gas leak procedures in this manual prior to operation.

 **WARNING**


Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.

**WARNING**

If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

**FOR YOUR SAFETY**

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or other appliances.

 Fuels used in gas fired appliances, and the products of combustion such as fuels, contain chemicals known to cause cancer, birth defects and/or other reproductive harm.  
This warning is issued pursuant to the California Health & Safety Code Sec. 25249.1



## CALIFORNIA PROPOSITION 65



### WARNING

This product is designed to operate with one of the following fuel sources: Liquid Propane or Natural Gas. The fuel used to operate this product, and the products of combustion of such fuel, can expose you to chemicals including Benzene which is known to the State of California to cause cancer, birth defects and other reproductive harm and Carbon Monoxide which is known to the State of California to cause birth defects or other reproductive harm.

(For more information go to: [www.p65Warnings.ca.gov](http://www.p65Warnings.ca.gov).)

**NOTE:** An exterior lid/cover is not required but highly recommended when the fire pit is not in use. Even though fire pits are designed for outdoors they are not impervious to all weather conditions if not protected. See the accessory page for information and sizes.

### TABLE OF CONTENTS

<b>Specifications</b>	4-5
<b>Preparation for Non-Combustible Structure</b>	6
Cross Ventilation Requirements	6
High Elevation	6
Hard Piping to Fire Pit	6
<b>Preparing a Non-Combustible Structure</b>	6
<b>Gas Pipe Sizing Chart</b>	7
<b>Installation into an Approved Enclosure</b>	7
<b>Pre-Installation Check List for Single Install</b>	8
<b>Preparing a Non-Combustible Structure for Single Install or Pool</b>	9
<b>Removing Carton Contents</b>	10
<b>Wiring Diagrams</b>	11
<b>Media Requirements</b>	12
<b>Operation</b>	13
Lighting Instructions	13
<b>Replacement Parts</b>	14
<b>Replacement Parts List</b>	15-16
<b>Fire Pit Maintenance</b>	16
<b>Liquid Propane (LP) Conversions</b>	17
<b>Trouble Shooting</b>	18-20
<b>Optional Accessories</b>	21



All media (i.e. lava rock, lava stones, lava boulders and fire glass) has the potential of thermal spalling. This is a process that may occur when media is wet and moisture gets trapped inside of the material due to rapid temperature differences. When this happens the media has the potential to crack or “pop” outside the fireplace.

#### **WE HIGHLY RECOMMEND COVERING ALL FIRE FEATURES WHEN NOT IN USE**

The use of a cover can lessen the impact of thermal spalling; however, heavy rains, high humidity and the presence of moisture may still cause the media to pop.

#### **ALWAYS USE CAUTION WHEN USING THE FIRE FEATURE**


Extra caution should be taken when lighting a fireplace when heavy rains, high humidity and moisture are present. Light the fireplace; leave the area allowing any moisture in the media to dissipate. We strongly recommend that during this drying out time that you monitor the fire feature from a distance. This drying out period should be no less than 30 minutes. Continue monitoring the flame from distance to ensure that all popping has ceased before fully enjoying the fire.



# SPECIFICATIONS

MODELS N= Natural P= Propane	INSIDE PAN DIMENSIONS A	OUTSIDE PAN DIMENSIONS B	BURNER DIMENSIONS	CUTOUT DIMENSIONS	GROUND LEVEL	SIDE WALL	COMBUSTIBLE CEILING	COMBUSTIBLE FLOOR
LOF-2412HAWS-N LOF-2412HAWS-P	24" x 12" (609 x 304mm)	26½" x 14½" (673 x 368mm)	21" x 10" (533 x 254mm)	25" x 13" (635 x 279mm)	8" (203mm)	36" (914mm)	96" (2438mm)	18" (457mm)
LOF-3012HAWS-N LOF-3012HAWS-P	30" x 12" (762 x 304mm)	32½" x 14½" (825 x 368mm)	27" x 10" (658 x 254mm)	31" x 13" (787 x 279mm)	8" (203mm)	36" (914mm)	96" (2438mm)	18" (457mm)
LOF-3614HAWS-N LOF-3614HAWS-P	36" x 14" (914 x 355mm)	38½" x 16½" (977 x 419mm)	33" x 10" (813mm)	37" x 15" (940 x 330mm)	8" (203mm)	36" (914mm)	96" (3048mm)	18" (457mm)
LOF-4814HAWS-N LOF-4814HAWS-P	48" x 14" (1219 X 355mm)	50½" x 16½" (1228 x 419mm)	45" x 10" (838 x 254mm)	49" x 15" (1244 x 330mm)	8" (203mm)	36" (914mm)	120" (3048mm)	18" (457mm)
LOF-6016HAWS-N LOF-6016HAWS-P	60" x 16" (1524 x 406mm)	62½" x 18½" (1582 x 469mm)	57" x 10" (1477 x 254mm)	61" x 17" (1549 x 330mm)	8" (203mm)	36" (914mm)	120" (3048mm)	18" (457mm)
LOF-7216HAWS-N LOF-7216HAWS-P	72" x 16" (1828 x 406mm)	74½" x 18½" (1892 x 469mm)	69" x 10" (1752 x 254mm)	73" x 17" (1854 x 330mm)	8" (203mm)	36" (914mm)	120" (3048mm)	18" (457mm)
LOF-8416HAWS-N LOF-8416HAWS-P	84" x 16" (2133 x 406mm)	86½" x 18½" (2197 x 469mm)	81" x 10" (2057x 254mm)	85" x 17" (2159 x 330mm)	8" (203mm)	8" (203mm)	120" (3048mm)	18" (457mm)
LOF-9616HAWS-N LOF-9616HAWS-P	96" x 16" (2438 x 406mm)	98½" x 18½" (2501 x 469mm)	93" x 10" (2362 x 254mm)	97" x 17" (2463 x 330mm)	8" (203mm)	8" (203mm)	120" (3048mm)	18" (457mm)

**Table 1** Fire Pit Dimensions




**Fig. 1** H-style burner pan specifications.

Model: N= Natural P= Propane	Natural Orifice #	Btu Ratings	Propane Orifice #
LOF-2412HAWS-N LOF-2412HAWS-P	OAS-NG29	75,000 (21.98kW)	OAS-LP41
LOF-3012HAWS-N LOF-3012HAWS-P	OAS-NG22	100,000 (29.30kW)	OAS-LP35
LOF-3614HAWS-N LOF-3614HAWS-P	OAS-NG16	125,000 (36.63kW)	OAS-LP31
LOF-4814HAWS-N LOF-4814HAWS-P	OAS-NG11	150,000 (43.96kW)	OAS-LP29
LOF-6016HAWS-N LOF-6016HAWS-P	OAS-NG05	175,000 (51.28kW)	OAS-LP26
LOF-7216HAWS-N LOF-7216HAWS-P	OAS-NG02	200,000 (58.61kW)	OAS-LP22
LOF-8416HAWS-N LOF-8416HAWS-P	OAS-NG01	225,000 (65.94kW)	OAS-LP19
LOF-9616HAWS-N LOF-9616HAWS-P	OAS-NG25/64"	250,000 (73.26kW)	OAS-LP12

**Table 2** H-burner specifications.

**Disclaimer:** Btu listings are based on 7.0"WC for Natural Gas and 11.0"WC for Liquid Propane (LP) at the burner orifice. Flex line size and proper gas pipe sizing will also affect Btu's. As a result your Btu's may vary slightly from Table 2 specifications.




**Fig. 2** Clearance to Combustibles for models. (Not to be used in an enclosed space)



## SPECIFICATIONS

MODELS N= Natural P= Propane	INSIDE PAN DIMENSIONS A	OUTSIDE PAN DIMENSIONS B	BURNER LENGTH	CUTOUT DIMENSIONS	GROUND LEVEL	SIDE WALL	COMBUSTIBLE CEILING	COMBUSTIBLE FLOOR
LOF-2406TAWS-N LOF-2406TAWS-P	24" x 6" (609 x 152mm)	26½" x 8½" (673 x 215mm)	21" (533mm)	25" x 7" (635 x 178mm)	8" (203mm)	36" (914mm)	96" (2438mm)	18" (457mm)
LOF-3006TAWS-N LOF-3006TAWS-P	30" x 6" (762 x 152mm)	32½" x 8½" (825 x 215mm)	27" (686mm)	31" x 7" (787 x 178mm)	8" (203mm)	36" (914mm)	96" (2438mm)	18" (457mm)
LOF-3606TAWS-N LOF-3606TAWS-P	36" x 6" (914 x 152mm)	38½" x 8½" (977 x 215mm)	33" (838mm)	37" x 7" (787 x 178mm)	8" (203mm)	36" (914mm)	96" (2438mm)	18" (457mm)
LOF-4806TAWS-N LOF-4806TAWS-P	48" x 6" (1219 X 152mm)	50½" x 8½" (1280 x 215mm)	45" (1143mm)	49" x 7" (1244 x 178mm)	8" (203mm)	36" (914mm)	96" (2438mm)	18" (457mm)
LOF-6006TAWS-N LOF-6006TAWS-P	60" x 6" (1524 x 152mm)	62½" x 8½" (1587 x 215mm)	57" (1448mm)	61" x 7" (1549 x 178mm)	8" (203mm)	36" (914mm)	96" (2438mm)	18" (457mm)
LOF-7206TAWS-N LOF-7206TAWS-P	72" x 6" (1828 x 152mm)	74½" x 8½" (1892 x 215mm)	69" (1752mm)	73" x 7" (1854 x 178mm)	8" (203mm)	36" (914mm)	120" (2438mm)	18" (457mm)
LOF-8406TAWS-N LOF-8406TAWS-P	84" x 6" (2133 x 152mm)	86½" x 8½" (2197 x 215mm)	81" (2057mm)	85" x 7" (2159 x 178mm)	8" (203mm)	36" (914mm)	120" (3048mm)	18" (457mm)
LOF-9606TAWS-N LOF-9606TAWS-P	96" x 6" (2438 x 152mm)	98½" x 8½" (2501 x 215mm)	93" (2362mm)	97" x 7" (2463 x 178mm)	8" (203mm)	36" (914mm)	120" (3048mm)	18" (457mm)

**Table 3** Fire Pit Dimensions



**Fig. 3** T-style burner pan specifications.

Model: N= Natural P= Propane	Natural Orifice #	Btu Ratings	Propane Orifice #
LOF-2406TAWS-N LOF-2406TAWS-P	OAS-NG34	50,000 (14.65kW)	OAS-LP47
LOF-3006TAWS-N LOF-3006TAWS-P	OAS-NG34	50,000 (14.65kW)	OAS-LP47
LOF-3606TAWS-N LOF-3606TAWS-P	OAS-NG29	75,000 (21.98kW)	OAS-LP41
LOF-4806TAWS-N LOF-4806TAWS-P	OAS-NG22	100,000 (29.30kW)	OAS-LP35
LOF-6006TAWS-N LOF-6006TAWS-P	OAS-NG16	125,000 (36.63kW)	OAS-LP31
LOF-7206TAWS-N LOF-7206TAWS-P	OAS-NG11	150,000 (43.96kW)	OAS-LP29
LOF-8406TAWS-N LOF-8406TAWS-P	OAS-NG05	175,000 (51.28kW)	OAS-LP26
LOF-9606TAWS-N LOF-9606TAWS-P	OAS-NG02	200,000 (58.61kPa)	OAS-LP22

**Table 4** T-burner specifications.

**Disclaimer:** Btu listings are based on 7.0"WC for Natural Gas and 11.0"WC for Liquid Propane (LP) at the burner orifice. Flex line size and proper gas pipe sizing will also affect Btu's. As a result your Btu's may vary slightly from Table 2 specifications.

Pressure	NG
Min. Inlet	3.5" WC (½ PSI) (0.87kPa)
Max. Inlet	14.0" WC (½ PSI) (3.48kPa)
Normal Inlet	7.0" WC (¼ PSI) (1.74 kPa)
Pressure	LP
Min. Inlet	8.0" WC (½ PSI) (1.99kPa)
Max. Inlet	14.0" WC (½ PSI) (3.48kPa)
Normal Inlet	11.0" WC (½ PSI) (2.73 kPa)

**Table 5** Gas Pressures



## PREPARING A NON-COMBUSTIBLE STRUCTURE

**DESCRIPTION** These models feature a field serviceable (30VDC) commercial grade outdoor electronic system with a maximum gas capacity of 290,000 Btu's. Certified by **Lab Test Certification** for USA and Canada the system meets: ANSI Z21.20-2014 •CAN/CSA-C22.2 No. 60730-2-5-14. The system features a built-in safety shut-off in case of flame loss and auto relight. It is and it is shipped as a Natural Gas (NG) model. Models must be ordered specifically as Natural Gas (NG) or Propane (LP). **Note:** Only Natural gas models can be converted to Propane (LP) gas, if applicable. This system must be installed with a burner pan, burner and orifice and installed into a non-combustible enclosure. The "All Weather System" (AWS) requires a 120VAC Ground Fault Interrupter (GFI) to be installed in a weatherproof box. The power supply Model #GOE-30VDC is used for a single installation greater than 10-feet or more from pools or spas.

In the absence of local codes use the latest edition of the National Fuel Gas Code NFPA54 and National Electrical Code (NEC), or NFPA 70. The weatherproof box (supplied) should be mounted securely within 6-feet of the GFI box. The GFI box can power the adapter and optional remote control receiver, if applicable. **Note:** Gas line must be bonded at EACH FIRE FEATURE. See NEC- 680.26B

**READ THIS MANUAL COMPLETELY BEFORE BEGINNING INSTALLATION. UNDERSTAND HOW THE AWS SYSTEMS OPERATES AND INSTALLS.**

### **VENTILATION FOR NON-COMBUSTIBLE ENCLOSURE**

Fire features are subjected to many outdoor elements such as rain, snow, wind, heat or cold. **A minimum of 18 square inches (opposite sides) of cross ventilation is required to keep the components in good working order.** Use Fig. 4 on as guide to assist to incorporate proper ventilation.




Fig. 4 Shows cross ventilation for a linear enclosure.

**LEVEL FLAT SURFACE** Install fire feature on any level, outdoor non-combustible, flat stable surface or a combustible floor according to the clearances specified in this manual for a Firegear burner. **NOTE:** Depending on venting locations, do not place fire pit directly on grass, dirt, or rocks that could prevent proper ventilation. **Ensure proper water drainage is also incorporated into the fire feature enclosure.**

### **HIGH ELEVATION INSTALLATION**

This appliance is listed for elevations from 0- 4500 feet in Canada and the U.S. If elevation exceeds 4500 feet it may be necessary to decrease the input rating by changing the existing burner orifice to a smaller size. Input should be reduced 4% for each 1000 feet beyond the 4500 feet above sea level. Check with your local gas utility for assistance in determining the proper orifice in your location. In some cases the heating value may already be reduced and downsizing the orifice may not be necessary.

### **HARD PIPING TO FIRE FEATURE WITHOUT GAS PROXIMITY**

**NOTE:** Refer to the NFPA54 (National Fuel Gas Code) for proper pipe sizing. See gas line sizing chart on page 7 as a reference.

1. Turn **OFF** gas supply system. **NOTE:** All gas connections (except for brass to brass) require the following. Clean pipe threads using either a wire brush or steel wool. Apply pipe sealant to the fittings before making any connection.
2. Ensure all gas connections are snug, but do not over tighten! **BE CAREFUL!**
3. Install necessary pipe for the distance required and a manual shut-off valve at the exterior house wall. Check with local codes for proper procedures. If pipe is to pass through a foundation or house wall, make sure to seal the area around the pipe with weather sealant. Consult a plumber for proper installation to ensure you are providing adequate gas supply for your application.
4. The primary gas shut-off (not supplied) will require a 1/2" male flared fitting to enable connection of the stainless steel flex gas line (not supplied) with the fire feature (see Fig. 5 page 9).
5. Do not place an LP tank inside any fire pit enclosure. Locate all Liquid Propane (LP) tanks outside the enclosure.
6. To prevent performance problems with LP gas fire pits, do not use a LP tank less than 100lbs. capacity.

### **IMPORTANT**

Installation of Natural or LP gas should be done by a qualified installer, service agency or gas supplier. This appliance must be isolated from the gas supply piping system by closing its manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2" psi (3.5kPa)



# GAS PIPE SIZING CHART

## NATURAL GAS : PIPE SIZING CHART

Length of Pipe in Feet	1/2"	3/4"	1"	1 - 1/4"	1 - 1/2"	2"	2 - 2 1/2"	3"	4"
10	108	230	387	793	1237	2259	3640	6434	-
20	75	160	280	569	877	1610	2613	5236	9521
30	61	129	224	471	719	1335	2165	4107	7859
40	52	110	196	401	635	1143	1867	3258	6795
50	46	98	177	364	560	1041	1680	2936	6142
60	42	89	159	336	513	957	1559	2684	5647
70	38	82	149	317	476	896	1447	2492	5250
80	36	76	140	239	443	840	1353	2315	4900
90	33	71	133	275	420	793	1288	2203	4667
100	32	68	126	266	411	775	1246	2128	4518
125	28	60	117	243	369	700	1143	1904	4065
150	25	54	105	215	327	625	1008	1689	3645
175	23	50	93	196	303	583	993	1554	3370
200	22	47	84	182	280	541	877	1437	3160
300	17	37	70	145	224	439	686	1139	2539

- Natural Gas (NG) flow is given in thousands of BTU/hr. = 1 cubic foot of NG gas - 1000 BTU
- Nominal pressure at the burner for Natural Gas is 3.5" of water column. (Typical machine supply 5"-7")
- Pipe length must include additional length for all fittings. Add approximately 5 feet of pipe per fitting.
- Natural Gas Example: A machine with a burner that requires 440,000 BTU would need a 1 -1/4" pipe for a 20" long run.

## LIQUID PROPANE : PIPE SIZING CHART

Length of Pipe in Feet	1/2"	3/4"	1"	1 - 1/4"	1 - 1/2"	2"	2 - 2 1/2"	3"	4"
10	275	567	1071	2205	3307	6221	10140	17990	35710
20	189	393	732	1496	2299	4331	7046	12510	25520
30	152	315	590	1212	1858	3465	5695	10110	20620
40	129	267	504	1039	1559	2992	4778	8481	17300
50	114	237	448	913	1417	2646	4343	7708	15730
60	103	217	409	834	1275	2394	3908	6936	14150
70	89	185	346	724	1086	2047	3329	5908	12050
80	78	162	307	630	976	1811	2991	5309	10830
90	69	146	275	567	866	1606	2654	4711	9613
100	63	132	252	511	787	1496	2412	4281	8736
125	54	112	209	439	665	1282	2083	3618	7382
150	48	100	185	390	590	1138	1808	3210	6549
175	43	90	168	353	534	1030	1637	2905	5927
200	40	83	155	325	491	947	1505	2671	5450
300	37	77	144	303	458	887	1404	2492	5084

- Liquid Propane (LP) Gas flow is given in thousands of BTU/hr. = 1 cubic foot of LP gas - 2500 BTU.
- This chart refers to low pressure LP, after regulation, Standard nominal pressure at the burner for Liquid Propane Gas is 11" of water column.
- Pipe length must include additional length for all fittings. Add approximately 5 feet of pipe per fitting.
- LP Example: A machine with a burner that requires 440,000 BTU would need a 1" pipe for a 20' long run.

NOTE: The sizing charts above list the specific pipe sizes required for the amount of BTU's for a new gas line installations. If you are using an existing gas line you must take into consideration the existing gas line capacities to ensure you will have proper pressure. **This chart is for reference only, we recommend you consult with a Licensed Plumber/Gas Fitter or NFPA54 (National Fuel Gas Code - current edition) for more details.**

**Table 4** Gas pipe sizing.



# PRE-INSTALLATION CHECK LIST FOR A SINGLE INSTALL

## GAS INFORMATION


**Gas Volume** - Ensure the correct size pipe is used for the total gas load. If installing more than one fire feature, ensure the correct size pipe is based upon the distance of the furthest fire feature away and the total gas load is for all gas appliances on that gas line (i.e. fire pit, BBQ, torches, etc.).

**Gas Pressure & Type of Gas** - What is the gas pressure being supplied to the fire pit? Is the fire pit(s) configured for the proper gas type? The AWS gas valve is shipped for Natural gas. To convert to Propane (LP) gas, the secondary pilot orifice must be changed.

**Manual Shut-off/Key Valve** - Is there a manual shut-off or key valve installed within 6-feet of the fire feature? Did you verify proper distance with local and national codes?

**Purging a New Gas Line** - Has the gas line been purged of both air and possible debris? Any gas lines buried underground must be pressure tested up to 60PSI to ensure no leaks. After inspection is complete, most plumbers will release pressure in the line at one location by opening the manual ball/key valve. It is recommended to release pressure by opening a ball/key valves associated with all the fire features. **Example:** There are four fire features on a job, open the first key valve for a few seconds, then close it. Then move on to the next key valve and do the same thing until you have purged the debris out of all four gas lines.

**Main Burner Orifice** - All fire pits **MUST** have a main burner orifice installed on the inlet side of the burner. An orifice limits the amount of gas flow to the burner to ensure the flame is a safe and reasonable height to not pose a risk to people or property. The drawings below show the difference between a Natural gas and Propane (LP) orifice. Because LP gas does not burn as clean as Natural and requires ventilation holes at the base of the orifice to provide a cleaner flame. See Fig. 5.



**Fig. 5** Natural (NG) orifice on left; LP (vent holes) on right.

## ELECTRICAL INFORMATION

**Wire Gauge** - Is the wire gauge correct? Wiring must be 12AWG or greater (solid or stranded) for all installations.

**Note:** It is recommended to fill the wire nuts with either dielectric grease or silicone prior to installing the wire nut. This will ensure a waterproof connection.

**Why GFI circuit?** A GFI is a type of circuit breaker which shuts off electric power when it senses an imbalance between the outgoing and incoming current. It protects the house wires and receptacles from overheating and possible fire.

**Power Supply** - Firegear Outdoors offers two power supplies for use with AWS fire pits. Each power supply requires 120VAC power to operate and converts it to 30VDC to operate the gas valve. **DO NOT CONNECT 120VAC DIRECTLY TO THE GAS VALVE WIRES - DAMAGE WILL OCCUR.**

The **GOE-30VDC** (supplied) is used for one fire pit only, installed 10-feet or greater from a pool or spa. This power supply has a 3-foot power cord to plug into 120VAC outlet and a 3-foot leads to connect to the gas valve on the 30VDC side.

The **FG-PS30V320** (optional) model has an 8-foot power cord and can be used for one or a maximum of four fire pits. The maximum distance the furthest fire pit can be from the power supply is 500-feet. In addition, the **FG-PS30V320** model enables a fire pit to be installed within 5-feet of a pool or spa.

**Bonding** - Gas lines must be bonded AT EACH fire pit. (Refer to National Electric Code 2017 Section: 680.26(B)).

## MEDIA INFORMATION

Acceptable media placed over top of the burner:

- Lava Rock** 1" - 2" size  
FG-LAVA-10 (10 LB)  
FG-LAVA-40 (40 LB)
- GL Glass** 1/2" - 3/4" size  
Various colors are available  
See Product catalog for details  
*Sold in 5 LB bags or 8 bags to a case*
- GRL Reflective Glass** 1/2" - 3/4" size  
Various colors are available  
See Product catalog for details  
*Sold in 5 LB bags or 8 bags to a case*

## DRAINAGE INFORMATION

For any fire pit ABOVE ground level requires a drain line or a way for water to exit the fire pit.

**Note: The AWS system is not approved to be installed BELOW ground level.**





## PREPARING A NON-COMBUSTIBLE STRUCTURE FOR A SINGLE INSTALL

### POWER SUPPLY LOCATION

The GOE-30VDC power supply is to be installed inside the enclosure due to the wire length limitations. The power cord is 3-feet long the 30VDC leads to the valve are 3-feet long. See Fig. 5.

## Non-Pool Certified Applications (Must be 10-feet or more away from pool or spa)





Fig. 6 Example of a single fire feature install. **Note:** Must be 10-feet or more from a pool/spa.

## PREPARING A NON-COMBUSTIBLE STRUCTURE FOR A SINGLE POOL INSTALL




**Note: Actual Power supply must be 10-feet or more from the pool or spa**

Fig. 7 Example of a single fire feature install within 5-feet of a pool/spa.

**Note:** Requires FG-PS-30V320 power supply (purchased separately). Do not use the GOE-30VDC. FG-PS-30V320 power supply can be installed up to a maximum of 500-feet away from fire pit.



## REMOVING FIRE PIT ASSEMBLY FROM CARTON



**Fig. 8** Shows carton contents. **Note:** An H-burner was illustrated for this drawing.

Open carton and remove contents. Inspect for any damage or missing parts.

Before the fire pit is set inside the enclosure, install the 46" flex connector to the gas valve box and to the manual key valve.

This system can use an optional hand held remote control (Model 1420-A). Wire it as shown in Fig. 9. The remote control receiver will fit inside the weatherproof box (provided). Use the instructions provided with the remote control to "learn" (program) the transmitter to the receiver.

**Note:** There is an extra red jumper wire provided to extend either red wire of the 1420-A remote control receiver. It is not required to use this wire. It depends on each application.


Use dielectric grease on all wire connections and ¼" connectors to prevent moisture issues from the outdoor environment.

The AWS system is polarity sensitive. There is a red sleeve attached to the positive (+) side of the adapter. When wiring the remote control receiver, one red wire from the receiver connects to the adapter with the red sleeve. The other red wire of the receiver connects directly to the red wire from the gas valve control box. See Fig. 10 on page 11.


Carefully install the fire pit into the prepared enclosure, connect the gas line and wire according to the figure drawings in this manual.



# WIRING DIAGRAMS FOR A SINGLE INSTALL



**Fig. 9** Wire diagram of AWS system with optional 1420-A remote control receiver.



**Fig.10** Shows typical installation of fire pit using AWS system



## MEDIA REQUIREMENTS

<b>Media Required Per H-Burner Models:</b> N=Natural P= Propane	<b>Lava Rock Only</b>	<b>Glass Only</b>	<b>Lava Stones Only</b>
LOF-2412HAWS-N/P	10lbs	15lbs	10lbs
LOF-3012HAWS-N/P	15lbs	20lbs	15lbs
LOF-3614HAWS-N/P	20lbs	25lbs	20lbs
LOF-4814HAWS-N/P	30lbs	35lbs	30lbs
LOF-6016HAWS-N/P	45lbs	50lbs	45lbs
LOF-7216HAWS-N/P	55lbs	60lbs	55lbs
LOF-8416HAWS-N/P	65lbs	70lbs	65lbs
LOF-9616HAWS-N/P	75lbs	85lbs	75lbs

**Table 5** H-Burner Media requirements

<b>Media Required Per T-Burner Models:</b> N=Natural P= Propane	<b>Lava Rock Only</b>	<b>Glass Only</b>	<b>Lava Stones Only</b>
LOF-2406TAWS-N/P	10lbs	10lbs	10lbs
LOF-3006TAWS-N/P	10lbs	10lbs	10lbs
LOF-3606TAWS-N/P	10lbs	15lbs	10lbs
LOF-4806TAWS-N/P	10lbs	15lbs	10lbs
LOF-6006TAWS-N/P	15lbs	20lbs	15lbs
LOF-7206TAWS-N/P	20lbs	25lbs	20lbs
LOF-8406TAWS-N/P	25lbs	30lbs	25lbs
LOF-9606TAWS-N/P	30lbs	35lbs	30lbs

**Table 6** T-Burner Media requirements

### **INSTALLATION OF LAVA ROCK/MEDIA INTO BURNER PAN**

**Note:** It is a good idea to conduct a test fire before placing media into the fire pit. This will enable you to check for any gas leaks and ensure the fire pit lights properly.


Install lava rock/media into the burner pan. Ensure the lava rock is a 1 to 2-inch diameter for proper operation.

**Note:** Do not pour Lava Rock directly from bag. It should be placed naturally and NOT packed in tight. Loose fitting is important to ensure robust flames. Be sure rocks are free of any excessive dust. This prevents the burner pan weep holes from being plugged and holding water.

**IMPORTANT:** Do not place rock over top or under the screen cover. The screen must be free of any debris to ensure proper lighting of burner and good flame sense (See Fig. 10).

Cover the burner completely with media but do not make the depth greater than 1-inch otop of the burner port-holes.

Do NOT cover the top of the screen hood with any rock or glass. It must be free an any debris to operate properly.



**Fig. 11** Media placement around pilot hood.



## OPERATION

**CAUTION:** Children and adults should be alerted to the hazards on high surface temperatures and should stay away to avoid burns or clothing ignition. Young children should be carefully supervised when they are in the area of the appliance.

**WARNING:** Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of control system and any gas control, which has been under water.

### SAFETY WARNINGS

1. Never leave the fire pit unattended during operation.
2. Clothing or other flammable materials should not be placed on or near the appliance.
3. Any guard or other protective device removed for servicing the appliance must be replaced prior to operating the appliance.
4. Installation and repair should be done by a qualified service person. The appliance should be inspected before use and at least annually by a qualified service person. More frequent cleaning may be required as necessary. It is imperative the control compartment, burners and circulating air passageways of the appliance be kept clean.
5. Inspect the fuel supply connection before each use of the appliance.
6. Temporary storage of this appliance indoors is permissible only if it has been disconnected from its fuel supply (Natural or L.P. gas line).

### WARNING

1. This appliance is hot when operated and can cause severe burns if contacted.
2. Do not burn any solid fuels in this appliance.

### **READ ALL LIGHTING INSTRUCTIONS BEFORE ATTEMPTING TO LIGHT FIRE PIT**

**CAUTION: ENSURE YOU HAVE LEAK TESTED THE FIRE PIT BEFORE OPERATING AND THE TRANSMITTER AND RECEIVER HAVE BEEN “LEARNED”(PROGRAMED TOGETHER) FOR WIRELESS OPERATION.**

**WARNING: Do not stand over fire pit during ignition or operation due to high surface temperatures.**

## LIGHTING INSTRUCTIONS

### **TURNING ON FIRE PIT/FEATURE**

Prior to turning the fire pit ON, visually inspect the fire pit to ensure debris such as leaves or other combustible materials have not collected on top of the fire pit, which could burn and emit embers once the fire pit is turned ON. At the same time, ensure anyone standing close to the fire pit is aware you are turning it ON and steps away, at a safe distance prior to lighting.

The ignition sequence is as follows:

1. Turn the manual key valve to the ON position.
2. Turn the fire pit ON by pressing the ON button of the remote control. The hot surface igniter will heat up and begin to “glow” in approximately 10 seconds.
3. Once the hot surface igniter heats up, the pilot gas valve opens, a “click” is heard, and gas is released to the burner, lighting the fire pit.



The entire ignition sequence ignites within 20 seconds or less. If not, press the OFF button on the remote control and wait 5 minutes before trying again.

### **TURNING OFF FIRE PIT/FEATURE**







1. Turn the fire feature OFF by pressing the OFF button on the remote control (or switch/timer if applicable).
2. If you are no longer burning the fire pit until another time, we recommend turning the key valve to OFF position.





# AWS REPLACEMENT PARTS



Drawings not to scale.



10a



## REPLACEMENT PARTS


Item	Description	Qty.	Part Number
1	24" x 12" LH-Burner Pan Only (used with 21" x 10" burner)	1	78047
1	30" x 12" LH-Burner Pan Only (used with 27" x 10" burner)	1	78041
1	36" x 14" LH-Burner Pan Only (used with 33" x 10" burner)	1	78042
1	48" x 14" LH-Burner Pan Only (used with 45" x 10" burner)	1	78043
1	60" x 16" LH-Burner Pan Only (used with 57" x 10" burners)	1	78044
1	72" x 16" LH-Burner Pan Only (used with 69" x 10" burner)	1	78045
1	84" x 16" LH-Burner Pan Only (used with 81" x 10" burner)	1	78046
1	96" x 16" LH-Burner Pan Only (used with 93" x 10" burner)	1	78062
1	21" x 10" H-Burner (used with 24" x 12" LH burner pan)	1	10614
2	27" x 10" H-Burner only (used with 30" x 12" LH-burner pan)	1	10604
2	33" x 10" H-Burner only (used with 36" x 14" LH-burner pan)	1	10605
2	45" x 10" H-Burner only (used with 48" x 14" LH-burner pan)	1	10616
2	57" x 10" H-Burner only (used with 60" x 16" LH-burner pan)	1	10610
2	69" x 10" H Burner only (used with 72" x 16" LH-burner pan)	1	10611
2	81" x 10" H-Burner only (used with 84" x 16" LH-burner pan)	1	10613
2	93" x 10" H-Burner only (used with 96" x 16" LH-burner pan)	1	10619
2	24" x 6" LT- Burner Pan Only (use with 21" T-burner)	1	78032
3	30" x 6" LT-Burner Pan Only ((use with 27" T-burner)	1	78033
3	36" x 6" LT-Burner Pan Only (use with 33" T-burner)	1	78034
3	48" x 6" LT-Burner Pan Only (use with 45" T-burner)	1	78035
3	60" x 6" LT-Burner Pan Only (use with 57" T-burner)	1	78036
3	72" x 6" LT-Burner Pan Only (use with 69" T-burner)	1	78037
3	84" x 6" LT-Burner Pan Only (use with 81" T-burner)	1	78058
3	96" x 6" LT-Burner Pan Only (use with 93" T-burner)	1	78061
4	21" T- Burner Only (used with 24" x 6" T-burner pan)	1	10615
4	27" T- Burner Only (used with 30" x 6" T-burner pan)	1	10600
4	33" T- Burner Only (used with 36" x 6" T-burner pan)	1	10601
4	45" T-Burner Only (used with 48" x 6" T-burner pan)	1	10602
4	57" T-Burner Only (used with 60" x 6" T-burner pan)	1	10603
4	69" T-Burner Only (used with 72" x 6" T-burner pan)	1	10612
4	81" T-Burner Only (used with 84" x 6" T-burner pan)	1	10617
4	93" T-Burner Only (used with 96" x 6" T-burner pan)	1	10618
5	Burner Tube Support Bracket	4	78019
6	Burner Tube Hook Bracket	4	78020
7	OAS# (Orifice air shutter) for Natural Gas	1	See pages 4 & 5
7A	OAS# (Orifice air shutter) for LP	1	See pages 4 & 5
8	½" Flex Gas Line (46-inch Length)	1	T-200-9898-46
9	AWS Ignition Control Box (Contains Gas Valve)	1	FG-ICB
10	AWS Pilot Assembly - 30-inch	1	FG-PBA
11	LOF Heat Shield	1	78027
12	30VDC Transformer (Power Supply)	1	GOE-30VDC
13	½" Flare x to ½" MIP	1	U1-8D-S
14	Weatherproof Cover	1	FG-COVER
15	Weatherproof Junction Box	1	FG-JBOX



## REPLACEMENT PARTS

Item	Description	Qty.	Part Number
16	½" NPT Female to ½" Male Flare Fitting (not shown)	1	U3-8D-S
17	½" MIP Lock Nut	1	105-8

### Valve Box Reference



## MAINTENANCE

1. The fire pit should be inspected and cleaned before initial use at least annually by a qualified field service person.
2. Any component that is found faulty must be replaced with an approved component.
3. Any tampering or modifying with the fire pit is dangerous and voids all warranties.
4. During winter months in cold climates and various seasons operation the fire pit may be affected by weather conditions. It is recommended to use a cover/lid overtop of your fire pit to protect it from humid/rainy weather conditions when not in use. Heavy rains/downpours could affect the fire pit operation if not covered; if this occurs ensure you allow the fire pit time to dry out before attempting to operate. **NOTE:** If a combustible type cover is used over the fire pit when not in use be sure to remove it before operation to prevent a severe safety hazard.
5. Carbon (soot) may build up on the surface of logs (if installed) during heavy use. Sooting may also occur periodically on the screen of the ignitor hood. To clean, brush off with a dry bristle brush or cloth. Keep soot away from clothing or furniture.
6. Over time stainless steel parts can discolor when heated, usually a golden or brown hue. This discoloration is normal and does not affect the performance of the appliance.





## CONVERTING TO LP GAS

Conversion Kit	Common Parts	Pilot Conversion Kit	Btu Ratings	LP Orifice	Models
OAS-LPK47	S499-8, #113-SS4-D5, U3-8D-S	FG-AWS-PBO-P	50,000 (14.65kW)	OAS-LP47	LOF-2406TAW-S-N LOF-3006TAW-S-N
OAS-LPK41	S499-8, #113-SS4-D5, U3-8D-S	FG-AWS-PBO-P	75,000 (21.98kW)	OAS-LP41	LOF-3606TAW-S-N LOF-2412HAW-S-N
OAS-LPK35	S499-8, #113-SS4-D5, U3-8D-S	FG-AWS-PBO-P	100,000 (29.30kW)	OAS-LP35	LOF-4806TAW-S-N LOF-3012HAW-S-N
OAS-LPK31	S499-8, #113-SS4-D5, U3-8D-S	FG-AWS-PBO-P	125,000 (36.63kW)	OAS-LP31	LOF-6006TAW-S-N LOF-3614HAW-S-N
OAS-LPK29	S499-8, #113-SS4-D5, U3-8D-S	FG-AWS-PBO-P	150,000 (43.96kW)	OAS-LP29	LOF-7206TAW-S-N LOF-4814HAW-S-N
OAS-LPK26	S499-8, #113-SS4-D5, U3-8D-S	FG-AWS-PBO-P	175,000 (51.28kW)	OAS-LP26	LOF-8406TAW-S-N LOF-6016HAW-S-N
OAS-LPK22	S499-8, #113-SS4-D5, U3-8D-S	FG-AWS-PBO-P	200,000 (58.61kW)	OAS-LP22	LOF-9606TAW-S-N LOF-7216HAW-S-N
OAS-LPK19	S499-8, #113-SS4-D5, U3-8D-S	FG-AWS-PBO-P	225,000 (65.94kW)	OAS-LP19	LOF-8416HAW-S-N
OAS-LPK12	S499-8, #113-SS4-D5, U3-8D-S	FG-AWS-PBO-P	250,000 (73.26kW)	OAS-LP12	LOF-9616HAW-S-N


**Table 6** LP conversion chart

When converting Natural gas burners to LP gas the main burner orifice must be kept a minimum of 6-inches away from the burner connection (nipple) to prevent any back pressure at the LP orifice. See Fig. 12 below for details. **Note:** It is acceptable to install a 90° elbow, if necessary, to run the gas line the opposite direction (see Fig 13 or 14). A 90° elbow is not provided with the kit. **Note:** Pilot conversion kit (FG-AWS-PBO-P) must be ordered separate.




All NPT pipe threads must be sealed with approved gas Teflon tape or pipe compound.  
Check for any gas leaks before presuming normal operation after conversion is complete.


**CAUTION:** *Ensure there is ventilation under the burner to provide fresh air for air shutter/orifice.*



**Fig. 12** LP conversion illustration.




**Fig. 13** Optional LP conversion illustration shows a 90° elbow (not supplied).



**Fig. 14** Optional LP conversion illustration shows a 90° elbow and close nipple (not supplied).



## Sequence of Operation



The system is designed to relight itself if blown out. It will try (3) times to relight before it goes into a "hard" lock out. Then it must be turned OFF and back ON to reset it .

---

## START UP ISSUES

### 1. Turned the Fire Feature ON... but nothing happens.

- **No Power** - Check for power at the fire feature(s). Confirm proper power is being supplied to the system. 30VDC from power supply to valve and 120VAC volts where power supply is plugged into.
- **Defective Controller** - If for some reason someone connected 120VAC power directly to the gas valve, the controller inside the valve box will be damaged. If this happens, a burned electrical smell might be present.

### 2. Glow Plug does not glow.

- **Connector Not Plugged In Correctly** - Check the 2-Pin connector from pilot to the gas valve, Ensure it is plugged into place with the locking latch.
- **Pins Not Secure** - Check the pins inside the 2-pin connector, ensure they are not loose. If loose push them back in until tight and try system again.
- **Possible Defective Igniter** - Unplug the igniter and check resistance across the two pins inside the plastic housing coming from the pilot assembly. Use a multi-meter to check resistance. No resistance or resistance greater than 8 ohms indicates a defective igniter. Page 27 valve reference shows the igniter and thermopile 2-pin connections for testing.



## TROUBLESHOOTING

### 3. Glow Plug Glows, But Does Not Ignite the Gas

- **Insufficient Power** - If the glow plug is not getting enough power, it will not get ignite the gas.
- **Thin Wire** - The recommended minimum wire gauge is 12AWG . If wire is less than 12-gauge there may not be enough power to get the igniter hot enough.
- **No Gas** - Was the gas line purged of air. If gas line was not bled it may take a while before the gas gets to the fire feature.
- **Manual Shut Off Valve** - Is the manual shut-off or key valve open?
- **Debris** - Debris can get trapped inside the screen of the gas valve. Excessive amounts of pipe dope or Teflon tape and restrict gas flow.
- **Debris in Pilot Burner** - New gas lines, until bled, have air and will have some debris. Ensure gas it turned OFF and electrical is unplugged. Remove the two brass fitting from the gas valve, then use “canned air” to blow through the pilot outlets.
- **Wrong Pilot Orifice** - If the wrong pilot orifice is installed into the primary pilot it will not light.
- **Oxygen Starvation** - To ignite gas we need oxygen, fuel and a heat source. If the pilot assembly is buried underneath the glass media or lava rock it will not allow the pilot to light.
- **Weak Igniter** - In some cases, from the manufacturer’s glow plug will have slight difference in assembly which can cause some igniter’s burn hotter than others. These are tested before they are sent to customers but sometimes a weak one can get out. If this occurs, the symptom will always be the same - inconsistent or no ignition at all. In this case, replace the pilot burner.

### 4. Pilot Lights, But No Flame to the Main Burner

- **Valve Box Installed Backwards** - Check the label on the gas valve box and ensure the burner is connected to the OUTLET side of the gas valve box.
- **Thermopile Pins Not Secure** - Check the pins in the pilot burner connector, remove it from the gas valve and check for loose pins. If loose, push inward until tight and try again. If this happens, the glow plug will stay ON for up to 30 seconds before turning OFF. It normally shuts off in about 5 seconds.
- **Defective Thermopile** - Thermopile’s rarely go bad however if a product is used consistently for extended periods of time a thermopile can get too hot (like a blow torch) and eventually cause it to swell. Simply loosen the thermopile from the pilot assembly and slide it out. If it will not slide out because is it too tight, then it will need to be replaced.
- **Debris** - Debris can get trapped inside the screen of the gas valve. Over time rust and other debris can restrict the gas flow on the Outlet screen of the valve that can partially or sometimes even stop the flow. Inspect the screen, remove it and clean it then replace it.
- **Defective Controller or Main Gas Valve** - If you have inspected the thermopile connections and no debris is on the controller or gas valve; checked the power, then the gas valve or controller may be defective and will need replaced.

### 5. Fire Features Lights... Turns OFF Within A Few Seconds... and Restarts Again (Keeps repeating this sequence)

- **Gas Volume Insufficient** - When initially turning ON the fire feature pilot is lit and there is enough gas for the pilot to light, however once main gas valve is turned ON, the flow of gas to pilot drops not providing enough gas to keep the thermopile hot enough therefore the pilot will drop out and relight. This is usually caused by insufficient Gas Volume and can be caused by installing gas pipe too small to deliver proper amount of gas or by installing a Manual Gas Shutoff (Ball valve or Key Valve) with a capacity that is too small to allow enough gas to pass through to the feature.
- **Main Burner Orifice Not Installed** - Ensure the correct orifice is being used. If using LP gas it should have vent holes, Natural gas does not. See Fig. 3, page 8. The orifice/air mixer restricts the amount of gas flowing to the Main Burner. This restriction ensures that not ALL the gas will flow to the Main Burner, so there is still enough gas left for Pilot Burner.
- **Oxygen Starvation** - to ignite gas we need oxygen, fuel and a heat source. If the pilot assembly is buried underneath the glass media or lava rock it will not allow the pilot to light.
- **Defective Thermopile** - See Symptom 4, page 29 for Defective Thermopile.
- **Defective Controller** – If your plumbing is supplying enough gas, the Main Burner orifice is installed, the Pilot Burner is getting plenty of air and the Thermopile is not defective the only thing left is a Defective Controller inside the valve box. If you have a Defective Controller the only way to fix it is to replace it.



## TROUBLESHOOTING

### 6. Fire Feature Cycles (Turns On and Off) Every Few Minutes

- **Gas Volume Insufficient** – See symptom 5 page 29 for “Gas Volume Insufficient” for detailed explanation.
- **Oxygen Starvation (Pilot Burner)** – See symptom 5 page 29 for “Oxygen Starvation” for detailed explanation.
- **Defective Thermopile** – See symptom 4 page 29 for “Defective Thermopile” for detailed explanation
- **Defective Controller** – See symptom 5 page 29 for “Defective Controller” for detailed explanation

### 7. Main Burner Flame Lazy/Small or Flame NOT Spread Out Over Entire Burner

- **Gas Volume Insufficient** – See symptom 5, page 29 for “Gas Volume Insufficient” for detailed explanation
- **Debris On Inlet Screen; Valve Box** – See symptom 3, symptom 4, page 29 for “Debris on inlet screen for detailed explanation
- **Debris On Outlet Screen; Valve Box** – See symptom 4, page 29 for “Debris on Outlet Screen for detailed explanation.
- **Obstruction In Plumbing Between Gas Valve Outlet and Main Burner** – If your plumbing was sized correctly to deliver the proper amount of gas and the screens in the valve box are clean, inspect the plumbing between the valve and the burner for obstructions. Also, inspect inside the burner inlet to ensure no obstructions in there as well.

### 8. Main Burner Flame “Flares Up” Every Few Minutes

- **Fire glass/Media Layer too Thick** – Fire glass/media comes in different sizes. Use only ½” - ¾” diameter. If you put a thick layer of fire glass/media on top the burner, over 1” in depth; there is a good chance some of the gas will get “trapped” within the media while the feature is ON. When this happens, the trapped gas in the fire feature ignites and you see the “Flare Up” effect. Remove some of the fire glass/media from the burner to see if this fixes the problem.
- **Gas Leak** – Natural Gas is lighter than air therefore when released into the atmosphere it rises. If you have a Natural Gas fire feature and there is a gas leak the Natural Gas will rise to the top of the feature. Once it encounters the flame a flare up will occur. Propane is heavier than air so if there is a gas leak when using propane the gas will fall into the bottom of the feature. That is why it is REQUIRED drainage/ventilation be installed at the bottom of the feature when using Propane. You do NOT want Propane accumulating inside the fire feature.

## SHUTDOWN ISSUES

### 9. Turn the Feature OFF...but a Small Flame Continues to Burn in the Pilot Burner

- **Leak in the Pilot Burner Gas Valve** – When debris enters the gas valve by way of either the Inlet or outlet there is a chance some of that debris will enter the Pilot Burner Gas Valve and contaminate the seal inside the valve. If this occurs, the possibility exists the valve will not seal properly when turned **OFF** thereby allowing a small amount of gas to flow even after turned OFF. Often this will result in a small flame that continues to burn in the Pilot Burner after the feature has been turned OFF.




### 10. Turn the Feature OFF...But Small Flames Continue to Burn Out the Main Burner

- **Leak in the Main Burner Gas Valve** - when debris enters the gas valve by way of either the Inlet or Outlet there is a chance some of that debris will enter the Main Burner Gas Valve and contaminate the seal inside the valve. If this occurs the possibility exists the valve will not seal properly when turned off thereby allowing a small amount of gas to flow even after turned off. Often this will result in a small flame that continues to burn on the Main Burner after the feature has been turned OFF.



## OPTIONAL ACCESSORIES

The following accessories are available from your local Firegear dealer/distributor.  
Each accessory comes with a separate installation manual. Read each instruction thoroughly before installing.

 <p><b>Stainless Lids</b> See catalog for a windshield to fit your application.</p>	<p style="text-align: center;"><u>Media</u></p> <p><i>Lava Stones</i> 1" to 2" size (50lbs.) <b>Models:</b> FG-LS50 (Bag)</p> <p><i>Lava Rock</i> 1" to 2" size <b>Models:</b> FG-LAVA-40 (Bag) FG-LAVA-10 (Bag)</p> <p>See catalog for variety of glass media in various colors.</p>	<p style="text-align: center;"><u>Paver Control Panels</u> PAVER-CO-AWS    AWS systems</p> <p style="text-align: center;"><u>Vent Kits</u> Provide 18 sq. in of ventilation per side of enclosure)</p> <p><b>Model:</b> VENT-KIT-6X12SS <b>Model:</b> PAVER-VENT-4-LNTS <b>Model:</b> PAVER-VENT-6-LNTS</p>
<p style="text-align: center;"><u>Shut-Off Valves</u></p> <p><b>Model:</b> 01-387 3/8" OD Flare x 1/2" FIP <b>Model:</b> 01-487 1/2" OD Flare x 1/2" FIP <b>Model:</b> 01-266 3/8" OD Flare x 3/8" OD Flare <b>Model:</b> 01-288 1/2" OD Flare x 1/2" OD Flare</p>	<p style="text-align: center;"><u>LP Conversion Kit</u></p> <p><b>Model:</b> FG-AWS-PBO-P</p> <p>Converts primary pilot orifice to LP gas. <b>Note:</b> In addition, requires the main burner orifice to be changed to an L.P. orifice (purchased separately from supplier) See pages 4 &amp; 5 for LP orifice.</p>	<p style="text-align: center;"><u>Glass Windshields</u> See catalog for a windshield to fit your application.</p> <p style="text-align: center;"><u>FLEXFRAME</u> Universal brackets to support fire pit when using paver blocks or other non-combustible enclosures.</p> <p><b>Model:</b> FLEXFRAME-SS (2 piece) <b>Model:</b> FLEXFRAME-SS3 (3 piece)</p>
<p style="text-align: center;"><u>Emergency Stop</u> (Emergency shut-off valve)</p> <p><b>Model:</b> FG-EMER-STOP (includes J-Box and weatherproof cover)</p> 	<p style="text-align: center;"><u>Timer</u> (Mechanical gas timer)</p> <p><b>Model:</b> FG-TIMER- 2HR * Includes weatherproof J-box and cover</p> 	<p style="text-align: center;"><u>Pool Certified Power Supply</u></p> <p><b>Model:</b> FG-PS-30V320 Power supply required for any pool/ spa installations with 5-feet of water.</p>

**NOTE:** See the Firegear Outdoors catalog for other accessories also available.

**FOR TECHNICAL SERVICE, CALL: (800) 966-8126**

Firegear Outdoors  
14520 Delta Lane, Suite 105  
Huntington Beach, CA 92647

*Manual changes often occur, ensure to check the Firegear Outdoor website for any recent updates and warranty information.*



## **FIREGEAR LIMITED WARRANTY - 2021**

Firegear Outdoors hereby warrants to the end user that products will be free from material and workmanship defects that prevent safe and correct operation of the product. The warranty commences from date of sale to the end user for the following period:

### **CONSUMER RESIDENTIAL APPLICATIONS – MANUFACTURED AFTER 12/02/2019**

- BURNER SYSTEMS, BURNERS, COMPONENTS AND ACCESSORIES
- LIFETIME WARRANTY ON CONSTRUCTION AND MANUFACTURER DEFECTS
- LIFETIME WARRANTY - STAINLESS STEEL BURNERS AND PANS
- LIFETIME WARRANTY - BRASS BURNERS
- FIVE (5) YEAR WARRANTY - GAS VALVE, SPARK IGNITER, PILOT ASSEMBLIES
- FIVE (5) YEAR WARRANTY - AWS ELECTRONIC IGNITION SYSTEMS (24VAC, 30 VDC)
- FIVE (5) YEAR WARRANTY - TFS/TMSI ELECTRONIC COMPONENTS
- FIVE (5) YEAR WARRANTY – MT COMPONENTS (KEY VALVE)
- FIVE (5) YEAR WARRANTY - REFRACTORY GAS LOG SETS
- FIVE (5) YEAR WARRANTY - READY TO FINISH/ANF FIRE PIT ENCLOSURES
- FIVE (5) YEAR WARRANTY – SKYTECH MANUFACTURED OPTIONAL CONTROLS

### **OUTDOOR FIREPLACE – KALEA BAY**

- LIFETIME WARRANTY - CONSTRUCTION AND MANUFACTURER DEFECTS
- LIFETIME WARRANTY - STAINLESS STEEL COMPONENTS
- FIVE (5) YEAR WARRANTY - GAS VALVE, PILOT ASSEMBLY, POWER SUPPLY, CONTROLS
- FIVE (5) YEAR WARRANTY – SKYTECH MANUFACTURED OPTIONAL CONTROLS

### **SANCTUARY SERIES – GFRC FIRE FEATURES**

- THREE (3) YEAR WARRANTY - GFRC STRUCTURE
- REFER TO THE APPROPRIATE BURNER SYSTEM FOR WARRANT

*WARRANTY COVERS MANUFACTURING DEFECTS OR STRUCTURAL FAILURE. SMALL STRESS CRACKS AND SURFACE CRAZING ARE A NATURAL OCCURRENCE IN GFRC PRODUCTS AND NOT COVERED BY WARRANTY.*

### **READY TO FINISH/ANF ENCLOSURES**

- FRAME – LIFETIME WARRANTY ON CONSTRUCTION AND MANUFACTURER DEFECTS

### **ACCESSORIES**

- LIFETIME WARRANTY - CONSTRUCTION AND MANUFACTURER DEFECTS
- LIFETIME WARRANTY - STAINLESS STEEL COMPONENTS (LIDS, STAINLESS STEEL COVERS)
- ONE (1) YEAR WARRANTY – ESTOP1-OH, ESTOP2-5H WINDSHIELDS, HOSES AND REGULATORS



## COMMERCIAL APPLICATIONS – MANUFACTURED AFTER 12/02/2019

### BURNER SYSTEMS, BURNERS, COMPONENTS AND ACCESSORIES

- TWO (2) YEAR WARRANTY ON CONSTRUCTION AND MANUFACTURER DEFECTS
- TWO (2) YEAR WARRANTY - STAINLESS STEEL BURNERS AND PANS
- TWO (2) YEAR WARRANTY - BRASS BURNERS
- TWO (2) YEAR WARRANTY - GAS VALVE, SPARK IGNITER, PILOT ASSEMBLIES
- TWO (2) YEAR WARRANTY - AWS ELECTRONIC IGNITION SYSTEMS (24VAC, 30 VDC)
- TWO (2) YEAR WARRANTY – MT COMPONENTS (KEY VALVE)
- TWO (2) YEAR WARRANTY - REFRACTORY GAS LOG SETS
- FIVE (5) YEAR WARRANTY - READY TO FINISH/ANF FIRE PIT ENCLOSURES
- TWO (2) YEAR WARRANTY – SKYTECH MANUFACTURED OPTIONAL CONTROLS

### OUTDOOR FIREPLACE – KALEA BAY

- LIFETIME WARRANTY - CONSTRUCTION AND MANUFACTURER DEFECTS
- LIFETIME WARRANTY - STAINLESS STEEL COMPONENTS
- TWO (2) YEAR WARRANTY - GAS VALVE, PILOT ASSEMBLY, POWER SUPPLY, CONTROLS
- TWO (2) YEAR WARRANTY – SKYTECH MANUFACTURED OPTIONAL CONTROLS

### SANCTUARY SERIES – GFRC FIRE FEATURES

- THREE (3) YEAR WARRANTY - GFRC STRUCTURE
- REFER TO THE APPROPRIATE BURNER SYSTEM FOR WARRANTY  
*WARRANTY COVERS MANUFACTURING DEFECTS OR STRUCTURAL FAILURE. SMALL STRESS CRACKS AND SURFACE CRAZING ARE A NATURAL OCCURRENCE IN GFRC PRODUCTS AND NOT COVERED BY WARRANTY.*

### READY TO FINISH/ANF ENCLOSURES

- FRAME – LIFETIME WARRANTY ON CONSTRUCTION AND MANUFACTURER DEFECTS

### ACCESSORIES

- LIFETIME WARRANTY - CONSTRUCTION AND MANUFACTURER DEFECTS
- LIFETIME WARRANTY - STAINLESS STEEL COMPONENTS (LIDS, STAINLESS STEEL COVERS)
- ONE (1) YEAR WARRANTY – ESTOP1-OH, ESTOP2-5H WINDSHIELDS, HOSES AND REGULATORS



The end-user must provide a bill of sale, canceled check, or payment record to verify the purchase date and to establish the warranty period. This Limited Warranty shall be valid and limited to the original purchaser only.

**WARNING:** Any modification to the product will void the warranty.

This Limited Warranty shall be limited to the repair and/or replacement of parts that have been proven to be defective under normal use and service. All warranty claims must be made by the OEM/Distributor/Dealer account on behalf of the end-user. You may contact Technical Support at 800-966-8126.

Our Technical Service Department must confirm all approved defects. If a defect is confirmed and we approve the claim, we will replace such parts without charge. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

The manufacturer may request defective products returned with an RMA (Return Merchandise Authorization) issued by Firegear Outdoors for specific products, which is considered to be the nature of the defect and or warranty claim. Product to be returned should; be packed so as not to incur damages during transportation. Firegear is not responsible for damages on returned items. RMA is valid for thirty (30) days from the date issued. The RMA must be clearly marked on the outside of the package.

Please check with your local building code department or governing agency for proper approvals before purchasing. Firegear Outdoors is not responsible for any violation of local codes.

Travel, diagnostic cost, service labor to repair the defect on warranty parts to and from the factory will be the responsibility of the owner. We will not be responsible for labor charges and/or damage incurred in installation, repair, and replacement. Firegear is not responsible for Issues related to gas or electrical installation.

The Limited Warranty is voided if not assembled, installed, and operated as intended. This Limited Warranty does not cover any defects due to accident, abuse, misuse, alteration, misapplication, vandalism, improper installation or improper maintenance or service, removal from the original location, or re-installation into another location, or failure to perform normal and routine maintenance.

Damage due to severe weather conditions such as hail, hurricanes, earthquakes, tornadoes, discoloration due to overheating, exposure to chemicals (including chlorine and salt), either directly or in the atmosphere, or very high humidity, is not covered by this Limited Warranty. Coastal, humid and/or salt environments are subject to manufacturer review. All out-of-box claims must be made within 30 days of purchase and must be made prior to installation. Any product installed damaged will be considered damaged during installation and not covered under warranty.

There are no other express warranties except as set forth herein. For consumer applications, any applicable implied warranties of merchantability and fitness are limited in duration to the period of coverage of this Limited Warranty. Some states do not allow limitation on how long an implied warranty lasts, so this limitation may not apply to you.

For Commercial Applications, the liability of Firegear Outdoors is limited to the express terms of this warranty. We expressly disclaim any and all implied warranties, including any warranties of fitness for a particular purpose or merchantability.





We are not liable for any special, indirect or consequential damages. Our maximum liability is limited to the purchase price of the purchased units. Some states do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you.

We do not authorize any person or company to assume for it any other obligation or liability in connection with the sale, installation, use, removal, return, or replacement of its equipment, and or such representation are binding.

Firegear Outdoors  
14520 Delta Lane, Suite 105  
Huntington Beach, CA 92647





Having problems getting the gas appliance to operate?  
Don't leave the job site! We want to help! Call 800.966.8126 for  
Technical Support between the hours of 8:00AM to 5:00PM PST.  
**BEFORE YOU CALL WE WILL NEED THIS INFORMATION**

1. Model Number: \_\_\_\_\_
2. Serial Number: \_\_\_\_\_
3. How long is the gas line run? Nat Gas \_\_\_\_\_ LP Gas \_\_\_\_\_
4. What size is gas line? \_\_\_\_\_
5. Inlet Gas Pressure: \_\_\_\_\_ WC  
Manifold Gas Pressure: \_\_\_\_\_ WC
6. What type of media are you using? \_\_\_\_\_
7. Review the troubleshooting section in the installation manual.
8. What are the symptoms? Please be prepared to explain.
9. Be prepared to send photos to us when on the phone.
10. Found missing or damaged parts? Let us know ASAP or send photos.

