


USER MANUAL
PLATINUM
Brushless Electronic Speed Controller
PLATINUM-260A-HV-SBEC-V5
PLATINUM-260A-HV-OPTO-V5



20230717

HW-SMA052DUL-A0



Thank you for purchasing this HOBBYWING product! Please read this declaration carefully before use, once you start to use, we will assume that you have read and agreed with all the content. Brushless power systems can be very dangerous and any improper use may cause personal injury and damage to the product and related devices, so please strictly follow the instruction during installation and use. Because we have no control over the use, installation, or maintenance of this product, no liability may be assumed for any damages or losses resulting from the use of this product. We do not assume responsibility for any losses caused by unauthorized modifications to our product. Besides, we have the right to modify our product design, appearance, features and usage requirements without notification. We, HOBBYWING, are only responsible for our product cost and nothing else as result of using our product. Regarding the possible semantic different between two different versions of declaration, for users in mainland China, please take the Chinese version as standard; for users in other regions, please take the English version as standard.

01 Warnings


- Before using this product, read the instruction manual carefully. Ensure that the equipment is used appropriately to avoid damaging the ESC. The wrong usage will overheat the motor and may damage the electronics.
- It is important to ensure that all wires soldered are properly secured to avoid short circuits from happening. A good soldering station is recommended to do such a job to avoid overheating the circuit board as well as to ensure connections are properly welded.
- Even though the product has relevant protective measures, always use it in a safe manner in accordance with the operating environment noted in the manual (e.g. voltage, current, temperature and etc).
- Always remember to disconnect the battery each time after using it. Failure to do so will cause the battery to be completely discharged, resulting in an unpredictable danger.

02 Specifications


Model	PLATINUM 260A HV SBEC V5	260A / 400A	PLATINUM 260A HV OPTO V5
Continuous/Peak current	260A / 400A		
Input voltage	6-14S LiPo battery		
BEC	Switch Mode BEC; output voltage 5-12V adjustable (adjusted 0.1V); output current cont. 10A, Peak 30A	No BEC	
Input/Output wires	1 x black and 1 x red BAWG silicone wires / 3 x black 10AWG silicone wires	No BEC	
Independent parameter programming interface	Connect LCD program box or OTA module, or to power the cooling fan		
LED light	Display the statuses and fault alerts		
Size/Weight	89 x 50 x 34mm / 297g (With wires)	M3, 39 x 98mm	89 x 50 x 34mm / 287g (With wires)
Mounting holes	700-800 class electric helicopter (main rotor length 700-880mm), or fixed-wing		
The scope of application	700-800 class electric helicopter (main rotor length 700-880mm), or fixed-wing		

03 User Guide


1 Wiring diagram



2 Normal boot process




3 Throttle stick calibration operation method




04 ESC programming and Data checking

- The ESC parameters can be programmed specifically to meet different flight needs.
- The ESC will be able to record the calibration speed of the current flight (only in storage fixed speed mode), the minimal voltage, maximum temperature and other information. Please do not disconnect the power from the battery as the information will not be saved after the power has been disconnected. Connect LCD program box or OTA module to view.

1 Use Multifunction LCD program box to program ESC parameters (need to purchase separately)



2 Use OTA Module to program ESC parameters (need to purchase separately)



05 Programmable parameter items and instructions

Programmable parameter items and parameter values				
Item	Value			
1 Flight mode	Fixed-wing	Helicopter external Governo	*Helicopter Elf Governor	Helicopter store Governor
2 LiPo cells	*Auto Calculation	6S	8S	10S 12S 14S
3 Low-Voltage Cutoff Type	*Soft Cutoff		Hard Cutoff	
4 Cutoff Voltage	Disabled	2.8V-3.8V (Default *3.0V)		
5 BEC Voltage	5-12V(Default: *6.0V)			
6 Response time	4-25(Default: *15)			
7 Governor parameter P	0-9(Default: *5)			
8 Governor parameter I	0-9(Default: *5)			
9 Auto Restart Time	0-90 seconds(Default: *25 seconds)			
10 Restart acceleration time	1-3 seconds(Default: *1.5 seconds)			
11 Brake Type	* Disabled		Normal brake	
12 Brake Force	0-100%(Default 0%)			
13 Timing	0°-30°(Default 25°)			
14 Motor direction	*CW		CCW	
15 Active Freewheeling	*Enabled		Disabled	
16 Start-up force	1-7 (Default *3)			

** in the form below indicate factory defaults.

Programmable parameters project description

- Flight mode**
 - 1.1. Fixed-wing mode:** Suitable for fixed-wing. In this mode, the throttle has to be more than 5% (including 5%) to start the motor and the throttle response is rapid.
 - 1.2. Helicopter external Governor mode:** Suitable for helicopter aircraft without any fixed speed equipment or helicopter aircraft using external speed control equipment. The throttle has to be higher than 5% (including 5%) before starting the motor. After the slow start is completed, the motor will start in a smoother manner, followed by a faster throttle response accelerated to the current throttle value;
 - 1.3. Helicopter Elf Governor Mode:** Suitable for helicopter aircraft flying at fixed speed. The throttle has to be higher than 40% (including 40%) before starting the motor. In the slow start process, the motor starts off in an ultra-smooth acceleration to complete the speed calibration.
 - 1.4. Helicopter store Governor mode:** Suitable for the use of fixed speed flight helicopter aircraft. The throttle in this mode has to be more than 40% (including 40%) before starting the motor. The motor starts in an ultra-smooth manner, after the completion of slow start speed into the fixed speed operating state.
- *Note that speed calibration must be done each time other modes are switched to using this mode.
- LiPo cells**

The number of battery cells can be calculated automatically and set manually. Select Auto-calculation to calculate the number of battery cells. Error on battery cells will be detectable during self-test and can be adjusted accordingly.
- Low-Voltage Cutoff Type**

Soft Cutoff: The output power will be gradually reduced to 50% of the total power output after low voltage protection is triggered.
Hard Cutoff: Disconnect the power output immediately after low-current protection is triggered.
- Cutoff Voltage**

2.8V-3.8V with 0.1V step adjustability. When using 6 lithium batteries, the final protection voltage should be set by x6.
- BEC Voltage**

The ESC is built-in with a BEC of 5-12V and has the capability to adjust 0.1v per step.
- Response time**

Adjust the response speed of the throttle in "helicopter elf Governor" or "store Governor". The higher the value, the slower the throttle response speed. 4-25 fully adjustable.
- Governor parameter P**

This item is for controlling the ESC compensate the amount of the motor speed during the process of maintaining the speed-governing effect; the higher the value, the bigger the amount; and vice versa. This function functions together with the Governor Parameter I.
- Governor parameter I**

When the speed falls below, or exceeds the value set, the speed is compensated by the ESC. This parameter is used to resize the degree of rotation. Too large parameters will cause excessive make-up, too small parameters will cause insufficient replacement.
- Auto Restart Time**

This feature is only available in helicopter elf or storage fixed speed modes. It is the time set to push the throttle from more than 40% to 25% to 40% throttle range, and then push back more than 40%. The parameter will not take effect when the throttle range is below 25% or between 25%-40% beyond the set time. The ESC will execute the "helicopter elf / storage fixed speed" modes of the default start-up process only if the throttle range is above 40%.
- Restart acceleration time**

1-3 seconds, with 0.5 seconds step adjustability. This parameter controls the time required for the motor to accelerate from zero to full speed during a quick restart. (This is an auxiliary function and is only valid if the "time to turn off and land" function is valid)
- Brake types**

Normal brake: This function will stop the motor from braking during operating according to the value set on the braking force.
- Brake Force**

The greater the value, the shorter the time taken for the motor to come to a standstill. 0-100%, with 1% step adjustability. This function is only valid in normal brake mode.
- Timing**

This item is for adjusting the ESC timing, it's adjustable between 0 and 30° with the step of 1°.
- Motor direction**

This item is for setting the rotation direction of the motor, it's "CW" by default. After connecting the motor to the ESC, (if the motor rotates clockwise), when setting this item to "CCW", the motor will rotate counterclockwise; (if the motor rotates counterclockwise), when setting this item to "CCW", the motor will rotate clockwise.
- Active Freewheeling**

This item can be enabled or disabled when the "Flight mode" is set to the "Fixed-wing" or "Helicopter (External Governor) mode"; it's fixed at "Enabled" when the "Flight Mode" is set to the "Helicopter (Elf Governor)" or "Helicopter (Store Governor)" mode. With this item enabled, the throttle linearity will be great.
- Start-up force**

This item is for adjusting the start-up force of the motor (during the start-up process). The higher the value, the larger the start-up force. It's adjustable between 1 and 7.

06 Speed Governor Function

1 Explanation for ESC Speed-governing

Establish the "Motor RPM-Throttle Amount Curve" via the speed standardization, and then set the throttle amount to some fixed value on the transmitter, in that condition, the motor will output the RPM corresponds to the throttle amount and keep rotating at that speed.

In the "Helicopter (Elf Governor)" mode, the ESC won't save the "Motor RPM-Throttle" curve after it's disconnected from the battery, so every time the ESC is connected to the battery, it will standardize the speed, otherwise you cannot use the speed-governing function normally. In this mode, due to the differences like batteries' different discharge capacity, the standardized RPM is a little different every time. In consequence, at the same throttle amount, the RPM may be a bit different when using different batteries, but this won't affect the speed-governing effect.

In the "Helicopter (Store Governor)" mode, the ESC will save the "Motor RPM-Throttle" curve after the speed standardization. So after adjusting to this mode from any other mode, you need to standardize the speed when the ESC is connected to the battery for the first time and you needn't standardize the speed again after disconnecting the ESC from the battery first and then connecting it to the battery again. If adjusting to any other mode from this mode and saving the "Motor RPM-Throttle" curve, and then adjusting back to this mode, the "Motor RPM-Throttle" curve saved by the ESC will be cleared, and you need to standardize the speed once again. If your ESC remains in this mode in future, then it will always carry out its operation as per the saved "Motor RPM-Throttle" curve. When standardize the speed for the first time, we recommend using a battery in good condition. After the RPM standardization, change another battery with the same number of cells to fly your aircraft. At the same throttle amount, the RPM should be consistent with the RPM of the first flight.


2 RPM Standardization

- Theory of RPM Standardization**

During the RPM standardization, the ESC will establish a "Motor RPM-Throttle" curve by itself based on the actual battery voltage and the actual KV rating of the motor. Therefore, you need to standardize the speed with a fully charged battery, and ensure the main blade pitch is 0° (in order to make the helicopter not take off). In general, please use the default "Throttle Curve & Pitch Curve" of the transmitter (as shown below) when they standardize the speed.

Attention! Please ensure the main blade pitch is 0° and the throttle amount is above 40% (we recommend using 50%) when standardizing the speed.
- Procedures of RPM Standardization**
 - We recommend using the default "Throttle Curve & Pitch Curve". (If you don't want to use the default setting, then please ensure the throttle amount is 50% and the main blade pitch is 0° when the motor rotates.
 - Turn on the transmitter, move the throttle stick to the bottom position and then wait for the ESC completing the self detection.
 - If you've set the "throttle cut" function, please lock the "throttle cut", and then move the throttle stick to the 50% position and then unlock the "throttle cut". If there is no "throttle cut", then you can move the throttle stick to the 50% position directly.
 - The ESC drives the motor to rotate, the main blades start to accelerate slowly because the main blade pitch is 0°, so the helicopter won't take off, but you still needs to be careful, you need to wait for the acceleration completing and the speed getting stable, and then lock the "throttle cut" or move the throttle stick to the bottom position.
 - The ESC will stop driving the motor, the main blades start to slow down and then stop rotating.
 - The RPM standardization completes.


Attention! Please calibrate the throttle range before the RPM standardization. There will be no need if you've carried out the ESC/ Radio Calibration when the first time you used this ESC or you didn't restore the settings to factory defaults after the calibration (changing the transmitter & receiver is an exception).



3 How to Set the Speed-governing Function

- The best throttle amount (set in the Helicopter "Store Governor" mode) of the ESC ranges from 70% to 90%, so please try to set the throttle amount (set in the Helicopter "Store Governor" mode) within this range. A low throttle amount (set in the Helicopter "Store Governor" mode) will make the ESC always function inefficiently, while a high throttle amount (set in the Helicopter "Store Governor" mode) will leave the ESC a very small compensation space, then compensation insufficiency issue may happen and cause (speed decrease) problem when the load is high. In that case, we recommend changing the motor or drive gear ratio (you need to re-standardize the speed after you change the motor or drive gear ratio).
- In the "Helicopter (Store Governor)" mode, if you fly your aircraft with a low performance battery after standardizing the speed with a high performance battery may cause damage to the low performance battery.
- In "Helicopter (Store Governor)" mode, different battery packs can bring the same stable RPM only if they have the same cell count. This won't change even when you change the battery pack. However, battery packs with different cell count don't have the same effect. For instance, in "Helicopter (Store Governor)" mode, you can't use a 4S to calibrate the motor RPM and then use a 6S to drive the motor, hoping it can run at the same RPM.
- You can decide the control feel via adjusting Governor Parameter P/I. In "Helicopter (Store Governor) or Helicopter (Elf Governor)" mode, connect your ESC to a smart phone or PC, then you can check the "throttle vs speed" chart.

- In "Helicopter (Store Governor)" mode, you can check the standardized speed (Max. RPM) and needn't standardize the speed every time when the ESC is connected to the battery as in the "Helicopter (Elf Governor)" mode, so it's more convenient. We recommend using this mode in the condition that you're using fixed motor, drive gear ratio and battery (with same cell count). In this mode, only if the drive gear ratio is accurate, the main blades' RPM corresponds to the throttle amount (set in the Helicopter "Store Governor" mode) you will get will be accurate as well. About how to "set the speed-governing function" in this mode, let's take an example. 1.
 - In "Helicopter (Store Governor)" mode, connect the ESC to the LCD program box or WiFi Express module when the RPM standardization completes, and then find the record (as shown below) as per the instruction about the "data checking" process. The value shown in the image is just an example, please take the value actually displayed on your LCD program box as standard. This value is the max. electrical RPM the motor can reach at the 100% throttle.
 - Take a helicopter with single reduction gear unit as an example, with the motor poles is 10, the motor drive gear is 13T and the main drive gear is 120T (that the drive gear ratio is 9.3), then you can get the main blades' RPM at the 100% throttle.
- Formula: Main Blades' RPM (at the 100% throttle)=Max. RPMs (Motor Poles ÷2)÷Drive Gear Ratio**
- The Main Blades' RPM (at the 100% throttle) in the example is: 157*1000÷(10÷2)÷(120÷13)=3400 RPM. If the Main Blades' RPM needs to remain at 2700RPM during the 3D flight process, then you need to set the throttle amount (set in the Helicopter "Store Governor" mode) to 2700÷3400=0.8, that is you need to set the throttle amount to 80%. At this time, you need to set the value of the 3D throttle curve (i.e. IDLE1) to 80% (as shown below). So next time, when you fly your helicopter, let it take off in the "Normal" mode first and then switch to the "IDLE1" mode directly, then your helicopter can start the 3D flight with 80% throttle amount (that's the standardized speed of 2700 RPM).
- Notes:** in general, you can set and save 2/3 sets of throttle curve IDLE settings on a high quality transmitter (and you need to adjust the main blade pitch of each set of IDLE setting as per the actual demand), and switch between these settings during the flight and have the different throttle amount (set in the Helicopter "Store Governor" mode) to meet the different RPM demands (i.e. when setting IDLE1 to 70%, IDLE2 to 80%, IDLE3 to 90% in the way as explained earlier, then you will have three different throttle amounts (set in the Helicopter "Store Governor" mode) to meet different flight demands).
- In the "Helicopter (Elf Governor)" mode, you are not allowed to check the Max. RPM, so you need to set the transmitter in advance and check the main blades' RPM with the help of some external device (like RPM viewer) and then decide the throttle amount you need to set. Here you can calculate the throttle amount roughly. For example, if the KV rating of the motor is 480KV, the battery is a 12S LiPo, the motor drive gear is 13T and the main drive gear is 110T, then the main blades' RPM is: KV Rating * Battery Voltage ÷ Drive Gear Ratio (480*12*4.2*13÷110=2850). So if you want your motor to rotate at the speed of 2150RPM, then the throttle amount is: 2150÷2850=0.75 (that is 75%), and then you adjust it accordingly as per your preference or the data you read on the RPM viewer.



07 Warning Tones and Protection

1. LED indicators and warning notes			
Protection	Tone	LED indicator	Instruction
The input voltage is abnormal	"BB, BB, BB, BB..."	Red LED, followed by the tone	The input voltage is not within the input voltage range
Throttle signal loss	"B...B...B...B..."	Red LED, followed by the tone	The throttle signal input was not detected
The throttle stick is not moved to the 0% position.	"B, B, B, B..."	Red LED, followed by the tone	The throttle value is not at 0% throttle
The throttle range is too small	"B, B, B, B..."	Red LED, followed by the tone	When calibrating the throttle stroke, set the throttle travel too small
Temperature protection	"BB, BB, ..." or "BBB, BBB..."	Red LED, followed by the tone	The internal temperature of the ESC exceeds the protection temperature
Low voltage protection	"BBBB, BBBB..."	Red LED, followed by the tone	The operating voltage is lower than the set protection voltage
Current protection	None	Red is always bright	The operating current is higher than the set current

- Protection function description**
 - **Abnormal power-on voltage protection**

The ESC enters a protective state once the input voltage detected is not in the operating range. Prompting LED light to flash.
 - **Start-up protection**

The start-up protection will be able to detect the motor speed from when the speed stops rising or the rising speed is unstable. If the throttle input is less than 15%, the ESC will try to restart automatically. (This may occur due to, Poor contact between the ESC and motor connections, individual output wires, faulty motor, propellers blocked by other objects, Binding gears, etc.)
 - **Temperature protection**

When the operating temperature of the ESC has exceeded 110 degrees Celsius, power will be gradually reduced for safety, but will not be turned off. There will still be up to 50% of power, to ensure that the motor has the power to land. After the temperature drops, the ESC will gradually be restored back to maximum power. ESC temperature must not exceed 70 degrees or it will not work. Prompting LED light to flash (above is the soft-off protection mode, if you choose hard-off, cut off the power directly)
 - **Throttle signal loss protection**


When the throttle signal is lost for more than 0.25 seconds, the output is immediately switched off to avoid further damage due to the propeller rotating at a high speed. Once the signal has been restored, the power output will be restored.
 - **Overloading protection**

When there is a sudden surge of current, power will be cut off and will be restarted. If the load is still abnormal after the restart, the power will be completely cut off.
 - **Low voltage cutoff protection**

When the operating voltage of the ESC has exceeded the protection voltage set, power will be gradually reduced for safety, but will not be turned off. There will still be up to 50% of power, to ensure that the motor has the power to land.
 - **Over-current protection**

The current will be cut off immediately once the set value has been breached.

PLATINUM 空模无刷电子调速器 使用说明书



20230717

HW-SMA052DUL-A0



感谢您购买本产品！在使用之前，请仔细阅读本说明，一旦使用，即被视为对本声明全部内容的认可和接受！

01 产品注意事项


- 使用本产品前，请认真查看各设备及飞行器的使用说明书，确保动力匹配合理，避免因错误的动力匹配导致电机过热、最终损坏电机。

02 产品规格

Table with 3 columns: Model (PLATINUM 260A HV SBEC V5 / PLATINUM 260A HV OPTO V5), Specifications (Current, Voltage, BEC, etc.), and Dimensions.


03 使用向导

1 接线示意图




- 1. BEC输出线（红、棕）：这条额外的BEC输出线插入接收机电池专用通道或任意空闲通道。

2 正常的开机过程



3 油门行程校准操作方法




04 参数设定与电调运行信息查看方法

- 本电调可进行参数设定，以满足不同的飞行需求。

1 使用LCD参数设定盒调参（需另购）

1.1 接线示意图



- 1.2 参数设定方法
按上图连接电调与LCD参数设定盒，将电调连接电池。


更改任意参数设定值后，电调均需重新上电，新的参数设定值才可生效。

1.3 电调运行信息查看方法

- 按上图连接电调与LCD参数设定盒。

2 OTA模块调参（需另购）

2.1 接线示意图



- 2.2 参数设定方法
按上图连接电调与OTA模块，将电调连接电池。

2.3 电调运行信息查看方法

- 按上图连接电调与OTA模块。

05 可编程参数项及说明

一、可编程参数项目

Table of programmable parameters including Flight Mode, Motor Parameters, and Protection Settings.

二、可编程参数项目说明

- 1. 飞行模式：电调可以设置四种飞行模式，以适应不同的飞行器。
1.1 固定翼模式：适用于固定翼飞行器，选择该模式后，油门高于5%启动电机。

06 定速功能说明及设置

1 电调定速说明

- 通过转速标定，建立电机转速-油门值对应曲线，然后在遥控器上将油门值设置为某一固定值。

2 转速标定

Includes sub-sections for 2.1 转速标定原理 and 2.2 转速标定过程, with diagrams and formulas.

3 定速功能设置

- 电调的最佳定速油门区间为70%-90%，设置定速油门请尽量在这个范围内。

07 LED指示灯，警示音及保护功能说明

一、LED指示灯，警示音及保护功能说明：

Table mapping protection types (e.g., Input Voltage, Low Voltage) to LED indicators and warning sounds.

二、保护功能说明：

- 1. 上电电压异常保护：电调连接电池或电源时，会检测输入的电压。