
DIESEL 4KW Air Parking Heater

Technical Description, Installation, Operation and Maintenance Instructions



Production Type

Order No

Diesel electric DC12V/220VAC 4W2005 12C11

Diesel electric DC12V/110VAC 4T3006 12C02

Version: Jul. 26, 2021

Plateau version

Foreword

Thank you for using the parking heater

This manual describes the technical description, installation, operation and maintenance instructions for the parking heater. To ensure the correct use of the heater please read this manual carefully before installation and use. Please keep it properly after reading it. For review.

Note:

- The contents of this manual are subject to change without prior notice, but the instructions are guaranteed to be consistent with the products purchased.
- we try our best to express the problems that users should know through the instructions. If you have questions or find something wrong, please contact us directly.
- When the user unpacks for the first time, check the main unit and accessories against the packing list. If you find any problems, please contact the dealer immediately.
- If there is a problem in use, please contact the company's marketing department or our authorized customer service station. We will be happy to help you.

Please carefully save the after-sales service warranty sheet and provide feedback as required. This sheet is the only valid proof of after-sales service.

Note:

Must be installed and used in accordance with the requirements of the manual to ensure long-term use of the product!

20210726 Edition Subject to Change

Plateau version

1. Application

FJH-4/IC-E Model air parking heater (hereinafter referred to as heater) is a special heater for caravan that integrates hot water and warm air. This heater cannot be used in bus or dangerous goods carriers.

2. Main Technical Data

	1	
Rated Voltage	DC12V	
Operating Voltage Range	DC10.5V~16V	
Short-term Maximum Power	8	8-10A
Average Power Consumption	1	. 8-4A
Fuel type	DIESEL	
Fuel Heat Power (W)	2000	4000
Fuel Consumption (g/H)	240/270	510/550
Quiescent current	1mA	
Warm Air Delivery Volume m3/h	287max	
Water Tank Capacity	10L	
Maximum Pressure of Water Pump	2. 8bar	
Maximum Pressure of System	4. 5bar	
Rated Electric Supply Voltage	~220V/110V	
Electrical Heating Power	900W	1800W
Electrical Power Dissipation	3. 9A/7. 8A	7.8A/15.6A
Working (Environment)	-25°C∼+80°C	
Working Altitude	≤5000m	
Weight (Kg)	15.6Kg (without water)	
Dimensions (mm)	510×450×300	
Protection level	IP21	

Table 1

3. Function

The heater is a hot water and warm air integrated machine, which can provide domestic hot water while heating the occupants. This heater allows use during driving. This heater also has the function of using local electricity heating.

In hot water warm air work mode, this heater can be used to heat both the room and the hot water. If only hot water is needed, please choose hot water working mode.

When the ambient temperature is below 3° C, please empty

the water in the water tank to prevent freezing of the water tank.

There are three energy options to choose from:

-- Diesel Mode

Heater automatic adjust the power.

-- Electrical Mode

Manually select the 900W or 1800W heating mode according to the power supply capacity of the RV camp site.

-- Hybrid Mode

When the power demand is low (for example, maintaining the room temperature stage), the electrical heating is preferred. Until the city electricity cannot meet, the diesel heating is started, and the diesel heating function is turned off first in the power adjustment phase.

In hot water working mode, gas mode or electrical mode is used to heat the tank. The tank temperature can be set to 40° C or 60° C.

-- Diesel Mode

The heater operates at the lowest power. Stop heating immediately after reaching the set temperature.

-- Electrical Mode

Manually select the 900W or 1800W heating mode according to the power supply capacity of the camp site.

4. Safety work environment

- -- The device can only be operated with appropriate control panels and accessories
- --Danger of toxic exhaust fumes. The heater 's exhaust can be toxic in enclosed spaces(e.g. garages, workshops). If the vehicle is parked in closed rooms:

 Shut off the fuel supply to the heater, Deactivate the time switch, Switch off the heater at the control panel.
- --If the cowl has been placed near or directly beneath an opening window, the appliance must be equipped with an automatic shut-off device in order to prevent operation with the window open.
- ——Heat sensitive objects (e.g. spray cans) or flammable materials/liquids must not be stored in the same compartment where the appliance is installed because nunder certain conditions, this area may be subject to elevated temperatures.
- --The openings for circulated air intake, the installation compartment and the space around the unit must be kept free of obstacles so that the unit does not overheat.
- --Keep the cowl for the exhaust duct and combustion air intake free of contamination (slush, ice, leaves etc.) at all times.

Danger from hot surfaces and exhaust gas. Do not touch the area around the wall cowl and do not lean any objects against the wall cowl or the vehicle.

Obligations of the operator/vehicle owner

- --The operator is responsible for the water with which the boiler is filled and for its quality.
- -- The vehicle owner is responsible for correct operation

- of the appliance.
- --Liquid fuel system must comply with the technical and administrative regulations of the respective country of use. The national legislation and regulations must be observed.
- --Pressure regulating devices and hoses must be replaced with new ones no more than 10 years after their date of manufacture (every 8 years if used commercially).
- --Inspect hose lines regularly and have them replaced if they are broken.
- -If the heater is not being used, always drain off the water if there is a risk of frost.NO claims may be made under the warranty for damage caused by frost.

Safe operation

- —The flow rate of the pressure regulating equipment must correspond to at least the maximum consumption of all devices installed by the system manufacturer.
- --Ensure that the inside of the vehicle is sufficiently ventilated when the unit is started up there may be some smoke and /or smell due to dust or dirt. Especially if it has not been used for a long time.
- -This appliance can be used by children aged 8 and over, as well as by persons with reduced physical.
- -The integrity and tight fit of the exhaust double duct must be checked regularly, particularly at the end of long trips. Also check the mounting of the unit and the cowl
- --When cleaning the vehicle, do not spray water directly into the cowl

5. Heater installation

The typical installation of the heater is




Figure 1

- 1-LCD control switch
- 2-External temperature sensor
- 3-Recirculating air inlet (minimum 150cm2)
- 4-Heat pipe
- 5-Heat outlet
- 6-Smoking cowl

★ Must be installed and repaired by professionals authorized by the company!

The company does not bear any responsibility for the following acts:

- --Modified heater and accessories
- --Modification of exhaust lines and accessories
- -- Do not follow the operating installation instructions
- -- Do not use our company's special accessories

Figure 2

1-LCD switch 9- Combustion air inlet

2- External temperature sensor 10-Electronic control unit

3-Cold water inlet 11-Water container

4-Hot water outlet 12-Burner

5-Fuel connection 13-Heat exchanger
6-Warm air outlets 14-Power electronic

7-Circulated air intake 15-Heating elements

8-Exhaust discharge 16-Overheating switch

Heater installation Figure 3.




Figure 3

1_12V Power cord 2_ LCD switch Lead wire 3_ LCD switch back cover 4_ LCD switch bracket 5_ Self-tapping screw M3*10
6_ LCD control switch 7_ Cross countersunk head flat tail self-tapping screw M3*6 8_ Self-tapping screw ST5*25
9_ Heater 10_ Controller cover 11_ External temperature sensor lead wire 12_ External temperature sensor
13_Fuelpump connector 14_Fuel pump 15_Fuel pipe clamp(\$\phi\$9-11)16_Damper 17_Fuel pipe connector 18_6-Fuel pipe (transparent, from heater to fuel pump) 19_Fuel pipe clamp(\$\phi\$8-10)20_ Fuel pipe (blue, from fuel tank to fuel pump) 21_\$\phi\$10 Steel
(water) pipe elbow transition fitting 22_ Hose(water) transition fitting 23_ Intake pipe mounting clamp 24_ Self-tapping screw ST3.5×25 25_ Air intake pipe 26_ German type clamp 27_ Exhaust pipe 28_ Sealing rubber spacer 29_(Exhaust pipe)
clamp 30_ Intake and exhaust combine cow131_ Intake and exhaust combine cover 32_ Air outlet
33_ Hot air ducting 34_ Ducting clamp 35_\$\phi\$60T-pipe 36_\$\phi\$60connector 37_\$\phi\$60 Elbow 38_ G1/2-\$\phi\$10 Ferrule fitting
39 Frost valve 40_ G1/2 T pipe 41_ Reducing valve 42_Filter (only diesel) 43_Fuel suction pipe
44_Self tapping self-drilling screw ST5*30 45_ G1/2-\$\phi\$10 Ferrule fitting 46_Vent valve 47_no return valve
A_ Connect to 12V Battery B_ connect to water equipment C_ connect to system water tank
D_Flow out of the car E_ Hook, clamp LCD switcher cord

Note: No. 21, 22, 35, 36, 37, 40, 45, 46, 47 are optional parts


The heater installation location should be selected from load-bearing floor, double floor or underfloor.


If there is no suitable floor, you can first make a load bearing surface with plywood.

★The heater must be firmly fixed to the mounting surface with screws to prevent damage to the gas pipeline during driving and cause danger. Depending on the actual installation, may only install three screws. Two die-cast aluminum fixing screws are fixed then choose a plastic right angle to fix it. To ensure that the heater evenly distributes heat, the

To ensure that the heater evenly distributes heat, the heater should be installed in the center as much as possible to ensure that the heating circuit is equal long as possible.


No cover is allowed to add to the heater surface.





To prevent the danger from heater accidentally loosening, the upper cover of the heater compartment is screwed to the upper cover (Figure 4-1). Next to the installation location it is necessary to install a strong partition strip in front of the heater, perpendicular to the direction of travel. Above the floor height180mm can be attached to a septum (minimum 30*50mm).

Heat sensitive objects and flammable objects should be placed away from the heater.



Figture. 5

★ The exhaust cowl must be on the side wall or ceiling.


In the exhaust cowl installed area, there is no ventilation window in the range of 300mm, and there is no refueling port or tank respirator in the range of 500mm.

The exhaust cowl is mounted below the window that is close to or operable. A window switch should be installed to ensure that the heater is turned off automatically when the window is opened.


Air Inlet Hose Installation

The exhaust pipe is passing through the intake pipe.

The length of the intake and exhaust pipe is as shown in Fig. 6, and the shortest is 60cm and the longest is 100cm. The exhaust cowl is only allowed under the exhaust outlet 20cm.



After the intake and exhaust pipes are pierced from the through holes, they must be cut short, and the exhaust pipes are slightly shorter than the intake pipes. Avoid excessive expansion or tension on the exhaust pipe.




Figure, 7

The length of the intake and exhaust pipes is 100 cm to 200 cm, as shown in Figure 7. The piping must be arranged in the ascending direction.

The Exhaust Cowl (air inlet and outlet) Installation Select a flat mounting surface so that combustion air can enter from all sides. Drill one hole of $\phi 83$. Seal (Fig. 8-8), with the plane facing the exhaust cowl.

Wear the fixing clip before installing the exhaust pipe (Figure 8-3). Pay attention to the installation of the smoke cap upwards.

20mm at the end of the exhaust pipe should be compressed, do not straighten. Insert the exhaust pipe into the exhaust cowl interface (Figure 8-10), as deep as possible. Try to fix the clips on the top, tighten.




Figture. 8

Place the air intake pipe (Figure 8-2) over the exhaust cowl tooth (Figure 8-11). Set on the fixed clip (Figure 8-7), tighten.

Secure the exhaust cow1 with 6 screws (Figure 8-9). Use 2 screws to fix the exhaust cow1.

Fix the exhaust pipe on the side wall with mounting clip.

Connect Air Inlet Pipe to The Heater




Figture. 9

20mm at the end of the exhaust pipe should be compressed, do not straighten.

Try to insert the exhaust pipe on exhaust port as deep as possible. fix the clip on top, tighten.

Place the air intake pipe (Figure 9-3) over the air inlet port (Figure 9-5). Set on the fixed clip (Figure9-6), tighten.

Warm Air Intake




Figture. 10

The warm air intake is drawn in by the heater. There must be a total area between the room and the heater not less than 150cm2 opening.

Ensure that the warm air intake is not contaminated by the engine or heater exhaust, if necessary, with structural isolation measures.

Warm Air Distribution

Most of the warm air is imported into the floor area of the living compartment through the bellows.



Figture. 11

The four air outlets on the heater are connected to the ϕ 65 bellows. Use only pressure piping that meets the quality requirements of the Belief. Other pipes that do not meet our quality standards (especially wind resistance, pipe diameter and number of ripples) shall not be used. If the warm air duct must withstand a considerable amount of bending immediately after the hot air outlet of the heater in a limited space, we recommend using a 90° elbow (Figure 3-37). This elbow can be connected to a diameter of 65mm hot air duct.




Figure. 12

In the case where the length of the pipe is less than 2 meters, the air outlet cannot be installed at a height higher than the connection of the warm air duct. When the pipe length is less than 50cm, the pipe must be siphon between the connector and the outlet. These measures prevent the undesirable heating caused by (fairing effect) convection of the vehicle during summer operation.

 \bigstar The warm air pipe must be firmly inserted into the connection port.

To get the best warm air distribution, Belief recommends using 4 warm air outlets for the heater. If only three warm air outlets are required, then a lower warm air outlet must be selected to seal.

★ The cross section of the heater duct must not be reduced due to pipe connections or the analogue. In other words, no less than four warm air outlets (figure 3_32) are opened. Make sure that more than four warm air outlets are opened.

Fuel system connection

The fuel is extracted from the vehicle fuel tank or supplied from the 10L special fuel tank. The fuel is transferred and the fuel supply is adjusted through the special fuel pump (provided by the manufacturer). Fuel extraction from the vehicle engine return system or downstream of the vehicle internal delivery pump is not permitted. Please install only the fuel hose and piping within the delivery range.

The fuel shall meet national standards
GB19147-2013 diesel standard for vehicles

Winter fuel should meet the low temperature requirements brand, do not allow the use of biofuels.

Fuel line system




Figure. 13

Installation of oil pipe

Only the flexible nylon pipe, which has good lightresistance and thermal stability, supplied with the
heater can be used as the fuel pipe. Allowable length
of fuel line: the maximum length of fuel line on the
inlet side is 2 meters, and the maximum length on the
pressure side is 6 meters. As shown in figure 13.

Safety Regulations for Fuel Pipe

Use a hose cutter or sharp cutter to cut the fuel hose and pipeline into a certain length. The cut area cannot be compressed and must be free of burrs. Fuel pipelines must be firmly connected to prevent vibration-induced damage or noise (the recommended distance between connecting points is about 50 cm). Fuel pipelines must be protected from mechanical damage. The laving of fuel pipelines will not adversely affect the stability of vehicle rotation and engine operation. Protect fuel-carrying parts from high temperatures that may affect operation (use appropriate glass fiber lined aluminum thermal protection hoses). Do not install or fix fuel lines near the exhaust pipes of heaters or vehicle engines. If the lines are crossed, keep enough distance from the thermal components - provide a thermal radiation shield if necessary. Pipe installation should be able to prevent flying stones from hitting, and keep away from heating parts of vehicles. Protective devices should be installed when necessary.


Installation of oil pump

The oil pump shall be fixed with a fixed jacket (rubber) of the oil pump. The outlet of the oil pump should be inclined upward, and its installation angle should be selected in the range of 15-35 as shown in Figure 14. When conditions permit, the tubing between the pump and the heater mainframe should gradually rise. In order to prevent the oil pump from being heated (the maximum operating temperature is 40 C), do not install it near the exhaust pipe.

The height difference between the fuel level and the oil pump, and the height difference between the oil pump and the main engine inlet, will generate pressure (or suction) in the oil pipeline, so these dimensions should meet the requirements of Figure 14 (negative pressure will occur in the closed tank, when the minimum liquid level of the tank is required to be no more than 0.4m).

Connection between heater and oil pump

The pipeline from the oil pump to the main engine should go up as far as possible. Mark the appropriate position on the floor of the vehicle for passage the hole of the fuel pipeline and the oil pump connecting the cable. Before drilling, pay attention to check the hidden cable, fuel pipeline, frame section, etc.



The lower body protection device is then used to seal the edges of the openings on the floor of the vehicle. In order to prevent the cable between the tubing and the oil pump from being cut, please add the lead-in bushing or section edge protection material. The tubing should be bundled at the appropriate place for fixing, and the bundling distance is not more than 50 cm.

Connections between tubing and oil pump, main engine and oil tank (oil intake nozzle) shall be made by using tubing joints matched by this unit and using oil. The pipe clip is clamped tightly. Prevent bubbles from forming at the junction (Figure. 15).





Figure 15

Installation of Fuel Filter

Install the fuel filter before the oil inlet of the oil pump. When installing, it should be noted that the fuel filter must be vertical upward (to ensure that impurities deposit downward). Fuel filter replacement cycle for two years, tubing connection head and clip must be replaced at the same time.


Installation of oil intake nozzle (Figure16)

Firstly, the oil intake nozzle is fitted with O-ring, and then it passes through the bottom hole (self-processing) through the inside of the tank. Put gaskets on the outside of the tank and tighten them with nuts. The tightening torque is 6Nm+1Nm. The O-ring must be clamped between the inner wall of the tank and the oil intake nozzle to ensure good sealing between the oil intake nozzle and the oil tank. (Accessories such as oil intake nozzles are attached to the tank)



Installation of suction pipe (Figure 17)

Use when drawing fuel from the fuel tank of the vehicle itself. When installing, attention should be paid to the size of the installation hole on the tank (or the cover of the tank) is 25 (+0.2), the edge is neat and the surrounding is smooth, so as to ensure good sealing between the suction pipe seat and the tank. The distance between the bottom of the suction pipe and the bottom of the tank should be 30-40 mm, which can not only ensure the full absorption of fuel, but also prevent the deposition of impurities at the bottom of the tank from being inhaled.



The connection of water pipe

A pressure pump or submerged pump with a pressure of 2.8 bar can be used to supply water to the water tank. If the water tank is connected to a centralized water supply (rural or urban connection), or if a highpressure pump is used, a decompress or must be used, which will prevent pressure above 2.8 bar.

★Before the relief valve is triggered, the temperature rise and expansion of the water may cause up to 4.5 bar of pressure (which may also occur with the submerged pump). Water pipes connected to water tanks and safety/drainage valves must be safe for drinking water, pressure-resistant (up to 4.5 bar) and hot water resistant up to 80° C. Antifreeze valve (Figure3-39, Freeze-proof automatic water discharger), A mechanical safety/drainage valve. When there is a danger of frost, it will automatically drain water from the tank through the drain.

Pressure relief valves must be installed (Figure3-41, 0.5MPa). If there is too much pressure in the system, the pressure will automatically be released intermittently through the relief valve.

A vent valve (Figure 3-46) must be installed to ensure that the antifreeze valve drains the water from the tank through the drain.

Installation of External Temperature Sensor

Install the car and measure the room temperature. The installation position of the sensor is determined by the manufacturer of the RV according to the specific conditions of the vehicle. When choosing the installation location, please note that the external temperature sensor should not be subjected to direct thermal radiation. In order to obtain the best room temperature control, an external temperature sensor is installed above the entrance door.





Figure 18

Make sure that the external temperature sensor is always mounted on the vertical wall. It must be surrounded by free-flowing air.

Drill a hole 10 mm in diameter. The single-wire terminal passes through the opening from the back and connects the end of the cable to the sensor with an insulating plug (without observing polarity). Slide into the external temperature sensor and connect the two ends of the cable with two insulating connectors to the heater electronic devices (if necessary, extend the cable to a maximum length of 10 meters, 2 *0.5 mm 2 cable). The external temperature sensor provided must always be connected, otherwise the heater will switch to failure.

Install LCD switch


Gas heater must be operated by special liquid crystal switch. See the relevant instructions for details.




Electrical Connection

Lay wires to avoid scratches. If there are sharp edges, such as metal panel threading, please use lead bushing or edge protection accessories. Connector cables shall not adhere to or touch metal surfaces, exhaust pipes or hot air pipes.

The electrical connection socket is located below the controller cover. The controller cover can be removed by pressing and sliding along the arrow at the same time. When removing or installing the controller cover, make sure that the connecting cable is not pulled out or squeezed.





- 1- DC12Vpositive electrode
- 2- DC12Vnegative electrode
- 3- Fuse
- 4- Window Switch
- 5- External temperature sensor
- 6- 7-control switch

Figure20

When the window switch is not installed, the short wiring cannot be removed. All cables connected to the heater should be poked in a sagging direction. This prevents condensate from slipping off the connector cable and entering the heater.




Figure21

Connector cables and plugs must not be subjected to force. (Figure 22), Tie connector cables and fasten them to the housing with straps to eliminate tension. All cables must be firmly connected together. They should not be loosened or disconnected by vibration, resulting in fire hazards!




Figure22

DC12V Power

The electric circuit, switch and control equipment of the heater must be located in a position that will not adversely affect its operation under normal working conditions. The heater has reverse polarity protection. If the controller is not properly polarized, the LED indicator will not work.

In order to provide the best power supply, the heater must be connected to the on-board power supply (or battery) protected by fuse (10A) with a 2 x 2.5 mm 2 cable (2 x 4 mm 2 for a length exceeding 6 m). If necessary, the voltage drop of the power supply line must be considered. Connect the negative pole line to the main grounding. If the heater is directly connected to the battery, the positive and negative lines must be protected. Do not connect other power-consuming equipment.

Electrical connection of oil pump





Figure23

Make sure the plug is firmly connected.



6. Operating precautions


Heaters are not allowed to operate during refueling or in enclosed spaces (enclosed parking lots, repair shops or ferry compartments). Check regularly whether the intake and exhaust pipes are in good condition and the fixing is reliable, especially after a trip. Also check the fixing of intake and exhaust pipes and smoke caps. When black smoke is found, the company's authorized professionals are requested to carry out the inspection. Ensure that the exhaust pipe and intake pipe at the smoke exhaust cap are free from blockages such as snow, ice and leaves. Warm air outlet and circulating air inlet are unobstructed to avoid overheating of heater. In the case of overheating, the overheating switch will immediately cut off the fuel supply.

If the fuel heater wants to meet the heating needs in driving, it should install safety shut-off device.

★If there is no safety shut-off device, the heater must be turned off before driving.

12V Fuse

Replacement with exactly the same fuse T20A is allowed only.




\sim 220V/110V Fuse

★ Fuses and wiring harnesses must be replaced by professionals authorized by the Company.

★All power supply must be disconnected before opening the control housing.


Fuse Specification: T10A/220V(20A/110V) Slow Fuse



\sim 220V/110V Overheat protection

The municipal electric heating function has a mechanical overheating protection switch. If the 12V power supply is interrupted during or after the heating process, the excess heat of the heater will trigger the overheating protection switch.

When the temperature of the water tank decreases, disconnect the power supply from 220V/110V, remove the cover of the controller, and reset the overheat protection switch by pressing the reset button by hand.



7. Operational instructions

Please read the instructions carefully before operation.

Start-up heater

Use special liquid crystal switch to operate.

Fuel oil, electricity, mixing mode, heating water tank or unheated water tank for main engine heating are set according to need.

Check the power supply capacity of RV camps, and choose the operation mode of 900W (3.9A/7.8A) or 1800W (7.8A/15.6A) accordingly. — Check whether the smoke exhaust cap is unobstructed

- -- Open Liquefied Gas Tank Switch Valve
- -- The tank is full of water when needed

Filling of water

Check whether the relief valve/drain valve is closed.

- ——Turn on the pump power supply (main gate or pump switch)
- ---Open the hot water tap in the kitchen or bathroom and keep the valve open until the air in the container is discharged and the water is continuously discharged.
- In the absence of water heater heating, if only the cold water system is in operation, the water heater will also be full of water. To avoid frost damage, the water heater must be drained through a safety/drainage valve, even if it is not running.
- ——In the case of frost, the frozen residual water can prevent filling. The water heater can thaw (no more than 2 minutes) if it is turned on for a while. The ice can be thawed through the inside of the heater.
- ——If the heater is connected to the central water supply system (rural or urban water supply system), a pressure reducer must be used to prevent pressure exceeding 2.8 bar (0.28 MPa).
- -- Open the circulating pump
- Open the hot tap in the kitchen and bathroom until the air is exhausted and the water tank is filled, and the water is not interrupted.

Turn off the heater

- -- Use special liquid crystal switch to operate.
- -After the heater is closed, the combustion-supporting fan and heating fan will continue to work for several minutes according to the temperature of the furnace body.

In case of freezing danger, it is necessary to ensure that the water tank is emptied.

-Close the circulating pump

-Turn on the hot tap in the kitchen and bathroom Heater drainage

- ---If the RV is not used during the frost. The heater must drain the water.
- ——Turn off the power supply (main power supply or pump switch) of the pump unit.
- --Turn on the hot tap in the kitchen and bathroom.
- ——In order to check the effluent, the safety/drainage valve (user-fitted, for manual emptying of the water tank) is installed. The anti-freeze valve cannot ensure that the water tank is completely emptied. Place a suitable container under the drain tank.
- ---Open the safety/drainage valve.
- ——The heater will be discharged directly to the outside through the safety/drainage valve. Check whether all water in the heater has been discharged into the container through the safety/drainage valve. Claims for damage caused by frost shall not be filed during the warranty period.

★The 10L bucket can be used for water inspection to ensure that the water tank is empty.

The valve of liquefied gas tank must be closed before heater is not used for a long time or running.

Maintenance/repair/cleaning

- -- The device can only be repaired and cleaned by experts.
- -- Maintenance, repair and cleaning cannot be done by children.
- —With new equipment, or the equipment has not been used for some time, thoroughly flush all hot/cold water hoses before use.

8. Failure

8. 1 General Failure Handling

- 8. 1. 1 During the use of the heater, it may appear that it cannot start normally or turn off it after starting and is in the fault lock state. At this time, the heater can be turned off for more than 5S and restart.
- 8.1.2 The heater may cause circuit failure due to the following reasons: the connector is rusted, the poor contact, the plug is incorrect, the wire or fuse is rusted, the battery pile is rusted, etc.

Pay attention to inspection, maintenance and prevent these phenomena from occurring during use.

- $8.\,1.\,3$ When the following conditions occur, it can be handled and eliminated by the user:
- The heater does not start after the power is turned on and the LCD switch screen does not light. The reason is that the fuse is open, or the wiring is wrong. In addition, check whether the plug on the LED switch lead wire is properly connected to the host.

8. 2 Fault Lock Status

- $8.\,\,2.\,\,1$ The fault generated by the heater is indicated by the fault code on the LED switch.
- $8.\,2.\,2$ The faults can be eliminated according to the methods ted in Table 2.

	Fault Lock Status Debug Method		
Fault Code	Fault Name	Fault Debug Method	
10	Overvoltage fault	Check vehicle power supply system	
11	Under voltage fault	Check vehicle power supply system	
21	Warm air outlet temperature sensor disconnection	Check if the sensor is in good condition	
22	Warm air outlet temperature sensor short circuit	Check if the sensor is in good condition	
23	Water temperature sensor disconnection	Check if the sensor is in good condition	
24	Water temperature sensor short circuit	Check if the sensor is in good condition	
25	External temperature sensor disconnection	Check if the sensor is in good condition	
26	External temperature sensor short circuit	Check if the sensor is in good condition	
27	Combustion support temperature sensor disconnection	Check if the sensor is in good condition	
28	Combustion support temperature sensor short circuit	Check if the sensor is in good condition	
31	Combustion failure	a. Check gas supply system b. Check whether combustion inlet and outlet are blocked c. Check the Ignition coil, ignition electrode, d. Flame sensor	
32	Combustion failure	a. Check gas supply system b. Check whether combustion inlet and outlet are blocked c. Check the flame sensor	
33	Flame sensor fault	a. Check the flame sensor lead wire b. Check the flame sensor	
41	Warm air outlet overheats	Check whether air outlet is blocked	
42	Warm air overheats switch protection	a. Check whether air outlet is blocked b. Check warm air overheat switch	

Table 2

	Fault Lock Status Debug Method		
Fault Code	Fault Name	Fault Debug Method	
43	Water overheat	a. Check whether water depletion in the tank b. Check if the sensor is in good condition c. Check whether air outlet is blocked	
44	Warm air overheats switch protection.	a. Check whether air outlet is blocked. b. Check warm air overheat switch	
45	Overheating fault	a. Check whether air outlet is blocked b. Check water temperature sensor c. Check warm air sensor	
51	Communication fault	Check interconnecting cable	
61	Oil Pump Break	a. Check whether the oil pump lead is damaged or not b. Check whether the connection of oil pump leads is reliable. c. Refurbishment oil pump d. Replacement of motherboard	
62	Short circuit of oil pump	a. Check whether the oil pump lead is damaged b. Check whether the connection of oil pump leads is reliable c. Refurbishment oil pump d. Replacement of motherboard	
63	Circuit Breaking of Electric Plug	a. Check the power supply voltage b. Check the resistance of the plug at room temperature (0.2/12V) c. Cleaning up Carbon Accumulation in Electric Plug d. Replacement of motherboard	
65	Electric plug without drive	Replacement of motherboard	
81	Combustion support fan disconnection	Check combustion air blower	
82	Combustion support blower boot failure	a. Check the blower motor lead wire b. Check combustion air blower	
83	Combustion support blower spindle speed too low	Check combustion air blower motor	
84	Warm air blower motor disconnection	Check warm air blower motor	
85	Warm air blower motor boot failure	a. Check the blower motor lead wire b. Check warm air blower motor	
86	Warm air blower spindle speed too low	Check warm air blower motor	
110	Window alarm	Check window switch interconnecting cable	
120	Low voltage alarm	Recommended charging	
220	220V Connectionless	Check AC 220V/110V power supply system	

Table 2 to continue

9. Operational Precautions

Initial Installation

The heater is installed for the first time. In order to completely eliminate the air in the fuel supply system and make the fuel pipeline full of fuel, a separate pump function is specially designed. See LCD switch instructions for details

Rinse the water tank with clean water before the heater is first installed and used. When the heater is not in use, please empty the water tank so as not to freeze the water tank. The company is not liable for damage to the water tank caused by freezing.

- -- Open the circulating pump
- -- Open the hot tap in the kitchen and bathroom until
 the air is exhausted and the water tank is filled, and
 the water is not interrupted.
- The heater should be tested before use. During the trial run, all connections should be carefully checked for leaks and security conditions. If there is smoke emission, abnormal combustion noise or fuel gas odor, the heater should be closed and the fuse should be pulled out so that it cannot operate. It can only be used after being inspected and repaired by professionals.
- When the heater is first used, it may emit odor in a short time. This is normal in the first few minutes of operation, and it does not mean that the heater is out of function.

Quarterly Maintenance

- Before each heating season, the following maintenance work must be carried out by professionals:

Check whether the air inlet and outlet are contaminated and foreign matter.

Clean the outside of the heater.

Check for corrosion and loosening of circuit joints.

Check whether the intake and exhaust pipes are blocked or damaged.

Check the fuel line for leakage.

●Long-term shutdown

— When the heater is not used for a long time, it should be run every 4 weeks for about 10 minutes each time to prevent mechanical parts such as solenoid valves and combustion-supporting air fans from failing to function (freezing).

- The inlet and outlet of heater must be kept free of blockage and dirt, so that the warm air duct is unimpeded, in order to prevent overheating failure.

- When replacing low-temperature fuel, the heater should run for at least 15 minutes to fill the fuel system with new oil.

•Heater life


- The heat exchanger of the heater cannot be used for more than 10 years. Upon expiration, it must be replaced by genuine parts and replaced by the heater manufacturer or its authorized agent.
- When the exhaust pipe of the heater discharges combustion exhaust gas for 10 years, it must be renewed with genuine parts.

Other considerations

- Water tanks must be cleaned regularly, at least twice a year.

- In the process of transportation and storage, the ambient temperature of heater should not exceed the range of - 40 ~85 °C in order to prevent damage to electronic components.
- -Only authorized customer service stations are allowed to install and repair heaters, and non-original parts are prohibited to avoid danger.
- The manufacturer is not responsible for the maintenance of the heater due to the failure to install and operate in accordance with the regulations.
- The heater must be turned off before refueling.
- When welding automobiles, the positive pole of the heater should be removed from the battery and grounded to prevent damage to the controller.

LCD Switch Instruction Manual



This product can be used with both commercial and LPG or fuel for heating water or a RV or both, making your trip more convenient and comfortable.

This manual describes the use method, installation instructions, technical parameters, fault inquiry, etc. of the LCD switch (referred to as LCD switch) of the Belief hot water & air integrated heater. Please read this manual carefully before use. Please keep it in a safe place after reading it.

Safety Warning:

- 1. If the information in the manual cannot be read or executed accurately, it may cause fire or explosion, resulting in property damage, personal injury or death.
- 2. Do not store near the heater with flammable, explosive or volatile gas or liquid holding equipment.

If you smell the gas:

- Evacuate everyone from the vehicle.
- Turn off the gas supply to the gas container or gas source.
- Do not touch any electrical switches or use any phone or radio in the car.
- Do not start the engine or generator of the vehicle.
- Do not open the gas supply until a gas leak is detected.


Installation and service must be performed by a certified service technician, service organization, or gas supplier.

- 3. The heater must be installed in a motorhome or trailer.
- 4. The LCD switch can only be used when the whole machine is installed properly.
- 5. Please correct any malfunctions immediately. The remedy specified in the troubleshooting table in these operating instructions can only be repaired by itself.
- 6. Do not perform any repair work or modification on the LCD switch! Any changes to the device or its controls can be dangerous and will void the warranty.
- 7. Defective LCD switches can only be repaired by the manufacturer or the service department of the manufacturer.
- 8. Do not use heaters in garages, multi-storey car parks or ferries, when refueling. Turn off the heater on the LCD switch to ensure that the heater cannot be turned on by remote control.

Important Information:

If a new or replacement heater is connected to the LCD switch, the process described in "Power on Start" must be repeated.

I. Display and control section



- -- Information is displayed on an LCD with backlight.
- -- In the menu bar (3, 4), the function of the LCD switch can be arbitrarily selected. The operating parameters are displayed on the status bar (2) and display (5, 6).
- -- After the 220V is turned on, the 220V mains power supply indication column (5) displays the power supply sign.
- -- During operation, set the parameter bar (7) to display the change between time and set room temperature.
- -- Press the return button, the selected parameters are invalid and return to the previous interface.

Rotary Button

Select, modify, and save icons for menu bars 3 and 4 by rotating the button.

The selected icon flashes.

Clockwise rotation indicates:

- --Options scroll from left to right of a menu bar, to the end and to the front of another menu bar.
 - -- Add one to the value.

Counterclockwise rotation indicates:

- --Options scroll from right to left on one menu bar, to the front end and then to the end of another menu bar.
 - -- The value is reduced by one.

Tap the rotary button to indicate:

--Select to confirm saving and return to the main menu.

Pressing the rotary button for a long time (more than 3s) indicates:

-- The heater heating function or other function is turned off and the LCD switch is turned off to enter the sleep state.

Return Button

-- Discard the current selection and return to the previous option.

II. Switch Setting

1. Power On

After a few seconds, the time is displayed at 00:00.




Click the rotary button to display the initial interface options in the display area.




Clock setting (current time setting)

Click the rotary button to display the icon in the menu bar (3).



- -- Use the rotary button to select the "Set Clock" icon in the menu bar (4).
- -- Click the rotary button to enter the clock settings.



-- Use the rotary button to set the time. "A--" is displayed in the morning and "P--" is displayed in the afternoon, and it is automatically switched.

- -- Click the rotary button again to determine the time, then the minute display flashes.
 - -- Set the minute with the rotary button.
- -- Click the rotary button to confirm the value and exit the clock setting.

2. Rotate button to start

-- Press the rotary button for a long time (more than 3s), the LCD will start.

3. Shutdown

Press the rotary button for more than 3s at the initial interface to shut down. When the LCD switch is turned off, the heating process and any connected equipment are also automatically turned off. The parameters before shutdown are retained.



Downtime Process

Since the heater has a higher residual heat after heating and a post-cleaning need (combustor after combustion), the fan typically runs for a few minutes for cooling.

III. Heating Function Setting

The heating function setting should first set the energy, and then select water heating or room heating or simultaneous heating, and finally set the circulating wind speed. The default heating function settings is the energy setting gas and the circulating wind speed setting eco.

1. Energy Setting

Rotate the button to select the energy icon in the menu bar (3).




- -- Click on the selected icon.
- -- Use the rotary button to select the desired energy mode.
- -- Click the rotary button to confirm.

Vorking	Mode	Energy Mode
GAS		LPG Diesel
MIX 1		etrical 900 W+GAS
MIX 2	elec	etrical 1800 W+GAS
EL 1		electrical 900 W
EL 2		electrical 1800 W

If the energy type is not selected, once the heater starts to operate (room temperature, hot water icon is activated), the status bar shows the type of energy selected during the previous heating process or the energy type gas set at the factory.


2. Adjustment of Indoor Temperature

Click the rotary button to display the icon in the menu bar (3).



- -- Select the room temperature heating system with the rotary button according to the connected device.
- -- Confirm the selection by clicking the rotary button on the selected room temperature icon.
- -- Use the rotary button to select the desired temperature.
- -- Click the rotary button to confirm its value.

Temperature Display: °C degrees Celsius Adjustment Range: 5~30°C Stepping: 1°C



Flame icon = room temperature heating start, this icon will flash until the predetermined room temperature is reached.

3. Adjustment of Water Heating

Click the rotary button to display the icon in the menu bar (3).



- -- Use the rotary button to select an icon in the menu bar (3).
- -- Click the rotary button to confirm and enter the setting level.
- -- Use the rotary button to select the desired water temperature setting level.
- -- Click the rotary button to confirm the value.

Work Mode Description
OFF Water heat is turned off. Water heating icon disappear
ECO scheduled water temperature target 40°C
HOT scheduled water temperature target 60°C

BOOST preferentially heats the water for 40 minutes or the water temperature reaches 60°C.



This icon will flash until the predetermined water temperature is reached.

In the "heating and hot water mode" the water temperature of 40°C can only be stored for a limited time (room heating priority).

4. Choice of Wind Speed

Click the rotary button to display the icon in the menu bar (3).



- -- Rotate the button to select an icon in the menu bar (3).
 - -- Click the rotary button to confirm and enter the setting level.
- -- Use the rotary button to select the desired fan speed.
- -- Press the rotary button to confirm and save.

Work	Description
Mode	
OFF	Turn off the fan.
VENT	Circulation ventilation, you
	can choose 10 levels Wind
	speed. May increase the
	abrasion of the motor,
	depends on how often it is
	used.
ECO	Low wind speed
LOW	Mid-speed
HIGH	High wind speed results in
	higher
	power consumption, higher
	noise
	levels and increased motor
	abrasion.
BOOST	Room heats up quickly





5. Start Heating

After the setting is finished, press the return key or wait for 10s to enter the clock interface, and the heating starts. The clock and set temperature are displayed alternately.



6. End Heating

Press the rotary button for more than 3 seconds to shut down.

IV. Timing Heating Settings

Click the rotary button to display the icon in the menu bar (3). Click the rotary button to enter the timing settings.



Warning: Danger of toxic exhaust gases.


Even if the vehicle is stopped, unmanned, the activated time switch will turn on the heater. Exhaust gases from heaters may be toxic in confined spaces such as garages, workshops, and repair shops.

If the vehicle is parked in a closed room:

- Turn off the fuel supply to the heater.
- -- Turn off the timer switch of the LCD switch.
- -- Turn off the heater on the LCD switch. Press the rotary button for 3 seconds to turn it off.

1. Enter the Startup Time


Use the rotary button to set the start time. Click the rotary button to confirm and proceed to the next setting.



2. Enter the End Time

Use the rotary button to set the heating end time. Click the rotary button to confirm and

proceed to the next setting.



3. Set the Room Temperature

Use the rotary button to select the desired room temperature. Click the rotary button to confirm the value.



4. Set the Water Temperature

Use the rotary buttons to select the desired hot water level. Click the rotary button to confirm.



5. Energy Mode Selection

Use the rotary buttons to select the desired energy mode. Click the rotary button to confirm the value.




6. Select Fan Speed Grade

Use the rotary buttons to select the desired fan speed level. The fan speed rating is selected only after the room temperature heating mode is set. Click the rotary button to confirm.



7. Timing Enabled

Use the rotary button to select Enable Timing (ON). If OFF is selected, the timing is canceled, but the settings are saved. Click the rotary button to confirm that the timing is valid.



The time switch is only enabled once until it is disabled (turned off) or powered down. If the time switch is programmed and enabled, the time switch icon is displayed in the status line (2). The timing icon flashes if the time switch is enabled and activated.

8. Cancel Timing

With the timing set, use the rotary button to select the timing setting. Click the rotary button to enter the settings.

Use the rotary button to select the cancel timing (OFF). If you select ON, continue to use timing. Click the rotary button to confirm that the cancellation timing is valid. But the previous settings are still saved.

V. Parameter Settings

The content after the parameter setting is maintained after the power is turned off. Use the rotary button to select the "Settings" icon in the menu bar (4). Click the button to enter the settings.



1. Voltage inquiry

Click the rotation button to display the voltage: 12.0V.




2. Air pressure and temperature inquiry

Use the rotate button to select the atmos icon.



Click the rotation button to enter the query.



Use the rotary button to switch between atmospheric pressure and ambient temperature.

Atmospheric pressure:99KPa Ambient temperature: 26 °C

3.Offset Setting


The external temperature sensor of the heater can be adjusted separately depending on the installation of the sensor. The offset setting can be in the range of -5°C to 5°C. The deviation is 1°C. Use the rotary button to select the OFFSET icon and click the rotary button to enter the settings. Use the rotary

button to select the offset value. Click the rotary button to confirm and save.




4. Switching temperature units

Use the knob to switch between centigrade and Fahrenheit, and click OK.



5. LCD Backlight Adjustment

The LCD backlight has 10 levels of incremental adjustment. Use the rotary button to select the BRIGHT icon and click the rotate button to enter the settings. The brightness of the LCD changes as the rotary button rotates. After confirming by clicking the rotary button, return to the previous operation. The backlight brightness is set to 6 by default.



6.Set the Time Format

Use the rotary button to select the time format setting icon and click the rotary button to enter the settings. Use the rotary button to select the 12h or 24h icon and click the rotary button to confirm. The default setting is 24h.



7. Fast Pump Oil Settings

Select pump oil icon GoOil with rotary button.




Click on the rotary button to enter the fast pump oil. The default fast pump time is 90 seconds. The remaining time can be adjusted with a knob.

Press the return key or stop the fast pump if the pump oil time exceeds the set value.

8. Software Version Number

Use the rotary button to select the INdEx icon and click the rotary button to enter the query item. Use the rotary button to view the information of the LCD switch or the information of the main controller. Click the rotary button or want to go back to return to the previous operation.




C5.1000-- LCD switch version H11.100-- master controller version

9. Factory Setting

The reset function resets the LCD switch to factory settings. All previous settings will be deleted. All devices used before RESET is installed and powered.

Use the rotary button to select the RESET icon and click the rotary button to display the factory setting PR SET.

After confirming, the initialization "INIT....." is displayed.



VI. Fault Display

How to Read the Warning Code:
-- Use the rotary button to select the icon i and click the rotary button to display the current warning code (for troubleshooting, please refer to the relevant heater instruction manual).

There are faults in the fault that are automatically recovered and manually recovered after repair.

An automatic recovery fault is a warning fault in which an operating parameter has exceeded a defined normal working range and reached an undefined state. In this case, the device will continue to run and the warning symbol (1) will be displayed in the menu bar (4) without warning code. After the fault is repaired, the warning symbol disappears automatically (it can also be manually restored), and the device continues to work according to the original settings. For example: warning fault code W 120 H.



field (7) when the fault occurs. The cause of the fault can be determined and remedied by the help of the troubleshooting guide. The fault code disappears after a few seconds, and the warning disappears, and the warning symbol is displayed in the menu bar (4).

Select Reheat after the fault is identified and resolved, first remove the fault code. Press the rotary button to display the fault code, then press the rotary button, the displayed fault code disappears and return to the initial time interface. Re-enter the heating parameters to initiate heating. If the fault is removed, the heating will be normal or the fault will occur again. The LCD switch will jump to the "Fault" menu again, the warning symbol will be displayed again, and the affected device will still be in the warning state. Since the fault has not been eliminated, if you want to return to the set level, press the back button (9). For example: fault code E 31 H. Shutdown and power off can also eliminate faults.



The fault code table and troubleshooting methods can be found in the tenth fault code table at the end of the manual.

VII. Technical Parameters

Display: LCD, black and white, with backlight.

Dimensions: 92×103×40mm Working temperature: -25°C~60°C Storage temperature: -25°C~70°C Power supply: DC10.5~16V

Power consumption: Max.65mA (100%)

backlight)

Standard current: 10mA Quiescent current: 3mA

The above parameters are subject to change without notice.

Maintain:

The LCD switch is maintenance-free. To clean the front panel, use a damp cloth or use a neutral soap solution.

VIII. Installation Instructions

Installation in vehicles must comply with applicable technical and administrative

regulations.

Safety Information:

Installation and services must be performed by an authorized installer, service agent. Improper installation, alteration, repair will result in property damage, personal injury or loss of life and will void the warranty.

Don't try to install it yourself. Do not use high voltage equipment unless the electronic circuit (board) is disconnected. Do not use a battery charger to power the heater, even while testing. If the vehicle requires soldering, do not connect a 12-volt DC power supply to the unit. Electric welding can cause serious damage to the equipment. Do not shorten the electrical connection cable or remove the label indicating polarity. Turn off the vehicle's onboard power supply during installation and turn off the power when the device is connected. The device can only be installed in the specified location. When the gas heater is not used, it is best to turn off the gas valve.




Figure1

Installation location:

Install the LCD switch in a waterproof and moisture-proof position.

Install the LCD switch at the height of your eyes for easy reading and operation.

Prepare a mounting opening for the LCD switch, as shown in Figure 2.

Route the connector cable connecting the cables in a tension-free circuit. It must be possible to pull the liquid crystal switch out of the mounting hole by 20 cm so that no tensile stress is applied to the plug connection. Never drawing the connector cable when connecting to the LCD switch.

Assembly:

Install as shown in Figure 3.

Install the LCD switch holder to the wall with 4 M3×10 screws.

- Hang the front panel of the LCD switch on the holder
- ② Fasten the LCD switch to the holder
- ③ Secure with M3×6 screws.
- ④ Install the rotary button (Figure 3-4) onto the shaft.

flat tail self-tapping

nail M3×6

(fastening the switch panel)

·Cross head self-tapping nail M3×10

1

1

(installed on the wall)

Operation and installation 1

instructions

·Connecting cable,

length 6m

Installation Method of LCD Switch





Figure2



IX. Accessories

Name Ouantities A

·LCD switch

·Cross countersunk head

X. Fault code table

Error Code	Fault name	Troubleshooting
10	Overvoltage fault	a Check vehicle power supply system
11	Low voltage fault	a Check vehicle power supply system
21	Heater outlet temperature sensor open circuit	a Check if the sensor is in good condition
22	Heater outlet temperature sensor short circuit	a Check if the sensor is in good condition
23	Water temperature sensor open circuit	a Check if the sensor is in good condition
24	Water temperature sensor short circuit	a Check if the sensor is in good condition
25	External temperature sensor open circuit	a check if the sensor is in good condition
26	External temperature sensor short circuit	a Check if the sensor is in good condition
27	Combustion temperature sensor open circuit	a check if the sensor is in good condition
28	Combustion temperature sensor short circuit	a Check if the sensor is in good condition
31	Ignition failure	a Check gas supply system b Check if the combustion and exhaust ports are blocked c Check the high voltage package, ignition electrode, flame probe
32	Burning failure	a check gas supply system b Check if the combustion and exhaust ports are blocked c Check the flame probe
33	Flame sensor failure	a Check flame probe lead b Checks the flame probe
41	Warm air outlet temperature is too high	a Check if the air inlet and outlet are blocked
42	Warm air overheats switch protection	a Check if the air outlet is blocked b Check the heater overheat switch
43	Water temperature is too high	a Check if the water tank is short of water b Check if the sensor is in good condition c Check if the air outlet is blocked
44	Water temperature overheating switch protection	a Check if the air outlet is blocked b Check the water temperature overheat switch

Error Code	Fault name	Troubleshooting
45	Continuous overheating failure	a Check if the air outlet is blocked b Check the water temperature sensor c Check the heater air sensor
51	communication fail	a Check the connection cable
61	0il Pump Break	a Check whether the oil pump lead is damaged or not b Check the reliability of oil pump lead connection c Repair oil pump d Replacement of mainboard
62	Short circuit of oil pump	a Check whether the oil pump lead is damaged or not b Check the reliability of oil pump lead connection c Repair oil pump d Replacement of mainboard
63	Circuit Breaking of Electric Plug	a Check power supply voltage b Check the resistance of the plug at room temperature (0.2/12V) c Cleaning up Carbon Accumulation in Electric Plug d Replacement of mainboard
65	Electric plug without drive	a Replacement of mainboard
71	Gas valve failure	a Check gas valve coil and lead
72	Gas valve power failure	a Replacement motherboard
81	Combustion blower circuit breaker	a Check combustion air blower motor
82	Combustion blower failed to start	a Check the motor lead connection b Check the combustion air blower motor
83	Combustion fan speed is too low	a Check combustion air blower motor
84	Heater fan disconnect	a Check heater fan motor
85	Heating fan failed to start	a Check the motor lead connection b Check the heater fan motor
86	Heating fan speed is too low	a Check heater fan
91	High voltage package failure	a Check the ignition coil and lead
92	High voltage power supply failure	a Replacement motherboard
93	High voltage circuit failure	a Replacement motherboard

Fault code table (to be continued)

Error Code	Fault name	Troubleshooting
94	Gas valve circuit failure	a Replacement motherboard
110	Window alarm	a Check window switch connection cable
120	Low voltage alarm	a Recommended charging
220	220V no connection	a Check AC 220V power supply system

If these measures cannot correct the fault, or the fault code is displayed, it cannot be found in the fault code table guide, please contact the service provider.