


# MANUAL Air Filter System

Translation of the original German manual

© 2023 Mr Beam Lasers GmbH | München, 03. July 2023 | Revision 2.0



# **WELCOME**

We are delighted that you have chosen an Air Filter System! Please read this manual thoroughly, even if you are already familiar with some of the functions.



Knowledge base

www.mr-beam.org/support



Digital manual

www.mr-beam.org/downloads

# Manual CONTENTS

WELCOME

U1	1.1 Using the Manual 1.2 About Mr Beam Air Filter System				
02	OVERVIEW OF COMPONENTS  2.1 Scope of supply of Air Filter System (Third party devices)  2.1 Scope of supply of Air Filter System (Mr Beam)  2.3 Overview of Air Filter System  2.4 Connections				
03	SAFETY AND CONFORMITY 3.1 Intended use 3.2 Safety instructions 3.3 Description of the workplace 3.4 Qualification of the user 3.5 Warning and safety signs				
04	SETUP 4.1 Unpacking 4.2 Connect to third party devices 4.3 Connect to Mr Beam	1 <sup>1</sup> 2 <sup>1</sup> 2 <sup>1</sup>			
05	CONTROL THE AIR FILTER SYSTEM 5.1 Controller operation	23			
06	SERVICING AND MAINTENANCE 6.1 Cleaning and repair 6.2 Changing the filters	2'			
07	ADDITIONAL INFORMATION 7.1 Technical data 7.2 Storage & Transport / Support 7.3 Disposal	3 3: 3:			
80	GENERAL TERMS AND CONDITIONS 8.1 General Terms and Conditions 8.2 Contact addresses	3:			

Page 2 01: Welcome | Page 3

## 1.1 Using the Manual



Caution: Before the initial start-up and use of the Mr Beam Air Filter System, these operating instructions must be read carefully and observed. Non-observance of individual points listed in the operating instructions can cause personal injury and/or damage to property!

The operating instructions are to be regarded as part of the product. No liability is assumed by Mr Beam Lasers GmbH for damages and malfunctions resulting from non-observance of these operating instructions.

No part of these operating instructions may be reproduced, edited or otherwise modified in any form without prior written permission from Mr Beam Lasers GmbH. The rights for reproduction in any form, especially in electronic, print and other media are reserved.

Mr Beam Lasers GmbH reserves the right to change specifications on the hardware and software described in this manual at any time and without prior notice.

Additional devices must be matched to the basic device.

If you have any questions, please contact Mr Beam Support:

www.mr-beam.org/ticket.

To facilitate understanding of the operating instructions, the following symbols are used:



**Note/Attention:** In these areas, there is a risk of material damage if the operating instructions are not observed.



**Caution:** These areas represent a particular danger for the user or the personnel responsible for maintenance if the operating instructions are not observed!

Please make sure that you have the latest version of the Air Filter System Operating Instructions.

The latest version of the operating manual can be found at:

www.mr-beam.org/downloads/

Please keep the operating instructions for future reference. The operating instructions must be passed on to any subsequent owner or user of the product.

This is the original German operating manual. If your national language is not included with the operating instructions, you can obtain them at

www.mr-beam.org/downloads/download it.

Issue date of this Manual: 03. Juli 2023

## 1.2 About Mr Beam Air Filter System

The Mr Beam Air Filter System (from now on only referred to as Air Filter System) enables the operation of a Mr Beam laser cutter in closed rooms without the possibility of exhausting air to the outside. This ensures that no unfiltered exhaust air escapes and the user is not endangered at any time.

The Air Filter System also allows exhaust air to be extracted and filtered from other laser cutters, 3D printers and soldering stations.


Air is extracted via the exhaust hose. Vapors, particles and odors are then filtered through a three-stage filter for indoor use.

When used with the Mr Beam Lasercutter, the Air Filter System automatically regulates the extraction rate. When used without the Mr Beam Lasercutter, the power of the suction can be regulated manually via the Mr Beam Air Filter Controller (hereinafter referred to as the Controller).

## Manufacturer

Mr Beam Lasers GmbH Gollierstr. 70 80339 Munich Germany

Page 4 | 01: Welcome 01: Welcome




# OVERVIEW OF COMPONENTS

In the following section, you will get an overview of the various components and connections of your Mr Beam Air Filter System.


# 2.1 Scope of supply of Air Filter System (Use with third party devices)



Mr Beam Air Filter System



Exhaust air hose with 2x 50 mm suction nozzle



Mr Beam Air Filter Controller (hereinafter referred to only as controller)




Cable Mr Beam Air Filter System, power cable and power supply


# 2.2 Scope of supply of Air Filter System (Use with Mr Beam Lasercutter)



Mr Beam Air Filter System



2 screws, 2 washers and Mr Beam suction nozzle




Exhaust air hose with 1x 50 mm suction nozzle





Cable Mr Beam Air Filter System

# 2.3 Overview of Air Filter System



# 2.4 Connections





# SAFETY AND CONFORMITY

Please note that this chapter is particularly important. Your Air Filter System can only work safely if you observe all aspects. It is therefore essential that you have read and understood this chapter before commissioning your Air Filter System!

## 3.1 Intended use

Your Air Filter System is designed to extract and filter exhaust air from laser cutters, 3D printers, soldering stations and nail salons. All other applications are not intended.

Air is extracted from the work surface via the hose. Then, a three-stage filter safely filters vapors, particles and odors for indoor use.

Operation is permitted only when the Air Filter System is in good working order and filters are properly installed. Regularly check the condition of your filters and replace them if necessary (see Section 6.2 Changing the filters). The manufacturer accepts no liability for personal injury and/or damage to property resulting from improper use or use contrary to the intended purpose of the Air Filter System. The electronic components of the Air Filter System may only be repaired or maintained by persons who are familiar with the intended area of application and the hazards of the Air Filter System and who have received appropriate training.

Use of the Air Filter System when exhausting unsuitable exhaust gases will void the warranty. Unsuitable exhaust gases are: Gases above 50 °C, flammable gases and gases containing chlorine. The Air Filter System is not suitable for the extraction of condensing moisture or liquids or sparks.

The user must clarify which pollutants are contained in the exhaust gases before commissioning the Air Filter System. If the pollutants can cause damage to persons or your Air Filter System, commissioning is not possible. If the Air Filter System cannot filter out the pollutants, it will not be possible to extract these exhaust gases. It is pointed out that it is the user's responsibility to comply with the national and regional threshold limits for dust, fumes and gases.

The non-observance of the operating, maintenance and servicing instructions, which are presented in this operating manual by Mr Beam Lasers GmbH, excludes any liability of Mr Beam Lasers GmbH in any case.



**Note:** The warranty does not cover damage or defects caused by non-observance of the operating instructions.

Page 12

## 3.2 Safety instructions

## Use device only in original condition

The use of a device that has recognizable defects or that has adaptations that have not been approved by Mr Beam Lasers GmbH is not permitted and can lead to damage to property or bodily injury.

- » Before starting each use, you are obliged to check the Air Filter System for externally visible defects, damage or conspicuous features. Possible defects include damage to the exhaust air hose and bent parts on the housing. Any changes detected, including unusual operating behavior, must be rectified immediately. Further use of the Air Filter System is excluded until the defect has been completely remedied.
- » Operate the Air Filter System only with devices and spare parts that are included in the scope of delivery and/or approved by Mr Beam Lasers GmbH.
- » Do not rebuild or disassemble your Air Filter System under any circumstances. Care and maintenance procedures as described in chapter 6 "Care and maintenance" are excluded. Do not operate any device that has been rebuilt or disassembled!


## Avoid leakage of harmful vapors

Failure to observe the safety measures may result in the emission of fire odors and vapors, which may be harmful to health.

- » Refrain from any mode of operation that impairs the safety of the Air Filter System.
- » To avoid injury to third parties, you are obliged to exclude the commissioning of the Air Filter System by unauthorized persons (e.g. precautions against unauthorized use)

- At all times, the disabling and/or disassembly of safety devices and any reconstruction or modification of the Air Filter System is prohibited. Failure to do so may result in serious injury.
- » Use the Air Filter System only with properly installed filters that cover the entire surface. Check that the filters are correctly seated, especially before using the Air Filter System for the first time and after transporting it.
- » Regularly check the condition of the filters and replace them if necessary (see Section 6.2 Changing the filters).
- » Before commissioning the unit, clarify whether pollutants can arise from the processing of materials that can harm the Air Filter System, the environment and/or persons. It is pointed out that it is the user's responsibility to comply with national and regional limits for dust, fumes and gases.
- >> Use the Air Filter System only in ventilated, dry rooms.

## 3.3 Description of the workplace



- The power outlet must be easily accessible and located in the immediate vicinity of the device. In case of emergency, you must be able to disconnect the power plug.
- >> Ensure that the circuit of the socket is adequately protected.
- Ensure that cleanliness and clarity are always guaranteed in and around the workplace of the Air Filter System.
- Ensure that a fire extinguisher and fire blanket are in close proximity at all times.
- The working temperature must be between 5°C and 30°C. Avoid high temperature fluctuations.
- Use the Air Filter System only in ventilated, dry rooms to avoid contact with moisture. Failure to do so may result in damage to individual parts. (Humidity between 30% and 60%, no condensation).
- Use the Air Filter System only in low-dust environments.
- Avoid strong mechanical vibrations acting on the Air Filter System.

- Ensure sufficient air circulation in the room so that possible pollutants do not accumulate.
- » Place the Air Filter System on a stable, level and horizontal work surface.


# 3.4 Qualification of the user


- » If several persons work with the Air Filter System, the owner, proprietor or other person responsible for access to the device has the responsibility to ensure that all users are sufficiently qualified and are familiar with the safety regulations.
- » Minors are only allowed to use the Air Filter System under adult supervision.

## 3.5 Warning and safety signs

All warning and information signs attached to your Air Filter System are located in places which may be a source of danger before and/or during operation. Damaged or lost warning and information signs must be replaced immediately. The missing warning and information signs can be ordered from Mr Beam Support (mr-beam. org/ticket) or reproduced independently using this template.


Print this page in DIN A4 format so that the warning and information signs correspond to their original size.





## EG Konformitätserklärung

## **EU Declaration of Conformity**



Mr Beam Lasers GmbH Firma / Company: Adresse / Address Gollierstrasse 70 Produktkategorie / Product category: Abluftfilter / Air Filte

Modellhezeichnung / Model name: ΔF2

Hersteller / Manufacturer: Mr Beam Lasers GmbH Artikelnummer / Article number: 903-##### Seriennummer / Serial number: AF2-#### 17 05 2023 Frstellungsdatum / Creation date:

17.05.2023 / Version 1.0 Aktuellste Version / Latest revision: mr-beam.org/conformity

### Das Produkt erfüllt die einschlägigen Harmonisierungsrechtsvorschriften der Union: The product fulfill the relevant European harmonisation legislations.

Rechtsvorschrift / Legislation:

2006/42/EC Maschinenrichtlinie / Machinery Directive (ABI. L 157, 9.6.2006, p. 24-86) 2014/30/FU EMV Richtlinie / EMC Directive (ABI. L 96, 29.3.2014, p. 79-106)

2014/35/EU Niederspannungsrichtlinie / Low Voltage Directive (ABI. L96, 29.3.2014, p. 357-374)

2011/65/EU:2014-02-14 RoHS (ABI. L 174, 1.7.2011, p. 88-110)

Die Übereinstimmung mit den Anforderungen der europäischen Harmonisierungsrechtsvorschriften wurde durch die Anwendung der folgenden harmonisierten

### The compliance with the requirements of the European harmonisation legislations was proved by the application of the following harmonised standards and technical specifications:

Normen / Standards: Beschreibung

EN 12100:2011-03 Sicherheit von Maschinen - Allgemeine Gestaltungsleitsätze -

(inkl Berichtigung 1:2013-08) Risikobeurteilung und Risikominderung

EN 61000-6-1:2019 Elektromagnetische Verträglichkeit (EMV) - Teil 6-1: Fachgrundnormen -

Störfestigkeit für Wohnbereich, Geschäfts- und Gewerbebereiche sowie Kleinbetriebe

EN 61000-6-3:2022-07-01 Elektromagnetische Verträglichkeit (EMV) - Teil 6-3: Fachgrundnormen -

EN 60335-1:2020 Sicherheit elektrischer Geräte für den Hausgebrauch und ähnliche Zwecke Household and similar electrical appliances - Safety - Part 1: General

EN 60335-2-65-2013 Sicherheit elektrischer Geräte für den Hausgebrauch und ähnliche Zwecke. Hausehold and similar electrical annliances – Safety – Part 2-65:

Teil 2-65: Besondere Anforderungen für Luftreinigungsgeräte

EN 60335-2-69:2015 Sicherheit elektrischer Geräte für den Hausgebrauch und ähnliche Zwecke
– Teil 2-69: Besondere Anforderungen für Staub- und Wassersauger für
requirements for wet and dry vacuum cleaners, including power brush, for

Sicherheit elektrischer Geräte für den Hausgebrauch und ähnliche Zwecke Household and similar electrical appliances - Safety - Part 2-2: Particular Teil 2-2: Besondere Anforderungen für Staubsauger und Wassersauger

Safety of machinery - General principles for design - Risk assessment and risk

Electromagnetic compatibility (EMC) - Part 6-1: Generic standards - Immunity for

residential, commercial and light-industrial environments

Electromagnetic compatibility (EMC) - Part 6-3; Generic standards - Emissio

Störaussendung für Wohnbereich, Geschäfts- und Gewerbebereiche sowie standard for residential, commercial and light-industrial environments

Particular requirements for air-cleaning appliances

### Weitere Informationen / additional information

keine / none

EN 60335-2-2:2014

Place / Date

München / 17.05.2023 / Version 1.0

Roland Kaindl (TKRM UG haftungsbeschränkt CF Consulting / Dokumentenverantwortliche

This copy of the Declaration of Conformity is dated 17 May 2023. In addition, you can find current versions of the manual and declaration of conformity to download at: www.mr-beam.org/conformity

# **SETUP**


In the following chapter, we will guide you from unpacking to setting up the network connection.

When setting up your Air Filter system, remember that it was assembled and packaged with great care by us. Please take the time to unpack and set it up with the same care.

# 4.1 Unpacking


## Open box

- 1. Place the box [1] on a flat surface.
- 2. Open the box [1]. Do not use any sharp objects that could damage the surface.
- 3. Pull out the upper transport protection [2].



## Remove from box

- 1. Take the Air Filter System [3] out of the box [1].
- 2. Take the box with the accessories [4] out of the box [1].




## Check filters

- 1. Open the air filter system by opening the closing screws [14].
- 2. Check the correct fit of the prefilter and main filter. More detailed information can be found in Section 6.2 Changing the filters.



Attention: If one of the filters has slipped and the Air Filter System is started up without being checked, the exhaust air can escape unfiltered. This can result in personal injury and damage to property.



Page 18 04: Setup | Page 19


# 4.2 Connect to third party devices

## Connect to the device

1. Connect one of the 50 mm suction nozzles [7] to your third-party device [8].



**Note:** If you want to use a different suction nozzle, you can unscrew the suction nozzle [7]. The exhaust air hose is equipped with a left-hand thread.




## **Connect Air Filter Syste**

 Connect the controller [9] to the designated connection of the Air Filter System (center) using the air filter connection cable [10].



**Note:** The micro USB port of the controller is for maintenance purposes only. It is not used during regular use.




### **Exhaust air**

- 1. Connect the exhaust air hose [6] to the Air Filter System.
- 2. Now connect the power cable to the Air Filter System connector [8] (right) and then to the power outlet.



**Attention:** Disconnect all cables and the exhaust air hose again for relocation, transport and maintenance.




## 4.3 Connect to Mr Beam

## Connecting the suction nozzle

 Connect the Mr Beam suction nozzle [5] to the free end of the exhaust air hose [6].




**Note:** The exhaust air hose [6] is equipped with a left-hand thread.



## Connect to the Mr Beam laser cutter

- Mount the suction nozzle [5] on your Mr Beam laser cutter. Use the supplied knurled screws and washers [11] for this purpose. Tighten them moderately.
- 2. Then connect the Air Filter connection cable [10] to your Mr Beam lasercutter.




### Exhaust air

- 1. Connect the exhaust air hose [6] to the Air Filter System.
- 2. Then connect the Air Filter connection cable [10] to the Air Filter system.



Attention: Disconnect all cables and the exhaust air hose again for relocation, transport and maintenance.



Page 20 | 04: Setup | Page 21


# CONTROL THE AIR FILTER SYSTEM

After commissioning the Air Filter System, we will introduce you to the basics of using the controller.

# 5.1 Controller operation


## Recognition of the system

If you have connected the controller correctly to the Air Filter Systems, you will see the Mr Beam Air Filter 2 on the display [12].



## Operate rotary button

- 1. Turn the rotary button [13] to navigate through the menu of the controller.
- 2. Press the rotary button [13] to select menu items.



## Change fan setting

- 1. Click on the "Preset" menu item.
- 2. Turn the rotary button [13] to adjust the fan power in percent.




**Note:** The current percentage is shown graphically on the edge of the display on each page of the menu.

3. Turn up the fan power more if you can see smoke at the current setting.



**Note:** The higher the fan power is set, the louder the Air Filter System is.




# 5.1 Controller operation

## Show filter consumption

The "Filter consumption" page shows you the percentage filter consumption of the pre-filter and main filter. It also shows the runtime since the last filter change took place.



**Note:** The percentage display of the filter consumption is only a guide value. Regularly check both filters by visual inspection.



## Reset filter consumption



**Note:** Only reset the filter consumption if you have changed the filter..

- 1. Click on the "Pre-filter" or "Main filter" menu item.
- 2. Click the "Filter changed" menu item to reset the filter consumption and "last change".



## Open Expert settings

1. Open the Expert settings by pressing and holding the knob while turning it clockwise.




**Note:** Changes in the Exptert settings are made at your own risk!





More detailed information about the controller interfer about the controller interface can be found in our knowledge base:

www.mr-beam.org/controller



# SERVICING AND MAINTENANCE

In order to be able to guarantee a permanent, fault-free function of your Air Filter System, regular regular maintenance & care is essential. In the following chapter you will find information on proper cleaning.

# 6.1 Cleaning and repair

## Cleaning



**Note:** No tools are required for regular cleaning, nor do any parts need to be unscrewed.

- 1. Disconnect all connections to the unit before starting cleaning.
- Remove all dust and dirt from all visible parts and surfaces of the Air Filter System.



Caution: Do not use aggressive cleaning agents or cleaning agents containing chlorine for cleaning. Improper handling of chemicals can cause damage to property and personal injury. We recommend the use of mild soapy water or commercially available detergents in low concentrations.

3. Check how far your filters are clogged. Change them if necessary. For more information on changing the filters, see Section 6.2 Changing the filters.

## Repair

Repair of the Air Filter System by the user is not intended. To ensure that your Air Filter System is quickly ready for use again in the event of a defect, please contact Customer Service.



In this case, please write an e-mail to the customer

www.mr-beam.org/support

# 6.2 Changing the filters

Change your filters regularly in order to permanently obtain high-quality work results from your Air Filter System. Before starting to change the filters, disconnect all connections of the device.

Regularly check the condition of your filters. Change the pre-filter mat when it has lost its pink color. Change the main filter when the fins under the grid show a

yellowish or brownish color. The software displays an average value for the status of the filters. This value is for orientation purposes only.




Pre-filter mat as well as main filter are available at Mr Beam Online Shop:

www.mr-beam.org/af2filter

### Remove protective cover

- 1. Remove the exhaust air hose [6] and all cables of the Air Filter System.
- 2. Unscrew the locking screws [14].
- 3. Remove the cover [15] of the Air Filter System.



### Remove filter




**Caution:** Wear gloves, safety glasses and a respirator to protect yourself from the dusts for the following steps.

- 1. Remove the prefilter mat [16].
- 2. Remove the main filter [17] if required.



**Note:** Pack old filters in a closed plastic bag to avoid stirring up particles. Dispose of them according to local disposal regulations.






# 6.2 Changing the filters

### Insert Pre-filter mat

1. Place the new pre-filter mat [16] on the grid of the main filter [17] (old or new) so that it covers the entire surface.




**Note:** The soft, fluffy side must face up.




## Insert filter


 Place the main filter [17] including the prefilter [16] in the housing of the Air Filter System.



### Close housing

- 1. Attach the cover [15].
- 2. Close the housing with the two locking screws [14].
- 3. Connect the exhaust air hose [6] of the Air Filter System to the housing.





# ADDITIONAL INFORMATION

## 7.1 Technical data

Dimensions Air Filter System (ca.)

Width/Depth/Height  $270 \times 270 \times 270 \text{ mm}$  Weight 5,6 kg Sound level maximum 56 dB (A)

Air Filter Controller

Width/depth/height (with button)  $77 \times 56 \times 32 \text{ mm}$  Weight 59 g Display size 1,28"

**Environmental conditions** 

Ambient temperature 15 - 25 °C Humidity 30% - 60%

Power supply

Operating voltage 19 V Power consumption 90 W



**Note:** Technical changes are reserved.



## 7.2 Storage & Transport / Support

## Storage & Transport

For the following subitems, the guidelines from Section 4 Setup must be observed in each case. In particular, the temperature and humidity values must not lie outside the specified range.



**Note:** Please retain the original packing and padding material in order to be able to ship the Air Filter System in this case.

- » If your Air Filter System will be unused for a shorter period of time (for example, a vacation trip), we recommend covering it to protect it from dust and other contaminants.
- » Disconnect all cables and the exhaust hose before packing the Air Filter System to prevent them from being damaged.
- The Air Filter System may only be transported, shipped and stored for longer periods in its original packaging and original cushioning material. Do not expose the Air Filter System to high temperature and humidity fluctuations during this time.
- The Air Filster system must not be thrown, bumped, shaken or subjected to other mechanical stresses. Check the correct fit of the pre-filter and main filter before commissioning after transport.



Caution: If one of the filters has slipped and the Air Filter System is started up without being checked, the exhaust air may escape unfiltered. This can result in personal injury as well as property damage.

## Mr Beam Support

If you need help troubleshooting a problem, contact customer service at any time at: www.mr-beam.org/ticket

Please first read the operating instructions completely and install the latest software update before contacting customer support.

## 7.3 Disposal

## Dismantling, disassembling

The Air Filter System can be disposed of as a complete unit. You therefore do not need to disassemble or dismantle it before disposal. Only the cables and suction hoses can be handed over separately from your Air Filter System to the electronic waste collection point. Please observe the relevant guidelines in your country. If disassembly or dismantling of the unit is required, please contact Mr Beam Lasers GmbH. As described in Section 3 Safety and Conformity, disassembly of the Air Filter System by the user is not intended.

## Disposal, environmental aspects

The Air Filter System may be used in accordance with local laws and regulations not be disposed of in household disposed of with household waste.

Your Air Filter System is an electronic device and must be and must be disposed of in accordance with the directive on waste electrical and electronic equipment of the respective country via the local collection points for waste electronic equipment.

If you have any further questions, please contact Mr Beam Lasers GmbH.

WEEE Number: DE17853778

1	1	1	1	1	1	1	1	1		7				7	_
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+
+	+	+	+	+	+	+	+	+	+	+	+	+	+	+	+

# GENERAL TERMS AND CONDITIONS

## 8.1 General Terms and conditions


The latest applicable general terms and conditions, as well as the warranty conditions of Mr Beam Lasers GmbH, can be found at:

www.mr-beam.org/policies/terms-of-service

## 8.2 Contact adresses

Address	Mr Beam Lasers GmbH Gollierstr. 70 80339 Munich Germany
Mr Beam Support	www.mr-beam.org/ticket
Instagram	instagram.com/mrbeamlasers/
Youtube	youtube.com/@MrBeamLasers
Facebook	facebook.com/mrbeamlasercutter/
Twitter	twitter.com/MrBeamLasers

Changes and errors excepted.



You can find us on many social media using the hashtag #madewithmrbeam such as Instagram, Twitter or Facebook, with inspiration from other members of the Mr Beam community. Naturally, we would also be happy if you share your works there and tell your friends about it. We are curious to see how you use your Mr Beam and what you will create with it!