



• J-LX®

•J-LXL®



6530-542C Rev A

## **Attention New Spa Owner!**

Congratulations on the purchase of your new Jacuzzi<sup>®</sup> spa! The following is a list of automated functions performed by your spa. These functions are listed below in an attempt to alleviate any operational concerns you may have during the first 24 hours of ownership! Also listed below are important maintenance recommendations you should observe on a regular basis to protect your new investment.

#### Automated Operations

Approximately two minutes after power is applied to the spa, the first filtration/ heating cycle turns on pump 1. An automatic "blow-out" function also activates pump 2 for a period of one minute to flush all lines. Then, after one minute, pump 2 turns off and pump 1 continues to operate for the duration of the cycle. **Note:** This function only occurs during the first filtration/heating cycle each day.

#### Maintain Healthy Spa Water

Always maintain your spa's water chemistry within the following parameters:

	With CLEARRAY®	Without CLEARRAY®
рН	7.4-7.6	7.4-7.6
Free Chlorine	no less than 1.0 ppm	3.0-4.0 ppm
Free Bromine	no less than 2.0 ppm	2.0-4.0 ppm
Total Alkalinity	100-150 ppm	100-150 ppm
Calcium Hardness	150-250 ppm	150-250 ppm

**IMPORTANT:** CLEAR**RAY**® Water Purification System is factory installed. If the CLEAR**RAY**® system is altered or is not operating efficiently then follow the "without CLEAR**RAY**®" water chemistry parameters as defined by the Association of Pool and Spa Professionals. CLEAR**RAY**® requires an annual bulb replacement to properly sanitize your water.

**TO DECREASE RISK OF INFECTION OR DISEASE!** Always maintain your spas filter as outlined below to ensure healthy spa water. Refer page 43 "Water Quality Maintenance" for additional information.

#### **Required Filter Maintenance**

Your new spa is equipped with an advanced water filtration system that provides unsurpassed water quality! To ensure maximum water quality at all times, you should clean both filter cartridges every month, or earlier as necessary. See page 35 for detailed filter cartridge cleaning/replacement instructions.

#### **Required Water Replacement**

TO DECREASE RISK OF INFECTION OR DISEASE! You should replace the spa's water every 3 months. The frequency depends on a number of variables including frequency of use, number of users, and attention paid to water quality maintenance. You will know it is time for a change when you cannot control sudsing and/or you can no longer get the normal feel or sparkle to the water, even though the key water balance measurements are all within the proper parameters. See page 43 for additional information.

\*\*Specifications and operations subject to change without notice.\*\*

# Table of Contents

1.0 2.0	Important Spa Owner Information FCC Notice	1 1
<b>3.0</b> 3.1	Important Safety Instructions for all Spa Owners	6
3.2	Hyperthermia	7
3.3	Important Additional CSA Safety Instructions (Canada Only)	
3.4	General Electrical Safety Instructions	8
4.0	Choosing A Location	9
4.1	Outdoor Location	10
4.2	Indoor Location	10
5.0	General Electrical Safety Instructions	11
6.0	Power Requirements	12
7.0	Electrical Wiring Instructions	13
8.0	Spa Fill Up Pročedure	15
9.0	Control Functions	20
9.1	Control Panel	20
9.2	J-LXL® General Spa Features And Controls	21
9.3	J-LXL Air Controls Diagram	
9.4	J-LXL Massage/Waterfall Selector Diagram	
9.5	J-LX™ General Spa Features And Controls	
9.6	J-LX Air Controls Diagram	
9.7	J-LX Massage/Waterfall Selector Diagram	. 26
10.0	Operating Instructions	27
10.1	Setting Water Temperature	27
10.2	Activate Jet Pumps	
10.3	Light On/Off Button	
10.4	Light Mode Button	28
10.5	Jets	
10.6	Selecting Desired Massage Action	29
10.7	Waterfall Feature	29
10.8	Air Controls	
10.9	Optional BLUEWAVE® Spa Stereo System	. 29
11.0	Automatic Filtration Cycles	30
11.1	Standard Filtration/Heating Modes (F0-F3)	30
11.2	Economy Filtration/Heating Modes (F4-F6)	. 30
11.3	Lock Modes (L1-L3)	
11.4	Selecting The Filtration/Heating Mode	
11.5	Programming the Circulation Pump Filtration Cycle	
11.6	Programming the CLEAR <b>RAY</b> ® (Ultraviolet) Water	
	Purification System	33

12.0	Spa Maintenance	35
12.1	Cleaning The Filters	
12.2	Draining and Refilling	
12.3	Pillow Čare	
12.4	Cleaning The Spa Interior	
12.5	Maintaining the Cover	
12.6	Maintaining The Synthetic Cabinet	
12.7	Top Rail Care And Maintenance	40
12.8	Stainless Steel Corners	41
12.9	Winterizing	
12.10	Restarting Your Spa in Cold Weather	
13.0	Water Quality Maintenance	43
13.1	pH Control	
13.2	Sanitizing	
13.3	CLEARRAY® (Ultraviolet) Water Purification System	44
13.4	CLEAR <b>RAY®</b> Bulb Replacement and Quartz	
	Tube Maintenance	
14.0	Error Conditions/Error Messages	48
14.1	Summer Logic	
14.2	Panel Displays COL	
14.3	Panel Displays ICE	
14.4	Panel Displays SN1	
14.5	Panel Displays SN2	
14.6	Panel Flashes FL1 or FL2	
14.7	Panel Displays OH	
14.8	Panel Displays ()	
14.9	Panel Displays BLB	50
15.0	Troubleshooting Procedures	50
15.1	None of the Components Operate (e.g. Pump, Light)	
15.2	Pump Does Not Operate But Light Does	50
15.3	Poor Jet Action	
15.4	Water is Too Hot	
15.5	No Heat	
16.0	Circuit Board Diagrams	52
16.1	North American Dedicated Power Models (60 Hz)	
16.2	Export Models (50 Hz)	
17.0	Optional BLUEWAVE® Spa Stereo System	54
17.1	Pairing the Remote and Stereo	
17.2	Audio Settings	
17.3	Wireless Remote Control Functions	57
17.4	Electronic Device Connections and Functions	58
17.5	Wireless Remote Battery Replacement Procedure	
17.6	BLUEWAVE® Spa Stereo System Specifications	
17.7	Stereo Cautions	

### 1.0 Important Spa Owner Information

Your Jacuzzi spa is constructed to the highest standards and is capable of providing many years of trouble-free use. However, because heat retentive materials are utilized to insulate the spa for efficient operation, an uncovered spa surface and wall fittings directly exposed to sunlight and high temperatures for an extended period are subject to permanent damage. Damage caused by exposing the spa to this abuse is not covered under warranty. We recommend that you always keep the spa full of water when it is exposed to direct sunlight and that you keep the Jacuzzi premium insulating cover in place at all times when the spa is not in use. Read and carefully follow the requirements for your spa's support base found in Section 4.0 titled, "Choosing A Location" (page 9).

#### Jacuzzi constantly strives to offer the finest spas available, therefore modifications and enhancements may be made which affect the specifications, illustrations and/or instructions contained herein.

### 2.0 FCC Notice

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1. Rearrange or relocate the receiving antenna.
- 2. Increase the separation between the equipment and receiver.
- 3. Connect the equipment into an outlet on a circuit different from the circuit connected.
- Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for FCC compliance could void the user's authority to operate this equipment.

### 3.0 Important Safety Instructions for all Spa Owners

### READ AND FOLLOW ALL INSTRUCTIONS CAREFULLY!

This spa was manufactured to meet the standards and specifications outlined in the "Virginia Graeme Baker Pool and Spa Safety Act" (VGB Safety Act). When installing and using this spa, basic safety precautions should always be followed, including:

### 1. $2^{1}$ DANGER: RISK OF SEVERE INJURY OR DROWNING!

- Extreme caution must be exercised to prevent unauthorized access by children.
- To avoid accidents, ensure that children do not use this spa unless supervised at all times. Adult supervision is a critical safety factor in preventing children from drowning.
- Use the straps and clip tie downs to secure the spa cover when not in use. This will help discourage unsupervised children from entering the spa. Keep the spa cover secure in high-wind conditions.
- There is no representation that the cover, clip tie-downs, or actual locks will prevent access to the spa.

# 2. **DANGER:** RISK OF SEVERE INJURY OR DROWNING!

- Keep hair, loose articles of clothing or hanging jewelry away from suction fittings, rotating jets or other moving components to avoid entrapment that could lead to drowning or severe injury.
- Never use the spa unless all suction guards, filter, filter lid, or skimmer assembly are installed to prevent body and/or hair entrapment.
- Never operate or use the spa if the filter, filter lid, or skimmer assembly are broken or any part of the skimmer assembly is missing. Please contact your dealer or nearest service center for service.
- The suction fittings and suction covers in this spa are sized to match the specific water flow created by the pump(s). If it is necessary to replace the suction fittings, suction covers or pump(s), be sure that the flow rates are compatible and are in compliance with the VGB Safety Act.
- Never replace a suction fitting or suction cover with one rated less than the flow rate marked on the original suction fitting. Using improper suction fittings or suction covers can create a body or hair suction entrapment hazard that may lead to drowning or severe injury.

# 3. **DANGER:** RISK OF SEVERE INJURY FROM ELECTRIC SHOCK OR DEATH FROM ELECTROCUTION!

Install the spa at least 5 feet (1.5m), from all metal surfaces. As an alternative, a spa may be installed within 5 feet of metal surfaces if each metal surface is permanently connected (bonded) by a minimum No. 8 AWG (8.4 mm<sup>2</sup>) solid copper conductor attached to the wire connector on the grounding lug, inside the equipment compartment on the equipment box.

- A grounding wire connector is provided on this unit to connect a minimum No. 8 AWG (8.4 mm<sup>2</sup>) solid copper conductor between this unit and any metal equipment, metal enclosures of electrical equipment, metal water pipe, or conduit within 5 feet (1.5m) of the unit.
- Never permit any electrical appliance, such as a light, telephone, radio, television, etc. within 5 feet (1.5m) of a spa unless such appliances are built-in by the manufacturer.
- Never bring any electrical appliances into or near the spa.
- Never operate any electrical appliances from inside the spa or when you are wet.
- The electrical supply for this product must include a suitably rated switch or circuit breaker to open all ungrounded supply conductors to comply with section 422-20 of the National Electrical Code/USA, ANSI/NFPA 70. The disconnecting means must be readily accessible and visible to the spa occupant but installed at least 5 feet (1.5m), from the spa.
- The electrical circuit supplied for the hot tub must include a suitable ground fault circuit interrupter (GFCI) as required by NEC Article 680-42.

### 4. **<u>A</u> WARNING:** RISK OF SEVERE INJURY OR DEATH!

- Extreme caution must be exercised to prevent diving or jumping into the spa or slipping and falling, which could result in unconsciousness, drowning, or serious injury. Remember that wet surfaces can be very slippery.
- Never stand, walk or sit on the top railing of the spa.
- 5. **WARNING: RISK OF HYPERTHERMIA (OVER-HEATING)** CAUSING SEVERE INJURY, BURNS, WELTS OR DEATH!
- Water temperature in excess of 104°F (40°C) may be injurious to your health.
- Refer to Section 3.2 Hyperthermia for specific causes and symptoms of this condition.
- The water in the spa should never exceed 104°F (40°C). Water temperatures between 100°F (38°C) and 104°F (40°C) are considered safe for a healthy adult.
- Lower water temperatures are recommended for young children (children are especially sensitive to hot water) and when spa use may exceed 10 minutes.
- The Consumer Products Safety Commission/USA has stated that the water temperature in a spa should not exceed 104°F (40°C).
- Always test the spa water temperature before entering the spa. The user should measure the water temperature with an accurate thermometer since the tolerance of water temperature-regulating devices may vary as much as +/- 5°F (2°C).

# 6. **WARNING:** RISK OF SEVERE INJURY OR DEATH!

- Since excessive water temperatures have a high potential for causing fetal damage during the early months of pregnancy, if pregnant or possibly pregnant, consult your physician before using a spa.
- Pregnant or possibly pregnant women should limit spa water temperatures to 100°F (38°C).
- Persons suffering from obesity or a medical history of heart disease, low or high blood pressure, circulatory system problems, diabetes, infectious diseases or immune deficiency syndromes should consult a physician before using a spa.
- If you experience breathing difficulties in association with using or operating your spa, discontinue use and consult your physician.
- Persons using medication should consult a physician before using a spa since some medication may induce drowsiness, while other medication may affect heart rate, blood pressure, and circulation.
- Persons suffering from any condition requiring medical treatment, the elderly, or infants should consult with a physician before using a spa.
- The use of alcohol, drugs, or medication before or during spa use may lead to unconsciousness with the possibility of drowning.

# 7. A WARNING: RISK OF SEVERE INJURY OR DEATH!

- Prolonged immersion in a spa may be injurious to your health.
- Observe a reasonable time limit when using the spa. Exposures at higher temperatures can cause high body temperature (overheating). Symptoms may include dizziness, nausea, fainting, drowsiness, and reduced awareness. These effects could possibly result in drowning or serious injury.
- Never use a spa immediately following strenuous exercise. Enter and exit the spa slowly. Wet surfaces can be slippery.

### 8. Z WARNING: TO DECREASE RISK OF INFECTION OR DIS-EASE!

- To reduce the risk of contracting a waterborne illness (e.g. an infection, bacteria or virus) and/or respiratory ailments, maintain water chemistry within the parameters listed on the inside cover of this manual and consult with a licensed engineer regarding proper ventilation if installed indoors or in an enclosed area.
- People with infectious diseases should not use a spa to avoid water contamination, which could result in spreading infections to others.
- Always shower before and after using your spa. Maintain water chemistry in accordance with manufacturer's instructions. Failure to do so may result in contracting a waterborne illness (e.g. an infection, bacteria or virus).

- 9. **VARNING:** In addition to maintenance of filters and water chemistry, proper ventilation is recommended to reduce the risk of contracting a waterborne illness (e.g. an infection, bacteria or virus) and/or respiratory ailments that could be present in the air or water. Consult a licensed architect or building contractor to determine your specific needs if installing your hot tub indoors.
- 10. CAUTION: TO DECREASE RISK OF PRODUCT DAMAGE.
- Maintain water chemistry in accordance with manufacturer's instructions.
- Proper chemical maintenance of spa water is necessary to maintain safe water and prevent possible damage to spa components.
- 11. A WARNING: RISK OF SEVERE INJURY OR DEATH! The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 12. **NOTE:** This spa is not intended nor designed to be used in a commercial or public application. The spa buyer shall determine whether there are any code restrictions on the use or installation of this spa since local code requirements vary from one locality to another.

## Hot Tub Safety Literature

To ensure you have a safe and enjoyable hot tub experience, learn all you can about hot tub safety and emergency procedures. Especially useful are the brochures listed below:

- <u>Children Aren't Waterproof</u>
- Pool and Spa Emergency Procedures For Infants and Children
- Layers of Protection
- The Sensible Way to Enjoy Your Spa or Hot Tub


The Association of Pool and Spa Professionals publishes these brochures. To acquire a brochure:

- Ask your hot tub dealer (they may have copies)
- Go to http://apsp.org
- Conduct your own search on the internet
- Write to the following address: The Association of Pool and Spa Professionals 2111 Eisenhower Avenue Alexandria VA 22314 703.838.0083

### 3.1 Entrapment Risk

The Consumer Products Safety Commission/USA has reported that users of pools and spas have become entrapped (stuck) to drain and/or suction fittings causing death, drowning, or serious injury (see diagram below). This spa was manufactured to meet the standards and specifications outlined in the "Virginia Graeme Baker Pool and Spa Safety Act" (VGB Safety Act). Entrapment risk can be minimized if proper precautions are taken.

> **DANGER: RISK OF PERSONAL INJURY OR DEATH**! Never operate the spa if a suction fitting, suction cover, filter, filter lid or skimmer assembly are broken, damaged or missing.



Filter, Filter Lid, Skimmer Assembly (location and style vary by models)

Suction Fittings, Suction Covers (locations vary by models)

### NOTE: SUCTION COVERS MUST BE REPLACED EVERY 5 YEARS.

- 1. **DANGER:** RISK OF SEVERE INJURY OR DROWNING! Hair entrapment: May occur if hair is entangled, knotted or snagged in a drain suction or skimmer assembly. This has been reported in persons who when submerge themselves underwater, allowing hair to come close and/or within the reach of the suction fittings, suction covers or skimmer assembly.
- Keep hair away from suction fittings, suction covers, filter, filter lid or skimmer assembly.
- Children are at risk for hair entrapment if swimming under water.
- Never allow children to play or get near the suction fittings, suction covers, filter, filter lid or skimmer assembly.
- 2. **DANGER:** RISK OF SEVERE INJURY OR DROWNING! Limb entrapment: May occur when a limb becomes entrapped, inserted or sucked into a suction or outlet opening.
- Always keep suction fittings, suction covers, filter, filter lid or skimmer assembly in place when operating to avoid limb entrapment.
- Never allow children to play or get near the suction fittings, suction covers, filter, filter lid or skimmer assembly.

- 3. **DANGER:** RISK OF SEVERE INJURY OR DROWNING! Body entrapment: May occur when part of the torso becomes entrapped, inserted or sucked into a suction or outlet opening.
- Never allow children to play or get near the suction fittings, suction covers, filter, filter lid or skimmer assembly.
- 4. **DANGER:** RISK OF SEVERE INJURY OR DROWNING! Evisceration (disembowelment) entrapment: May occur when the buttocks becomes entrapped, inserted or sucked into a suction or outlet opening.
- Never sit on suction fittings, suction covers, filter, filter lid or skimmer assembly.
- Never allow children to play or get near the suction fittings, suction covers, filter, filter lid or skimmer assembly.
- 5. **DANGER:** RISK OF SEVERE INJURY OR DROWNING! Mechanical entrapment: May occur when jewelry, swimsuit, or hair accessories become entangled, knotted or snagged in a drain suction or skimmer assembly.
- Never allow your jewelry, swimsuit, or hair accessories to come close to the suction fittings, suction covers or skimmer assembly.
- Never allow children to play or get near the suction fittings, suction covers, filter, filter lid or skimmer assembly.

### 3.2 Hyperthermia

Prolonged immersion in hot water may induce hyperthermia (overheating). The use of alcohol or drugs can greatly increase the risk of fatal hyperthermia in spas. A description of the causes, symptoms, and effects of hyperthermia are as follows:

Hyperthermia occurs when the internal temperature of the body reaches a level several degrees above the normal body temperature of 98.6°F (37°C). The symptoms of hyperthermia include drowsiness, lethargy (fatigue), and an increase in the internal temperature of the body (feeling of being too hot). The effects of hyperthermia include:

- Unawareness of impending hazard;
- Failure to perceive heat;
- Failure to recognize the need to exit spa;
- Physical inability to exit spa;
- Fetal damage in pregnant women; and
- Unconsciousness and DANGER of drowning.

A Warning Sign is provided in your warranty packet. Please install at a location near your spa, where it is visible to users of the spa. For additional or replacement Warning Signs please contact your local Jacuzzi dealer and reference item number #6530-082.

### 3.3 Important Additional CSA Safety Instructions (Canada Only)

When using this electrical equipment, basic safety precautions should always be followed, including the following:

### 1. READ AND FOLLOW ALL INSTRUCTIONS.

- A green colored terminal or a terminal marked G, Gr, Ground, Grounding or the symbol\* is located inside the supply terminal box or compartment. To reduce the risk of electric shock, this terminal must be connected to the grounding means provided in the electric supply service panel with a continuous copper wire equivalent in size to the circuit conductors that supply this equipment (\*IEC Publication 417, Symbol 5019).
- At least two lugs marked "Bonding Lugs" are provided on the external surface or on the inside of the supply terminal box/ compartment. To reduce the risk of electric shock, connect the local common bonding grid in the area of the spa to these terminals with an insulated or bare copper conductor not smaller than No. 6 AWG (10 mm<sup>2</sup>).
- 4. All field installed metal components such as rails, ladders, drains or other similar hardware within 10 feet (3m) of the spa shall be bonded to the equipment grounding buss with copper conductors not smaller than No. 6 AWG (10 mm<sup>2</sup>).
- 5. SAVE THESE INSTRUCTIONS.

### 3.4 General Electrical Safety Instructions

Your new Jacuzzi spa is equipped with a "state-of-the-art" equipment system. It contains the most advanced safety and self-protective equipment in the industry. Nonetheless, this spa must be installed properly to ensure dependable usage. Please contact your local Jacuzzi dealer or local building department should you have any questions regarding your installation.

Proper grounding is extremely important. Jacuzzi spas are equipped with a current collector system. A pressure wire connector is provided on the surface of the control box, located outside the equipment door (Figure B, page 14) to permit connection of a bonding wire between this point and any ground metal equipment, metal water pipe or conduit within 5 feet (1.5m) of the spa, or copper clad grounding rod buried within 5 feet (1.5m) of the spa. Bonding wire must be at least No. 8 AWG (8.4 mm<sup>2</sup>) solid copper wire. This is a most important safety assurance feature. Before installing your spa, check with your local building department to insure installation conforms to local building codes.

### 4.0 Choosing A Location

**IMPORTANT:** Because of the combined weight of the spa, water and users, it is extremely important that the base upon which the spa rests be smooth, flat, level and capable of uniformly supporting this weight, without shifting or settling, for the entire time the spa is in place. If the spa is placed on a surface which does not meet these requirements, damage to the skirt and/or the spa shell may result. Damage caused by improper support is not covered under warranty. It is the responsibility of the spa owner to assure the integrity of the support over time. We recommend a poured, reinforced concrete slab with a minimum thickness of 4 inches (10 cm). Wood decking is also acceptable provided it is constructed so that it meets the requirements outlined above.



**WARNING:** For spas that are to rest on balconies, roofs or other platforms not specifically tied into main structural support, consult a professional Structural Engineer with experience in this type of application.

The spa must be installed in such a manner as to provide drainage away from it. Placing the spa in a depression without provisions for proper drainage could allow rain, overflow and other casual water to flood the equipment and create a wet condition in which it would sit in. For spas which will be recessed into a floor or deck, install so as to permit access to the equipment, either from above or below, for servicing. Make certain that there are no obstructions which would prevent removal of all side cabinet side panels and access to the jet components, especially on the side with the equipment bay.

CAUTION: If the spa is indoors or located in an enclosed area, proper ventilation should be discussed with an Engineer or authority competent enough to understand the necessary provisions needed to vent moist or heated air and air associated with chemical odors outdoors. When the spa is in use considerable amounts of moisture will escape potentially causing mold and mildew. This can cause health risk. Over time, this can damage certain surfaces, surroundings, and equipment.

### 4.1 Outdoor Location

In selecting the ideal outdoor location for your spa, we suggest that you take into consideration:

- The proximity to changing area and shelter (especially in colder weather).
- The pathway to and from your spa (this should be free of debris so that dirt and leaves are not easily tracked into the spa).
- The closeness to trees and shrubbery (remember that leaves and birds could create extra work in keeping the spa clean).
- A sheltered environment (less wind and weather exposure can result in lowered operation and maintenance costs).
- The overall enhancement of your environment. It is preferable not to place the spa under an unguttered roof overhang since run-off water will shorten the life expectancy of the spa cover.
- For spas that are to rest on balconies, roofs or other platforms not specifically tied into main structural support, consult a professional Structural Engineer with experience in this type of application.
- In the unlikely event that you should ever need to access or gain entry to any portion of the spa for servicing, it is highly recommended that you plan your outdoor installation to provide full access to the entire spa. Please take this into consideration when placing the spa in a deck or enclosed by a surrounding.
- Consider locating your spa away from any reflective surface or glass to prevent any damage to the synthetic skirt.
- Do not shim the spa. To ensure proper support the spa must sit flat on the intended foundation.

### 4.2 Indoor Location

For indoor installations many factors need to be considered before installing a spa indoors:

WARNING: In addition to maintenance of filters and water chemistry, proper ventilation is recommended to reduce the risk of contracting a waterborne illness (e.g. an infection, bacteria or virus) and/or respiratory ailments that could be present in the air or water. Consult a licensed architect or building contractor to determine your specific needs if installing your hot tub indoors.

• Proper Foundation: <u>Consult a Structural Engineer when</u> <u>considering a foundation that will adequately support the spa</u> <u>the entire time it is in place</u>. Proper support is critical especially if the spa is to rest on a second story or higher. For spas that are to rest on balconies, roofs or other platforms not specifically tied into the main structural support, you should consult a professional Structural Engineer with experience in this type of application.

- Proper Drainage: It is extremely important to have in place measures to sufficiently handle excessive water spillage. Be sure the flooring in which the spa rests on has adequate drainage and can handle the entire contents of the spa. Be sure to make provisions for ceilings and other structures that may be below the spas installation. Areas around your spa can become wet or moist so all flooring and subsequent furniture, walls and adjacent structures should be able to withstand or resist water and moisture.
- Proper Ventilation: Proper ventilation should be discussed with an Engineer or authority competent enough to understand the necessary provisions needed to vent moist or heated air and air associated with chemical odors outdoors. When the spa is in use considerable amounts of moisture will escape, potentially causing mold and mildew over time which can damage certain surfaces and/ or surroundings.
- **Sufficient Access:** In the unlikely event that you should ever need to access or gain entry to any portion of the spa for servicing, it is highly recommended that you plan your indoor installation to provide full access to the entire spa.
- **Warranty:** Damage caused by not following these guidelines or any improper installation not in accordance to local codes or authorities is not covered under the spas warranty. Please consult your local state or city building ordinances.
- **Do not shim the spa.** To ensure proper support the spa must sit flat on the intended foundation.

### 5.0 General Electrical Safety Instructions

Your new Jacuzzi spa is equipped with a "state-of-the-art" equipment system. It contains the most advanced safety and self-protective equipment in the industry. Nonetheless, this spa must be installed properly to insure dependable usage. Please contact your dealer or local building department should you have any questions regarding your installation.

Proper grounding is extremely important. Jacuzzi spas are equipped with a current collector system. A pressure wire connector is provided on the surface of the control box, located outside the equipment door (Figure B, page 14) to permit connection of a bonding wire between this point and any ground metal equipment, metal water pipe or conduit within 5 feet (1.5m) of the spa, or copper clad grounding rod buried within 5 feet (1.5m) of the spa. Bonding wire must be at least No. 8 AWG (8.4 mm<sup>2</sup>) solid copper wire. This is a most important safety assurance feature. Before installing this spa, check with the local building department to insure installation conforms to local building codes.



### 6.0 Power Requirements

Jacuzzi spas are designed to provide optimum performance and flexibility of use when connected to the maximum electrical service listed below. Minor circuit board modifications can be performed to allow your new spa to accept an electrical service other than the factory operation setting.



Note: Refer to pages 52-53 for circuit board configuration details or contact your authorized Jacuzzi dealer.

North American Models (60 Hz)			
	<u>240V/40A*</u>	240V/50A**	240V/60A***
Circuit Breaker (2-Pole):	40A	50A	60A
Number of Wires:	3	3	3
Frequency:	60 Hz	60 Hz	60 Hz
Current Draw:	26A	36A	45A
* In 40A configuration. t	he heater will i	not operate wh	ile either iets

 In 40A configuration, the heater <u>will not operate</u> while either jets pump is running in high speed. Note: pump 2 runs only in high speed.

\*\* In 50A configuration, the heater <u>will not operate</u> while both jets pumps are running in high speed. <u>This is the factory setting</u>. Note: pump 2 runs only in high speed.

\*\*\* In 60A configuration the heater will operate while both jets pumps are running in high speed.

Export Models (50 Hz)			
	230V/20A*	230V/30A**	230V/40A***
Circuit Breaker:	20A	30A	40A
Number of Wires:	3	3	3
Frequency:	50 Hz	50 Hz	50 Hz
Current Draw:	15A	23A	29A

 In 20A configuration, the heater <u>will not operate</u> while either jets pump is running in high speed. <u>This is the factory setting.</u> Note: pump 2 runs only in high speed.

\*\* In 30A configuration, the heater <u>will operate</u> while one jets pump is running in high speed. *Note: pump 2 runs only in high speed.* 

\*\*\* In 40A configuration the heater **will operate** while both jets pumps are running in high speed.

### 7.0 Electrical Wiring Instructions

**IMPORTANT NOTICE:** The electrical wiring of this spa must meet the requirements of the National Electrical Code/USA (NEC) and any applicable state or local codes. The electrical circuit must be installed by a qualified electrician and approved by a local building/ electrical inspection authority.



- Dedicated 240V models must be permanently connected (hardwired) to the power supply. No plug-in connections or extension cords are to be used in conjunction with the operation of this spa. Supplying power to the spa which is not in accordance with these instructions will void both the independent testing agency listing and the manufacturer's warranty.
- The power supplied to this spa must be a dedicated circuit with no other appliances or lights sharing the power provided by the circuit.
- 3. To determine the current, voltage and wire size required, refer to Section 6.0 "Power Requirements" (page 12).
- Wire size must be appropriate per NEC/USA and/or local codes.
- We recommend type THHN wire.
- All wiring must be copper to ensure proper connections. **Do not use aluminum wire.**
- 4. When using wire larger than #6 (10 mm<sup>2</sup>), add a junction box near the spa and reduce to short lengths of #6 (10 mm<sup>2</sup>) wire to connect to the spa.
- 5. The electrical supply for this product must include a suitably rated switch or circuit breaker to open all ungrounded supply conductors to comply with Section 422-20 of the National Electrical Code/USA, ANSI/NFPA 70. The disconnecting means must be readily accessible to the spa's occupant but installed at least 5 feet (1.5m) from spa water.
- The electrical circuit supplied for the spa must include a suitable ground fault circuit interrupter (GFCI) as required by NEC/USA Article 680-42.
- The electrical supply for this product must include a suitably rated isolating switch and circuit breaker to comply with local electrical regulations. This RCD/GFCI circuit breaker must be installed at the power supply in the house electrical box.
- For Australia/ New Zealand, the spa should be supplied through a residual current device (RCD) with a rated tripping current not exceeding 30mA (IEC 60335-2-60).
- To gain access to the spa's power terminal block, remove the screws securing the synthetic cabinet corners and front panel under the control panel (page 14). Then remove the control box door screws and door (Figure B).

Note: The stainless steel corners will require a square drive bit.

- 10. Select the power supply inlet you want to use (Figure A). Feed power cable to control box, then install it through the large opening provided in the bottom side of the box.
- 11. Connect wires, color to color, on terminal blocks TB1 and TB3 (Figure C, page 15). TIGHTEN SECURELY! All wires must be hooked up securely or damage could result.
- 12. Install the control box door and screws, then reinstall the front panel and cabinet corners.

#### **Removing the Front panel**





Figure A Equipment Area




Note: Equipment location (such as pumps, CLEAR**RAY** system, drain, heater etc.) varies by model.


- 1. Control Box
- 2. Power Supply Entrance(s)
- 3. 2-Speed Jets Pump
- 4. Heater
- 5. Spa Drain Valve
- 6. Pump Drain Plug(s)

- 7. 1-Speed Jets Pump
- 8. Circulation Pump
- 9. CLEAR**RAY** (Ultraviolet) Water Purification System
- 10. Electronic Ballast (for the CLEAR**RAY** System)
- 11. Control Panel

#### Figure B Control Box

- 1. Terminal Block
- 2. Bonding Lug
- 3. Grounding Terminal





### 8.0 Spa Fill Up Procedure

For best results, read each step in its entirety before proceeding with that step.

#### 1. Prepare The Spa For Filling

- Clear all debris from the spa. (Although the spa shell has been polished at the factory, you may want to treat it with a specially formulated spa cleaner.) Consult your authorized Jacuzzi dealer for additional information prior to filling spa.
- Remove filter cover, then remove filter cartridge as outlined in Section 12.1 (page 35).

#### 2. Fill Spa

Place the end of your garden hose into the empty filter fitting.

# CAUTION: TO DECREASE BUILD UP ON COMPONENTS AND MINIMIZE ACRYLIC DAMAGE.

Never fill with water from a water softener. If your water is extremely "hard", it is preferable to fill half-way with hard water and the rest of the way with softened water. Water that is too soft can be corrosive to metal components.

# **WARNING:** TO DECREASE RISK OF INFECTION OR DISEASE.

Fill hot tub with clean tap water from garden hose, to reduce risk of contracting a waterborne illness (e.g. an infection, bacteria or virus) and/or respiratory ailments. Fill until water covers all jets but does not touch the bottom of the lowest headrest. (DO NOT OVERFILL!)

**IMPORTANT:** Always fill your spa through the filter fitting after draining. Failure to do so may cause air to be trapped in the pumps, preventing the pumps from circulating water. Remove the hose and replace the filter cartridge. Note: DO NOT overtighten filter cartridge, finger tight only!

#### 3. Turn On Power

Turn on power to spa at the home's circuit breaker to start boot up sequence (Sec. 10.0, page 27). The heater and filter pump will automatically activate after several seconds. If the control panel LED flashes water temperature and "COL" or "ICE" this is normal, refer to page 48 for additional information.

**Note:** "COL" and "ICE" will only appear when the spa is in Economy mode.

#### 4. Activate Jets Pumps

Turn on jets pump(s) to ensure proper mixing when adding start-up chemicals in step 5.



#### 5. Add Start-Up Chemicals

Add the spa water chemicals as recommended by your authorized Jacuzzi dealer. Section 13.0 "Water Quality Maintenance" (page 43) for general guidance.



### WARNING: RISK OF POISONING OR DEATH.

Never leave chemicals opened and accessible to anyone. Use chemicals according to the vendors instructions. Always store chemicals in a safe and/or locked location. Keep away from and out of reach of children.

### 6. Establish A Stable Sanitizer Reading

Establish a stable sanitizer reading of no less than 1.0 ppm free chlorine or 2.0 ppm bromine. To ensure healthy water conditions, always maintain a constant sanitizer reading within the levels recommended on the inside cover of this manual. If sanitizer levels cannot be stabilized, perform the decontamination procedure steps 9-15 on the following page.

**Note:** The "decontamination procedure" steps 9-16 should also be used after the spa has been "Winterized" (Section 12.9, page 41) or has been sitting without power for an extended period.

### 7. Set Spa To Heat

To warm spa water to a comfortable temperature, follow these steps:



 The LED display on the control panel displays the actual temperature of the spa water. Press either the COOLER ( 
 ) or WARMER

(  $\bigcirc$  ) button once to display the "set" temperature for 5 seconds. If you want the water to heat to a different temperature, simply press **COOLER** (  $\bigcirc$  ) or **WARMER** (  $\bigcirc$  ) within 5 seconds. The set temperature increases or decreases by one degree each time one of these buttons is pressed.

• The heater will turn off when the temperature corresponding to the thermostat setting is achieved.

#### Important Heater Details:

- The maximum water temperature setting for your spa is 104°F (40°C) and the minimum setting is 65°F (18°C).
- For North American spas connected to a 40 amp service, jets pump #1 must be set to low speed and jets pump #2 must be turned off to operate the heater.
- For Export spas connected to a 20 amp service, jets pump #1 must be set to low speed and jets pump #2 must be turned off to operate the heater.
- Setting the thermostat at maximum will not accelerate the heating process. This will only result in a higher ultimate temperature.
- The heater operates until the water reaches the programmed "set temperature", then turns off. The heater will reactivate after the water cools to approximately 1.5° below the set temperature.

#### 8. Place Cover On Spa

- Keeping the insulating cover in place anytime the spa is not in use will reduce the time required for heating, thereby minimizing operating costs.
- The time required for initial heat-up will vary depending on the starting water temperature.




### DANGER: RISK OF PERSONAL INJURY.

Check water temperature carefully before entering hot tub! Excessive water temperature can cause burns, welts and body temperature to rise, hyperthermia (over-heating).

### **Decontamination Procedure (Steps 9-16)**

Steps 9-16 below are only required when sanitizer levels are unstable after performing steps 1-6 above. Disregard steps 9-15 below if sanitizer levels remain stable after performing steps 1-6 above (refer to the inside cover of the manual).

 Add 2.5 ounces of sodium dichlor for every 100 gallons of water. Refer to the following table for approximate water fill volume by model.



Water Fill Volume by Model			
Spa Model	Average Fill Volume*	Sodium Dichlor	
J-LX	390 Gal (1,476 L)	10.0 oz	
J-LXL	390 Gal (1,476 L)	10.0 oz	

\*Use average fill volume for chemical maintenance

10. Leave spa cover open during this step to allow excessive chemical vapors to exit spa, protecting pillows and plastic knobs from chemical attack. If spa is indoors, open doors and windows for proper ventilation. Turn on all jet pumps for one hour, then place the massage selector knob in the center "combo" position and open all air controls.



**Note:** You will need to press the jets pump button(s) every 20 minutes since these functions have an automatic 20 minute time-out function that turns them off.


### WARNING: RISK OF PERSONAL INJURY!

- To decrease the risk of injury, drowning or entrapment, never leave your hot tub unattended for any reason while the cover is open and accessible, especially to small children and animals!
  - Precautions should be taken to minimize your exposure to chemical vapors (that could cause lung, brain, or skin damage).
- 11. Turn off power to the spa at the circuit breaker, then drain spa as outlined in Section 12.2 "Draining and Refilling" (page 38).
- 12. Fill spa until water covers all jets but does not touch the bottom of the lowest headrest. DO NOT OVERFILL.

# CAUTION: TO DECREASE BUILD UP ON COMPONENTS AND MINIMIZE ACRYLIC DAMAGE.

Never fill with water from a water softener. If your water is extremely "hard", it is preferable to fill half-way with hard water and the rest of the way with softened water. Water that is too soft can be corrosive to metal components.

- Consult your authorized Jacuzzi dealer for chemical recommendations, then add chemicals to hot tub water to achieve a constant sanitizer reading within the levels recommended on the inside cover of this manual.
- 14. Turn on jet pumps when adding chemicals to ensure proper mixing and leave your hot tub cover open until the sanitizer level becomes stable to protect pillows and plastic knobs from chemical attack. Refer to the inside cover of the manual.




15. Establish a sanitizer reading no less than 1.0 ppm free chlorine or 2.0 ppm bromine, then allow the hot tub to set undisturbed for 8 hours. Retest water after 8 hours to determine if sanitizer levels are stable. If sanitizer levels are stable, your spa is ready for use. To ensure healthy water conditions, always maintain a constant sanitizer reading within the levels recommended on the inside cover of this manual. If sanitizer levels are not stable at this time, it will be necessary to repeat this procedure in its entirety (steps 1-15) until stable sanitizer readings are achieved.

**IMPORTANT:** If the CLEAR**RAY**® water purification system is removed from the hot tub or is not operating effectively follow the "without CLEAR**RAY**®" water chemistry parameters as defined by the Association of Pool and Spa Professionals.

16. After adequate sanitizer levels are achieved, close all spa air controls to maximize heat retention when spa is not in use.

### 9.0 Control Functions

- 9.1 Control Panel
- A. LED Display: Can display current water temperature (default display), water temperature set point, selected filtration/heating mode, and error messages.




- B. Warmer ( 🗇 ) Button: Increases water temperature set point.
- C. Cooler ( <-> ) Button: Decreases water temperature set point.
- D. Light On/Off ( ) Button Options: Turns waterfall, footwell and accent lighting on in unison. Press once for high intensity; press a second time for medium intensity; press a third time for low intensity; press a fourth time to turn off. The displayed color is changed using the light mode button (E) below.
- E. Light Mode ( <a>) Button: Selects one of 4 color modes for waterfall, footwell and accent lighting. See page 28 for additional information.</a>
- F. Jets 1 Button: Turns jets pump #1 on and off. Press once for low speed; press a second time for high speed; press a third time to turn pump off.
- G. Jets 2 Button: Turns high-speed jets pump #2 on and off. Press once to turn pump #2 on; press a second time to turn pump #2 off.
- H. Heat Indicator: Lit when heater is on.

#### **Operation Details**

- Temperature Adjustment: 65 to 104°F (18 to 40°C). Factory default setting is 100°F (38°C).
- Light Operation: All LED lights run for 2 hours, then automatically shut off.
- Jets 1/Jets 2 Button Operation: Jets run for 20 minutes when activated, then turn off automatically to conserve energy. Simply press either jets button to continue operation for an additional 20 minutes.

#### 9.2 J-LXL® General Spa Features And Controls




- 1. Control Panel
- 2. Toggle Air Controls (3)
- 3. Filter/Skimmer Grill
- 4. PowerPro MX2 Footwell Jets (2)
- 5. Pillows (3)
- Massage Selector Valve (side mounted)
- 7. Heater Return Fitting
- 8. Waterfall (Stainless steel)
- 9. Spa Light
- 10. Footwell Suction Fittings (4)

- 11. PowerPro RX Jets (4)
- 12. PowerPro FX2 Jets (3)
- 13. PowerPro NX2 Jets (6)
- 14. PowerPro FX Jets (23)
- 15. Accent Lights (8)
- 16. Top Rail
- 17. Optional BLUEWAVE® Spa Stereo System
- Optional Audio System Speakers (4)
- 19. Waterfall valve

#### 9.3 J-LXL Air Controls Diagram

**Air Control Operation** Rotate Air Controls 1-3 to add air to designated jet groups.




Specifications/features subject to change without notice.

#### 9.4 J-LXL Massage/Waterfall Selector Diagram

#### **Massage Selector Operation**

Rotate Massage Selector 1 to divert water between designated jet groups.



#### Massage Selectors (1)

Massage Selector #1 controls pump #1.


#### Jets (2)

• These jets are always on when the jets pump #2 is running.

### Waterfall (3)

 Waterfall is on when the jets pump 1 is running. Waterfall valve controls waterfall output (On/Off).

#### 9.5 J-LX<sup>™</sup> General Spa Features And Controls




Specifications/features subject to change without notice.

- 1. Control Panel
- 2. Toggle Air Controls (4)
- 3. Filter/Skimmer Grill
- 4. PowerPro MX2 Jets (2)
- 5. Pillows (4)
- Massage Selector Valve (side 6. mounted)
- 7. Heater Return Fitting
- Waterfall (Stainless steel) 8.
- Spa Light 9.
- 10. Footwell Suction Fittings (4)

- 11. PowerPro RX Jets (4)
- 12. PowerPro FX2 Jets (5)
- 13. PowerPro NX2 Jets (4)
- 14. PowerPro FX Jets (21)
- 15. Accent Lights (8)
- 16. Top Rail
- 17. Optional BLUEWAVE® Spa Stereo System
- 18. Optional Audio System Speakers (4)
- 19. Waterfall Valve

#### 9.6 J-LX Air Controls Diagram

**Air Control Operation** Rotate Air Controls 1-4 to add air to designated jet groups.




Specifications/features subject to change without notice.

### 9.7 J-LX Massage/Waterfall Selector Diagram

#### **Massage Selector Operation**

Rotate Massage Selector 1 to divert water between designated jet groups.



#### Massage Selectors (1)

Massage Selector #1 controls pump #1.

#### Jets (2)

• These jets are always on when the jets pump #2 is running.

#### Waterfall (3)

 Waterfall is on when the jets pump 1 is running. Waterfall valve controls waterfall output (On/Off).

### 10.0 Operating Instructions


The spa control system has automatic functions that operate upon start-up and normal operation to protect the system. Upon power up, the readout displays the following information:

- 1. Control panel displays current software release, then;
- Control panel displays "888" and all indicator LEDs are lit, permitting visual inspection of all display segments and indicator lights for proper operation.
- 3. After the initial start-up sequence ends, the actual water temperature is displayed. If water temperature at this time is less than the factory default temperature setting of 100°F (38°C) and the spa is set to either standard filtration/heating mode (page 30), the heater will turn on and run until the water temperature rises to the factory setting, then turn off.

**Note:** It is common for the heater to turn on after the spa is first filled because tap water is often very cold.

#### 10.1 Setting Water Temperature

The spa's thermostat provides optimum control of water temperature. The temperature set point (set temperature) can be adjusted from 65-104°F (18-40°C). To raise the set temperature, press the **WARMER** ( + ) button. To lower the set temperature, press the **COOLER** ( ) button. The first press of either **WARMER** ( ) or **COOLER** ( ) button displays the set temperature. To access the overtemp feature that allows



the spa to reach  $106^{\circ}F$  ( $41^{\circ}C$ ) follow the steps below (Figure 1).



WARNING: RISK OF HYPERTHERMIA (OVER-HEATING) CAUSING SEVERE INJURY, BURNS, WELTS OR DEATH! Water temperature in excess of 104°F (40°C) may be injurious to your health.

- A. Press and hold the **WARMER** ( +) button then;
- B. Press and hold the **JETS 1** ( ) button at the same time for 2 seconds. You will see the temperature rise to 106°F (41°C) on the LED display. To lower the temperature, press the **COOLER** ( ) button.
- C. When the overtemp has been activated, the decimal point after the last digit will flash on and off every second as an indicator for being in the overtemp mode.

**Note:** Once the temperature goes below 104°F (40°C) and you would like to raise the temperature to 106°F (41°C) again, you will have to repeat the steps above.

### 10.2 Activate Jet Pumps

The control panel JETS 1 button activates jets pump 1. The first press activates low speed, the second press activates high speed, and the third press shuts jets pump 1 off. The JETS 2 button activates jets pump 2. The first press activates high speed, the second press turns jets pump 2 off. When manually activated. either pump will automatically turn off after 20 minutes.

#### 10.3 Light On/Off Button

Pressing this button activates the waterfall, footwell, accent lights in unison as follows: high - medium - low - off. Note: Lights automatically turn off after 2 hours.

#### 10.4 Light Mode Button

This button offers 4 light modes for your enjoyment. Press this button to select your favorite lighting effect as follows:

#### High-Speed Color Blend Mode Press Once V Ý·····È∯′····È∯′····È∯∕····È∭∕····È∭∕····È∭∕ Low-Speed Color Blend Mode Press Again Freeze Color Blend Mode: Press Selects or "freezes" your low speed blending color of choice. Again BLUE (X4) VIOLET (X5)RED (X6) AMBER (X7) GREEN (X8) AQUA (X9) NEAR WHITE (X10) Press Solid Color Mode: Again Selects one of 7 solid (high-intensity) colors of choice.

ᡁᡔ**ᠿ**ᠵᠿᠵᠿᠵᠿᠵᠿᠵᠿᠵ

#### 10.5 Jets

The water flow through individual lets in your spa can be adjusted or turned off by rotating the outside jet ring. Some jets offer an adjustable center nozzle that allows you to change the water discharge angle. Simply tilt the center nozzle in these jets to the desired angle to customize your personal massage. Other







jets offer a spiral action that produces a surging stream of air and water that provides a vigorous massage.

**Note:** Always keep at least 6 adjustable jets open at all times to ensure proper filtration characteristics within the spa. Jets may not spin with jets pump 1 running in low speed.

### 10.6 Selecting Desired Massage Action

All models incorporate a massage selector valve that allows you to customize the massage and performance by diverting water between various jet systems within the spa. Simply turn valve to positions A, B or C to divert water pressure to various jet groups.

**Note:** The valve is intended to operate in positions A (Combo), B, or C for optimum performance. It is considered normal for sound levels within the valve to increase between these positions due to the large amounts of water flowing through it. For optimum filtration benefits, always leave this valve in position A when the spa is covered and select positions B or C for maximum jet performance during spa use.

### 10.7 Waterfall Feature

The waterfall is on when jets pump 1 is running. Turn waterfall control valve <u>counterclockwise</u> to increase waterfall output. Turn control valve <u>clockwise</u> to decrease or turn off waterfall output.

**Note:** When the waterfall is in the OFF position, some water may still flow through. This is considered normal.

### 10.8 Air Controls

Certain jet systems have their own "toggle" on/off air control. Each control introduces air into the water lines that supply specific jet groups. Simply press any air control button Jacuzzi logo side down to open or press the opposite side of button to close.

**Note:** To minimize heat loss, close all air controls (Jacuzzi logo up) when spa is not in use. Certain jets may not draw air when jets pump 1 is running in low speed. This is considered normal.

### 10.9 Optional BLUEWAVE® Spa Stereo System

Spas equipped with the optional Jacuzzi audio system offer enhanced enjoyment. These models include an integrated FM/Apple device/USB/AUX/Bluetooth receiver with high-quality marine speakers for unsurpassed sound quality and long-life.

**Note:** The DRM (Digital Rights Management) Files cannot be played on this deck. Personal files (MP3, WMA, iTunes or AAC) can be played as long as they are not DRM encrypted.









### 11.0 Automatic Filtration Cycles

Your new spa includes an 8-hour circulation pump which filters the water continuously. The circulation pump draws water through the skimmer bag and one of two filter cartridges to effectively remove small debris in your spa.

**Note:** The 8-hour circulation pump system also supplies heated water to the spa when the heater turns on. To set a time for the circulation pump filtration cycle, simply turn power on to the spa two minutes prior to the desired time.

The control system activates a programmable "Standard" or "Economy" filtration/heating cycle to remove larger debris missed by the 8-hour circulation pump filtration system. These cycles utilize pump #1 low speed and the second filter cartridge to quickly "skim" the water of large debris and minimize their "bath-tub ring" effect. Apart from their skimming benefit, each mode also effects the operation of your spa's heater.

### 11.1 Standard Filtration/Heating Modes (F0-F3)

Standard filtration/heating modes are typically selected by customers in cold climates where heat up times are extended due to lower ambient temperatures. In these modes, the water temperature is regulated by the set temperature, 8-hour circulation pump and heater which turns on as needed. After the programmed set temperature is reached, the heater turns off and the circulation pump continues to operate for the remainder of its filter cycle and clean your spa unless in summer logic; see Section 14.1, page 48.

### 11.2 Economy Filtration/Heating Modes (F4-F6)

Economy filtration/heating modes are typically selected by customers in warm climates where heat up times are minimized due to higher ambient temperatures. In these modes, the water temperature is regulated by the set temperature, 8-hour circulation pump and heater only while a programmed filter cycle is running (unless in summer logic; see Section 14.1, page 48).

### 11.3 Lock Modes (L1-L3)

These modes are designed for use during spa service or to prevent unauthorized use.

### 11.4 Selecting The Filtration/Heating Mode

Press and hold both control panel **WARMER** ((+)) and **COOLER** ((-)) buttons at the same time, then release. Then press either **WARMER** ((+)) or **COOLER** ((-)) button to select filtration/heating mode F0-F6 or lock modes L1-L3. During the filtration/heating cycle the jets pump 1 low speed and circulation pump will activate.

An automatic "blow-out" function also activates pump 2 for a period of one minute to flush all lines. Then, after one minute, pump 2 turns off and pump 1 continues to operate for the duration of the cycle. **Note:** This function only occurs during the first filtration/heating cycle each day.

### Standard Filtration/Heating Modes

- **F0** No filtration per day (a 1-minute "Blow-Out" cycle every 24 hours to purge all plumbing lines)
- F1 1 hour of filtration per day (one 30-minute cycle every 12 hours); This is the factory default setting.
- F2 1.5 hours of filtration per day (one 30-minute cycle every 8 hours)
- F3 2 hours of filtration per day (one 30-minute cycle every 6 hours)

### **Economy Filtration/Heating Modes**

- **F4** 1 hour of filtration/heating per day (one 30-minute cycle every twelve hours)
- **F5** 1.5 hours of filtration/heating per day (one 30-minute cycle every eight hours)
- **F6** 2 hours of filtration/heating per day (one 30-minute cycle every six hours)

### Lock Modes

(When in a lock mode the display will flash between the temperature and the Lock mode number)

L1 Lock Out: Disables all spa functions to permit filter cleaning.

**Note:** The spa should not be left in this lock mode for an extended period of time. Especially in colder climates or when freezing conditions exist.

- L2 Lock Mode: Disables the jets to prevent unauthorized use of spa. Filtration/heating cycle will continue to operate as programmed in this mode. The temperature display flashes when this function is enabled. Example: The "F3" filtration/heating cycle was enabled prior to choosing lock mode. The spa continues to perform the "F3" cycle until lock mode is canceled, allowing another cycle to be selected.
- L3 Lock Mode (disables the temperature up and down buttons to prevent unauthorized temperature adjustments). Filtration/heating cycle will continue to operate as programmed in this mode. The jets and lights buttons will still continue to operate as normal. The temperature display flashes when this function is enabled.

**Note:** To exit a Lock Mode you will need to re-enter the filtration/heating modes and select a cycle from F0-F6.

To set a time for the first filtration/heating cycle, simply turn power on to the spa two minutes prior to the desired time. Example: If you desire your first filtration/heating cycle to begin at 10:00 AM turn off power to the spa and turn it back on again at 9:58 AM. You can also press the Warmer, Cooler and Jets Pump 1 buttons simultaneously for 2 seconds to restart the spa.

Note: Start time is approximate and may vary slightly from day to day.







**11.5** Programming the Circulation Pump Filtration Cycle Press and hold the Jets pump 1 ( ) and Cooler ( ) button <u>at the</u> <u>same time</u> for 3 seconds to access the circulation pump programming. Once you have entered the circulation pump filtration cycle, continually press the Warmer ( ) or Cooler ( ) button to scroll up through the cycles below. Then select a cycle and press the Jets pump 1 ( ) button to activate that cycle. Upon pressing the jets pump 1 button the system will save your selection, exit the program menu and return to the main menu.

### Note:

- Any time the circulation pump runs, e.g. when heating, outside of a programmed cycle (except for C0 and C6), that run time will reduce the length of the next cycle.
- After 10 seconds the programming screen will revert back to the temperature if no buttons are pressed. You cannot have more than one circulation pump cycle activated at a time.

	0 hours of circulation per day
EF	4 hours of circulation per day
53	8 hours of circulation per day (recommended factory default setting)
	12 hours of circulation per day
[4]	16 hours of circulation per day
65	20 hours of circulation per day
ЕЬ	24 hours of circulation per day


**Note:** The recommended factory default setting for the JLX Collection is 8 hours. This setting should not be altered. Running the circulation pump less than the factory recommended time might result in issues with water quality maintenance.



In extreme bitter cold weather we recommend you program the circulation pump to run 24 hours. Refer to the "Winterizing" section on page 41.

- 11.6 Programming the CLEARRAY® (Ultraviolet) Water Purification System
- A. Programming the CLEARRAY System (U) or Corona Discharge Ozone (O3)

Press and hold the **Jets pump 1** ( ) and **Cooler** ( ) button <u>at the</u> <u>same</u> time for 3 seconds. Scroll pass the circulation pump programming menus by pressing the Warmer button, Figure 1.



 After the last cycle, "C6", the LED screen will display "U" or "O3." If the LED screen is displaying "U" then pressing the Jets pump 1 will change the sanitizing system from "U" to "O3" and exit the programming menu. If the LED screen is displaying "O3" then pressing the Jets pump 1 will change the sanitizing system from "O3" to "U" and exit the programming menu. You will see one of the two configurations below:

A. C0, C1, C2, C3, C4, C5, C6, U, 365 (duration countdown timer)

B. C0, C1, C2, C3, C4, C5, C6, O3, =

**Note:** For the O3 option the "=" disables the duration countdown timer.

2. If you do not wish to change the option do not press any buttons and after 10 seconds the display will return to the main menu.


**Note:** If the CLEAR**RAY** System has been selected, when the time allotted has expired (365 days) the display screen will flash between the water temperature and "blb." At this time the UV bulb must be replaced, the quartz tube must be cleaned and the duration countdown timer needs to be reset.



# B. Resetting the duration countdown timer (CLEARRAY® System only)

Once the duration countdown timer for the CLEAR**RAY** System has reached zero, you will need to reset it, replace the UV bulb and clean the quartz tube.

To reset the duration countdown timer:



- 1. Press and hold the Jets pump 1 ( ) and Cooler ( ) button <u>at</u> the same time for 3 seconds.
- 2. Press the **Warmer** ((+) button until the display shows "0."
- 3. If the timer has reached "0", pressing the Jets pump 1 ( ) button will reset the counter. If the timer is not at "0" pressing the Jets pump 1 button will not reset it.

**Note:** If the spa power is interrupted, the duration countdown timer is not affected. The number of days remaining is stored in the memory and will continue to countdown once power is regained.

- 4. If the duration countdown timer is not at "0" and you need to reset it:
  - a. Press and hold the Jets pump 1 and Cooler buttons at the same time for 3 seconds.
  - b. Press the Warmer button to scroll to "U."
  - c. Press the Jets pump 1 button to switch from "U" to "O3."
  - d. Press and hold the Jets pump 1 and Cooler buttons at the same time for 3 seconds.
  - e. Press the Warmer button to scroll to "O3."
  - f. Press the Jets pump 1 button to switch from "O3" to "U." The timer has been reset to 365 days.

# 12.0 Spa Maintenance

Proper and regular maintenance of your spa will help it retain its beauty and performance. Your authorized Jacuzzi dealer can supply you with all the information, supplies, and accessory products you will need to accomplish this.



#### DANGER: RISK OF SEVERE INJURY OR DROWNING BY ENTRAPMENT!

- Keep hair, loose articles of clothing or hanging jewelry away from suction fittings, rotating jets or other moving components to avoid entrapment that could lead to drowning or severe injury.
- Never use the spa unless all suction guards, filter, filter lid, or skimmer assembly are installed to prevent body and/or hair entrapment.
- Never operate or use the spa if the filter, filter lid, or skimmer assembly are broken or any part of the skimmer assembly is missing. Please contact your dealer or nearest service center for service.
- The suction fittings and suction covers in this spa are sized to match the specific water flow created by the pump(s). If it is necessary to replace the suction fittings, suction covers or pump(s), be sure that the flow rates are compatible and are in compliance with the VGB Safety Act, page 2.
- Never replace a suction fitting or suction cover with one rated less than the flow rate marked on the original suction fitting. Using improper suction fittings or suction covers can create a body or hair suction entrapment hazard that may lead to drowning or severe injury.
- Owners must alert all spa users to the potential risk of Hair, Limb, Body, Evisceration (disembowelment), and Mechanical Entrapment, page 6.

# 12.1 Cleaning The Filters

Your Jacuzzi spa is equipped with a skimmer bag, filter skimmer and two high performance pleated filter cartridges located under the filter cover. Fine debris are filtered by the circulation pump drawing water through the skimmer bag, filter skimmer and filter cartridge 8 hours a day. Large debris are filtered by jets pump #1 drawing water through the skimmer bag, filter skimmer and second filter cartridge during an automated skimming/heating cycle or when jets pump 1 is manually activated during spa use. Combined, these filters provide unsurpassed water quality by trapping surface oils and suspended particles. The filter cartridge should be cleaned once a month or as necessary, depending on use, for optimum performance.


An optional chemical feeder is available through your authorized Jacuzzi dealer that installs under the filter cap (#2472-673). Always remove the chemical feeder cap and feeder (when used) during the filter cleaning process by turning the cap handle counterclockwise. Reinstall the cap and feeder back onto the filter cartridge after the filter cleaning process is complete. It is recommended that latex gloves be used to avoid touching the chemical feeder during the filter cleaning process.

**Note:** When used, the chemical feeder MUST remain on the circulation pump filter cartridge! This filter cartridge is the one with the grid across the wall fitting as shown (right).

#### TO DECREASE RISK OF DEATH, DROWNING OR ENTRAPMENT, ALWAYS TURN POWER TO SPA OFF BEFORE CLEANING THE FILTER CARTRIDGES!


**Note:** Refer to steps below and on the following page for complete filter cleaning/replacement instructions.

▲ DANGER: TURN POWER TO SPA OFF! TO DECREASE RISK OF DEATH, DROWNING, OR ENTRAPMENT, NEVER OPERATE SPA WHEN FILTER IS NOT PROPERLY INSTALLED A OR IF SKIMMER ASSEMBLY IS DAMAGED OR ALTERED!









Periodically, the filter cartridge will need a more thorough cleaning to remove imbedded oils and minerals. For this, we suggest cleaning as illustrated followed by soaking the filter overnight in a plastic container filled with a solution of water and specially formulated filter cleanser available from your authorized Jacuzzi dealer. The average life expectancy of each filter is approximately two years with proper care and water quality maintenance. Replacement cartridges may be purchased from your authorized Jacuzzi dealer.

# 12.2 Draining and Refilling

About every 3 months, you will want to replace the spa's water. The frequency depends on a number of variables including the amount of use, attention paid to water quality maintenance, etc. You will know it is time for a change when you cannot control sudsing and/or you can no longer get the normal feel or sparkle to the water even though the key water balance measurements are all within the proper parameters.

**CAUTION! READ THIS BEFORE DRAINING:** To prevent damage to the spa's components, **turn off power to the spa at the circuit breaker before draining it.** Do not turn the power back on until your spa has been refilled.


**CAUTION:** There are certain precautions to keep in mind when draining your spa. If it is extremely cold, and the spa is outdoors, freezing could occur in the lines or the equipment, see "WINTER-IZING" (page 41). On the other hand, if it is hot outdoors, do not leave the spa's surface exposed to direct sunlight.

# To drain your spa, perform the following steps:

- 1. Turn off power to spa at breaker.
- Locate the drain valve on the front/lower plastic pan. Hold the larger (rear) body to prevent it from turning, then loosen and remove the front cap to expose the underlying male hose threads.
- 3. Attach a garden hose to the exposed threads.
- 4. Gently rotate the larger (rear) valve body 1/3 turn counterclockwise to unlock the drain valve.
- 5. Pull the larger (rear) body outward to open drain.
- After the spa drains, perform steps 2-5 in reverse order to close the drain prior to refilling the spa.

After refilling, turn on power to the spa and follow the steps listed under "Spa Fill Up Procedure" (page 15). Always fill your spa through both filter wall fittings.

1. Turn off power to spa.




#### 12.3 Pillow Care

Remove and clean the headrest pillows as needed with soapy water using a cloth or soft-bristle brush. Always remove the



pillows when adding chemical shock treatment to the spa water. The pillows can be returned to the spa when the sanitizer reading is stable as recommended on the inside cover of the manual.



Wash pillow(s) in a mild detergent soap and warm water solution. Never machine wash your pillows or attempt to clean them with a non-approved vinyl cleaning agent!

To reinstall pillows: Simply align pillow over mounting stud receptacle, then gently push inward to snap in place.

#### 12.4 Cleaning The Spa Interior

To preserve the sheen of your spa's surface, it is crucial that you avoid using abrasive cleaners or cleaners which have adverse chemical effect on the surface. If you are not certain as to the suitability of a particular cleanser, consult your authorized Jacuzzi dealer. Regardless of the cleanser used, use extreme care to assure that no soap residue is left on the surface. This could cause severe sudsing when the spa is refilled.

#### 12.5 Maintaining the Cover

Using the Jacuzzi insulating spa cover anytime the spa is not in use will significantly reduce your operating costs, heat-up time and maintenance requirements. To prolong the life of the cover, handle it with care and clean it regularly. Below are the care instructions.

#### A. Standard Vinyl cover maintenance

To Clean and Condition the Vinyl Cover:

- 1. Use a garden hose to loosen debris and dirt.
- 2. Using a large sponge or a soft bristle brush, use diluted or mild soap and scrub the vinyl top. Rinse clean and do not allow soap to dry on cover. Do not use soap on the underside of the cover.
- Please check with your Jacuzzi Dealer for recommended cover care and conditioning products. Condition using non-petroleum based conditioners to keep the vinyl supple and threads/stitching from drying out. Do not use solvents, abrasive cleaners or strong detergents. Do not use products that contain silicone or alcohol.

- B. To clean and condition the ProEndure<sup>™</sup> cover:
- 1. Brush off dirt, leaves and any loose debris.
- 2. Thoroughly hose down the cover.
- Using a large sponge or a soft bristle brush, use diluted or mild soap (such as woolite or dreft, no detergents) and scrub the cover. Allow the solution to soak in.
- 4. Rinse clean and do not allow soap to dry on cover. Continue to rinse until all the soap solution is removed. Do not use soap on the underside of the cover. The fabric dries quickly allow it to air. Do not apply heat or machine dry.
- 5. Retreating the fabric, using 303 High Tech Fabric Guard<sup>™</sup>, after cleaning is highly recommended. Follow the instructions from the manufacturer.
- 6. Additional cleaning and care information may be found at www. sunbrella.com

**NOTE:** Do not use solvents, abrasive cleaners or strong detergents. Do not use products that contain silicone or alcohol.

#### C. Additional Care and Maintenance Instructions:

- 1. Debris can accumulate on the spa cover. Removal of snow or other debris will help to avoid breakage of the foam cores.
- 2. Be sure to lock the cover straps to secure the cover from unwanted or accidental entry.
- 3. Do not place heavy objects on the cover.
- 4. Do not walk, sit or stand on the cover.
- 5. Do not drag or use the flaps/skirt or the cover lock straps to remove the cover.
- 6. Use only recommended cover lift systems.
- 7. Use only chemicals and cleaners recommended by Jacuzzi.
- 8. Remember to keep spa covered when not in use. Maintaining proper water levels assures efficient operation and efficient electrical usage.
- 9. Do not expose your spa to the sun for extended periods of time as UV rays can damage the interior surface.
- 10. Use caution when removing cover. Before removing cover, assure all locks have been released to avoid lock breakage and or cover strap damage.

# 12.6 Maintaining The Synthetic Cabinet

Your new spa's synthetic cabinet requires little or no maintenance of any kind. To clean, simply wipe cabinet with a clean towel and mild soap solution.

#### 12.7 Top Rail Care And Maintenance

Parts should be cleaned with soap and water and a non-abrasive cleaning pad. More stubborn stains can be cleaned with a water based cleaning solution or cleaners specified for vinyl surfaces. Solvent based or aggressive degreasing cleaners should not be used.

Small scratches or nicks resulting in the lighter colored sub surface being exposed can be made less obvious by using common furniture repair markers. These are generally available in packs with several wood tones from which a close match can be selected to the color of the scratched part.

#### 12.8 Stainless Steel Corners

To prolong the life of the stainless steel, handle it with care and clean it regularly. Below are the care instructions.

- 1. A simply solution of warm water with a couple of drops of liquid soap makes an excellent cleaner.
- 2. Dampen a soft cloth (such as a microfiber cloth) into the cleaning solution.
- 3. Following the grain of the stainless steel, wipe and clean the steel.
- 4. Dry off the stainless steel using another clean, dry soft cloth.

**Note:** Never use abrasive cleaners, steel wool, scrubbing brushes, or scrubbing pads on the stainless steel. Should scratches occur, products are available at local home centers that can help fix them.

**CAUTION:** Never spray cabinet with a garden hose for any reason since this action may induce an electrical short in the spa's electrical equipment.

# 12.9 Winterizing

Your Jacuzzi spa is designed to automatically protect itself against freezing when operating properly. During periods of severe freezing temperatures, you should check periodically to be certain that the electrical supply to the spa has not been interrupted. In extreme, bitter cold weather less than 32°F (0°C), choose the F3 "Standard" filtration/ heating mode and program the circulation pump to run for 24 hours to prevent freezing (page 30).

If you do not intend to use your spa, or if there is a prolonged power outage during periods of severe freezing temperatures, <u>it is important</u> <u>that all water be removed from the spa and equipment to protect</u> <u>against damage from freezing.</u>

Expert winterization of your spa is highly recommended, contact your authorized Jacuzzi dealer. In emergency situations, damage can be **minimized** by taking the following steps:

#### CAUTION: TURN OFF POWER TO HOT TUB!

- 1. Turn off power to the spa.
- 2. Follow the directions on page 38 for draining the spa.
- 3. Turn the massage/diverter selector(s) into the middle combo position to allow the water in the plumbing lines to drain, page 29.
- 4. Turn the waterfall valve(s) to the open position to allow the water in the plumbing lines to drain, page 29.

- 5. Open all the air controls and leave them open until you resume use of the spa, page 29.
- 6. As the water level drops below the seats, use whatever means necessary to get the water out of the recessed seating areas and into the foot well, such as a wet/dry vacuum.
- When the water level ceases to drop, use whatever means available to remove any remaining water from the foot well, such as a wet/dry vacuum.
- Remove the synthetic cabinet panel under the control panel and locate the drain plugs on the front of the pump(s), (Figure A, page 14). Remove plugs to allow water to drain out of pumps and heater.

**Note:** Approximately one to two gallons will be released during this procedure. Use a wet/dry vacuum or other means to keep this from flooding the equipment compartment. Replace the drain plugs.

- Loosen the hose clamp on the circulation pump intake behind the control box (Figure A, page 14) and pull the hose off (twist hose back and forth while pulling outward). Tip hose down and allow to drain, then reinstall hose and clamp.
- 10. Loosen hose clamp at bottom of CLEARRAY® system and pull hose off of CLEARRAY fitting (twist the hose back and forth while pulling downward). Tip hose down and allow to drain. Then reinstall hose and clamp. Remove the cover of the CLEARRAY system to access the UV bulb and quartz tube. Remove and store the UV bulb in a safe location. Remove and dry off the quartz tube then reinstall it. Depending on the length of time, consider replacing the UV bulb when you resume use of your hot tub.
- 11. Reinstall synthetic cabinet side panel and cover spa so that no casual moisture can enter into it.

Consult your authorized Jacuzzi dealer if you have any questions regarding winter use or winterizing.

# 12.10 Restarting Your Spa in Cold Weather

If you want to start up your spa after it has sat empty for a time in freezing temperatures, be aware that the water remaining in certain sections of the piping may still be frozen. This situation will block water flow preventing the spa from operating properly and possibly damaging the equipment. We recommend you consult your authorized Jacuzzi dealer for guidance before attempting to restart your spa under these conditions.

# 13.0 Water Quality Maintenance

To decrease the risk of contracting a waterborne illness (e.g. an infection, bacteria or virus) and/or respiratory ailments, maintain water quality within specified limits. This will enhance your enjoyment and prolong the life of the hot tub's equipment. Doing so requires regular attention because the water chemistry involved is a balance of several factors. Procrastination in regard to water maintenance will result in poor and potentially unhealthful conditions for soaking and even damage to your hot tub investment. For specific guidance on maintaining water quality, consult your authorized Jacuzzi dealer who can recommend appropriate chemical products for sanitizing and maintaining your hot tub.

# WARNING: FAILURE TO MAINTAIN WATER QUALITY WILL:

- Increase risk of contracting a waterborne illness (e.g. an infection bacteria or virus) and/or respiratory ailments.
  - Damage the equipment, components and spa shell, which are not covered under the hot tub's warranty.

**CAUTION:** Never store hot tub chemicals inside the hot tub's equipment bay. The equipment bay may reach elevated temperatures, this is where high voltage electronic devices are located. This area is not intended for storage of any kind.

#### 13.1 pH Control

pH is a measure of relative acidity or alkalinity of water and is measured on a scale of 0 to 14. The midpoint of 7 is said to be neutral, above which is alkaline and below which is acidic. In spa water, it is very important to maintain a slightly alkaline condition of 7.4 to 7.6 pH. Problems become proportionately severe the further outside of this range the water gets. A low pH will be corrosive to metals in the spa equipment. A high pH will cause minerals to deposit on the interior surface (scaling). In addition, the ability of the sanitation agents to keep the spa clean is severely affected as the pH moves beyond the ideal range. That is why almost all spa water test kits contain a measure for pH as well as the sanitizer.

# 13.2 Sanitizing

To destroy bacteria and organic compounds in the spa water, a sanitizer must be used regularly. Chlorine and bromine are the two most popular sanitizers used to date. The "Proclear Mineral Spa Clarifier" designed especially for your hot tub is a beneficial product for water maintenance. Many other additives are available for your spa. Some are necessary to compensate for out-of-balance water; some aid in cosmetic water treatment and others simply alter the feel or smell of the water. Your authorized Jacuzzi dealer can advise you on the use of these additives. When adding spa shock (chlorine or non-chlorine) or pH balancing chemicals activate the jets pump(s) and leave the spa cover open for a minimum of 20 minutes. By doing this you will allow excessive chemical vapors to exit the spa, protecting pillows and plastic knobs from chemical attack.



#### WARNING: RISK OF PERSONAL INJURY, DROWNING **OR ENTRAPMENT!**

Never leave your hot tub unattended for any reason while the cover is open and accessible, especially to small children and animals!

CAUTION: RISK OF PERSONAL INJURY OR SPA DAMAGE! Never add chlorine tablets (trichlor) or acid to your hot tub for any reason! These chemicals may damage components within your hot tub, burn or irritate your skin, create a rash and void the manufacturer warranty for your spa.

# 13.3 CLEARRAY® (Ultraviolet) Water Purification System

CLEARRAY Water Purification System is exclusive technology utilizing natural ultraviolet technology to eliminate waterborne bacteria, viruses, and algae in portable spas. The ultraviolet light otherwise known as UV-C or germicidal light inactivates the microorganisms disrupting the DNA so that it cannot reproduce and is considered lifeless. CLEARRAY is plumbed inline with your filtration system. After the water is drawn from the pump, filter, and heater it is then directed though the CLEARRAY system. Water passes through an ultraviolet light energy that treats and disinfects the water. The water is then pumped back into the spa giving you crystal clear water instantly. The system has a ballast that is the power supply for the purification system; it has two LED indicator lights the green indicating incoming power flow and the red indicating the system is properly working. CLEARRAY is standard for all models.




**Note:** The CLEAR**RAY** System only runs when the circulation pump is running and shuts off when either jets pump is manually activated during spa use. The system will remain off for 5 minutes after both jets pumps time out or are manually turned off, then resume operations if the circulation pump is programmed to run.

After a year the bulb must be replaced. If the UV timer has been programmed correctly a message will appear on the LED display when the time allotted has expired. In order to clear the "blb" message a new UV bulb needs to be installed and the timer must be reset (Section 11.6, page 34).

#### 13.4 CLEARRAY® Bulb Replacement and Quartz Tube Maintenance

**Important:** It is **MANDATORY** that the UV bulb is replaced and the quartz tube be cleaned every 12 months to maintain optimum performance.





**DANGER:** TURN THE SPA BREAKER TO THE OFF POSITION!

WARNING: DRAIN THE SPA IF YOUR ARE REPLACING OR CLEANING THE QUARTZ TUBE!



WARNING: ALLOW BULB TO COOL DOWN PRIOR TO REMOVING FROM QUARTZ TUBE.

**DANGER:** NEVER LOOK AT THE LIT BULB. THIS CAN CAUSE SEVERE EYE DAMAGE OR BLINDNESS.

# UV BULB REPLACEMENT AND QUARTZ TUBE MAINTENANCE:

**Note:** Location of CLEAR**RAY** System and connection may vary by model.

1. Turn the breaker to the spa OFF. DRAIN YOUR SPA.

**Note:** If you are only replacing the UV bulb then the spa does not have to be drained. You will need to drain it if you are replacing or cleaning the quartz tube.




**DANGER:** NEVER REMOVE COVER WITHOUT FIRST TURNING OFF AT POWER SOURCE AND DRAINING YOUR SPA.


 Once the UV bulb has cooled off remove the CLEARRAY System enclosure cover (9) and gasket (8) by removing the four screws (10). This will expose the UV bulb and connections, Figure 2.



Figure 2



- 3. Disconnect UV bulb socket (7) from the power cord socket (11), Figure 3.
- 4. Slowly remove the UV bulb (3) out of the quartz tube, Figure 4.
- 5. Remove the quartz seal compression nut (5) by
- turning it **<u>counterclockwise</u>**, Figure 5. Use a pair of channel-lock pliers if needed, Figure 6. You will notice that there is a stainless steel compression washer (4) which slides over the quartz tube, save the washer (4) for later use, Figure 7.



- Now you are ready to clean or replace the quartz tube (2).
  For cleaning the quartz tube (2), follow steps 7 and 8 then proceed from step 9. For replacing quartz tube (2), skip steps 7 and 8 and proceed from step 9.
- 7. <u>Cleaning quartz tube:</u> Clean the quartz tube by wiping, until clear, using a paper towel or a dry cotton cloth. If needed, a household tub and shower lime removal product can be used.



**WARNING:** Do not use abrasive cleaners as they can scratch the quartz tube surface.

- 8. Rinse the quartz tube with clean water to completely remove any cleaning products that were used in step 7.
- 9. <u>Replacing quartz tube:</u> You will notice that the new quartz tube does not have a black cushion on the domed end as the old quartz tube does. This is normal as the cushion was provided with the original quartz tube to protect it from breakage during transportation. Place the new quartz tube (2) into the water chamber (1) with the domed end first making sure it is inserted and seated inside the quartz end holder. Only a small portion will be exposed when it is seated correctly.
- 10. Reinstall the compression washer (4) over the open end of the quartz tube (2).
- 11. Reinstall and hand tighten the quartz seal compression nut (5) by turning it **clockwise**.
- 12. Refill your spa.
- 13. <u>System Test 1:</u> Assure there is no water dripping from the seal compression nut (5). If water is visible, STOP and tighten the compression nut (5) using a pair of channel lock pliers to a maximum of 1/4 turn. If that does not fix the leak, then repeat quartz tube maintenance process from step 1 through step 12. Make sure there is no water leaking before proceeding to step 14.

- 14. <u>System Test 2:</u> Reconnect the CLEARRAY unit to the controller. Turn breaker back ON. Turn on the pump to circulate the water through the CLEARRAY System. Wait for 5 minutes and assure no water is dripping. If water is visible, STOP, fix the leak by repeating quartz tube maintenance process from step 1 through step 13. <u>Make</u> <u>sure there is no water visible. Turn the pump and breaker OFF</u> <u>BEFORE proceeding to step 15.</u>
- 15. Reconnect the UV bulb socket (7) to the power cord socket (11) make sure you use the latex glove provided when handling the UV bulb.




**WARNING:** DO NOT TOUCH THE NEW UV BULB WITH YOUR BARE HAND. Oil on your skin will cause hot spot on the UV bulb and shorten the life of your UV bulb. Use the provided latex glove to handle the UV bulb.

- 16. Slide the new UV bulb (3) back inside the quartz tube.
- 17. Reinstall the black bulb boot (6) back over the quartz seal compression nut (5).
- 18. Reinstall the enclosure cover (9) with gasket (8) and secure with the screws.
- 19. Properly dispose of the old UV bulb.



**WARNING:** This CLEAR**RAY** System includes a UV bulb, which contains mercury. Dispose of the bulb in accordance with disposal laws. See www.lamprecycle.org.

20. Once power is activated you can check the ballast (12), Figure 8, to see if the CLEAR**RAY** System is functioning. A solid green light indicates that the CLEAR**RAY** System is being provided power and should always be on. A solid red light indicates that UV bulb is activated.



# 14.0 Error Conditions/Error Messages

Your spa has a self-diagnostic control system. The system will automatically display the following if a problem is detected. Always insist on genuine Jacuzzi replacement parts.

# 14.1 Summer Logic

When the actual spa water temperature reaches 2°F (1°C) above the set temperature, the spa goes into "summer logic." The circulation pump will turn off automatically, if running, to avoid adding additional heat to the water, eventually creating an overheat condition. This setting is not user-programmable.

Note: Summer logic does not take effect until the spa water temperature reaches 95°F (35°C). This condition is more likely in excessively hot weather. Remember, the spa's ability to cool is directly affected by the ambient temperature. An excessively hot ambient temperature may prevent the spa from cooling down because it's fully insulated construction is designed to retain heat and minimize operating costs.

#### 14.2 Panel Displays COL

Cool Condition - Temperature has dropped 20°F (11°C) below the current set temperature. Jets pump 1 and the heater

have been activated to bring the temperature within 15°F (8°C) of the set temperature. No corrective action is required!

Note: This condition is common during first time fill ups or during refills since tap water is often very cold. "COL" will only appear when the spa is in Economy mode.

#### Panel Displays ICE 14.3

Freeze Protection - A potential freeze condition has been detected. No action is required. Jets Pump 1 and heater will

activate to circulate and warm water through the plumbing until spa is out of danger. See "Winterizing" (page 41).

**Note:** "ICE" will only appear when the spa is in Economy mode.

# 14.4 Panel Displays SN1

Open sensor (heater is disabled) or shorted sensor (spa is deactivated). The high-limit temperature sensor is not functioning. Contact your authorized Jacuzzi dealer or qualified service technician.

# 14.5 Panel Displays SN2

Open or shorted sensor (heater disabled). The temperature sensor is not functioning. Contact your authorized Jacuzzi dealer or gualified service technician.

686









# 14.6 Panel Flashes FL1 or FL2

A flashing "FL1" display means the flow switch is malfunctioning open, the filter cartridge is excessively dirty or an "air lock" condition has occurred at the circulation pump intake. A flashing "FL2" display means the flow

switch is malfunctioning closed. In either case, the spa heater will deactivate and jets pump #1 may also deactivate. To correct condition perform the following:

- 1. Turn power off to the spa.
- 2. Verify water level is above all jets but below lowest pillow. Add water if necessary.
- 3. Check for clogged or dirty filter cartridge (Sec. 12.1, page 35).
- 4. Purge "air lock" from circulation pump intake by removing filter cartridge. Hold your garden hose over the filter cartridge wall fitting while using a rag as a seal around hose end. Ask a helper to turn on water for 30 seconds, then turn off. Reinstall filter cartridge and check spa (Sec. 12.1, page 35).
- 5. If the circulation pump is not running, turn power off at the main breaker, then turn power back on.
- 6. If problem persists, contact your authorized Jacuzzi dealer.

# 14.7 Panel Displays OH

# MARNING: RISK OF HYPERTHERMIA (OVER-HEATING) CAUSING SEVERE INJURY, BURNS, OR WELTS.

Water temperature is above acceptable limits. **DO NOT ENTER SPA!** Water temperature has reached 112°F (44°C) and the low speed jets pump 1 and optional circulation pump (when equipped) has activated to circulate water through hea

(when equipped) has activated to circulate water through heater. Contact your authorized Jacuzzi dealer or qualified service technician.

# To correct condition:

- Remove the spa's cover and allow your spa to cool down.
- Program the filter settings for Economy Mode (page 30). Raise water temperature setting to cancel Summer Logic condition (page 48).
- If the condition persists, contact your authorized Jacuzzi dealer.

# 14.8 Panel Displays (- - -)

# MARNING: RISK OF HYPERTHERMIA (OVER-HEATING) CAUSING SEVERE INJURY, BURNS, OR WELTS.

Water temperature is above acceptable limits. **DO NOT ENTER SPA!** The safety "Watchdog" software has been triggered and the spa is deactivated. A problem has been

detected which could cause damage to the spa or its components.

Contact your authorized Jacuzzi dealer or qualified service technician.

0 H





# 14.9 Panel Displays BLB

UV bulb needs to be replaced. The message will flash between "blb" and the water temperature. The countdown timer for the UV bulb needs to be reset (Section 11.6, page 34). A new UV bulb can be purchased from a local Jacuzzi dealer.

# 15.0 Troubleshooting Procedures

In the event your Jacuzzi spa is not working the way it should, please first review all the installation and operating instructions in this manual and check for messages on the panel display. If you are still not satisfied it is working properly, please follow the appropriate troubleshooting instructions below.

**Note:** If any of the supply cords to accessories are damaged, they must be replaced by authorized service personnel. Contact your authorized Jacuzzi dealer or qualified service technician.

# 15.1 None of the Components Operate (e.g. Pump, Light)

Check the following:

- 1. Is there power to the spa?
- 2. Is the household circuit breaker tripped?
- 3. Contact your authorized Jacuzzi dealer or qualified service technician.

# 15.2 Pump Does Not Operate But Light Does

Press the JETS 1 button:

If no water movement is detected, make sure power is going to the spa and check the water level. If this does not solve the problem, contact your authorized Jacuzzi dealer or qualified service technician.

The main jets pump 1 operates but no water flows to jets. Check the following:

- 1. Jets may all be closed. Verify all jets are in the open "on" position (Sec. 10.5, page 28).
- 2. Pump may not be properly primed. This can happen after the spa is drained and refilled. Press the JETS 1 button on the control panel several times, never leaving the motor running for more than 5 to 10 seconds at a time. Turn power off and let the air out of spa plumbing system by removing the filter cartridge (Sec. 12.1, page 35). Make certain you reinstall the filter cartridge before turning on spa power and restarting the jets pump 1.

# 15.3 Poor Jet Action

- Make sure all jets are in the full open "on" position (page 28).
- Press the JETS 1 button to make certain pump #1 is on.
- Verify all air controls are in the "on" position by pressing down on their Jacuzzi Logo (page 29).
- Check for dirty filter. Clean, if necessary (Section 12.1, page 35).



#### 15.4 Water is Too Hot

Reduce thermostat setting.

#### 15.5 No Heat

- 1. Check thermostat setting.
- 2. Keep the spa cover in place while heating.
- 3. Check the settings to see if your spa is in economy filtration/heating mode (page 30).

Should checking the above steps fail to correct the problem, please call your Jacuzzi Hot Tub dealer so that they may arrange service. We build the best spas in the industry. Nonetheless, we are always striving to improve the quality and features of our products.


Your input as a Jacuzzi spa owner is a cherished part of this process. If you have any comments or suggestions, or if you wish to be informed on any new products for your spa, please write to us.

**CONGRATULATIONS** on your good taste and welcome to the happiest and most relaxed family in the world!

# 16.0 Circuit Board Diagrams


### 16.1 North American Dedicated Power Models (60 Hz)

This wiring diagram is used for all North American, 240V (60 Hz) dedicated power models.



#### 16.2 Export Models (50 Hz)


This wiring diagram is used for all Export 230 VAC 50 Hz spa models.





# *LX Collection* 17.0 Optional BLUEWAVE® Spa Stereo System

To start enjoying your new Stereo Receiver, please read the following operation instructions in their entirety.



# 1. Media Locker Handle

Slide the handle to lock and unlock the protective door.

#### 2. Power Button

Press power button once to turn "ON" stereo system. Press a second time to place the stereo in "Standby" mode and the red light will remain illuminated.

#### 3. Auxiliary Input Jack Connector

Allows you to connect an auxiliary device by using a 3.5 mm cable.

#### 4. Universal Serial Bus (USB) Device Connector

Allows you to connect your device via a USB port and a USB cable compatible with your device.

#### 5. Auxiliary Device Holding Base

The removable base securely holds the Auxiliary device, such as an iPod®/MP3/iPhone, in place. It can be removed for larger devices.

#### 6. 3.5 mm Cable (purchased separately)

Use this cable to connect your Auxiliary or MP3 device to the stereo via the "AUX" connection.

# 7. Apple 30-pin to USB Cable (purchased separately)

Use this cable to connect your compatible iPod, iPhone or MP3 device to the stereo via the "USB" connection.

#### WARNING: RISK OF ELECTRICAL SHOCK HAZARD EXISTS AND EQUIPMENT DAMAGE! Never install or remove electrical devices (e.g. Apple device/MP3/USB/Bluetooth) while hands are wet or while sitting partially or fully immersed in spa!

**CAUTION:** Never leave electrical devices in the Media Locker when spa is not is use to prevent damage from outdoor elements! Never spray Media Locker with a pressurized water hose for any reason! Damage to the device or spa stereo system caused by water intrusion is not covered under the manufacturer's warranty! Damage to Media Locker port or electrical devices due to excessive force or improper alignment during installation or removal from Media Locker is not covered under warranty.

# 17.1 Pairing the Remote and Stereo

In order for the remote to operate the stereo, you need to pair them using the following method:

- 1. Make sure the stereo unit is in "Standby" mode. LED power light will be red, Figure A.
- 2. Press any button on the <u>remote</u> to turn it ON. The remote LCD display will read "No Link."
- Press and hold the "Mode" button on the <u>remote</u> (Figure B). At the same time, press and hold the power button on the stereo for 2 seconds.
- 4. The remote LCD display will read "Welcome," "Load" and "Radio" if the pairing sequence was successful.

# 17.2 Audio Settings

The Audio button, Figure C, provides access to many of the stereo's settings. By continually pressing the Audio button you can scroll and adjust the following functions: BAS-TRE-BAL-FAD-DSP-AREA-LOUD-DX-STEREO (respectively).

**Note:** You can adjust the settings by pressing the Audio button, making your adjustments and pressing the Audio button to go the next feature. If you exit the setting menus continually press the Audio button until you reach the setting you would like to adjust.

 Bass Setting: Press the Audio button once to access the bass setting. The LCD display will change to "BAS 0," Figure D. Press the Up button to adjust the setting to a maximum of +5. Press the Down button to adjust the setting down to -5.


**Note:** The default setting is "0." This feature is disabled when a "Digital Sound Processor" (DSP) setting is active such as "Rock," "Classic," or "Pop."

Figure A



(@```@)







Treble Setting: Press the Audio button 2 times to access 2. the treble setting. The LCD display will change to "TRE 0," Figure E. Press the Up button to adjust the setting to a

maximum of +5. Press the Down button to adjust the setting down to -5. **Note:** The default setting is "0." This feature is disabled when a "Digital Sound Processor" (DSP) setting is active such as "Rock," "Classic," or "Pop."

- 3. Balance Setting: Press the Audio button 3 times to BRL L:R access the balance setting. The LCD display will change to "BAL L=R," Figure F. Press the Up button to adjust the setting to a maximum of 10R (only the right side speakers will have volume). Press the Down button to adjust the setting down to 10L (only the left side speakers will have volume).
- 4. Fade Setting: Press the Audio button 4 times to access FRD F=R the fade setting. The LCD display will change to "FAD Figure G F=R," Figure G. Press the Up button to adjust the setting to a maximum of 10F (only the front speakers will have volume). Press the Down button to adjust the setting down to 10R (only the rear speakers will have volume).
- 5. Digital Sound Processor (DSP) Setting: Press the Audio OSP OFF button 5 times to access the DSP setting. The LCD Figure H display will change to "DSP OFF," Figure H. Press the Up button to select one of the preset settings such as Rock. FM: <u>ю</u>ьт Classic or Pop. If a preset setting is select a small icon will appear on the LCD display, Figure I. Figure I
- Area Setting: Press the Audio button 6 times to access 6. ARER USA the Area setting. The LCD display will change to "AREA Figure J USA," Figure J. Press the Up button to select either USA or EUR setting.
- 7. Loud Setting: Press the Audio button 7 times to access LOUD OFF the Loud setting. The LCD display will change to "LOUD Figure K OFF," Figure K. Press the Up button to select either OFF or ON.
- 8. Distant Setting: Press the Audio button 8 times to ΠX access the Distant setting. The LCD display will change to Figure L "DX," Figure L. Press the Up button to select either Distant (DX) or Local for station frequency. The "LOCAL" setting allows for better FM reception when a local station is too strong. Leave the setting to "DX" if this condition does not exist.
- 9. Stereo Setting: Press the Audio button 9 times to access STERED the Stereo setting. The LCD display will change to Figure M "STEREO," Figure M. Press the Up button to select either Stereo or Mono.



TRE D Figure E

# 17.3 Wireless Remote Control Functions


A wireless radio frequency (RF) remote control is supplied on all spas with the optional audio system. This remote provides control of the radio and over some media device functions.

# A. External Media Device Playback

The supplied remote control provides no control over external Auxiliary player operation except for volume control and source selection. All external Auxiliary playback operations are performed solely by the Auxiliary player.

Button	Operation	
(1)	Power Button: Press once to turn remote "ON" (remote LCD display will read "No Link"); Press a second time to turn stereo "ON" (remote LCD display will read "Welcome") Press a third time to place the stereo in "Standby" mode.	
AUDIO	Audio Button: Allows access to most of the stereo sound functions. Press continuously to scroll through the following settings (if appli- cable): Bas-Tre-Bal-Fad-DSP-Area-Loud-DX-Stereo.	
MODE	Mode Button: Press continuously to switch between "RADIO," "USB," and "AUX IN" modes. "BT AUDIO" appears when a Bluetooth device in paired with the stereo.	
+	Volume Up Button: Used to increase volume between 0 to 30.	
$\bigcirc$	Volume Down Button: Used to decrease volume between 30 to 0.	

Button	Device Mode (USB port)	Radio Mode	
(HII)	Play/Pause Mode: Press to pause track, press again to resume playing	Mute Button: Press to mute sound, press again to reactivate sound	
K	Track Down Button: Press to rewind tracks	Seek Down Button: Seeks down for stations	
	Track Up Button: Press to move forward tracks	Seek Forward Button: Seeks forward for stations	
1 DIR -	Press the button to change music folders	Preset 1: Press to access a preset station	
2 REPEAT	Apple Device: Press once to repeat song. Press again to repeat entire album. Press again to turn off. USB Mode: Press once to turn on. Press again to turn off.	Preset 2: Press to access a preset station	
3 DIR +	Press the button to change music folders	Preset 3: Press to access a preset station	
RANDOM	Press to play songs in a random order	Not used	



# LX Collection 17.4 Electronic Device Connections and Functions

#### **IMPORTANT:**

- If stereo unit is "ON" (blue light is illuminated on the stereo power button) then press the power button on the remote once.
- If stereo unit is in "Standby" (red light is illuminated on the stereo power button) then press the power button on the remote once to activate the remote (remote LCD display will read "NO LINK"). Press the button again to activate the stereo unit (remote LCD display will read "WELCOME").

#### **Operating the Radio:** Α.

- FM Turn power "ON" to the stereo. Press the power button 1. on the remote. Figure A
- 2. The LCD screen on the remote will display the following: "Welcome," "Load," "Radio" and the station number, Figure A.
- 3. You can use the seek button to search for frequencies.
- You can save up to 3 stations as presets. Follow the steps below to 4 set a station:
  - a. Find a station you want to save.
  - Press and hold one of the three preset buttons. The station b. preset number (1, 2 or 3) on the display will quickly flash to confirm the setting. To set the additional two stations, conduct this step again.

#### B. Connecting Your Apple device/MP3 Player Using the USB:

- Locate the USB port in the stereo locker (Figure B). 1.
- 2. Use a 30-pin cable for compatible devices (Figure C) or a cable provided with your device.
- 3. Connect the USB end of the cable into the USB connection on stereo.
- Connect the 30-pin end of the cable to the Apple device/MP3 Player 4. (purchased separately), Figure D.
- 5. After connecting the cable to both devices, set the player into the rubber holding base, Figure E.

Note: This also charges most compatible Apple devices when connected.





Figure C

(purchased

separately)



1067

Figure D (device purchased separately)



58



#### CAUTION: RISK OF ELECTRICAL SHOCK OR EQUIP-MENT DAMAGE!

Apple device/MP3/USB/AUX/Bluetooth) while hands are wet or while sitting partially or fully immersed in spa!

**Note:** The DRM (Digital Rights Management) Files cannot be played on this deck. Personal files (MP3, WMA, iTunes or AAC) can be played as long as they are not DRM encrypted.

#### C. Operating USB/MP3/Apple device

- 1. Turn power "ON" to the stereo unit. Turn power "ON" to the remote.
- The LCD screen on the remote will display the following: "Welcome," "USB," "Load," "Apple" (final display will vary depending on the device connected). All functions are performed through the remote.
- 3. While the music is playing the remote screen will display and continually scroll through the following: Artist, Album, Song and Track information.
- 4. For operational functions refer to the "External Media Device Playback" section.

#### D. Operating the USB drive:

- 1. Plug in your USB device into the "USB" connection on the stereo, Figure A.
- 2. Turn power "ON" to the stereo unit and the stereo remote.
- The LCD screen on the remote will display the following: "Welcome," "USB," "Load," "TOL XX" (final display will vary depending on the whether the USB holds folders or files). All functions are performed through the remote.
- 4. While the music is playing the remote screen will display and continually scroll through the following: Title, Song, Artist, Album, Dir, Music and Track information.
- 5. For operational functions refer to the "External Media Device Playback" section.

#### E. Connecting Your Auxiliary Player Using the 3.5 mm Cable:

- 1. Plug one end of the cable to "Aux" connection on the stereo, Figure F.
- 2. Plug the other end of the cable into the head phone jack connection on the Apple device/MP3 Player.
- 3. Press the Mode button on the remote to "AUX IN."
- All playback operations are conducted via the Auxiliary Player. The stereo remote functions do not work on the external Auxiliary Player (except volume control).




Figure F

- F. Connecting Your Bluetooth Device:
- 1. Turn power "ON" to the stereo unit.
- 2. From your Bluetooth device, make sure the Bluetooth setting is "ON."
- 3. Follow the pairing instructions for your Bluetooth device and connect to the "BLUEWAVE" device that appears on your screen.
- 4. If asked for a password, enter the code "0000."
- 5. The remote LCD screen will display, "BT AUDIO" if the process was successful.
- G. Operating Your Bluetooth Device:
- 1. Press the seek up or down buttons to scroll through the tracks (on the remote).
- 2. Press the volume up or down buttons to adjust volume level between 0 to 30 (on the remote).
- 3. Any other playback operations are conducted via the Bluetooth device.

# <u>I</u>


#### CAUTION: RISK OF ELECTRICAL SHOCK OR EQUIP-MENT DAMAGE!

Never install, remove or operate any electrical device (e.g. Apple device/MP3/USB/AUX/Bluetooth) while hands are wet or while sitting partially or fully immersed in spa!

# 17.5 Wireless Remote Battery Replacement Procedure

 Turn the remote unit over and locate the battery door (Figure A).

Battery Door



- iy. A
- Rotate the battery door, with a coin, counterclockwise to the Open position (Figure B). When the door is unlocked it will pop up slightly.
- 3. Remove battery door by lifting the door upward (Figure C).





- 4. Replace battery using an equivalent battery (Figure D).
- 5. Reinstall the battery cover, using the coin rotate the door to the Close position (Figure E).

**Note:** Remote unit is water resistant not waterproof. Although Fig. E it is designed to be used while in the spa, it should never be left in the spa while the cover is on and spa is not in use. The remote should be stored in a dry location such as the stereo remote pouch (if applicable) located on the outside of the spa cover or within your home. Extreme weather can affect the remote control battery. In extreme hot or cold environments store the remote control indoors to prolong battery life.

# 17.6 BLUEWAVE® Spa Stereo System Specifications

Power supply	10.7-14.4V DC
Tuner	
FM radio sensitivity.	8uV
FM radio reception	Stereo

# 17.7 Stereo Cautions

- 1. **CAUTION** Risk of Electric Shock. Do not leave compartment door open."
- 2. (h) "CAUTION Risk of Electric Shock. Replace components only with identical components."
- 3. "Do not operate the audio/video controls while inside in the spa."
- WARNING Risk of Electrocution. Do not connect any auxiliary components (for example cables, additional speakers, headphones, additional audio/video components, etc.) to the system."
- These units are not provided with an outdoor antennae; when provided, it should be installed in accordance with Article 810 of the National Electrical Code, ANSI/NFPA 70.
- 6. Do not service this product yourself as opening or removing covers may expose you to dangerous voltage or other risk of injury. Refer all servicing to qualified service personnel.







- 7. When the power supply connections or power supply cord(s) are damaged; if water is entering the audio/video compartment or any electrical equipment compartment area; if the protective shields or barriers are showing signs of deterioration; or if there are signs of other potential damage to the unit, turn off the unit and refer servicing to a qualified service personnel.
- This unit should be subjected to periodic routine maintenance (for example, once every 3 months) to make sure that the unit is operating properly.