


# Baridi 18 Bottle Wine Cooler, Fridge, Touch Screen, LED, Low Energy A, Stainless Steel/Black



Model No. DH29

Thank you for purchasing a Baridi product from the Dellonda range. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

# **Important Information**

Please read these instructions carefully and note any safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.







Refer to instructions


Indoor use only

Warning: Flammable material

### ELECTRICAL SAFETY

- WARNING! It is the user's responsibility to check the following:
- Check all electrical equipment and appliances
  to ensure that they are safe before using.
  Inspect power supply leads, plugs and
  all electrical connections for wear and
  damage. Dellonda recommend that an RCD
  (Residual Current Device) is used with all
  electrical products. You may obtain an RCD
  by contacting your local domestic stockist.
  If the product is used in the course of
  business duties, it must be maintained in a
  safe condition and routinely PAT (Portable
  Appliance Test) tested.
- Electrical safety information: It is important that the following information is read and understood.
- Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that they are secure.
- Important: Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating in these instructions.
- DO NOT pull or carry the appliance by the power cable.
- DO NOT pull the plug from the socket by the cable.
- DO NOT use worn or damaged cables, plugs or connectors.
- Ensure that any faulty item is repaired or replaced immediately by a qualified electrician.
- This product is fitted with a BS1363/A 13 Amp 3 pin plug. If the cable or plug is damaged

- during use, switch off the electricity supply and remove from use. Ensure that repairs are carried out by a qualified electrician.
- Replace a damaged plug with a BS1363/A 13 amp 3 pin plug. If in doubt contact a qualified electrician.



- A) Connect the GREEN/YELLOW earth wire to the earth terminal 'E'.
- B) Connect the BROWN live wire to the live terminal 'L'.
- C) Connect the BLUE neutral wire to the neutral terminal 'N'.
- Ensure that the cable outer sheath extends inside the cable restraint and that the restraint is tight.
- Dellonda recommend that repairs are carried out by a qualified electrician.

### GENERAL SAFETY

- DO NOT store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- WARNING: Ensure the supply cord is not trapped or damaged.
- WARNING: DO NOT locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

- This appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; holiday homes, hotels and other residential settings; and catering and similar non-retail applications.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of knowledge and experience if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

### INTRODUCTION

 Sleek and compact design with tempered mirror glass door to reflect UV light and help protect your wine. Also features stylish wooden shelves made of beech with space for up to 18 bottles of wine. Temperature range between 5-18°C controlled by touch screen controls. (Recommended ambient temperature up to 25°C). Features soft white LED light. Accommodates a maximum bottle height of 330mm. Compressor cooling technology with automatic defrost feature to make this unit as easy as possible to use. Energy Efficiency Class A.

### SPECIFICATION

- · Model no: DH29
- · Capacity: 18 bottles
- · Volume: 50L
- · Max. bottle height: 330mm
- Temperature range: 5-18°C
- · Rated current: 0.6A
- Voltage: 220-240V
- · Frequency: 50Hz
- · Energy efficiency class: A
- · Noise level: 42dB
- Dimensions (W x D x H): 345 x 450 x 770mm

### INSTALLATION

- The unit is designed to be free-standing.
   Ventilation Space a minimum space of 50mm is required for the rear of the fridge and 30mm for the top and both sides. This will maximise the efficiency, performance and life of the fridge and also ensure that there is sufficient space for the hinge to operate effectively.
- · Locate the unit away from direct sunlight or

- sources of heat i.e. radiator, stove etc. Extreme or cold ambient temperatures may also prevent the unit working effectively.
- DO NOT locate the unit in a damp or moist location.
- Ensure that the floor surface is strong and stable enough to support the unit when it is fully loaded.
- Level the unit when in location by using the adjustable levelling feet in each corner.
- Once in position allow the unit to rest for an hour before turning it on.
- Allow the unit 2-3 hours to reach set temperature after switching on before placing any items in the compartment.

### OPERATION



- To turn the unit on, press the 🚳 symbol.
- The unit's control panel will automatically lock out after 20 seconds of non-use.
- To unlock the control panel hold the symbol for approximately 2 seconds when an audible noise will be emitted to signify an active state.
- To turn on internal light press \*/\* symbol.
  The light will turn off after 10 minutes.
- To change the temperature units displayed, press and hold the approximately 2 seconds.
- To set the required operating temperature use the symbol to increase it, and the symbol to decrease it. Each press will cause a 1° change in the set value.

### MAINTENANCE

- Remove the power plug from the supply when performing cleaning or maintenance.
- DO NOT use abrasive or chemical cleaning materials on any surface of the unit.
- Wipe interior and exterior surfaces with a damp cloth and dry thoroughly with a clean dry cloth.
- For more soiled surfaces use a neutral detergent, wipe down with a clean damp cloth and dry thoroughly with a clean dry cloth.

## **Troubleshooting**

Symptom	Solution
Unit does not operate.	Not plugged in. Fuse/circuit breaker failure.
Turns on and off frequently. Poor cooling.	Room temperature higher than normal. Door opened too often. Door not properly closed. Temperature control incorrectly set. Door gasket not sealing. Not enough space around unit.
Vibrations	Check to assure unit is level.
Noisy unit	Contraction/expansion of panels. Unit not level. Check fan operation. Check heat pump.
Door will not close properly	Unit not level. Gasket distorted. Internals out of position.



# **Environment Protection, Waste Electrical and Waste Electronic Equipment Regulations (WEEE)**



Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of its useful life, please dispose of in an environmentally friendly way. Drain any fluids (if applicable) into approved containers, in accordance with local waste regulations. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. No liability is accepted for incorrect use of this product. Guarantee is 12 months from purchase date, proof of which is required for any claim.

# Dellonda Limited, Sole UK Distributor of Baridi

Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



