

4-In-1 CM20 USB Microphone Set
Instruction Manual


Document Information

© 2021 Shenzhen Neever Technology Co., Ltd. All Rights Reserved.
This document is the sole property of Shenzhen Neever Technology Co., Ltd. and shall not be reproduced, transmitted, transcribed, stored in a retrieval system or translated in any form, by any means, without prior written permission from Shenzhen Neever Technology Co., Ltd. Shenzhen Neever Technology Co., Ltd. reserves the right to change content in this instruction manual at any time and without prior notice.


Version Control

Date	Version number	Description	Issued by
22/02/2022	1.0	CM20 USB Microphone 4 in 1 set Instruction Manual	NEEWER




Package contents





System requirements



Installation




Instructions




Windows 10 system settings

1. Input settings
After the microphone is connected to the data cable, the user does not need to install any drivers to connect to the USB port of your computer. After the microphone has successfully connected, the microphone indicator will light up in blue.

1.1 Right-click the speaker icon in the lower right corner of your computer taskbar and click "Open Sound settings."




1.2 Click on Sound control panel



1.3 Select the "Recording" tab and select "NEEWER CM20 MIC" as the default device. When using the microphone to speak, the microphone's volume indicator will turn green and move in sync with your voice. If the indicator is gray, restart the computer and reinsert the device into the USB port.

2. Microphone input volume settings


2.1 On the front of the microphone (see User Guide 6 for details), gradually adjust the gain knob. Adjust the input volume. Double-click "NEEWER CM20 MIC" to enter the microphone properties and select the "Level" tab. Right-click the small speaker icon, select "decibels" and drag the slider to adjust the input volume.



3. Computer output microphone sound

3.1 In the "Playback" tab, select the device that needs to play the sound, such as "Realtek High Definition Audio", right-click, and set this device as the default device for the computer to play back the output sound.

3.2 In the "Recording" tab, double-click the microphone "NEEWER CM20 MIC" → enter the microphone properties tab → click "Listen" → choose "Listen to this device" → "Apply". This configuration will allow you to hear the sound via the computer's audio interface. (Note: When using any recording software or chat software, please do not choose "Listen to this device.")




Notes for Mac and Windows:


- If the computer prompts that the USB device is not recognized, please restart the computer and connect the microphone to another USB port.
- After the microphone is recognized but there is no sound, please check whether the system sound is muted and whether the microphone volume control is turned on.
- If the microphone is recognized but there is no sound (applicable to Windows 10 OS), please go to Start → Settings → Privacy → Microphone, and click to allow apps to access your microphone, and then reconnect the microphone.

Mac computer settings


- Connect the provided USB cable to the computer's USB port.
- After a successful connection, the microphone indicator will light up in blue.
- Select NEEWER CM20 MIC as audio input. Open System Preferences.




4. Click "System Preferences" and select "Sound" to open the properties tab.




5. Click the "Input" tab and select NEEWER CM20 MIC as the sound input device. Drag the volume slider below to adjust the input volume of the microphone.



6. In the "Output" tab, change the output device to the internal speakers or enable you to hear the sound through the computer.



7. When the speakers are set as the default device, it is not possible to monitor the microphone in real time. If you want to monitor your own voice, it is recommended to make use of a recording software (such as Audacity or QuickTime) and select the monitoring function of the software.



Notes for Mac:

1. When using a Mac computer, if you do not use a microphone to monitor the sound, but amplify the sound through a computer or a speaker, you must use the monitoring function of the recording software. Common recording software include Audacity and QuickTime. Adjust the software device, choose to monitor audio while recording, and then click the record button. By speaking or singing into the microphone, the sound will be replicated through your computer speakers.

2. When using dictation on a Macbook, select the default dialogue and voice software, and click "Open" under the dialogue window, so that the software can recognize the microphone.

3. If your Mac computer only has a USB-C port, an original Apple USB-C to USB female adapter is required to connect. Connect the USB adapter to the Mac first and then connect the microphone data cable.



Solutions to common microphone sound problems

- The microphone volume is too loud**
 - There is a harsh whistling sound, explosive sound, buzzing sound or electrical current sound. This issue can usually be resolved by turning down the volume of the microphone. There are two ways to adjust the gain: a. Use the volume button of the microphone to turn it down; b. For a microphone without a volume button, set the levels of the computer's microphone properties to turn it down.
 - If there is an echo and the sound feels empty, we recommend that you try turning down the volume, check whether the computer's "listen to this device" function is turned off, and check whether the sound source is facing the front of the microphone.
- The volume of the microphone fluctuates up and down**
 - This is caused by the built-in software function which automatically adjusts the volume of the microphone. This can result in problems such as intermittent, unstable, or distorted sound and automatic volume fluctuations.
 - For software with this function, such as QQ, Tencent Meeting, DingTalk, etc., you need to cancel the function in the settings, launch the software, and restart the microphone.
 - Some specific website scripts with automatic gain function cause abnormal sound. This isn't a problem with the microphone and, in this instance, there is no troubleshooting solution.
 - The voice system of some games uses the voice activation threshold to activate the microphone in the free speech state. When the microphone cannot be used in the game, please lower the threshold or use the default value to return to normal. For example, if the voice activation threshold of "League of Legends" is higher than 65%, there will be intermittent chats or silence, and it will return to normal after lowering the percentage or using the default value.


3. There is no sound from the microphone

3.1 Check whether the NEEWER microphone on the computer is set as the default device and check whether the NEEWER microphone on the software is set as the default recording device.
3.2 If all settings of the microphone seem to be correct, check whether the microphone privacy in the computer Windows 10 system is turned on and check whether the "Allow desktop apps to access your microphone" option is turned on. Check the operating indicator of the microphone. The blue light indicates the mic is in operational and the red light indicates that it is on mute.
3.3 Setting up the microphone in the wrong order will also cause the software to have no sound, especially when it comes to Mac systems. The correct steps to set up the mic: Connect the microphone first and then open the software. If this order isn't followed, please exit the software completely and connect the microphone before opening the software.
4. If you have any questions
Please contact us via <https://neewer.com/>

Specifications

Model	CM20
Functions	Recording, live-streaming, gaming microphone
Microphone Component	14mm condenser mic
Frequency Response	30Hz-18kHz
Sampling Rate	44.1kHz-48kHz
Bit Rate	16-bit
Polar Pattern	Cardioid
Sensitivity	17.5mV/Pa (at 1kHz)
Sound Pressure Level	125dB (at 1kHz THD<1%)
Distortion	<0.5% (1kHz)
Power Supply	DC USB 5V



包装清单




系统要求




安装说明




使用说明



USB-A/USB-C/OTG 指示





1.2 单击声音控制面板



2. 麦克风输入音量设置

2.1 在麦克风端 (详见使用指南), 逐步调整增益旋钮, 调节输入音量。双击 "NEEWER CM20 MIC" 进入麦克风属性, 选择 "级别" 选项, 右键弹出菜单选项下的小喇叭图标, 选择分贝, 拖动音量条以调整输入音量。




注意事项: 适用于MAC和Windows
1. 如果计算机提示无法识别USB设备, 请重新启动计算机并将麦克风连接到其他USB接口。
2. 如果识别麦克风但没有声音, 请检查系统声音是否静音, 是否打开麦克风音量控制。
3. 如果识别麦克风但没有声音, 计算机系统为Windows10, 请进入设置-隐私-麦克风, 并单击允许应用程序访问麦克风, 然后重新连接麦克风。

MAC电脑设置

- 将所提供的USB线连接计算机USB接口。
- 连接成功后, 指示灯亮蓝色。
- 选择NEEWER CM20 MIC作为音频输入, 打开系统偏好设置。
- 单击"系统偏好设置", 选择"声音", 打开属性页面。




5. 单击 "输入" 选项, 选择NEEWER CM20 MIC 作为声音输入设备, 可以拖动下方音量调节麦克风的输入音量。



7. 默认设置扬声器情况下, 无法实现实时监听麦克风; 如需监听自己的声音, 可以启动一个录音软件 (如 Audacity 或 QuickTime) 并选择软件的监听功能。



3. 如果Mac只有USB-C接口, 需要一个原装苹果USB C到USB母头适配器连接, 先将USB转接头连接Mac, 然后连接麦克风数据线。



3.1 在 "声音" 菜单中, 选择需要播放声音的设备, 如选择 "Realtek High Definition Audio", 右键弹出菜单选择此设备为默认设备, 电脑为外放声音。



1. 使用苹果电脑时, 如果不是用麦克风监听声音, 而是通过电脑或者音箱来听音, 必须借助监听软件的功能才能听音。常用录音软件有 Audacity 或 QuickTime, 调整软件设备, 选择录制监听音轨, 然后点击音轨, 便可实现一边说, 一边可从电脑音轨听到声音。
2. Macbook中使用语音转文字时, 选择默认的对话和语音软件, 点击对话框下的 "打开", 以便软件可识别麦克风。

1. 出现刺耳啸叫声, 声音或者嗡嗡声, 电流声, 一般通过调小麦克风音量可解决, 有两种方式可以调节增益: a. 通过麦克风自身音量键调小; b. 不带音量的麦克风通过设置电脑麦克风属性降低音量, 将耳罩。
1.2 出现静音情况, 声音感觉空响, 可以尝试调小音量, 检查电脑扬声器是否关闭, 检查扬声器是否对准麦克风的正面。
2. 麦克风音量忽大忽小:
2.1 这是某些软件自带的自动调节麦克风音量的功能引起, 导致声音断断续续, 不稳定, 失真, 音量参数自动跳动等异常情况。
2.2 带有此功能的软件, 常见有QQ, 腾讯会议, 钉钉等, 这些软件需要在设置上关闭该功能, 退出软件, 重启麦克风即可。
2.3 某些网站的脚本带有自动增益功能导致声音异常, 此问题非麦克风方面的问题, 关闭网页。
2.4 某些网站的脚本在自由发言状态下以语音激活功能来监听麦克风的, 麦克风在游戏无法使用或静音或者使用语音激活功能无法正常, 比如英雄联盟的语音激活功能, 高于65%会出现断断续续的通话情况或者无声, 降低或者使用默认值恢复正常即可。
3. 如果Mac只有USB-C接口, 需要一个原装苹果USB C到USB母头适配器连接, 先将USB转接头连接Mac, 然后连接麦克风数据线。

6. 在 "输出" 选项, 将输出设备更改为内置扬声器, 可以听到电脑外放的声音。



麦克风声音异常常见情况及解决方案
1. 麦克风音量过大:
1.1 出现刺耳啸叫声, 声音或者嗡嗡声, 电流声, 一般通过调小麦克风音量可解决, 有两种方式可以调节增益: a. 通过麦克风自身音量键调小; b. 不带音量的麦克风通过设置电脑麦克风属性降低音量, 将耳罩。
1.2 出现静音情况, 声音感觉空响, 可以尝试调小音量, 检查电脑扬声器是否关闭, 检查扬声器是否对准麦克风的正面。
2. 麦克风音量忽大忽小:
2.1 这是某些软件自带的自动调节麦克风音量的功能引起, 导致声音断断续续, 不稳定, 失真, 音量参数自动跳动等异常情况。
2.2 带有此功能的软件, 常见有QQ, 腾讯会议, 钉钉等, 这些软件需要在设置上关闭该功能, 退出软件, 重启麦克风即可。
2.3 某些网站的脚本带有自动增益功能导致声音异常, 此问题非麦克风方面的问题, 关闭网页。
2.4 某些网站的脚本在自由发言状态下以语音激活功能来监听麦克风的, 麦克风在游戏无法使用或静音或者使用语音激活功能无法正常, 比如英雄联盟的语音激活功能, 高于65%会出现断断续续的通话情况或者无声, 降低或者使用默认值恢复正常即可。
3. 如果Mac只有USB-C接口, 需要一个原装苹果USB C到USB母头适配器连接, 先将USB转接头连接Mac, 然后连接麦克风数据线。

3. 检查电脑上NEEWER麦克风是否为默认设备, 检查电脑上NEEWER麦克风是否作为默认设备。
3.2 麦克风所有参数都正确的情况下, 检查电脑Windows系统的麦克风隐私是否打开并开启, 检查系统 "允许桌面应用使用麦克风" 选项是否打开并开启, 查看麦克风的工作指示灯, 蓝灯是工作状态, 红灯是静音状态。
3.3 麦克风使用频率不对也会导致软件无声音, 尤其在Mac系统比较常见, 正确顺序: 先连接麦克风, 再打开软件, 若顺序不正确, 需完全退出软件后重新按照正确顺序操作。

4. 如果有任何问题

请联系我们 <https://neewer.com/>

产品参数

型号	CM20
类型	桌面直播麦克风
喇叭	14mm电容拾音头
频率响应	30Hz-18kHz
采样率	44.1kHz-48kHz
比特率	16bit
指向模式	心型
灵敏度	17.5mV/Pa (at 1kHz)
声压级	125dB (at 1kHz THD<1%)
失真	<0.5% (1kHz)
供电方式	USB/Type-C 数据线外接供电

UK [REP]
Lingfeng Electronic (UK) Ltd
International House, 10 Churchill Way, Cardiff, CF10 2HE,
United Kingdom
EU [REP]
NW Formations GmbH (for authorities only)
Hofenstrasse 9B, 71636 Ludwigsburg, Germany
Shenzhen Neever Technology Co., Ltd.
Room 1903, Block A, Lu Shan Building No. 3023
Chunfeng Rd Luo Hu District, Shenzhen
Guangdong 518001, China