



How to Repair an AccuValve Actuator Using Kit #12686

Written By: Curtis Boettjer






 **TOOLS:**

- Ratcheting Snap Ring Pliers (1)
- Snap Ring Pliers (1)
- Vise (1)
- 5/64" Allen Wrench (1)

 **PARTS:**

- O-Ring, 70 Duro #11679-230 (1)
- O-Ring, 70 Duro (-010) #11679-010 (1)
- O-Ring, 70 Duro #11679-011 (1)
- O-Ring, 70 Duro #11679-016 (1)
- Poly Seal, 125-2.5-SQB #12737 (1)
- Fitting, 1/8" NPT x 1/4" Tube #12736 (1)
- Exhaust Muffler, 1/8" #12735 (1)
- Spring, AccuValve #1269 (6)
- Snap Ring #12689 (1)
- Snap Ring #12690 (1)
- O-ring Lube #13969 (1)

Step 1 — Disassemble Actuator




- Remove the air fitting from the top of the actuator
- Using a 5/64" Allen Wrench, remove the retainer cap from the bottom of the actuator.
- Place the actuator in a bench vise. Tighten the vise enough to slightly compress the actuator springs.

⚠ Caution: the actuator assembly contains high-force springs under compression.


- Using the ratcheting snap ring pliers, compress and remove the snap ring that secures the actuator cap into the housing.
- Carefully take the actuator out of the vise. All of the internal actuator components can now be removed.

Step 2 — Reassemble Internal Components



- i** After cleaning and inspecting, replace *at least* the exhaust vent, two O-rings on the actuator shaft, poly seal, and all six springs.
- Inspect and lubricate all O-rings.
 - Install new O-rings on both ends of the shaft. Note the O-ring sizes and locations.
 - Install the Poly Seal on the actuator piston with the "thick" part of the seal facing "down" (pointing away from the springs).
 - Install the O-ring on the bearing cap.

Step 3 — Reassemble Actuator



Valve in vise

- After all the internal components have been re-installed, place the retainer cap with the tabs in the slots on the housing.
 - Twist the actuator cap until the four screw holes line up with the holes in the retainer.
 - Place the actuator in a bench vise. Tighten the vise enough to slightly compress the actuator springs.
- ⚠ Caution:** the actuator assembly contains high-force springs under compression.
- Using the ratcheting snap ring pliers, compress and replace the snap ring that secures the actuator cap into the housing.
 - Remove the actuator from the vise. Use a 5/64 Allen wrench to tighten the four screws that hold the retainer to the actuator cap.