# BIGTIMECLOCKS® **EH-**I®

1-702 726-9030info@bigtimeclocks.bizwww.bigtimeclocks.biz

## MODEL # XL-44R 2020 USER'S MANUAL

#### 1. GENERAL

- Use remote control keys to select function.(Clock mode, alarm setting, rotating display mode, temperature setting).
- PRESS CLOCK in any display to show time.
- PRESS Display to show date, time and temperature in a rotating sequence.
- Press MUTE to turn the remote control key tone "on" or "off". If there is a beep, sound is turned on. If there is no sound, sound is muted.

### 2. DATE & TIME

- PRESS in clock display mode to set year, press once more to set the date and once more to set the time
- PRESS ▼ once more to exit and save your settings.

#### 4. ALARM / TIME BREAKS

- PRESS \_\_\_\_\_ to set alarms. The first two digits will flash. You can set up to 16 alarms.
- PRESS, the start/stop button to activate or turn off an alarm (if "off" the display will show "- -")
- PRESS again to enter the alarm time setting. PRESS to switch from hours to minutes and once more to save data.
- PRESS Start/Stop to select the alarm buzzing duration: 15s,30s or 60s. The alarm will then self-shut.
- PRESS once more to exit and save your settings.

#### 5. ROTATING DISPLAY

• PRESS Start/Stop: to select a rotating display mode (time, date, temperature) or a fixed time display mode.

### 6. TEMPERATURE

PRESS **F/C** to change from Fahrenheit to Celsius temperature values.

### 7. 12/24hrs DISPLAY

PRESS AM/PM-12/24 to change the time display from 24hrs to 12hrs (am / pm) and vice versa. In 12-hour mode an AM/PM LED indicator will turn on (this light is off in 24 hour mode).

### 8. KEYPAD

- Use the numerical keypad when setting all values.;
- Press the "0" key in time display mode to turn on an hourly alarm. A light indicator will turn on when the function is activated. The hourly alarm is automatically set between 7:00am and 9:00pm only.

### 9. BRIGHTNESS

• Press **Brightness** key to choose one of six brightness levels

### 10. REMOTE

