

IGNITOR[®]

ELECTRONIC IGNITION

12-Volt Negative Ground Instructions

For Part Number: LU-146 & LU-146M

Before installing, please read the following important information....

1. The Ignitor is designed for 12-volt negative ground systems.
2. The Ignitor is compatible only with a "resisted style" coil. Eight cylinder engines require a minimum of 1.5 ohms of resistance. Six & four cylinder engines require a minimum of 3.0 ohms of resistance.
3. If your Ignition coil has the proper primary resistance, remove or bypass all external resistors. Do not remove resistors if the coil primary resistance is lower than specified.
4. Connect the Ignitor black wire to the negative (-) side of the coil.
5. The red wire from the Ignitor should be connected to the positive (+) side of the coil, or a 12-volt switching power source, if a resistor is used.

PRIOR TO INSTALLATION TURN IGNITION SWITCH OFF OR DISCONNECT THE BATTERY

1. Remove distributor cap and rotor. Do not disconnect spark plug wires from cap. Examine cap and rotor for wear or damage. Replace as needed.
2. Disconnect the point wire from the negative (-) side of the coil.
3. Remove breaker plate screws and lift out entire breaker plate assembly.
4. The Ignitor does not require any modification to distributor. Therefore the points, condenser, and hardware can be used as backup.
5. Clean all oil and dirt from inside of distributor housing.
6. Install Ignitor onto distributor and secure with original screws. **See Figure 4.**
7. Push the wire grommet into the distributor housing.
8. Install magnet sleeve over distributor shaft, onto the point cam, rotate sleeve until a slight locating position is felt before applying pressure. With sleeve lined up on cam or reluctor, press down firmly insuring sleeve is fully seated.
9. Some magnet sleeves may have green tape, **DO NOT REMOVE IT.**
10. The wire length inside the distributor can be adjusted through grommet to insure ample clearance. Make sure all wires are clear of moving parts.
11. Install the distributor rotor.
12. Install distributor cap and make sure all plug wires are attached securely.
13. See Wiring Instructions




FIGURE 4

LIMITED WARRANTY

Pertronix, Inc. Warrants to the original Purchaser of its solid-state ignition system (product) that the Ignitor, magnet assembly and wiring (components) shall be free from defects in material and workmanship for a period of (30) months from the date of purchase.

If within the period of the foregoing warranty Pertronix finds, after inspection, that the product or any component thereof is defective, Pertronix will, at its option, repair such products or component or replace them with identical or similar parts PROVIDED that within such period Purchaser:

1. Promptly Notifies Pertronix, in writing, of such defects.
2. Delivers the defective products product or component to Pertronix (ATTN: Warranty) with proof of purchase date; and
3. Has installed and used the product in a normal and Proper manner, consistent with Pertronix printed instructions.

THE FORGOING LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED, INCLUDING AND IMPLIED WARRANTY OR MERCHANTABILITY OR FITNESS FOR A PURPOSE.

THE FURNISHING OF A REPAIR OR REPLACEMENT COMPONENTS SHALL CONSTITUTE THE SOLE REMEDY OF PURCHASER AND THE SOLE LIABILITY OF PerTronix WHETHER ON WARRANTY, CONTRACT OR FOR NEGLIGENCE, AND IN NO EVENT WILL PerTronix BE LIABLE FOR MONEY DAMAGES WHETHER DIRECT OR CONSEQUENTIAL.



440 E. Arrow Highway, San Dimas, CA. 91773
909-599-5955 www.pertronix.com

WIRING INSTRUCTIONS

1. NOTE: A BALLAST RESISTOR OR RESISTOR WIRE MAY OR MAY NOT BE INCLUDED IN THE ORIGINAL EQUIPMENT.
2. Connect the Ignitor black wire to the negative (-) side of the ignition coil.
3. For installations that do not use a primary ballast resistor, connect the Ignitor red wire to the positive (+) side of the ignition coil. (See Figure 2)
4. For installations that use a primary ballast resistor, connect the Ignitor red wire to the ignition switch side of the resistor. (See Figure 3).
5. Reconnect battery and make sure all wires are connected.
6. The engine can now be started. Let the engine run for a few minutes and then set the timing in the conventional manner.

FIGURE 1

(CONVENTIONAL POINT SYSTEM)
WIRING DIAGRAM
WITH RESISTOR WIRE OR
BALLAST RESISTOR




FIGURE 2

(IGNITOR SYSTEM - WITHOUT BALLAST RESISTOR)

- THE BLACK WIRE MUST BE CONNECTED TO THE NEGATIVE (-) SIDE OF THE COIL.
- THE RED WIRE MUST BE CONNECTED TO THE POSITIVE SIDE OF THE COIL.





FIGURE 3

(IGNITOR SYSTEM - WITH BALLAST RESISTOR)

- THE BLACK WIRE MUST BE CONNECTED TO THE NEGATIVE (-) SIDE OF THE COIL.
- THE RED WIRE MUST BE CONNECTED TO THE 12-VOLT SIDE OF THE BALLAST RESISTOR OR RESISTANCE WIRE.



Ignitor COMMON QUESTIONS AND ANSWERS

Q. What is the first thing I should check if the engine would not start?
A. Make certain all wires are connected securely to the proper terminals.

Q. The engine will not start or runs rough. Are there any tests I can do?
A. Yes, remove the red ignitor wire from the coil. Connect jumper wire from the positive side of the battery to the red ignitor wire just removed from the coil. If the engine starts, then you have a low voltage problem. Remember this is just a test. Not intended for permanent installation.

Q. How can I fix a low voltage problem?
A. First, if you have an external ballast resistor or resistance wire, connect the red ignitor wire to the ignition wire prior to the ballast resistor or resistance wire. Second, if you do not have an external resistor you must connect the ignitor red wire to a 12-volt source that is controlled by the ignition switch.

Q. Should I remove the starter bypass wire?
A. No, the starter bypass wire is needed to provide voltage while starting (cranking).

Q. What type of coil do I need?
A. The ignitor is compatible only with a "points type" coil. Eight cylinder engines require a minimum of 1.5 Ohms of resistance in the primary circuit. Four & six cylinder engines require a minimum of 3.0 Ohms of resistance (primary).

Q. How do I check my coil for resistance?
A. First you need an ohmmeter. Remove all the wires from the coil. Attach the ohmmeter to both the positive and negative terminals. The reading should be 1.5 Ohms or greater for eight cylinder engines and 3.0 Ohms or greater for six cylinder engines. (Your local auto parts store can do this for you if you don't have an ohmmeter)

Q. What do I do if my coil does not have enough resistance?
A. You may purchase and install a ballast resistor from your local auto parts store. You may also choose to purchase a Flamethrower 40,000-volt coil, which provides resistance internally. Note: Many vehicles come with ballast resistor or resistance wire. These applications do not need an additional resistor.

Q. What happens if you leave the ignition switch on when the engine is not running?
A. This can cause your coil to overheat, which may cause permanent damage to the coil and the ignitor.

Q. May I modify the length of the wires?
A. Yes, you can cut the wires to any length your application may require. You may also add length of wire if needed (20-gauge wire). Please make sure all wire splice are clean and connections are secure.

Q. Will the shift interrupter on an OMC stern drive boat work with the ignitor?
A. The ignitor is compatible with all OMC stern drive applications, when equipped with a "diode fix". If you purchased a kit that does not include the "diode fix" diagram, call our tech line.

Q. How can I get additional help?
A. Call our tech line (909-547-9058) for any further instructions or questions.