



M₂C

UP POWER DOWN



START

- · If machine is not displaying Standby, turn on at wall
- Check the Upstand (1), Filter (2) and Scrap Tray (3) are in place and shut door
- · Press Power button for 3 seconds to turn machine on and begin the fill cycle

OPERATION

- Select cycle using Up/Down buttons (use the Heavy cycle whenever possible)
- Press Start button (once this is Green or Orange) to begin washing
- Timer counts down to 00 then resets after door is opened

START BUTTON COLOURS

White = machine is filling

Red = cycle is running

Green = rinse water is up to temperature

Purple = door is open

Orange = machine is heating

NOTE: The machine may be started while Orange light is on and while rinse water is being heated and the timer will pause at 22 seconds until rinse water is up to 83 degrees

SHUT DOWN - EVERY NIGHT

- Remove drain Upstand (1) and shut door
- Select Drain cycle via Up/Down buttons and press Start button
- When Drain cycle is finished after 100 seconds, clean the tank then remove and rinse Scrap Tray (3) and Filter (2) before replacing back in machine along with Upstand (1)

CLEANING - AT LEAST ONCE A WEEK

Remove, rinse and replace:

Upstand 1
Filter 2
Scrap Tray 3
Rinse Arm 4
Wash Arm 5

Inspect and clear all jets in the Wash/Rinse Arm using a small object such as a toothpick where necessary to remove any blockages prior to rinsing

SUGGESTED BEST PRACTICE

Cutlery Stack with handles or sharp blades down and avoid overloading Light Items Ensure these are secured or weighted down by heavier items

Pre-rinse Scrape and/or rinse plates & glasses in cool water

Chemical Chemicals can be adjusted and primed via the control panel, please review the operator

manual for full instructions

Use good quality non foaming commercial detergent and drying agent – do not use

domestic detergent which will cause the machine to foam

Wash results If wash results are deteriorating, check that you have haven't run out of detergent and

that the wash/rinse arms are clean and free of obstructions







M2C OPERATOR TROUBLESHOOTING

Issue	Cause											
	POOR PRE-SCRAPING	CARRY OVER OF SOAP FROM SINK	OVERLOADING RACKS	POOR MACHINE CARE	DRAIN UPSTAND NOT PLUGGED IN	JETS BLOCKED OR ARMS OBSTRUCTED	RINSE NOT WORKING	WATER SUPPLY PRESSURE LOW	DETERGENT DOSAGE LOW/HIGH*	RINSE FLUID DOSAGE LOW/HIGH*	POOR WATER QUALITY**	RINSE TEMPERATURE LOW <75°C
DISHES NOT CLEAN	•		•	•		•	•	•	•		•	•
STAINING	•					•	•	•	•		•	•
FOAMING		•		•			•		•	•		
PROTEIN BLOOM	•		•	•		•	•	•	•			•
DIRTY MACHINE	•		•	•		•	•	•	•		•	•
FOOD RESIDUE ON WARE	•		•	•		•		•	•		•	•
FILM/SPOTS ON WARE			•	•		•	•	•	•		•	•
DETERGENT RESIDUE						•	•	•	•			
GREASY FILM/NO FIZZ			•				•	•		•	•	
HIGH DETERGENT USE				•	•			•	•			
HIGH RINSE FLUID USE				•				•		•		
WET WASHWARE			•	•				•		•		
SCALE BUILD UP IN MACHINE				•							•	
FILTERS ON OTHER EQUIPMENT											•	

• Likely cause

Possible cause

IF PROBLEMS PERSIST CONTACT MOFFAT SERVICE ON 1300 264 217



^{*} For issues most likely due to incorrect chemical dosages or other chemical issues, we recommend you consult your chemical supplier and/or a local chemical expert prior to calling in a dishwasher technician.

^{**} For issues that are likely due to poor water quality (scale building up, filters being required on other kitchen equipment etc.), we recommend you consult a local water specialist prior to calling in a dishwasher technician.

^{***} To reset the machine after an error message has been displayed, simply turn the machine OFF and then back ON again. The machine will log the error for future reference.