ARDUINO UNO REV3





Use your Arduino Uno on the Arduino Web IDE

All Arduino boards, including this one, work out-of-the-box on the Arduino Web Editor, no need to install anything.

The Arduino Web Editor is hosted online, therefore it will always be up-to-date with the latest features and support for all boards. Follow this simple guide to start coding on the browser and upload your sketches onto your board.

Use your Arduino Uno on the Arduino Desktop IDE

If you want to program your Arduino Uno while offline you need to install the Arduino Desktop IDE The Uno is programmed using the Arduino Software (IDE), our Integrated Development Environment common to all our boards. Before you can move on, you must have installed the Arduino Software (IDE) on your PC, as explained in the home page of our Getting Started.

Connect your Uno board with an A B USB cable; sometimes this cable is called a *USB printer cable*



The USB connection with the PC is necessary to program the board and not just to power it up. The Uno automatically draw power from either the USB or an external power supply. Connect the board to your computer using the USB cable. The green power LED (labelled PWR) should go on.

Install the board drivers

If you used the Installer, Windows - from XP up to 10 - will install drivers automatically as soon as you connect your board.

If you downloaded and expanded the Zip package or, for some reason, the board wasn't properly recognized, please follow the procedure below.

• Click on the Start Menu, and open up the Control Panel.

- While in the Control Panel, navigate to System and Security. Next, click on System. Once the System window is up, open the Device Manager.
- Look under Ports (COM & LPT). You should see an open port named "Arduino UNO (COMxx)". If there is no COM & LPT section, look under "Other Devices" for "Unknown Device".
- Right click on the "Arduino UNO (COmxx)" port and choose the "Update Driver Software" option.
- Next, choose the "Browse my computer for Driver software" option.
- Finally, navigate to and select the driver file named "arduino.inf", located in the "Drivers" folder of the Arduino Software download (not the "FTDI USB Drivers" sub-directory). If you are using an old version of the IDE (1.0.3 or older), choose the Uno driver file named "Arduino UNO.inf"
- Windows will finish up the driver installation from there.

See also: step-by-step screenshots for installing the Uno under Windows XP.

Open your first sketch

Open the LED blink example sketch: File > Examples >01.Basics > Blink.

🥯 Blink Arduir	no 1.8.0								
ile Edit Sketch	dit Sketch Tools Help								
New Open Open Recent Sketchbook	Ctrl+N Ctrl+O t >								
Examples	>	Δ							
Close Save	Ctrl+W Ctrl+S	01.Basics	>	AnalogReadSerial	one s				
Save As	Ctrl+Shift+S	03.Analog	>	Blink	ol. 0				
Page Setup Print	Ctrl+Shift+P Ctrl+P	04.Communication 05.Control	>	DigitalReadSerial Fade	oin 6				
Preferences	Ctrl+Comma	06.Sensors 07.Display	>P	ReadAnalogVoltage	conn				

Select your board type and port

You'll need to select the entry in the Tools > Board menu that corresponds to your Arduino board.

∞ Blink Arduino 1.6.10								
File E	dit Sketch	Tools Help						
Blink		Auto Format Archive Sketch Fix Encoding & Reload	Ctrl+T					
1 / 2 3	/* Blink Turns	Serial Monitor Serial Plotter	Ctrl+Maiusc+M Ctrl+Maiusc+L		for one second, repeatedly.			
4	Most 7	WiFi101 Firmware Updater			and the two and			
6	Leonar	Board: "Arduino/Genuino Uno"			A			
7	pin th the do	Port Get Board Info Programmer: "Atmel EDBG" Burn Bootloader		•	Arduino/Genuino Uno Arduino Duemilanove or Diecimila Arduino Nano			
9 10 11	This e				Arduino/Genuino Mega or Mega 2560 Arduino Mega ADK			

Select the serial device of the board from the Tools | Serial Port menu. This is likely to be COM3 or higher (COM1 and COM2 are usually reserved for hardware serial ports). To find out, you can disconnect your board and re-open the menu; the entry that disappears should be the Arduino board. Reconnect the board and select that serial port.

∞ Blink Arduino 1.6.10								
File E	dit Sketch	Tools Help		10				
Blink		Auto Format Archive Sketch Fix Encoding & Reload	Ctrl+T					
1 /	*	Serial Monitor	Ctrl+Maiusc+M					
2	Blink Turns	Serial Plotter	Ctrl+Maiusc+L	for one second, repeatedly.				
4		WiFi101 Firmware Updater						
5	Most A Leonar	Board: "Arduino/Genuino Uno"	>	control. On the Uno and				
7	pin th	Port	>	Serial ports				
8	the do	Get Board Info		COM6 (Arduino/Genuino Uno)				
9 10 11	This e	Programmer: "Atmel EDBG" Burn Bootloader	>					

Upload the program

Now, simply click the "Upload" button in the environment. Wait a few seconds - you should see the RX and TX leds on the board flashing. If the upload is successful, the message "Done uploading." will appear in the status bar.



A few seconds after the upload finishes, you should see the pin 13 (L) LED on the board start to blink (in orange). If it does, congratulations! You've gotten Arduino up-and-running. If you have problems, please see the troubleshooting suggestions.

Learn more on the Desktop IDE

See this tutorial for a generic guide on the Arduino IDE with a few more infos on the Preferences, the Board Manager, and the Library Manager.

Tutorials

Now that you have set up and programmed your Uno board, you may find inspiration in our Project Hub tutorial platform

or have a look to the tutorial pages that explain how to use the various features of your board.

- examples for using various sensors and actuators
- reference for the Arduino language