

## Getting Started

Beagles are tiny computers ideal for learning and prototyping with electronics. Read the step-by-step getting started tutorial below to begin developing with your Beagle in minutes.

### Update board with latest software

This step may or may not be necessary, depending on how old a software image you already have, but executing this, the longest, step will ensure the rest will go as smooth as possible.

- **Step #0.A: Download the latest software image**

Download the latest Debian image from [beagleboard.org/latest-images](https://beagleboard.org/latest-images). The "IoT" images provide more free disk space if you don't need to use a graphical user interface (GUI).

**Note:** Due to sizing necessities, this download may take 30 minutes or more.

The Debian distribution is provided for the boards. The file you download will have an .img.xz extension. This is a compressed sector-by-sector image of the SD card.

BeagleBoard.org - latest-images x Jason

Secure https://beagleboard.org/latest-images

beagleboard.org®

Start ↓ Discover Boards ↓ Learn ↓ Explore ↓ Collaborate ↓ Google Custom Search Search

BeagleBoard.org > latest-images

## BeagleBoard.org Latest Firmware Images

Download the latest firmware for your BeagleBoard, BeagleBoard-xM, BeagleBoard-X15, BeagleBone, BeagleBone Black, BeagleBone Black Wireless, BeagleBone Blue, SeeedStudio BeagleBone Green, SeeedStudio BeagleBone Green Wireless, SanCloud BeagleBone Enhanced, element14 BeagleBone Black Industrial, Arrow BeagleBone Black Industrial, Mentorel BeagleBone uSomIQ or Neuromeka BeagleBone Air

See the [Getting Started guide](#) and the [community wiki page](#) for hints on loading these images.

### Recommended Debian Images

Jessie for **BeagleBone** via microSD card

- ▶ Debian 8.7 2017-03-19 4GB SD LXQT image for BeagleBone, [BeagleBone Black](#), BeagleBone Black Wireless, BeagleBone Blue, SeeedStudio BeagleBone Green, SeeedStudio BeagleBone Green Wireless, SanCloud BeagleBone Enhanced, element14 BeagleBone Black Industrial, Arrow BeagleBone Black Industrial and Mentorel BeagleBone uSomIQ - more info - bmap - sha256sum: cb8a97714c6b0a4113429fc4e9ef8d28bac88de96a40ae80cf927a343d816e5

Jessie IoT (non-GUI) for **BeagleBone** via microSD card

- ▶ Debian 8.7 2017-03-19 4GB SD IoT image for BeagleBone, BeagleBone Black, BeagleBone Black Wireless, BeagleBone Blue, SeeedStudio BeagleBone Green, SeeedStudio BeagleBone Green Wireless, SanCloud BeagleBone Enhanced, element14 BeagleBone Black Industrial, Arrow BeagleBone Black Industrial and Mentorel BeagleBone uSomIQ - more info - bmap - sha256sum: 1709035e9d9470fa0aa9b778e4d369ba91415acc7a5fec6713facbe52cc9285

Jessie for **SeeedStudio BeagleBone Green Wireless** via microSD card

- ▶ Debian 8.6 2016-11-06 4GB SD SeeedStudio IoT image for SeeedStudio BeagleBone Green Wireless - more info - bmap - sha256sum: 48582b8a1a134679ff324eacc1e0b4af6f2cdabfb56dafb6b932fe11129b404f

Jessie for **BeagleBoard-X15** via microSD card

- ▶ Debian 8.6 2016-11-06 4GB SD LXQT image for BeagleBoard-X15 - more info - bmap - sha256sum: b03799ae3c604d4355ca446cf343e252247e0c2d76fe4f81d0dc004ff02eb232

Jessie for **BeagleBoard-xM** via microSD card


<https://beagleboard.org/black> [BeagleBoard-xM - more info - bmap -](#)

- Step #0.B: Install SD card programming utility


Download and install [balenaEtcher](#).


# Flash. Flawless.

Flash OS images to SD cards & USB drives, safely and easily.



- Download for macOS
- Etcher for Windows (x86/x64) (Installer)
- Etcher for Windows (x86/x64) (Portable)
- Etcher for Linux x64 (64-bit) (AppImage)
- Etcher for Linux x86 (32-bit) (AppImage)

 **Validated Flashing**  
No more writing images on corrupted cards and wondering why your device isn't booting.


 **Hard Drive Friendly**  
Makes drive selection obvious to avoid wiping your entire hard-drive.

**FEATURES**  
A better way to burn.



# balena**Etcher**

An open source project by  balena




- Step #0.C: Connect SD card to your computer

Use your computer's SD slot or a USB adapter to connect the SD card to your computer.

- Step #0.D: Write the image to your SD card

Use Etcher to write the image to your SD card. Etcher will transparently decompress the image on-the-fly before writing it to the SD card.



- Step #0.E: Eject the SD card

Eject the newly programmed SD card.

- Step #0.F: Boot your board off of the SD card

Insert SD card into your (powered-down) board, hold down the USER/BOOT button (if using Black) and apply power, either by the USB cable or 5V adapter.

If using an original BeagleBone or PocketBeagle, you are done.

If using BeagleBone Black, BeagleBone Blue, BeagleBone AI or other board with on-board eMMC flash and you desire to write the image to your on-board eMMC, you'll

need to follow the instructions

at [http://elinux.org/Beagleboard:BeagleBoneBlack\\_Debian#Flashing\\_eMMC](http://elinux.org/Beagleboard:BeagleBoneBlack_Debian#Flashing_eMMC). When the flashing is complete, all 4 USRx LEDs will be steady on or off. The latest Debian flasher images automatically power down the board upon completion. *This can take up to 45 minutes.* Power-down your board, *remove the SD card* and apply power again to finish.

## Start your Beagle

- *If any step fails, it is recommended to update to the **latest software image** using the instructions above.*

-  **Power and boot**

Most Beagles include a USB cable, providing a convenient way to provide both power to your Beagle and connectivity to your computer. If you provide your own, ensure it is of good quality.

Alternatively, your Beagle may have a barrel jack. The voltage should be 5V except for BeagleBoard-X15 and BeagleBone Blue which use 12V.

*Note that BeagleBoard-X15 must always be powered by a 12V adapter with a barrel jack.*

If you are using your Beagle with an **SD (microSD) card**, make sure it is inserted ahead of providing power. Most Beagles include programmed on-board flash and therefore do not require an SD card to be inserted.

You'll see the power (PWR or ON) LED lit steadily. Within a minute or so, you should see the other LEDs blinking in their default configurations. Consult the Quick Start Guide (QSG) or System Reference Manual (SRM) for your board to locate these LEDs.

- USR0 is typically configured at boot to blink in a heartbeat pattern
- USR1 is typically configured at boot to light during SD (microSD) card accesses
- USR2 is typically configured at boot to light during CPU activity
- USR3 is typically configured at boot to light during eMMC accesses
- USR4/WIFI is typically configured at boot to light with WiFi (client) network association (*BeagleBone Blue and BeagleBone AI only*)

## Step 2

### Enable a network connection

If connected via USB, a network adapter should show up on your computer. Your Beagle should be running a DHCP server that will provide your computer with an IP address of either 192.168.7.1 or 192.168.6.1, depending on the type of USB network adapter supported by your computer's operating system. Your Beagle will reserve 192.168.7.2 or 192.168.6.2 for itself.

If your Beagle includes WiFi, an access point called "BeagleBone-XXXX" where "XXXX" varies between boards. The access point password defaults to "BeagleBone". Your Beagle should be running a DHCP server that will provide your computer with an IP address in the 192.168.8.x range and reserve 192.168.8.1 for itself.

If your Beagle is connected to your local area network (LAN) via either Ethernet or WiFi, it will utilize **mDNS** to broadcast itself to your computer. If your computer supports mDNS, you should see your Beagle as `beaglebone.local`. *Non-BeagleBone boards will utilize alternate names. Multiple BeagleBone boards on the same network will add a suffix such as `beaglebone-2.local`.*

The below table summarizes the typical addresses and should dynamically update to indicate an active connection.

**Note:** You must "load unsafe scripts" or load [this page](#) without HTTPS security for the automatic detection to work.

IP Address	Connection Type	Operating System(s)	Status
192.168.7.2	USB	Windows	
192.168.6.2	USB	Mac OS X, Linux	
192.168.8.1	WiFi	all	
beaglebone.local	all	mDNS enabled	

beaglebone-2.local

all


mDNS enabled

Step 3

Browse to your Beagle

Using either **Chrome** or **Firefox** (Internet Explorer will **NOT** work), browse to the web server running on your board. It will load a presentation showing you the capabilities of the board. Use the arrow keys on your keyboard to navigate the presentation.

- Click here to launch: <http://192.168.7.2>  
Older software images require you to EJECT the BEAGLE\_BONE drive to start the network. With the latest software image, that step is no longer required.



## Troubleshooting

*Do not use Internet Explorer.*

Virtual machines are not recommended when using the direct USB connection. It is recommended you use only network connections to your board if you are using a virtual machine.

When using 'ssh' with the provided image, the username is 'debian' and the password is 'tempwd'.

With the latest images, *it should no longer be necessary to install drivers* for your operating system to give you network-over-USB access to your Beagle. In case you are running an older image, an older operating system or need additional drivers for serial access to older boards, links to the old drivers are below.

Operating System	USB Drivers	Comments
Windows (64-bit)	<a href="#">64-bit installer</a>	If in doubt, try the 64-bit installer first. <ul style="list-style-type: none"> <li>• <b>Note #1:</b> Windows Driver Certification warning may pop up two or three times. Click "Ignore", "Install" or "Run"</li> <li>• <b>Note #2:</b> To check if you're running 32 or 64-bit Windows see this: <a href="http://support.microsoft.com/kb/827218">support.microsoft.com/kb/827218</a>.</li> <li>• <b>Note #3:</b> On systems without the latest service release, you may get an error (0xc000007b). In that case, please install the following and retry: <a href="http://www.microsoft.com/en-us/download/confirmation.aspx?id=13523">www.microsoft.com/en-us/download/confirmation.aspx?id=13523</a>.</li> <li>• <b>Note #4:</b> You may need to reboot Windows.</li> <li>• <b>Note #5:</b> These drivers have been tested to work up to Windows 10</li> </ul>
Windows (32-bit)	<a href="#">32-bit installer</a>	
Mac OS X	<a href="#">Network Serial</a>	Install both sets of drivers.
Linux	<a href="#">mkudevrule.sh</a>	Driver installation isn't required, but you might find a few udev rules helpful.

**Note:** Additional FTDI USB to serial/JTAG information and drivers are available from [www.ftdichip.com/Drivers/VCP.htm](http://www.ftdichip.com/Drivers/VCP.htm).

**Note:** Additional USB to virtual Ethernet information and drivers are available from [www.linux-usb.org/gadget/](http://www.linux-usb.org/gadget/) and [joshuawise.com/horndis](http://joshuawise.com/horndis).

Visit [beagleboard.org/support](http://beagleboard.org/support) for additional debugging tips.

Other currently available software images



Some of the starting images below involve multiple steps to produce an SD card image or otherwise change some of the steps above, so be sure to read all the instructions on their pages. Choose the starting point you want, download or produce the SD card image and follow the steps above.

At the time of release, not all of these distributions support BeagleBone Black, but should soon.

- Texas Instruments releases: [Android](#), [Linux](#), [StarterWare \(no OS\)](#)
- Linux: [Debian](#), [Angstrom Distribution](#), [Ubuntu](#), [ArchLinux](#), [Gentoo](#), [Sabayon](#), [Buildroot](#), [Erlang](#), [Fedora](#)
- Other: [QNX](#), [FreeBSD](#)
- [Projects page](#)

Hardware documentation

Time to read that manual and check out the design materials: [BeagleBoard](#), [BeagleBoard-xM](#), [BeagleBoard-X15](#), [BeagleBone](#), [BeagleBone Black](#), [BeagleBone Black Wireless](#), [BeagleBone Blue](#), [PocketBeagle](#), and [BeagleBone AI](#).

Other links to design materials for various releases can be found at [beagleboard.org/hardware/design](http://beagleboard.org/hardware/design).

- [Exploring BeagleBone and Embedded Linux Primer](#)

To take things to the next level of detail, consider "Exploring BeagleBone" which can be considered the missing software manual and utilize "Embedded Linux Primer" as a companion textbook to provide a strong base on embedded Linux suitable for working with any hardware that will run Linux.