


Service Manual

Multi-Split Type Air Conditioners 2/3MXL-Q Series



[Applied Models]

- Inverter Multi : Heat Pump

Multi-Split Type Air Conditioners 2/3MXL-Q Series

●Heat Pump Indoor Unit

CTXS07LVJU
FTXS09LVJU
FTXS12LVJU
FTXS15LVJU
FTXS18LVJU

FDXS09LVJU
FDXS12LVJU
CDXS15LVJU
CDXS18LVJU

FVXS09NVJU
FVXS12NVJU
FVXS15NVJU
FVXS18NVJU

FFQ09LVJU
FFQ12LVJU
FFQ15LVJU
FFQ18LVJU

Outdoor Unit

2MXL18QMVJU
3MXL24QMVJU

1. Safety Cautions.....	vi
1.1 Warnings and Cautions Regarding Safety of Workers.....	vi
1.2 Warnings and Cautions Regarding Safety of Users.....	viii
2. Icons Used	xi
Part 1 List of Functions	1
1. Functions.....	2
Part 2 Specifications	7
1. Indoor Unit.....	8
2. Outdoor Unit.....	13
Part 3 Printed Circuit Board Connector Wiring Diagram	15
1. Indoor Unit.....	16
1.1 CTXS07LVJU, FTXS09/12LVJU	16
1.2 FTXS15/18LVJU	18
1.3 FDXS09/12LVJU, CDXS15/18LVJU	20
1.4 FVXS09/12/15/18NVJU.....	22
1.5 FFQ09/12/15/18LVJU	24
2. Wired Remote Controller.....	25
2.1 BRC1E71	25
2.2 BRC1E72/73	26
3. Wireless Remote Controller	27
3.1 BRC7E830	27
4. Outdoor Unit.....	28
Part 4 Functions and Control.....	31
1. Functions for CTXS, FTXS, CDXS, FDXS, FVXS Series	32
1.1 Temperature Control	32
1.2 Frequency Principle.....	32
1.3 Airflow Direction Control (CTXS, FTXS, FVXS Series)	34
1.4 Fan Speed Control for Indoor Unit	37
1.5 Program Dry Operation	38
1.6 Automatic Operation.....	39
1.7 Thermostat Control.....	40
1.8 NIGHT SET Mode	41
1.9 ECONO Operation	41
1.10 INTELLIGENT EYE Operation (CTXS, FTXS Series).....	42
1.11 Inverter POWERFUL Operation	43
1.12 Clock Setting	44
1.13 WEEKLY TIMER Operation (CTXS, FTXS, FVXS Series).....	45
1.14 Other Functions.....	51
2. Functions for FFQ Series	52
2.1 Drain Pump Control.....	52
2.2 Thermostat Sensor in Remote Controller	54

2.3	Freeze Prevention Control	56
2.4	Hot Start Control (In Heating Operation Only).....	57
3.	Control Specification	58
3.1	Thermistor Functions.....	58
3.2	Mode Hierarchy	60
3.3	Frequency Control.....	61
3.4	Controls at Mode Changing/Start-up.....	63
3.5	Discharge Pipe Temperature Control.....	64
3.6	Input Current Control.....	65
3.7	Freeze-up Protection Control	66
3.8	Heating Peak-cut Control	66
3.9	Outdoor Fan Control.....	67
3.10	Liquid Compression Protection Function.....	67
3.11	Defrost Control	68
3.12	Low Hz High Pressure Limit	69
3.13	Electronic Expansion Valve Control	70
3.14	Malfunctions	75

Part 5 Remote Controller 76

1.	CTXS, FTXS Series	77
2.	CDXS, FDXS Series	79
3.	FVXS Series.....	81
4.	FFQ Series.....	83
4.1	<BRC1E71> Wired Remote Controller.....	83
4.2	<BRC1E72/73> Wired Remote Controller.....	88
4.3	<BRC7E830> Wireless Remote Controller	94

Part 6 Service Diagnosis..... 95

1.	General Problem Symptoms and Check Items	97
2.	Troubleshooting with LED	98
2.1	Indoor Unit.....	98
2.2	Outdoor Unit.....	99
3.	Service Diagnosis	100
3.1	CTXS, FTXS, CDXS, FDXS, FVXS Series	100
3.2	FFQ Series	106
4.	Code Indication on Remote Controller	112
4.1	CTXS, FTXS, CDXS, FDXS, FVXS Series	112
4.2	FFQ Series	112
4.3	Outdoor Unit.....	113
5.	Troubleshooting for CTXS, FTXS, CDXS, FDXS, FVXS Series	114
5.1	Indoor Unit PCB Abnormality	114
5.2	Freeze-up Protection Control/Heating Peak-cut Control	116
5.3	Fan Motor or Related Abnormality	117
5.4	Thermistor or Related Abnormality.....	121
5.5	Signal Transmission Error (Between Indoor Unit and Outdoor Unit).....	122
5.6	Unspecified Voltage (Between Indoor Unit and Outdoor Unit)	124

6.	Troubleshooting for FFQ Series	125
6.1	Indoor Unit PCB Abnormality	125
6.2	Drain Level Control System Abnormality	126
6.3	Fan Motor (AC Motor) or Related Abnormality	127
6.4	Drain System Abnormality	128
6.5	Thermistor or Related Abnormality	129
6.6	Remote Controller Thermistor Abnormality	130
6.7	Signal Transmission Error (Between Indoor Unit and Remote Controller)	131
6.8	Signal Transmission Error (Between MAIN Remote Controller and SUB Remote Controller)	132
6.9	Field Setting Abnormality	133
7.	Troubleshooting for Outdoor Unit	134
7.1	Refrigerant Shortage	134
7.2	Low-voltage Detection or Over-voltage Detection	136
7.3	Wiring Error Check Unexecuted	138
7.4	Unspecified Voltage (Between Indoor Unit and Outdoor Unit)/ Anti-icing Control in Other Rooms	139
7.5	Anti-icing Control for Indoor Unit	140
7.6	Outdoor Unit PCB Abnormality	142
7.7	OL Activation (Compressor Overload)	143
7.8	Compressor Lock	145
7.9	DC Fan Lock	146
7.10	Input Overcurrent Detection	147
7.11	Four Way Valve Abnormality	148
7.12	Discharge Pipe Temperature Control	150
7.13	High Pressure Control in Cooling	151
7.14	Compressor Sensor System Abnormality	152
7.15	Position Sensor Abnormality	154
7.16	CT or Related Abnormality	156
7.17	Thermistor or Related Abnormality (Outdoor Unit)	158
7.18	Electrical Box Temperature Rise	160
7.19	Radiation Fin Temperature Rise	161
7.20	Output Overcurrent Detection	162
8.	Check	164
8.1	Thermistor Resistance Check	164
8.2	Indoor Fan Motor Connector Check	165
8.3	Hall IC Check	165
8.4	Power Supply Waveform Check	166
8.5	Electronic Expansion Valve Check	167
8.6	Four Way Valve Performance Check	168
8.7	Inverter Unit Refrigerant System Check	168
8.8	Inverter Analyzer Check	169
8.9	Rotation Pulse Check on the Outdoor Unit PCB	170
8.10	Installation Condition Check	171
8.11	Discharge Pressure Check	171
8.12	Outdoor Fan System Check	172
8.13	Main Circuit Short Check	172
8.14	Capacitor Voltage Check	173

8.15 Power Module Check	174
-------------------------------	-----

Part 7 Trial Operation and Field Settings..... 175

1. Pump Down Operation	176
2. Wiring Error Check Function	177
3. Trial Operation	179
3.1 CTXS, FTXS, CDXS, FDXS, FVXS Series	179
3.2 FFQ Series	181
4. Field Settings	183
4.1 Outdoor Unit	183
4.2 CTXS, FTXS, CDXS, FDXS, FVXS Series	185
4.3 FFQ Series	190
5. Silicone Grease on Power Transistor / Diode Bridge	197





Part 8 Appendix..... 198

1. Piping Diagrams	199
1.1 Indoor Unit	199
1.2 Outdoor Unit	201
2. Wiring Diagrams	202
2.1 Indoor Unit	202
2.2 Outdoor Unit	207




1. Safety Cautions

Be sure to read the following safety cautions before conducting repair work. After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer.








Caution Items






The caution items are classified into  **Warning** and  **Caution**. The  **Warning** items are especially important since death or serious injury can result if they are not followed closely. The  **Caution** items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.








Pictograms



-  This symbol indicates an item for which caution must be exercised.
The pictogram shows the item to which attention must be paid.
-  This symbol indicates a prohibited action.
The prohibited item or action is shown in the illustration or near the symbol.
-  This symbol indicates an action that must be taken, or an instruction.
The instruction is shown in the illustration or near the symbol.

1.1 Warnings and Cautions Regarding Safety of Workers










 Warning	
Do not store equipment in a room with fire sources (e.g., naked flames, gas appliances, electric heaters).	
Be sure to disconnect the power cable from the socket before disassembling equipment for repair. Working on equipment that is connected to the power supply may cause an electrical shock. If it is necessary to supply power to the equipment to conduct the repair or inspect the circuits, do not touch any electrically charged sections of the equipment.	
If refrigerant gas is discharged during repair work, do not touch the discharged refrigerant gas. Refrigerant gas may cause frostbite.	
When disconnecting the suction or discharge pipe of the compressor at the welded section, evacuate the refrigerant gas completely at a well-ventilated place first. If there is gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it may cause injury.	
If refrigerant gas leaks during repair work, ventilate the area. Refrigerant gas may generate toxic gases when it contacts flames.	
Be sure to discharge the capacitor completely before conducting repair work. The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. A charged capacitor may cause an electrical shock.	







 Warning	
<p>Do not turn the air conditioner on or off by plugging in or unplugging the power cable. Plugging in or unplugging the power cable to operate the equipment may cause an electrical shock or fire.</p>	
<p>Be sure to wear a safety helmet, gloves, and a safety belt when working in a high place (more than 2 m). Insufficient safety measures may cause a fall.</p>	
<p>In case of R-32 / R-410A refrigerant models, be sure to use pipes, flare nuts and tools intended for the exclusive use with the R-32 / R-410A refrigerant. The use of materials for R-22 refrigerant models may cause a serious accident, such as a damage of refrigerant cycle or equipment failure.</p>	
<p>Do not mix air or gas other than the specified refrigerant (R-32 / R-410A / R-22) in the refrigerant system. If air enters the refrigerant system, an excessively high pressure results, causing equipment damage and injury.</p>	






 Caution	
<p>Do not repair electrical components with wet hands. Working on the equipment with wet hands may cause an electrical shock.</p>	
<p>Do not clean the air conditioner with water. Washing the unit with water may cause an electrical shock.</p>	
<p>Be sure to provide an earth / grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.</p>	
<p>Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and may cause injury.</p>	
<p>Be sure to conduct repair work with appropriate tools. The use of inappropriate tools may cause injury.</p>	
<p>Be sure to check that the refrigerating cycle section has cooled down enough before conducting repair work. Working on the unit when the refrigerating cycle section is hot may cause burns.</p>	






 Caution	
<p>Conduct welding work in a well-ventilated place. Using a welder in an enclosed room may cause oxygen deficiency.</p>	

1.2 Warnings and Cautions Regarding Safety of Users

 Warning	
<p>Do not store the equipment in a room with fire sources (e.g., naked flames, gas appliances, electric heaters).</p>	
<p>Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools may cause an electrical shock, excessive heat generation or fire.</p>	
<p>If the power cable and lead wires are scratched or have deteriorated, be sure to replace them. Damaged cable and wires may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Be sure to use an exclusive power circuit for the equipment, and follow the local technical standards related to the electrical equipment, the internal wiring regulations, and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work may cause an electrical shock or fire.</p>	
<p>Be sure to use the specified cable for wiring between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections may cause excessive heat generation or fire.</p>	
<p>When wiring between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Do not damage or modify the power cable. Damaged or modified power cables may cause an electrical shock or fire. Placing heavy items on the power cable, or heating or pulling the power cable may damage it.</p>	





 Warning	
<p>Do not mix air or gas other than the specified refrigerant (R-32 / R-410A / R-22) in the refrigerant system. If air enters the refrigerant system, an excessively high pressure results, causing equipment damage and injury.</p>	
<p>If the refrigerant gas leaks, be sure to locate the leaking point and repair it before charging the refrigerant. After charging the refrigerant, make sure that there is no leak. If the leaking point cannot be located and the repair work must be stopped, be sure to pump-down, and close the service valve, to prevent refrigerant gas from leaking into the room. Refrigerant gas itself is harmless, but it may generate toxic gases when it contacts flames, such as those from fan type and other heaters, stoves and ranges.</p>	
<p>When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength or the installation work is not conducted securely, the equipment may fall and cause injury.</p>	
<p>Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet securely. If the plug is dusty or has a loose connection, it may cause an electrical shock or fire.</p>	
<p>When replacing the coin battery in the remote controller, be sure to dispose of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.</p>	

 Caution	
<p>Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.</p>	
<p>Do not install the equipment in a place where there is a possibility of combustible gas leaks. If combustible gas leaks and remains around the unit, it may cause a fire.</p>	
<p>Check to see if parts and wires are mounted and connected properly, and if connections at the soldered or crimped terminals are secure. Improper installation and connections may cause excessive heat generation, fire or an electrical shock.</p>	
<p>If the installation platform or frame has corroded, replace it. A corroded installation platform or frame may cause the unit to fall, resulting in injury.</p>	

 Caution	
<p>Check the earth / grounding, and repair it if the equipment is not properly earthed / grounded. Improper earth / grounding may cause an electrical shock.</p>	
<p>Be sure to measure insulation resistance after the repair, and make sure that the resistance is 1 MΩ or higher. Faulty insulation may cause an electrical shock.</p>	
<p>Be sure to check the drainage of the indoor unit after the repair. Faulty drainage may cause water to enter the room and wet the furniture and floor.</p>	
<p>Do not tilt the unit when removing it. The water inside the unit may spill and wet the furniture and floor.</p>	

2. Icons Used

The following icons are used to attract the attention of the reader to specific information.

Icon	Type of Information	Description
 Warning	Warning	A Warning is used when there is danger of personal injury.
 Caution	Caution	A Caution is used when there is danger that the reader, through incorrect manipulation, may damage equipment, lose data, get an unexpected result or have to restart (part of) a procedure.
 Note:	Note	A Note provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
	Reference	A Reference guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

Part 1

List of Functions

1. Functions.....2

1. Functions

Category	Functions	CTXS07LVJU	FTXS09/12/15/18LVJU	Category	Functions	CTXS07LVJU	FTXS09/12/15/18LVJU
Basic Functions	Inverter (with inverter power control)	●	●	Health & Cleanliness	Air-purifying filter	—	—
	Operation limit for cooling (°CDB)	—	—		Photocatalytic deodorizing filter	—	—
	Operation limit for cooling (°FDB)	—	—		Air-purifying filter with photocatalytic deodorizing function	—	—
	Operation limit for heating (°CWB)	—	—		Titanium apatite photocatalytic air-purifying filter	●	●
	Operation limit for heating (°FWB)	—	—		Longlife filter (option)	—	—
	PAM control	—	—		Air filter (prefilter)	●	●
Compressor	Oval scroll compressor	—	—	Wipe-clean flat panel	●	●	
	Swing compressor	—	—	Washable grille	—	—	
	Rotary compressor	—	—	Filter cleaning indicator	—	—	
	Reluctance DC motor	—	—	Good-sleep cooling operation	—	—	
Comfortable Airflow	Power-airflow flap (horizontal blade)	—	—	Timer	WEEKLY TIMER operation	●	●
	Power-airflow dual flaps	●	●		24-hour ON/OFF TIMER	●	●
	Power-airflow diffuser	—	—		NIGHT SET mode	●	●
	Wide-angle louvers (vertical blades)	●	●	Worry Free (Reliability & Durability)	Auto-restart (after power failure)	●	●
	Auto-swing (up and down)	●	●		Self-diagnosis (R/C, LED)	●	●
	Auto-swing (right and left)	●	●		Wiring error check function	—	—
	3-D airflow	●	●		Anti-corrosion treatment of outdoor heat exchanger	—	—
	COMFORT AIRFLOW operation	●	●		Flexibility	Multi-split / split type compatible indoor unit	—
Comfort Control	Auto fan speed	●	●	Flexible power supply correspondence		—	—
	Indoor unit quiet operation	●	●	High ceiling application		—	—
	NIGHT QUIET mode (automatic)	—	—	Chargeless		—	—
	OUTDOOR UNIT QUIET operation (manual)	●	●	Either side drain (right or left)		●	●
	INTELLIGENT EYE operation	●	●	Power selection		—	—
	Quick warming function	—	—	°F/°C changeover R/C temperature display (factory setting: °F)		●	●
	Hot-start function	●	●			Remote Control	5-room centralized controller (option)
Automatic defrosting	—	—	Remote control adaptor (normal open pulse contact) (option)		●		●
Operation	Automatic operation	●	●	Remote control adaptor (normal open contact) (option)	●	●	
	Program dry function	●	●	DIII-NET compatible (adaptor) (option)	●	●	
	Fan only	●	●	Remote Controller	Wireless	●	●
Lifestyle Convenience	New POWERFUL operation (non-inverter)	—	—		Wired (option)	●	●
	Inverter POWERFUL operation	●	●				
	Priority-room setting	—	—				
	COOL/HEAT mode lock	—	—				
	HOME LEAVE operation	—	—				
	ECONO operation	●	●				
	Indoor unit ON/OFF button	●	●				
	Signal receiving sign	●	●				
R/C with back light	●	●					
	Temperature display	—	—				

Note: ● : Available
 — : Not available

Category	Functions	FDXS09/12LVJU	CDXS15/18LVJU	Category	Functions	FDXS09/12LVJU	CDXS15/18LVJU
Basic Functions	Inverter (with inverter power control)	●	●	Health & Cleanliness	Air-purifying filter	—	—
	Operation limit for cooling (°CDB)	—	—		Photocatalytic deodorizing filter	—	—
	Operation limit for cooling (°FDB)	—	—		Air-purifying filter with photocatalytic deodorizing function	—	—
	Operation limit for heating (°CWB)	—	—		Titanium apatite photocatalytic air-purifying filter	—	—
	Operation limit for heating (°FWB)	—	—		Longlife filter (option)	—	—
	PAM control	—	—		Air filter (prefilter)	●	●
Compressor	Oval scroll compressor	—	—	Wipe-clean flat panel	—	—	
	Swing compressor	—	—	Washable grille	—	—	
	Rotary compressor	—	—	Filter cleaning indicator	—	—	
	Reluctance DC motor	—	—	Good-sleep cooling operation	—	—	
Comfortable Airflow	Power-airflow flap (horizontal blade)	—	—	Timer	WEEKLY TIMER operation	—	—
	Power-airflow dual flaps	—	—		24-hour ON/OFF TIMER	●	●
	Power-airflow diffuser	—	—		NIGHT SET mode	●	●
	Wide-angle louvers (vertical blades)	—	—	Worry Free (Reliability & Durability)	Auto-restart (after power failure)	●	●
	Auto-swing (up and down)	—	—		Self-diagnosis (R/C, LED)	●	●
	Auto-swing (right and left)	—	—		Wiring error check function	—	—
	3-D airflow	—	—		Anti-corrosion treatment of outdoor heat exchanger	—	—
COMFORT AIRFLOW operation	—	—	Flexibility	Multi-split / split type compatible indoor unit	●	—	
Comfort Control	Auto fan speed	●		●	Flexible power supply correspondence	—	—
	Indoor unit quiet operation	●		●	High ceiling application	—	—
	NIGHT QUIET mode (automatic)	—		—	Chargeless	—	—
	OUTDOOR UNIT QUIET operation (manual)	●		●	Either side drain (right or left)	—	—
	INTELLIGENT EYE operation	—		—	Power selection	—	—
	Quick warming function	—		—	°F/°C changeover R/C temperature display (factory setting: °F)	●	●
	Hot-start function	●		●	Remote Control	5-room centralized controller (option)	●
	Automatic defrosting	—	—	Remote control adaptor (normal open pulse contact) (option)		●	●
Operation	Automatic operation	●	●	Remote control adaptor (normal open contact) (option)		●	●
	Program dry function	●	●	DIII-NET compatible (adaptor) (option)	●	●	
	Fan only	●	●	Remote Controller	Wireless (option)	●	●
Lifestyle Convenience	New POWERFUL operation (non-inverter)	—	—		Wired (option)	●	●
	Inverter POWERFUL operation	●	●				
	Priority-room setting	—	—				
	COOL/HEAT mode lock	—	—				
	HOME LEAVE operation	—	—				
	ECONO operation	●	●				
	Indoor unit ON/OFF button	●	●				
	Signal receiving sign	●	●				
	R/C with back light	●	●				
Temperature display	—	—					

Note: ● : Available
— : Not available

Category	Functions	FVXS09/12/15/18NVJU	Category	Functions	FVXS09/12/15/18NVJU	
Basic Functions	Inverter (with inverter power control)	●	Health & Cleanliness	Air-purifying filter	—	
	Operation limit for cooling (°CDB)	—		Photocatalytic deodorizing filter	—	
	Operation limit for cooling (°FDB)	—		Air-purifying filter with photocatalytic deodorizing function	—	
	Operation limit for heating (°CWB)	—		Titanium apatite photocatalytic air-purifying filter	●	
	Operation limit for heating (°FWB)	—		Longlife filter (option)	—	
	PAM control	—		Air filter (prefilter)	●	
Compressor	Oval scroll compressor	—	Timer	Wipe-clean flat panel	●	
	Swing compressor	—		Washable grille	—	
	Rotary compressor	—		Filter cleaning indicator	—	
	Reluctance DC motor	—		Good-sleep cooling operation	—	
Comfortable Airflow	Power-airflow flap (horizontal blade)	—	Worry Free (Reliability & Durability)	WEEKLY TIMER operation	●	
	Power-airflow dual flaps	—		24-hour ON/OFF TIMER	●	
	Power-airflow diffuser	—		NIGHT SET mode	●	
	Wide-angle louvers (vertical blades)	●	Flexibility	Auto-restart (after power failure)	●	
	Auto-swing (up and down)	●		Self-diagnosis (R/C, LED)	●	
	Auto-swing (right and left)	—		Wiring error check function	—	
	3-D airflow	—		Anti-corrosion treatment of outdoor heat exchanger	—	
COMFORT AIRFLOW operation	—	Remote Control	Multi-split / split type compatible indoor unit	—		
Comfort Control	Auto fan speed		●	Flexible power supply correspondence	—	
	Indoor unit quiet operation		●	High ceiling application	—	
	NIGHT QUIET mode (automatic)		—	Chargeless	—	
	OUTDOOR UNIT QUIET operation (manual)		●	Either side drain (right or left)	—	
	INTELLIGENT EYE operation		—	Power selection	—	
	Quick warming function		—	Remote Controller	°F/°C changeover R/C temperature display (factory setting: °F)	●
	Hot-start function		●		5-room centralized controller (option)	●
	Automatic defrosting	—	Remote Controller	Remote control adaptor (normal open pulse contact) (option)	●	
Operation	Automatic operation	●		Remote control adaptor (normal open contact) (option)	●	
	Program dry function	●		DIII-NET compatible (adaptor) (option)	●	
	Fan only	●		Wireless	●	
Lifestyle Convenience	New POWERFUL operation (non-inverter)	—		Wired (option)	—	
	Inverter POWERFUL operation	●				
	Priority-room setting	—				
	COOL/HEAT mode lock	—				
	HOME LEAVE operation	—				
	ECONO operation	●				
	Indoor unit ON/OFF button	●				
	Signal receiving sign	●				
	R/C with back light	●				
Temperature display	—					

Note: ● : Available
 — : Not available

Category	Functions	FFQ09/12/15/18LVJU	Category	Functions	FFQ09/12/15/18LVJU	
Basic Functions	Inverter (with inverter power control)	●	Health & Cleanliness	Air-purifying filter	—	
	Operation limit for cooling (°CDB)	—		Photocatalytic deodorizing filter	—	
	Operation limit for cooling (°FDB)	—		Air-purifying filter with photocatalytic deodorizing function	—	
	Operation limit for heating (°CWB)	—		Titanium apatite photocatalytic air-purifying filter	—	
	Operation limit for heating (°FWB)	—		Longlife filter (option)	●	
	PAM control	—		Air filter (prefilter)	—	
Compressor	Oval scroll compressor	—	Timer	Wipe-clean flat panel	—	
	Swing compressor	—		Washable grille	●	
	Rotary compressor	—		Filter cleaning indicator	●	
	Reluctance DC motor	—		Good-sleep cooling operation	—	
Comfortable Airflow	Power-airflow flap (horizontal blade)	—	Worry Free (Reliability & Durability)	WEEKLY TIMER operation	●★2	
	Power-airflow dual flaps	—		24-hour ON/OFF TIMER	—	
	Power-airflow diffuser	—		72-hour ON/OFF TIMER	●★1	
	Wide-angle louvers (vertical blades)	—		NIGHT SET mode	—	
	Auto-swing (up and down)	●	Flexibility	Auto-restart (after power failure)	●	
	Auto-swing (right and left)	—		Self-diagnosis (R/C, LED)	●	
	3-D airflow	—		Wiring error check function	—	
	COMFORT AIRFLOW operation	—		Anti-corrosion treatment of outdoor heat exchanger	—	
Comfort Control	Auto fan speed	—	Flexibility	Multi-split / split type compatible indoor unit	—	
	Indoor unit quiet operation	—		Flexible power supply correspondence	—	
	NIGHT QUIET mode (automatic)	—		High ceiling application	—	
	OUTDOOR UNIT QUIET operation (manual)	—		Chargeless	—	
	INTELLIGENT EYE operation	—		Either side drain (right or left)	—	
	Quick warming function	—		Power selection	—	
	Hot-start function	●		°F/°C changeover R/C temperature display (factory setting: °F)	●★2	
	Automatic defrosting	—				
Operation	Automatic operation	●	Remote Control	5-room centralized controller (option)	—	
	Program dry function	●		Remote control adaptor (normal open pulse contact) (option)	—	
	Fan only	●		Remote control adaptor (normal open contact) (option)	—	
Lifestyle Convenience	New POWERFUL operation (non-inverter)	—	Remote Control	DIII-NET compatible (adaptor) (option)	●	
	Inverter POWERFUL operation	—		Remote Controller	Wireless (option)	●
	Priority-room setting	—			Wired (option)	●
	COOL/HEAT mode lock	—				
	HOME LEAVE operation	—				
	ECONO operation	—				
	Indoor unit ON/OFF button	●★1				
	Signal receiving sign	●★1				
	R/C with back light	●★2				
	Temperature display	—				

Note: ● : Available
— : Not available

★1: With wireless remote controller
★2: With wired remote controller

Category	Functions	2MXL18QM VJU	3MXL24QM VJU	Category	Functions	2MXL18QM VJU	3MXL24QM VJU
Basic Functions	Inverter (with inverter power control)	●	●	Health & Cleanliness	Air-purifying filter	—	—
	Operation limit for cooling (°CDB)	-10 ~ 46	-10 ~ 46		Photocatalytic deodorizing filter	—	—
	Operation limit for cooling (°FDB)	14 ~ 114.8	14 ~ 114.8		Air-purifying filter with photocatalytic deodorizing function	—	—
	Operation limit for heating (°CWB)	-25 ~ 15.6	-25 ~ 15.6		Titanium apatite photocatalytic air-purifying filter	—	—
	Operation limit for heating (°FWB)	-13~ 60	-13~ 60		Longlife filter (option)	—	—
	PAM control	●	●		Air filter (prefilter)	—	—
	Standby electricity saving	—	—		Wipe-clean flat panel	—	—
Compressor	Oval scroll compressor	—	—	Timer	Washable grille	—	—
	Swing compressor	●	●		Washable grille	—	—
	Rotary compressor	—	—		Filter cleaning indicator	—	—
	Reluctance DC motor	●	●		Good-sleep cooling operation	—	—
Comfortable Airflow	Power-airflow flap (horizontal blade)	—	—	Worry Free (Reliability & Durability)	WEEKLY TIMER operation	—	—
	Power-airflow dual flaps	—	—		24-hour ON/OFF timer	—	—
	Power-airflow diffuser	—	—		NIGHT SET mode	—	—
	Wide-angle louvers (vertical blades)	—	—	Flexibility	Auto-restart (after power failure)	—	—
	Auto-swing (up and down)	—	—		Self-diagnosis (R/C, LED)	●	●
	Auto-swing (right and left)	—	—		Wiring error check function	●	●
	3-D airflow	—	—		Anti-corrosion treatment of outdoor heat exchanger	●	●
COMFORT AIRFLOW operation	—	—	Remote Control	Multi-split / split type compatible indoor unit	—	—	
Comfort Control	Auto fan speed	—		—	Flexible power supply correspondence	—	—
	Indoor unit quiet operation	—		—	High ceiling application	—	—
	NIGHT QUIET mode (automatic)	●		●	Chargeless	98.4 ft (30 m)	131.2 ft (40 m)
	OUTDOOR UNIT QUIET operation (manual)	●		●	Either side drain (right or left)	—	—
	INTELLIGENT EYE operation	—		—	Power selection	—	—
	Quick warming function	●		●	°F/°C changeover R/C temperature display (factory setting: °F)	—	—
	Hot-start function	—		—	Remote Control	5-room centralized controller (option)	—
	Automatic defrosting	●	●	Remote control adaptor (normal open pulse contact) (option)		—	—
Operation	Automatic operation	—	—	Remote control adaptor (normal open contact) (option)		—	—
	Program dry function	—	—	DIII-NET compatible (adaptor) (option)	—	—	
	Fan only	—	—	Remote Controller	Wireless	—	—
Lifestyle Convenience	New POWERFUL operation (non-inverter)	—	—		Wired (option)	—	—
	Inverter POWERFUL operation	—	—				
	Priority-room setting	●	●				
	COOL/HEAT mode lock	●	●				
	HOME LEAVE operation	—	—				
	ECONO operation	—	—				
	Indoor unit ON/OFF button	—	—				
	Signal receiving sign	—	—				
R/C with back light	—	—					
Temperature display	—	—					

Note: ● : Available
 — : Not available

Part 2 Specifications

1. Indoor Unit.....	8
2. Outdoor Unit.....	13

1. Indoor Unit

60 Hz, 208 - 230 V

Model			CTXS07LVJU			
			Cooling		Heating	
Rated Capacity			7 kBtu/h Class			
Front Panel Color			White			
Airflow Rate	H	cfm (m ³ /min)	332 (9.4)		350 (9.9)	
	M		261 (7.4)		290 (8.2)	
	L		194 (5.5)		233 (6.6)	
	SL		145 (4.1)		219 (6.2)	
Fan	Type		Cross Flow Fan			
	Motor Output	W	23			
	Speed	Steps	5 Steps, Quiet, Auto			
Air Direction Control			Right, Left, Horizontal, Downward			
Air Filter			Removable, Washable, Mildew Proof			
Running Current (Rated)		A	0.09 - 0.08		0.11 - 0.10	
Power Consumption (Rated)		W	18 - 18		21 - 21	
Power Factor (Rated)		%	96.2 - 97.8		91.8 - 91.3	
Temperature Control			Microcomputer Control			
Dimensions (H x W x D)		in. (mm)	11-5/8 x 31-1/2 x 8-7/16 (295 x 800 x 215)			
Packaged Dimensions (H x W x D)		in. (mm)	10-13/16 x 34-1/4 x 14-7/16 (274 x 870 x 366)			
Weight (Mass)		Lbs (kg)	20 (9)			
Gross Weight (Gross Mass)		Lbs (kg)	29 (13)			
Sound Pressure Level	H / M / L / SL	dB(A)	38 / 32 / 25 / 22		38 / 33 / 28 / 25	
Sound Power Level		dB	54		54	
Heat Insulation			Both Liquid and Gas Pipes			
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)			
	Gas	in. (mm)	φ 3/8 (φ 9.5)			
	Drain	in. (mm)	φ 5/8 (φ 16.0)			
Drawing No.			3D075490			

Model			FTXS09LVJU		FTXS12LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			9 kBtu/h Class		12 kBtu/h Class	
Front Panel Color			White			
Airflow Rate	H	cfm (m ³ /min)	381 (10.8)		403 (11.4)	
	M		279 (7.9)		307 (8.7)	
	L		194 (5.5)		205 (5.8)	
	SL		145 (4.1)		155 (4.4)	
Fan	Type		Cross Flow Fan		Cross Flow Fan	
	Motor Output	W	23		23	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable, Washable, Mildew Proof		Removable, Washable, Mildew Proof	
Running Current (Rated)		A	0.09 - 0.08		0.13 - 0.12	
Power Consumption (Rated)		W	18 - 18		26 - 26	
Power Factor (Rated)		%	96.2 - 97.8		96.2 - 94.2	
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H x W x D)		in. (mm)	11-5/8 x 31-1/2 x 8-7/16 (295 x 800 x 215)		11-5/8 x 31-1/2 x 8-7/16 (295 x 800 x 215)	
Packaged Dimensions (H x W x D)		in. (mm)	10-13/16 x 34-1/4 x 14-7/16 (274 x 870 x 366)		10-13/16 x 34-1/4 x 14-7/16 (274 x 870 x 366)	
Weight (Mass)		Lbs (kg)	20 (9)		22 (10)	
Gross Weight (Gross Mass)		Lbs (kg)	29 (13)		31 (14)	
Sound Pressure Level	H / M / L / SL	dB(A)	41 / 33 / 25 / 22		45 / 37 / 29 / 23	
Sound Power Level		dB	57		61	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 3/8 (φ 9.5)		φ 3/8 (φ 9.5)	
	Drain	in. (mm)	φ 5/8 (φ 16.0)		φ 5/8 (φ 16.0)	
Drawing No.			3D075491		3D075492	

Conversion Formulae

kcal/h = kW × 860
 Btu/h = kW × 3412
 cfm = m³/min × 35.3

60 Hz, 208 - 230 V

Model			FTXS15LVJU		FTXS18LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			15 kBtu/h Class		18 kBtu/h Class	
Front Panel Color			White		White	
Airflow Rate	H	cfm (m ³ /min)	568 (16.1)	593 (16.8)	583 (16.5)	625 (17.7)
	M		477 (13.5)	505 (14.3)	484 (13.7)	526 (14.9)
	L		385 (10.9)	417 (11.8)	385 (10.9)	431 (12.2)
	SL		360 (10.2)	371 (10.5)	360 (10.2)	399 (11.3)
Fan	Type		Cross Flow Fan		Cross Flow Fan	
	Motor Output	W	48		48	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable, Washable, Mildew Proof		Removable, Washable, Mildew Proof	
Running Current (Rated)		A	0.31 - 0.29	0.31 - 0.29	0.32 - 0.30	0.32 - 0.30
Power Consumption (Rated)		W	38 - 38	38 - 38	38 - 38	38 - 38
Power Factor (Rated)		%	58.9 - 57.0	58.9 - 57.0	57.1 - 55.1	57.1 - 55.1
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H x W x D)		in. (mm)	13-3/8 x 41-5/16 x 9-3/4 (340 x 1,050 x 248)		13-3/8 x 41-5/16 x 9-3/4 (340 x 1,050 x 248)	
Packaged Dimensions (H x W x D)		in. (mm)	13 x 45-11/16 x 16-7/8 (331 x 1,160 x 429)		13 x 45-11/16 x 16-7/8 (331 x 1,160 x 429)	
Weight (Mass)		Lbs (kg)	31 (14)		31 (14)	
Gross Weight (Gross Mass)		Lbs (kg)	44 (20)		44 (20)	
Sound Pressure Level	H / M / L / SL	dB(A)	45 / 40 / 35 / 32	43 / 38 / 33 / 30	46 / 41 / 36 / 33	45 / 40 / 35 / 32
Sound Power Level		dB	61	59	62	61
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 1/2 (φ 12.7)		φ 1/2 (φ 12.7)	
	Drain	in. (mm)	φ 5/8 (φ 16.0)		φ 5/8 (φ 16.0)	
Drawing No.			3D075043		3D075044	

Model			FDXS09LVJU		FDXS12LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			9 kBtu/h Class		12 kBtu/h Class	
External Static Pressure		inAq (Pa)	0.12 (30)		0.12 (30)	
Airflow Rate	H	cfm (m ³ /min)	305 (8.6)	305 (8.6)	305 (8.6)	305 (8.6)
	M		280 (7.9)	280 (7.9)	280 (7.9)	280 (7.9)
	L		260 (7.4)	260 (7.4)	260 (7.4)	260 (7.4)
	SL		235 (6.7)	235 (6.7)	235 (6.7)	235 (6.7)
Fan	Type		Sirocco Fan		Sirocco Fan	
	Motor Output	W	62		62	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Filter			Removable, Washable, Mildew Proof		Removable, Washable, Mildew Proof	
Running Current (Rated)		A	0.58 - 0.52	0.58 - 0.52	0.58 - 0.52	0.58 - 0.52
Power Consumption (Rated)		W	72 - 72	72 - 72	72 - 72	72 - 72
Power Factor (Rated)		%	59.7 - 60.2	59.7 - 60.2	59.7 - 60.2	59.7 - 60.2
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H x W x D)		in. (mm)	7-7/8 x 27-9/16 x 24-7/16 (200 x 700 x 620)		7-7/8 x 27-9/16 x 24-7/16 (200 x 700 x 620)	
Packaged Dimensions (H x W x D)		in. (mm)	10-13/16 x 36-5/16 x 30-1/4 (274 x 923 x 768)		10-13/16 x 36-5/16 x 30-1/4 (274 x 923 x 768)	
Weight (Mass)		Lbs (kg)	47 (21)		47 (21)	
Gross Weight (Gross Mass)		Lbs (kg)	64 (29)		64 (29)	
Sound Pressure Level	H / M / L	dB(A)	35 / 33 / 31	35 / 33 / 31	35 / 33 / 31	35 / 33 / 31
Sound Power Level		dB	51	51	51	51
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 3/8 (φ 9.5)		φ 3/8 (φ 9.5)	
	Drain	in. (mm)	φ 25/32 (φ 20)		φ 25/32 (φ 20)	
Drawing No.			3D075493		3D075494	

Conversion Formulae
kcal/h = kW x 860
Btu/h = kW x 3412
cfm = m ³ /min x 35.3

60 Hz, 208 - 230 V

Model			CDXS15LVJU		CDXS18LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			15 kBtu/h Class		18 kBtu/h Class	
External Static Pressure			0.16 (40)		0.16 (40)	
Airflow Rate	H	cfm (m³/min)	424 (12.0)	424 (12.0)	424 (12.0)	424 (12.0)
	M		388 (11.0)	388 (11.0)	388 (11.0)	388 (11.0)
	L		353 (10.0)	353 (10.0)	353 (10.0)	353 (10.0)
	SL		297 (8.4)	297 (8.4)	297 (8.4)	297 (8.4)
Fan	Type		Sirocco Fan		Sirocco Fan	
	Motor Output	W	130		130	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Filter			Removable, Washable, Mildew Proof		Removable, Washable, Mildew Proof	
Running Current (Rated)			0.79	0.79	0.79	0.79
Power Consumption (Rated)			172	172	172	172
Power Factor (Rated)			94.4	94.4	94.4	94.4
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H x W x D)			7-7/8 x 35-7/16 x 24-7/16 (200 x 900 x 620)		7-7/8 x 35-7/16 x 24-7/16 (200 x 900 x 620)	
Packaged Dimensions (H x W x D)			10-1/2 x 43-9/16 x 29-9/16 (266 x 1,106 x 751)		10-1/2 x 43-9/16 x 29-9/16 (266 x 1,106 x 751)	
Weight (Mass)			60 (27)		60 (27)	
Gross Weight (Gross Mass)			75 (34)		75 (34)	
Sound Pressure Level	H / M / L / SL	dB(A)	37 / 35 / 33 / 31	37 / 35 / 33 / 31	37 / 35 / 33 / 31	37 / 35 / 33 / 31
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 1/2 (φ 12.7)		φ 1/2 (φ 12.7)	
	Drain	in. (mm)	VP20 (O.D. φ 1-1/32 (φ 26), I.D. φ 25/32 (φ 20))		VP20 (O.D. φ 1-1/32 (φ 26), I.D. φ 25/32 (φ 20))	
Drawing No.			C: 3D075721		C: 3D075722	

Model			FVXS09NVJU		FVXS12NVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			9 kBtu/h Class		12 kBtu/h Class	
Front Panel Color			White		White	
Airflow Rate	H	cfm (m³/min)	290 (8.2)	311 (8.8)	300 (8.5)	332 (9.4)
	M		230 (6.5)	244 (6.9)	237 (6.7)	258 (7.3)
	L		169 (4.8)	177 (5.0)	173 (4.9)	184 (5.2)
	SL		145 (4.1)	155 (4.4)	159 (4.5)	166 (4.7)
Fan	Type		Turbo Fan		Turbo Fan	
	Motor Output	W	12.3		13.4	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable, Washable, Mildew Proof		Removable, Washable, Mildew Proof	
Running Current (Rated)			—	—	—	—
Power Consumption (Rated)			—	—	—	—
Power Factor (Rated)			—	—	—	—
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H x W x D)			23-5/8 x 27-9/16 x 8-1/4 (600 x 700 x 210)		23-5/8 x 27-9/16 x 8-1/4 (600 x 700 x 210)	
Packaged Dimensions (H x W x D)			27-3/8 x 30-15/16 x 11 (695 x 786 x 279)		27-3/8 x 30-15/16 x 11 (695 x 786 x 279)	
Weight (Mass)			31 (14)		31 (14)	
Gross Weight (Gross Mass)			40 (18)		40 (18)	
Sound Pressure Level	H / M / L / SL	dB(A)	38 / 32 / 26 / 23	38 / 32 / 26 / 23	39 / 33 / 27 / 24	39 / 33 / 27 / 24
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 3/8 (φ 9.5)		φ 3/8 (φ 9.5)	
	Drain	in. (mm)	φ 13/16 (φ 20.0)		φ 13/16 (φ 20.0)	
Drawing No.			3D101722		3D101724	

Conversion Formulae
 kcal/h = kW x 860
 Btu/h = kW x 3412
 cfm = m³/min x 35.3

60 Hz, 208 - 230 V

Model			FVXS15NVJU		FVXS18NVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			15 kBtu/h Class		18 kBtu/h Class	
Front Panel Color			White		White	
Airflow Rate	H	cfm (m ³ /min)	378 (10.7)	417 (11.8)	378 (10.7)	417 (11.8)
	M		325 (9.2)	357 (10.1)	325 (9.2)	357 (10.1)
	L		275 (7.8)	300 (8.5)	275 (7.8)	300 (8.5)
	SL		233 (6.6)	251 (7.1)	233 (6.6)	251 (7.1)
Fan	Type		Turbo Fan		Turbo Fan	
	Motor Output	W	23.3		23.3	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable, Washable, Mildew Proof		Removable, Washable, Mildew Proof	
Running Current (Rated)	A		—	—	—	—
Power Consumption (Rated)	W		—	—	—	—
Power Factor (Rated)	%		—	—	—	—
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H × W × D)	in. (mm)		23-5/8 × 27-9/16 × 8-1/4 (600 × 700 × 210)		23-5/8 × 27-9/16 × 8-1/4 (600 × 700 × 210)	
Packaged Dimensions (H × W × D)	in. (mm)		27-3/8 × 30-15/16 × 11 (695 × 786 × 279)		27-3/8 × 30-15/16 × 11 (695 × 786 × 279)	
Weight (Mass)	Lbs (kg)		31 (14)		31 (14)	
Gross Weight (Gross Mass)	Lbs (kg)		40 (18)		40 (18)	
Sound Pressure Level	H / M / L / SL	dB(A)	44 / 40 / 36 / 32	45 / 40 / 36 / 32	44 / 40 / 36 / 32	45 / 40 / 36 / 32
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 1/2 (φ 12.7)		φ 1/2 (φ 12.7)	
	Drain	in. (mm)	φ 13/16 (φ 20.0)		φ 13/16 (φ 20.0)	
Drawing No.			3D101718		3D094866	

Model			FFQ09LVJU		FFQ12LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			9 kBtu/h Class		12 kBtu/h Class	
Decoration Panel	Model		BYFQ60B3W1		BYFQ60B3W1	
	Color		White		White	
	Dimensions (H × W × D)		2-5/32 × 27-9/16 × 27-9/16 (55 × 700 × 700)		2-5/32 × 27-9/16 × 27-9/16 (55 × 700 × 700)	
	Weight (Mass)	Lbs (kg)	6 (2.7)		6 (2.7)	
Airflow Rate	H	cfm (m ³ /min)	318 (9.0)	318 (9.0)	353 (10.0)	353 (10.0)
	L		230 (6.5)	230 (6.5)	230 (6.5)	230 (6.5)
Fan	Type		Turbo Fan		Turbo Fan	
	Motor Output	W	55		55	
	Speed	Steps	2 Steps		2 Steps	
Air Direction Control			Horizontal, Downward		Horizontal, Downward	
Running Current (Rated)	A		0.44	0.38	0.47	0.42
Power Consumption (Rated)	W		87	76	98	89
Power Factor	%		85.8	87.0	91.3	91.8
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H × W × D)	in. (mm)		11-1/4 × 22-5/8 × 22-5/8 (285 × 575 × 575)		11-1/4 × 22-5/8 × 22-5/8 (285 × 575 × 575)	
Packaged Dimensions (H × W × D)	in. (mm)		14-9/16 × 27-1/16 × 26-9/16 (370 × 687 × 674)		14-9/16 × 27-1/16 × 26-9/16 (370 × 687 × 674)	
Weight (Mass)	Lbs (kg)		38.6 (17.5)		38.6 (17.5)	
Gross Weight (Gross Mass)	Lbs (kg)		46 (21)		46 (21)	
Sound Pressure Level	H / L	dB(A)	36.0 / 29.5	36.0 / 29.5	38.5 / 29.0	38.5 / 29.0
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 3/8 (φ 9.5)		φ 3/8 (φ 9.5)	
	Drain	in. (mm)	VP20 (O.D. φ 1-1/32 (φ 26) / I.D. φ 25/32 (φ 20))		VP20 (O.D. φ 1-1/32 (φ 26) / I.D. φ 25/32 (φ 20))	
Drawing No.			3D080626A		3D080627A	

Conversion Formulae
kcal/h = kW × 860
Btu/h = kW × 3412
cfm = m ³ /min × 35.3

60 Hz, 208 - 230 V

Model			FFQ15LVJU		FFQ18LVJU	
			Cooling	Heating	Cooling	Heating
Rated Capacity			15 kBtu/h Class		18 kBtu/h Class	
Decoration Panel	Model		BYFQ60B3W1		BYFQ60B3W1	
	Color		White		White	
	Dimensions (H x W x D)		2-5/32 x 27-9/16 x 27-9/16 (55 x 700 x 700)		2-5/32 x 27-9/16 x 27-9/16 (55 x 700 x 700)	
	Weight (Mass)	Lbs (kg)	6 (2.7)		6 (2.7)	
Airflow Rate	H	cfm	424 (12.0)	424 (12.0)	530 (15.0)	530 (15.0)
	L	(m³/min)	283 (8.0)	283 (8.0)	353 (10.0)	353 (10.0)
Fan	Type		Turbo Fan		Turbo Fan	
	Motor Output	W	55		55	
	Speed	Steps	2 Steps		2 Steps	
Air Direction Control			Horizontal, Downward		Horizontal, Downward	
Running Current (Rated)	A	0.57	0.52	0.71	0.65	
Power Consumption (Rated)	W	112	103	140	130	
Power Factor	%	86.1	86.0	85.5	86.2	
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (H x W x D)	in. (mm)	11-1/4 x 22-5/8 x 22-5/8 (285 x 575 x 575)		11-1/4 x 22-5/8 x 22-5/8 (285 x 575 x 575)		
Packaged Dimensions (H x W x D)	in. (mm)	14-9/16 x 27-1/16 x 26-9/16 (370 x 687 x 674)		14-9/16 x 27-1/16 x 26-9/16 (370 x 687 x 674)		
Weight (Mass)	Lbs (kg)	38.6 (17.5)		38.6 (17.5)		
Gross Weight (Gross Mass)	Lbs (kg)	46 (21)		46 (21)		
Sound Pressure Level	H / L	dB(A)	42.5 / 31.5	42.5 / 31.5	46.0 / 37.5	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connections	Liquid	in. (mm)	φ 1/4 (φ 6.4)		φ 1/4 (φ 6.4)	
	Gas	in. (mm)	φ 1/2 (φ 12.7)		φ 1/2 (φ 12.7)	
	Drain	in. (mm)	VP20 (O.D. φ 1-1/32 (φ 26) / I.D. φ 25/32 (φ 20)		VP20 (O.D. φ 1-1/32 (φ 26) / I.D. φ 25/32 (φ 20)	
Drawing No.			3D080628A		3D080629A	

Conversion Formulae
kcal/h = kW × 860
Btu/h = kW × 3412
cfm = m³/min × 35.3

2. Outdoor Unit

60 Hz, 208 - 230 V

Model		2MXL18QMVJU			
		Cooling	Heating		
COP ★	W/W	—	4.20		
EER ★	Btu/h-W	12.7	—		
SEER / HSPF		17.0	10.3		
Casing Color		Ivory White			
Compressor	Type	Hermetically Sealed Swing Type			
	Model	2YC63AAXD			
	Motor Output	W	1,920		
Refrigerant Oil	Model	FVC50K			
	Charge	oz (L)	29.7 (0.9)		
Refrigerant	Type	R-410A			
	Charge	Lbs (kg)	6.17 (2.8)		
Airflow Rate	H	cfm	2,150	1,963	
			M	2,150	1,963
			L	1,949	1,006
	H	m³/min	60.9	55.6	
			M	60.9	55.6
			L	55.2	28.5
Fan	Type	Propeller			
	Motor Output	W	51		
	Running Current	A	H: 0.32 / M: 0.32 / L: 0.27		
	Power Consumption	W	H: 62 / M: 62 / L: 54		
Starting Current	A	15.5			
Dimension (H × W × D)	in. (mm)	28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320)			
Packaged Dimension (H × W × D)	in. (mm)	31-7/8 × 41-3/8 × 17-1/2 (810 × 1,050 × 444)			
Weight (Mass)	Lbs (kg)	139 (63)			
Gross Weight (Gross Mass)	Lbs (kg)	155 (71)			
Sound Pressure Level	dB(A)	50	51		
Piping Connections	Liquid	in. (mm)	φ 1/4 × 2 (φ 6.4 × 2)		
	Gas	in. (mm)	φ 3/8 × 1, φ 1/2 × 1 (φ 9.5 × 1, φ 12.7 × 1)		
	Drain	in. (mm)	φ 5/8 (φ 15.9)		
Heat Insulation		Both Liquid and Gas Pipes			
No. of Wiring Connections		3 for Power Supply, 4 for Interunit Wiring (Including Ground Wiring)			
Max. Interunit Piping Length	ft (m)	164 (50) (for Total of Each Room)			
		82 (25) (for One Room)			
Amount of Additional Charge of Refrigerant	oz/ft (g/m)	0.21 (20) (98-7/16 ft (30 m) or more)			
Max. Installation Height Difference	ft (m)	49-1/4 (15) (between Indoor Unit and Outdoor Unit)			
		24-5/8 (7.5) (between Indoor Units)			
Drawing No.		C: 3D101750			

- Notes:**
- ★ Max.: for the combination of CTXS, FTXS series indoor units
Min.: for the combination of CDXS, FDXS series indoor units
 - The data are based on the conditions shown in the table below.

Cooling	Indoor ; 80°FDB (26.7°CDB) / 67°FWB (19.4°CWB) Outdoor ; 95°FDB (35°CDB) / 75°FWB (24°CWB)
Heating	Indoor ; 70°FDB (21°CDB) / 60°FWB (15.6°CWB) Outdoor ; 47°FDB (8.3°CDB) / 43°FWB (6°CWB)
Piping Length	24-5/8 ft (7.5 m)

Conversion Formulae
kcal/h = kW × 860
Btu/h = kW × 3412
cfm = m³/min × 35.3

60 Hz, 208 - 230 V

Model		3MXL24QMVJU		
		Cooling	Heating	
COP ★	W/W	—	4.56	
EER ★	Btu/h-W	12.7	—	
SEER / HSPF		17.9	12.5	
Casing Color		Ivory White		
Compressor	Type	Hermetically Sealed Swing Type		
	Model	2YC63AAXD		
	Motor Output	W	1,920	
Refrigerant Oil	Model	FVC50K		
	Charge	oz (L)	29.7 (0.9)	
Refrigerant	Type	R-410A		
	Charge	Lbs (kg)	6.17 (2.8)	
Airflow Rate	H	cfm	2,094	1,886
	M		2,094	1,780
	L		1,977	1,006
	H	m³/min	59.3	53.4
	M		59.3	50.4
	L		56.0	28.5
Fan	Type	Propeller		
	Motor Output	W	58	
	Running Current	A	H: 0.38 / M: 0.38 / L: 0.33	H: 0.38 / M: 0.33 / L: 0.07
	Power Consumption	W	H: 75 / M: 75 / L: 65	H: 75 / M: 65 / L: 14
Starting Current	A	17.5		
Dimension (H × W × D)	in. (mm)	28-15/16 × 34-1/4 × 12-5/8 (735 × 870 × 320)		
Packaged Dimension (H × W × D)	in. (mm)	31-7/8 × 41-3/8 × 17-1/2 (810 × 1,050 × 444)		
Weight (Mass)	Lbs (kg)	140 (63)		
Gross Weight (Gross Mass)	Lbs (kg)	156 (71)		
Sound Pressure Level	dB(A)	52	54	
Piping Connections	Liquid	in. (mm)	φ 1/4 × 3 (φ 6.4 × 3)	
	Gas	in. (mm)	φ 3/8 × 1, φ 1/2 × 2 (φ 9.5 × 1, φ 12.7 × 2)	
	Drain	in. (mm)	φ 5/8 (φ 15.9)	
Heat Insulation		Both Liquid and Gas Pipes		
No. of Wiring Connections		3 for Power Supply, 4 for Interunit Wiring (Including Ground Wiring)		
Max. Interunit Piping Length	ft (m)	230 (70) (for Total of Each Room)		
		82 (25) (for One Room)		
Amount of Additional Charge of Refrigerant	oz/ft (g/m)	0.21 (20) (131-1/4 ft (40 m) or more)		
Max. Installation Height Difference	ft (m)	49-1/4 (15) (between Indoor Unit and Outdoor Unit)		
		24-5/8 (7.5) (between Indoor Units)		
Drawing No.		C: 3D101754		

- Notes:**
- ★ Max.: for the combination of CTXS, FTXS series indoor units
Min.: for the combination of CDXS, FDXS series indoor units
 - The data are based on the conditions shown in the table below.

Cooling	Indoor ; 80°FDB (26.7°CDB) / 67°FWB (19.4°CWB) Outdoor ; 95°FDB (35°CDB) / 75°FWB (24°CWB)
Heating	Indoor ; 70°FDB (21°CDB) / 60°FWB (15.6°CWB) Outdoor ; 47°FDB (8.3°CDB) / 43°FWB (6°CWB)
Piping Length	24-5/8 ft (7.5 m)

Conversion Formulae
kcal/h = kW × 860
Btu/h = kW × 3412
cfm = m³/min × 35.3

Part 3

Printed Circuit Board

Connector Wiring Diagram


1. Indoor Unit.....	16
1.1 CTXS07LVJU, FTXS09/12LVJU	16
1.2 FTXS15/18LVJU	18
1.3 FDXS09/12LVJU, CDXS15/18LVJU	20
1.4 FVXS09/12/15/18NVJU.....	22
1.5 FFQ09/12/15/18LVJU	24
2. Wired Remote Controller.....	25
2.1 BRC1E71	25
2.2 BRC1E72/73	26
3. Wireless Remote Controller	27
3.1 BRC7E830	27
4. Outdoor Unit.....	28

1. Indoor Unit

1.1 CTXS07LVJU, FTXS09/12LVJU


Control PCB (PCB1)

- | | |
|--------------------------|--|
| 1) S1 | Connector for DC fan motor |
| 2) S21 | Connector for centralized control (HA) |
| 3) S25 | Connector for INTELLIGENT EYE sensor PCB |
| 4) S32 | Indoor heat exchanger thermistor |
| 5) S41 | Connector for swing motors |
| 6) S46 | Connector for display PCB |
| 7) S47 | Connector for signal receiver PCB |
| 8) H1, H2, H3, FG | Connector for terminal board |
| 9) JA | Address setting jumper |
| | * Refer to page 187 for detail. |
| 10) JB | Fan speed setting when compressor stops for thermostat OFF |
| | * Refer to page 189 for detail. |
| 11) JC | Power failure recovery function (auto-restart) |
| | * Refer to page 189 for detail. |
| 12) LED A | LED for service monitor (green) |
| 13) FU1 (F1U), FU2 (F2U) | Fuse (3.15 A, 250 V) |
| 14) V1 | Varistor |



Signal Receiver PCB (PCB2)


- 1) S48 Connector for control PCB



3P210728-1

Display PCB (PCB3)


- 1) S49 Connector for control PCB
- 2) SW1 Forced cooling operation **ON/OFF** button
- 3) LED1 (H1P) LED for operation (green)
- 4) LED2 (H2P) LED for timer (yellow)
- 5) LED3 (H3P) LED for INTELLIGENT EYE (green)
- 6) RTH1 (R1T) Room temperature thermistor



3P210728-1

INTELLIGENT EYE Sensor PCB (PCB4)

- 1) S26 Connector for control PCB




3EB86013-1

Note: The symbols in the parenthesis are the names on the appropriate wiring diagram.

1.2 FTXS15/18LVJU

Control PCB (PCB1)

- | | |
|--------------------|---|
| 1) S1 | Connector for DC fan motor |
| 2) S21 | Connector for centralized control (HA) |
| 3) S25 | Connector for INTELLIGENT EYE sensor PCB |
| 4) S32 | Indoor heat exchanger thermistor |
| 5) S41 | Connector for swing motors |
| 6) S46 | Connector for display PCB |
| 7) S47 | Connector for signal receiver PCB |
| 8) H1, H2, H3, FG | Connector for terminal board |
| 9) JA | Address setting jumper
* Refer to page 187 for detail. |
| 10) JB | Fan speed setting when compressor stops for thermostat OFF
* Refer to page 189 for detail. |
| 11) JC | Power failure recovery function (auto-restart)
* Refer to page 189 for detail. |
| 12) LED A | LED for service monitor (green) |
| 13) FU1 (F1U), FU2 | Fuse (3.15 A, 250 V) |
| 14) V1 | Varistor |



Caution

Replace the PCB if you accidentally cut a wrong jumper.

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.




Note:

The symbols in the parenthesis are the names on the appropriate wiring diagram.


Signal Receiver PCB (PCB2)

- 1) S48 Connector for control PCB




Display PCB (PCB3)

- 1) S49 Connector for control PCB
- 2) SW1 Forced cooling operation **ON/OFF** button
- 3) LED1 (H1P) LED for operation (green)
- 4) LED2 (H2P) LED for timer (yellow)
- 5) LED3 (H3P) LED for INTELLIGENT EYE (green)
- 6) RTH1 (R1T) Room temperature thermistor



INTELLIGENT EYE Sensor PCB (PCB4)

- 1) S36 Connector for control PCB




3P227885-1

i Note: The symbols in the parenthesis are the names on the appropriate wiring diagram.

1.3 FDXS09/12LVJU, CDXS15/18LVJU

Control PCB (A1P)

- | | |
|---------------|--|
| 1) S1 | Connector for AC fan motor |
| 2) S7 | Connector for AC fan motor (Hall IC) |
| 3) S21 | Connector for centralized control (HA) |
| 4) S26 | Connector for display PCB |
| 5) S32 | Connector for indoor heat exchanger thermistor |
| 6) H1, H2, H3 | Connector for terminal board |
| 7) FG (GND) | Connector for terminal board (ground) |
| 8) JA | Address setting jumper |
| | * Refer to page 187 for detail. |
| 9) JB | Fan speed setting when compressor stops for thermostat OFF |
| | * Refer to page 189 for detail. |
| 10) JC | Power failure recovery function (auto-restart) |
| | * Refer to page 189 for detail. |
| 11) LED A | LED for service monitor (green) |
| 12) FU1 (F1U) | Fuse (3.15 A, 250 V) |
| 13) V1 (V1TR) | Varistor |



Caution

Replace the PCB if you accidentally cut a wrong jumper.

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.




Note:

The symbols in the parenthesis are the names on the appropriate wiring diagram.

**Display PCB
(A2P)**

- | | |
|---------------|---|
| 1) S1 | Connector for control PCB |
| 2) SW1 (S1W) | Forced cooling operation ON/OFF button |
| 3) LED2 (H2P) | LED for timer (yellow) |
| 4) LED3 (H3P) | LED for operation (green) |
| 5) RTH1 (R1T) | Room temperature thermistor |



2P084375-1

★LED 1 does not function.




Note: The symbols in the parenthesis are the names on the appropriate wiring diagram.

1.4 FVXS09/12/15/18NVJU

Control PCB (PCB2)

- | | |
|--------------------|--|
| 1) S1 | Connector for fan motor |
| 2) S21 | Connector for centralized control (HA) |
| 3) S26 | Connector for service PCB |
| 4) S32 | Indoor heat exchanger thermistor |
| 5) S41 | Connector for lower air outlet motor |
| 6) S42 | Connector for swing motor |
| 7) S46 | Connector for display PCB |
| 8) S48 | Connector for sensor PCB |
| 9) H1, H2, H3 | Connector for terminal board |
| 10) E1 | Terminal for ground wire |
| 11) JA | Address setting jumper |
| | * Refer to page 187 for detail. |
| 12) JB | Fan speed setting when compressor stops for thermostat OFF |
| | * Refer to page 189 for detail. |
| 13) JC | Power failure recovery function |
| | * Refer to page 189 for detail. |
| 14) FU1 (F1U), FU2 | Fuse (3.15 A, 250 V) |
| 15) LED A | LED for service monitor (green) |
| 16) V1, V2 | Varistor |



2P383711-1



Caution

Replace the PCB if you accidentally cut a wrong jumper.

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.




Note:

The symbols in the parenthesis are the names on the appropriate wiring diagram.

Sensor PCB (PCB1)


- 1) S49 Connector for control PCB
- 2) RTH2 (R1T) Room temperature thermistor



3P191450-1

Service PCB (PCB3)


- 1) S27 Connector for control PCB
- 2) SW2 (S2W)-4 Switch for upward airflow limit setting
 - * Refer to page 189 for detail.
 - * Keep the other switches as factory setting.
- 3) SW4 (S4W) Switch for airflow selection
 - * Refer to page 36 for detail.



3P191448-1

Display PCB (PCB4)

- 1) S47 Connector for control PCB
- 2) SW1 (S1W) Forced cooling operation **ON/OFF** button
- 3) LED1 (H1P) LED for operation (green)
- 4) LED2 (H2P) LED for timer (yellow)



3P191447-1

★ LED3 does not function.




Note: The symbols in the parenthesis are the names on the appropriate wiring diagram.

1.5 FFQ09/12/15/18LVJU

Control PCB

- 1) X5A Connector for terminal board (for wired remote controller)
- 2) X10A, X11A Connector for transformer
- 3) X15A Connector for float switch
- 4) X17A, X18A Connector for indoor heat exchanger thermistor
- 5) X19A Connector for room temperature thermistor
- 6) X20A Connector for fan motor
- 7) X24A Connector for signal receiver PCB
(when the wireless remote controller is used)
- 8) X25A Connector for drain pump motor
- 9) X27A Connector for terminal board (for inter-unit wiring)
- 10) X33A Connector for wiring adaptor PCB (option)
- 11) X35A Connector for group control adaptor (option)
- 12) X36A Connector for swing motor
- 13) X40A Connector for ON/OFF input from outside (option)
- 14) HAP LED for service monitor (green)
- 15) SS1 Selector switch for emergency




2. Wired Remote Controller

2.1 BRC1E71

Wired Remote
Controller PCB

- 1) P1, P2 Terminal for indoor unit
- 2) R1T Room temperature thermistor




2P243326-3

2.2 BRC1E72/73

Wired Remote Controller PCB

- 1) P1, P2 Terminal for indoor unit
- 2) R1T Room temperature thermistor




2P298037-3
2P298037-7

3. Wireless Remote Controller

3.1 BRC7E830

Signal Receiver PCB


- | | |
|--------|--|
| 1) X1A | Connector for display PCB |
| 2) X2A | Connector for control PCB |
| 3) SS1 | MAIN/SUB setting switch
* Refer to page 194 for detail. |
| 4) SS2 | Address setting switch
* Refer to page 194 for detail. |



3P156326-3

Display PCB

- | | |
|---------------|---|
| 1) X1A | Connector for signal receiver PCB |
| 2) BS1 | Forced cooling operation ON/OFF button |
| 3) LED1 (H1P) | LED for operation (red) |
| 4) LED2 (H2P) | LED for timer (green) |
| 5) LED3 (H3P) | LED for filter cleaning sign (red) |
| 6) LED4 (H4P) | LED for defrost operation (orange) |



3P086209-1

★ LED5 and LED6 do not function.




Note: The symbols in the parenthesis are the names on the appropriate wiring diagram.

4. Outdoor Unit

Main PCB (PCB1)


1) S	Connector for terminal board (indoor - outdoor transmission)
2) S15	Connector for COOL/HEAT mode lock * Refer to page 184 for detail.
3) S20 (white)	Connector for electronic expansion valve coil A port
4) S21 (red)	Connector for electronic expansion valve coil B port
5) S22 (blue)	Connector for electronic expansion valve coil C port (24 class)
6) S40	Connector for overload protector
7) S70	Connector for DC fan motor
8) S80	Connector for four way valve coil
9) S90	Connector for thermistors (outdoor temperature, outdoor heat exchanger, discharge pipe)
10) S92	Connector for gas pipe thermistor
11) S93	Connector for liquid pipe thermistor
12) S201, S202	Connector for service monitor PCB
13) HL1, HN1	Connector for terminal board (power supply)
14) E1, E2	Connector for ground wire
15) U, V, W	Connector for compressor
16) FU1, FU2	Fuse (3.15 A, 250 V)
17) FU3	Fuse (30 A, 250 V)
18) V2, V3, V401	Varistor



2P350358-12

Service Monitor PCB (PCB2)

- | | |
|----------------|---|
| 1) S501, S502 | Connector for main PCB |
| 2) LED A | LED for service monitor (green) |
| 3) LED1 - LED5 | LED for service monitor (red) |
| 4) SW1 | Forced cooling operation ON/OFF switch
* Refer to page 176 for detail. |
| 5) SW2 | Operation mode switch
* Refer to page 176 for detail. |
| 6) SW3 | Wiring error check switch
* Refer to page 177 for detail. |
| 7) SW4 | Priority room setting switch
* Refer to page 183 for detail. |
| 8) SW6-1 | NIGHT QUIET mode setting switch
* Refer to page 184 for detail. |



3P346711-10

★ SW6-2 and all the switches of SW5 have no function. Keep them OFF.

Part 4

Functions and Control

1. Functions for CTXS, FTXS, CDXS, FDXS, FVXS Series	32
1.1 Temperature Control	32
1.2 Frequency Principle.....	32
1.3 Airflow Direction Control (CTXS, FTXS, FVXS Series).....	34
1.4 Fan Speed Control for Indoor Unit	37
1.5 Program Dry Operation	38
1.6 Automatic Operation.....	39
1.7 Thermostat Control.....	40
1.8 NIGHT SET Mode	41
1.9 ECONO Operation	41
1.10 INTELLIGENT EYE Operation (CTXS, FTXS Series).....	42
1.11 Inverter POWERFUL Operation	43
1.12 Clock Setting	44
1.13 WEEKLY TIMER Operation (CTXS, FTXS, FVXS Series).....	45
1.14 Other Functions.....	51
2. Functions for FFQ Series	52
2.1 Drain Pump Control.....	52
2.2 Thermostat Sensor in Remote Controller	54
2.3 Freeze Prevention Control	56
2.4 Hot Start Control (In Heating Operation Only).....	57
3. Control Specification	58
3.1 Thermistor Functions.....	58
3.2 Mode Hierarchy	60
3.3 Frequency Control.....	61
3.4 Controls at Mode Changing/Start-up.....	63
3.5 Discharge Pipe Temperature Control.....	64
3.6 Input Current Control.....	65
3.7 Freeze-up Protection Control	66
3.8 Heating Peak-cut Control	66
3.9 Outdoor Fan Control.....	67
3.10 Liquid Compression Protection Function.....	67
3.11 Defrost Control	68
3.12 Low Hz High Pressure Limit	69
3.13 Electronic Expansion Valve Control	70
3.14 Malfunctions	75


1. Functions for CTXS, FTXS, CDXS, FDXS, FVXS Series

1.1 Temperature Control

Definitions of Temperatures

The definitions of temperatures are classified as following.

- ◆ Room temperature: temperature of lower part of the room
- ◆ Set temperature: temperature set by remote controller
- ◆ Room thermistor temperature: temperature detected by room temperature thermistor
- ◆ Target temperature: temperature determined by microcomputer



★ The illustration is for CTXS, FTXS series as representative.

Temperature Control

The temperature of the room is detected by the room temperature thermistor. However, there is difference between the temperature detected by room temperature thermistor and the temperature of lower part of the room, depending on the type of the indoor unit or installation condition. Practically, the temperature control is done by the target temperature appropriately adjusted for the indoor unit and the temperature detected by room temperature thermistor.

1.2 Frequency Principle

Control Parameters

The frequency of the compressor is controlled by the following 2 parameters:

- The load condition of the operating indoor unit
- The difference between the room thermistor temperature and the target temperature

The target frequency is adapted by additional parameters in the following cases:


- Frequency restrictions
- Initial settings
- Forced cooling operation

Inverter Principle

To regulate the capacity, a frequency control is needed. The inverter makes it possible to control the rotation speed of the compressor. The following table explains the inverter principle:

Phase	Description
1	The supplied AC power source is converted into the DC power source for the present.
2	The DC power source is reconverted into the three phase AC power source with variable frequency. <ul style="list-style-type: none"> ■ When the frequency increases, the rotation speed of the compressor increases resulting in an increase of refrigerant circulation. This leads to a larger amount of heat exchange per unit. ■ When the frequency decreases, the rotation speed of the compressor decreases resulting in a decrease of refrigerant circulation. This leads to a smaller amount of heat exchange per unit.

The following drawing shows a schematic view of the inverter principle:



Inverter Features

The inverter provides the following features:

- The regulating capacity can be changed according to the changes in the outdoor temperature and cooling/heating load.
- Quick heating and quick cooling
The rotation speed of the compressor is increased when starting the heating (or cooling). This enables to reach the set temperature quickly.
- Even during extreme cold weather, high capacity is achieved. It is maintained even when the outdoor temperature is 2°C (35.6°F).
- Comfortable air conditioning
A fine adjustment is integrated to keep the room temperature constant.
- Energy saving heating and cooling
Once the set temperature is reached, the energy saving operation enables to maintain the room temperature at low power.

Frequency Limits

The following functions regulate the minimum and maximum frequency:

Frequency	Functions
Low	<ul style="list-style-type: none"> ■ Four way valve operation compensation. Refer to page 63.
High	<ul style="list-style-type: none"> ■ Compressor protection function. Refer to page 64. ■ Discharge pipe temperature control. Refer to page 64. ■ Input current control. Refer to page 65. ■ Freeze-up protection control. Refer to page 66. ■ Heating peak-cut control. Refer to page 66. ■ Defrost control. Refer to page 68.

Forced Cooling Operation

Refer to page 176 for detail.

1.3 Airflow Direction Control (CTXS, FTXS, FVXS Series)

Power-Airflow Dual Flaps

The large flap sends a large volume of air downward to the floor and provides an optimum control in cooling, dry, and heating operation.

Cooling / Dry

During cooling or dry operation, the flap retracts into the indoor unit. Then, cool air can be blown far and distributed all over the room.

Heating

During heating operation, the large flap directs airflow downward to spread the warm air to the entire room.









Wide-Angle Louvers

The louvers, made of elastic synthetic resin, provide a wide range of airflow that guarantees a comfortable air distribution.





Auto-Swing

The following table explains the auto-swing process for cooling, dry, heating, and fan:

CTXS, FTXS Series

	Flap (up and down)			Louver (right and left)
	Cooling / Dry	Heating	Fan	
07/09/12 class				
15/18 class				

FVXS Series

	Flap (up and down)	
	Cooling / Dry	Heating
Upward airflow limit OFF	 (R6831)	 (R6829)
Upward airflow limit ON	 (R6832)	 (R6830)


3-D Airflow

CTXS, FTXS Series

Alternative repetition of vertical and horizontal swing motions enables uniform air-conditioning of the entire room.

When the horizontal swing and vertical swing are both set to automatic operation, the airflow becomes 3-D airflow. The horizontal and vertical swing motions are alternated and the airflow direction changes in the order shown in the following diagram.





- (1) The louvers move from the right to the left.
- (2) The flaps move downward.
- (3) The louvers move from the left to the right.
- (4) The flaps move upward.



COMFORT AIRFLOW Operation

CTXS, FTXS Series

The flaps are controlled not to blow the air directly at the people in the room.



	Cooling	Heating
07/09/12 class	 (R4302)	 (R8413)
15/18 class	 (R9655)	 (R9654)

Airflow Selection Setting

FVXS Series

Airflow direction can be set with the airflow selection switch.

- Open the front panel.



(R17866)



Caution:

Before opening the front panel, be sure to stop the operation and turn the breaker off. Do not touch the aluminum fins (indoor heat exchanger) inside of the indoor unit, as it may result in injury.

When setting the airflow selection switch to

- The air conditioner automatically decides the appropriate blowing pattern depending on the operating mode/situation.

Operating mode	Situation	Blowing pattern
Cooling operation	When the room has become fully cool, or when 1 hour has passed since turning on the air conditioner.	Air is blown from the upper air outlet, so that air does not come into direct contact with people, and room temperature is equalized.
	At the start of operation or when the room is not fully cooled.	<p>(R17867)</p> <p>Air is blown from the upper and lower air outlets for high speed cooling during cooling operation, and for filling the room with warm air during heating operation.</p>
Heating operation	Normal time	
	At the start or when air temperature is low.	Air is blown from the upper air outlet, so that air does not come into direct contact with people.

- During dry operation, air is blown upper air outlet, so that cold air does not come into direct contact with people.

When setting the airflow selection switch to

- Regardless of the operating mode or situation, air is blown from the upper air outlet.
- Use this switch when you do not want air coming out of the lower air outlet (e.g., while sleeping).



1.4 Fan Speed Control for Indoor Unit


Outline

Phase control and fan speed control contains 9 steps: LLL, LL, SL, L, ML, M, MH, H, and HH. The airflow rate can be automatically controlled depending on the difference between the room thermistor temperature and the target temperature.

Automatic Fan Speed Control


In automatic fan speed control, the step SL is not available.

Step	Cooling	Heating
LLL	 (R11681)	 (R6834)
LL		
L		
ML		
M		
MH		
H		
HH (POWERFUL)		

 = The airflow rate is automatically controlled within this range when the **FAN** button is set to automatic.

Cooling

The following drawing explains the principle of fan speed control for cooling.



*The upper limit is M tap in 30 minutes from the operation start.

Heating

In heating operation, the fan speed is regulated according to the indoor heat exchanger temperature and the difference between the room thermistor temperature and the target temperature.



Note: The fan stops during defrost operation.

COMFORT AIRFLOW Operation

CTXS, FTXS Series

- The fan speed is controlled automatically within the following steps.

Cooling

L tap ~ MH tap (same as AUTOMATIC)

Heating


ML tap ~ MH tap

- The latest command has the priority between POWERFUL and COMFORT AIRFLOW.

1.5 Program Dry Operation

Outline Program dry operation removes humidity while preventing the room temperature from lowering. Since the microcomputer controls both the temperature and airflow rate, the temperature adjustment and **FAN** setting buttons are inoperable.

Detail The microcomputer automatically sets the temperature and airflow rate. The difference between the room thermistor temperature at start-up and the target temperature is divided into two zones. Then, the unit operates in an appropriate capacity for each zone to maintain the temperature and humidity at a comfortable level.



(R23000)

Room thermistor temperature at start-up	Target temperature X	Thermostat OFF point Y	Thermostat ON point Z ★
24°C or more (75.2°F or more)	Room thermistor temperature at start-up	X - 2.5°C (X - 4.5°F)	X - 0.5°C (X - 0.9°F)
18 ~ 23.5°C (64.4 ~ 74.3°F)		X - 2.0°C (X - 3.6°F)	X - 0.5°C (X - 0.9°F)
17.5°C or less (63.5°F or less)	18°C (64.4°F)	X - 2.0°C (X - 3.6°F)	X - 0.5°C = 17.5°C (X - 0.9°F = 63.5°F)

★ Thermostat turns on also when the room temperature is in the zone B for 10 minutes.

1.6 Automatic Operation

Outline

Automatic Cooling/Heating Function

When the automatic operation is selected with the remote controller, the microcomputer automatically determines the operation mode as cooling or heating according to the room temperature and the set temperature at start-up.


The unit automatically switches the operation mode to maintain the room temperature at the set temperature.

Detail

Ts: set temperature (set by remote controller)
 Tt: target temperature (determined by microcomputer)
 Tr: room thermistor temperature (detected by room temperature thermistor)
 C: correction value

- The set temperature (Ts) determines the target temperature (Tt).
 (Ts = 18 ~ 30°C, 64.4 ~ 86°F).
- The target temperature (Tt) is calculated as;
 $Tt = Ts + C$
 where C is the correction value.
 C = 0°C (0°F)
- Thermostat ON/OFF point and operation mode switching point are as follows.
 - Heating → Cooling switching point:
 $Tr \geq Tt + 3.0^\circ\text{C}$ (+5.4°F) (CTXS, FTXS series)
 $Tr \geq Tt + 2.5^\circ\text{C}$ (+4.5°F) (CDXS, FDXS, FVXS series)
 - Cooling → Heating switching point:
 $Tr < Tt - 3.0^\circ\text{C}$ (-5.4°F)
 - Thermostat ON/OFF point is the same as the ON/OFF point of cooling or heating operation.
- During initial operation
 $Tr \geq Ts$: Cooling operation
 $Tr < Ts$: Heating operation

CTXS, FTXS series




Ex: When the target temperature is 25°C (77°F)

Cooling → 23°C (73.4°F): Thermostat OFF → 22°C (71.6°F): Switch to heating

Heating → 27°C (80.6°F): Thermostat OFF → 28°C (82.4°F): Switch to cooling

CDXS, FDXS, FVXS series



Ex: When the target temperature is 25°C (77°F)

Cooling → 23°C (73.4°F): Thermostat OFF → 22°C (71.6°F): Switch to heating

Heating → 26.5°C (79.7°F): Thermostat OFF → 27.5°C (81.5°F): Switch to cooling

1.7 Thermostat Control

Outline

Thermostat control is based on the difference between the room thermistor temperature and the target temperature.

Detail


Thermostat OFF Condition

- The temperature difference is in the zone A.


Thermostat ON Condition

- The temperature difference returns to the zone C after being in the zone A.
- The system resumes from defrost control in any zones except A.
- The operation turns on in any zones except A.
- The monitoring time has passed while the temperature difference is in the zone B.
(Cooling / Dry: 10 minutes, Heating: 10 seconds)


Cooling / Dry



**Heating
CTXS, FTXS series**



CDXS, FDXS, FVXS series




Refer to Temperature Control on page 32 for detail.

1.8 NIGHT SET Mode

Outline When the OFF TIMER is set, NIGHT SET Mode is automatically activated. NIGHT SET Mode keeps the airflow rate setting.


Detail NIGHT SET Mode continues operation at the target temperature for the first one hour, then automatically raises the target temperature slightly in cooling, or lowers it slightly in heating. This prevents excessive cooling or heating to ensure comfortable sleeping conditions, and also conserves electricity.

Cooling



(R21924)

Heating




(R21925)

1.9 ECONO Operation

Outline ECONO operation reduces the maximum operating current and the power consumption. This operation is particularly convenient for energy-saving. It is also a major bonus when breaker capacity does not allow the use of multiple electrical devices and air conditioners. It can be easily activated by pushing the **ECONO** button on the wireless remote controller.

- Detail**
- When this function is activated, the maximum capacity also decreases.
 - The remote controller can send the ECONO command when the unit is in cooling, heating, dry, or automatic operation. This function can only be set when the unit is running. Press the **ON/OFF** button on the remote controller to cancel the function.
 - This function and POWERFUL operation cannot be used at the same time. The latest command has the priority.



(R22012)


1.10 INTELLIGENT EYE Operation (CTXS, FTXS Series)

Outline

This function detects the presence of humans in the room with a motion sensor and reduces the capacity when there is nobody in the room in order to save electricity.


Detail

1. INTELLIGENT EYE detection method



- The motion sensor detects human motion by receiving infrared rays and displays the pulse wave output.
- The microcomputer in the indoor unit carries out a sampling every 20 msec. and if the motion sensor detects 10 cycles of the wave in 1 second in total, the motion sensor judges humans are in the room as the human detection signal is ON.
- The motion sensor may detect human motion with up to 20 msec. latency.

2. Motions (in cooling)



- ★ In FAN operation, the fan speed is reduced by 60 rpm when no one is in the area.
- When the microcomputer does not have a signal from the motion sensor in 20 minutes, the motion sensor judges that nobody is in the room and operates the unit at a temperature shifted from the target temperature. (Cooling / Dry: 1 ~ 2°C (1.8 ~ 3.6°F) higher, Heating: 2°C (3.6°F) lower, Auto: according to the operation mode at that time.)



Note: For dry operation, the temperature cannot be set with a remote controller, but the target temperature is shifted internally.

1.11 Inverter POWERFUL Operation


Outline In order to exploit the cooling and heating capacity to full extent, the air conditioner can be operated by increasing the indoor fan rotating speed and the compressor frequency.

Detail When **POWERFUL** button is pressed, the fan speed and target temperature are converted to the following states for 20 minutes.

Operation mode	Fan speed	Target temperature
COOL	H tap + A rpm	18°C (64.4°F)
DRY	Dry rotating speed + A rpm	Lowered by 2 ~ 2.5°C (3.6 ~ 4.5°F)
HEAT	H tap + A rpm	30 ~ 31.5°C (86 ~ 88.7°F)
FAN	H tap + A rpm	—
AUTO	Same as cooling / heating in POWERFUL operation	The target temperature is kept unchanged.

A = 50 ~ 90 rpm (depending on the model)

Ex: POWERFUL operation in cooling



(R19193)


Note: POWERFUL operation cannot be used together with ECONO or COMFORT AIRFLOW operation.

1.12 Clock Setting

ARC452 Series ARC466 Series

The clock can be set by taking the following steps:

1. Press **CLOCK** button.
→ 0:00 is displayed and MON and ☉ blink.
2. Press **SELECT ▲** or **SELECT ▼** button to set the clock to the current day of the week.
3. Press **CLOCK** button.
→ ☉ blinks.
4. Press **SELECT ▲** or **SELECT ▼** button to adjust the clock to the present time.
Holding down **SELECT ▲** or **SELECT ▼** button increases or decreases the time display rapidly.
5. Press **CLOCK** button to set the clock. (Point the remote controller at the indoor unit when pressing the button.)
→ : blinks and clock setting is completed.



1.13 WEEKLY TIMER Operation (CTXS, FTXS, FVXS Series)

Outline


Up to 4 timer settings can be saved for each day of the week (up to 28 settings in total). The 3 items: ON/OFF, temperature, and time can be set.

Detail


★ The illustrations are for FVXS series as representative.

Setting example of the WEEKLY TIMER

The same timer settings are used from Monday through Friday, while different timer settings are used for the weekend.





- Up to 4 reservations per day and 28 reservations per week can be set using the WEEKLY TIMER. The effective use of the copy mode simplifies timer programming.
- The use of ON-ON-ON-ON settings, for example, makes it possible to schedule operating mode and set temperature changes. Furthermore, by using OFF-OFF-OFF-OFF settings, only the turn off time of each day can be set. This will turn off the air conditioner automatically if you forget to turn it off.



To use WEEKLY TIMER operation

Setting mode

- Make sure the day of the week and time are set.
If not, set the day of the week and time.




1. Press .

- The day of the week and the reservation number of the current day will be displayed.
- 1 to 4 settings can be made per day.

2. Press to select the desired day of the week and reservation number.

- Pressing  changes the reservation number and the day of the week.


3. Press .

- The day of the week and reservation number will be set.
- “ WEEKLY ” and “ON” blink.


4. Press to select the desired mode.


- Pressing  changes the “ON” or “OFF” setting in sequence.




- In case the reservation has already been set, selecting “blank” deletes the reservation.
- Proceed to **STEP 9** if “blank” is selected.
- To return to the day of the week and reservation number setting, press .

5. Press .


- The ON/OFF TIMER mode will be set.
- “ WEEKLY ” and the time blink.




6. Press  to select the desired time.

- The time can be set between 0:00 and 23:50 in 10-minute intervals.
- To return to the ON/OFF TIMER mode setting, press .
- Proceed to **STEP 9** when setting the OFF TIMER.

7. Press .

- The time will be set.
- “ WEEKLY” and the temperature blink.


8. Press  to select the desired temperature.


- The temperature can be set between 50°F (10°C) and 90°F (32°C).
COOL or AUTO: The unit operates at 64°F (18°C) even if it is set at 50°F (10°C) to 63°F (17°C).
HEAT or AUTO : The unit operates at 86°F (30°C) even if it is set at 87°F (31°C) to 90°F (32°C).
- To return to the time setting, press .
- The set temperature is only displayed when the mode setting is on.

9. Press .

- The temperature will be set and go to the next reservation setting.
- The temperature is set while in ON TIMER operation, and the time is set while in OFF TIMER operation.
- The next reservation screen will appear.
- To continue further settings, repeat the procedure from **STEP 4**.

10. Press  to complete the setting.




- Be sure to direct the remote controller toward the indoor unit and check for a receiving tone and blinking of the OPERATION lamp.
- “ WEEKLY” is displayed on the LCD and WEEKLY TIMER operation is activated.
- The TIMER lamp lights orange.




- A reservation made once can be easily copied and the same settings used for another day of the week. Refer to **Copy mode**.

NOTE


Notes on WEEKLY TIMER operation

- Do not forget to set the clock on the remote controller first.
- The day of the week, ON/OFF TIMER mode, time and set temperature (only for ON TIMER mode) can be set with the WEEKLY TIMER. Other settings for the ON TIMER are based on the settings just before the operation.
- WEEKLY TIMER and ON/OFF TIMER operation cannot be used at the same time. The ON/OFF TIMER operation has priority if it is set while WEEKLY TIMER is still active. The WEEKLY TIMER will enter the standby state, and “ WEEKLY” will disappear from the LCD. When the ON/OFF TIMER is up, the WEEKLY TIMER will automatically become active.
- Only the time and set temperature with the WEEKLY TIMER are sent with the . Set the WEEKLY TIMER only after setting the operation mode, the airflow rate and the airflow direction ahead of time.
- Turning off the circuit breaker, power failure, and other similar events will render operation of the indoor unit's internal clock inaccurate. Reset the clock.
-  can be used only for the time and temperature settings. It cannot be used to go back to the reservation number.





Copy mode

- A reservation made once can be copied to another day of the week. The whole reservation of the selected day of the week will be copied.



COPY




1. Press .
2. Press to confirm the day of the week to be copied.
3. Press .
 - The whole reservation of the selected day of the week will be copied.
4. Press to select the destination day of the week.
5. Press .
 - The reservation will be copied to the selected day of the week. The whole reservation of the selected day of the week will be copied.
 - To continue copying the settings to other days of the week, repeat **STEP 4** and **STEP 5**.
6. Press to complete the setting.
 - “ ” is displayed on the LCD and WEEKLY TIMER operation is activated.

NOTE


Note on COPY MODE

- The entire reservation of the source day of the week is copied in the copy mode.
- In the case of making a reservation change for any day of the week individually after copying the content of weekly reservations, press and change the settings in the steps of **Setting mode**.



Confirming a reservation



- The reservation can be confirmed.




1. Press .


- The day of the week and the reservation number of the current day will be displayed.

2. Press to select the day of the week and the reservation number to be confirmed.

- Pressing  displays the reservation details.
- To change the confirmed reserved settings, select the reservation number and press . The mode is switched to setting mode. Proceed to **Setting mode STEP 4.**

3. Press to exit the confirmation mode.




- “ WEEKLY” is displayed on the LCD and WEEKLY TIMER operation is activated.
- The TIMER lamp lights orange.




Display


To deactivate WEEKLY TIMER operation

Press while “ WEEKLY” is displayed on the LCD.

- “ WEEKLY” disappears from the LCD.
- The TIMER lamp goes off.
- To reactivate the WEEKLY TIMER operation, press  again.
- If a reservation deactivated with  is activated once again, the last reservation mode will be used.

NOTE

- If not all the reservation settings are reflected, deactivate the WEEKLY TIMER operation once. Then press  again to reactivate the WEEKLY TIMER operation.



To delete reservations

An individual reservation

1. Press .

- The day of the week and the reservation number will be displayed.

2. Press **to select the day of the week and the reservation number to be deleted.**

3. Press .

- “ WEEKLY” and “ON” or “OFF” blink.

4. Press **until no icon is displayed.**

- Pressing changes the ON/OFF TIMER mode in sequence.
- Selecting “blank” will cancel any reservation you may have.



5. Press .

- The selected reservation will be deleted.

6. Press .

- If there are still other reservations, WEEKLY TIMER operation will be activated.

Reservations for each day of the week

- This function can be used for deleting reservations for each day of the week.
- It can be used while confirming or setting reservations.

1. Press .

- The day of the week and the reservation number will be displayed.

2. Press **to select the day of the week to be deleted.**

3. Hold **for about 5 seconds.**

- The reservation of the selected day of the week will be deleted.

4. Press .

- If there are still other reservations, WEEKLY TIMER operation will be activated.

All reservations

Hold **for about 5 seconds with the normal display.**

- Be sure to direct the remote controller toward the indoor unit and check for a receiving tone.
- This operation cannot be used for the WEEKLY TIMER setting display.
- All reservations will be deleted.

1.14 Other Functions

1.14.1 Hot-Start Function

In order to prevent the cold air blast that normally occurs when heating operation starts, the temperature of the indoor heat exchanger is detected, and the airflow is either stopped or significantly weakened resulting in comfortable heating.



Note: The cold air blast is prevented using similar control when defrost control starts or when the thermostat is turned ON.

1.14.2 Signal Receiving Sign

When the indoor unit receives a signal from the remote controller, the unit emits a signal receiving sound.

1.14.3 Indoor Unit ON/OFF Button


An **ON/OFF** button is provided on the display of the unit.

- Press **ON/OFF** button once to start operation. Press once again to stop it.
- **ON/OFF** button is useful when the remote controller is missing or the battery has run out.

Operation mode	Temperature setting	Airflow rate
AUTO	25°C (77°F)	Automatic

- In the case of multi system operation, there are times when the unit does not activate with this button.

Ex: CTXS, FTXS series



ON/OFF button (R22266)

1.14.4 Auto-restart Function

If a power failure (including one for just a moment) occurs during the operation, the operation restarts automatically when the power is restored in the same condition as before the power failure.




Note: It takes 3 minutes to restart the operation because the 3-minute standby function is activated.

2. Functions for FFQ Series


2.1 Drain Pump Control

2.1.1 Normal Operation




- ◆ The float switch is OFF in normal operation.
- ◆ When cooling operation starts (thermostat ON), the drain pump turns ON simultaneously.
- ◆ After the thermostat turns OFF, the drain pump continues to operate for another 5 minutes.
- ◆ The aim of residual operation after thermostat OFF is to eliminate the dew that condenses on the indoor heat exchanger during cooling operation.

2.1.2 If the Float Switch is ON with the Thermostat ON in Cooling Operation




- ◆ When the float switch turns ON, the thermostat turns OFF simultaneously.
- ◆ After the thermostat turns OFF, the drain pump continues to operate for another 5 minutes.
- *1: If the float switch turns OFF again during the residual operation of the drain pump, cooling operation also turns on again (thermostat ON).
- *2: If the float switch remains ON even after the residual operation of the drain pump has ended, the error code **R3** is displayed on the remote controller.
- *3: The drain pump turns OFF once residual operation has ended, then turns ON again after 5 seconds.
- *4: After **R3** is displayed and the unit comes to an abnormal stop, the thermostat will remain OFF even if the float switch turns OFF again.

2.1.3 If the Float Switch is ON with the Thermostat OFF in Cooling Operation



- ◆ When the float switch turns ON, the drain pump turns ON simultaneously.
- ◆ If the float switch remains ON even after the residual operation of the drain pump has ended, the error code $R3$ is displayed on the remote controller.
- ◆ The drain pump turns OFF once residual operation has ended, then turns ON again after 5 seconds.

2.1.4 If the Float Switch Turns ON and OFF Continuously, or the Float Switch Turns ON While Rf Displayed



- ◆ When the float switch turns ON, the drain pump turns ON simultaneously.
- *1: If the float switch continues to turn ON and OFF 5 times consecutively, it is judged as a drain system error and the error code Rf is displayed on the remote controller.
- *2: The drain pump continues to turn ON/OFF in accordance with the float switch ON/OFF even after Rf is displayed on the remote controller.
- *3: While the error code Rf is displayed, if the float switch remains ON even after the residual operation of the drain pump has ended, the error code $R3$ will be displayed on the remote controller.


2.2 Thermostat Sensor in Remote Controller

Outline

Temperature is controlled by both the thermostat sensor in remote controller and air suction thermostat in the indoor unit. (This is however limited to when the field setting for the thermostat sensor in remote controller is set to Use.)

Cooling

If there is a significant difference in the set temperature and the suction temperature, fine adjustment control is carried out using a body thermostat sensor, or using the sensor in the remote controller near the position of the user when the suction temperature is near the set temperature.



■ **Assuming the set temperature in the figure above is 24°C (75.2°F), and the suction temperature has changed from 18°C (64.4°F) to 30°C (86°F) (A → F):**

(This example also assumes there are several other air conditioners, and the suction temperature changes even when the thermostat sensor is off.)

18 → 23°C (64.4 → 73.4°F) (A → C): Body thermostat sensor is used.

23 → 27°C (73.4 → 80.6°F) (C → E): Remote controller thermostat sensor is used.

27 → 30°C (80.6 → 86°F) (E → F): Body thermostat sensor is used.

■ **Assuming suction temperature has changed from 30°C (86°F) to 18°C (64.4°F) (F → A):**


30 → 25°C (86 → 77°F) (F → D): Body thermostat sensor is used.

25 → 21°C (77 → 69.8°F) (D → B): Remote controller thermostat sensor is used.

21 → 18°C (69.8 → 64.4°F) (B → A): Body thermostat sensor is used.

Heating

When heating, the hot air rises to the top of the room, resulting in the temperature being lower near the floor where the occupants are. When controlling by body thermostat sensor only, the indoor unit may therefore be turned off by the thermostat before the lower part of the room reaches the set temperature. The temperature can be controlled so the lower part of the room where the occupants are does not become cold by widening the range in which thermostat sensor in remote controller can be used so that suction temperature is higher than the set temperature.



(R18812)

■ **Assuming the set temperature in the figure above is 24°C (75.2°F), and the suction temperature has changed from 18°C (64.4°F) to 28°C (82.4°F) (A → D):**

(This example also assumes there are several other air conditioners, and the suction temperature changes even when the thermostat sensor is off.)

18 → 25°C (64.4 → 77°F) (A → C): Body thermostat sensor is used.

25 → 28°C (77 → 82.4°F) (C → D): Remote controller thermostat sensor is used.

■ **Assuming suction temperature has changed from 28°C (82.4°F) to 18°C (64.4°F) (D → A):**

28 → 23°C (82.4 → 73.4°F) (D → B): Remote controller thermostat sensor is used.

23 → 18°C (73.4 → 64.4°F) (B → A): Body thermostat sensor is used.

2.3 Freeze Prevention Control

Outline

When the temperature detected by liquid pipe thermistor (R2T) of the indoor heat exchanger drops too low, the unit enters freeze prevention control in accordance with the following conditions, and is also set in accordance with the conditions given below.

Detail

Conditions for starting:


Liquid pipe temperature $\leq -1^{\circ}\text{C}$ (30.2°F) (for total of 40 minutes)

or

Liquid pipe temperature $\leq -5^{\circ}\text{C}$ (23°F) (for total of 10 minutes)

Condition for cancelling:

Liquid pipe temperature $\geq 7^{\circ}\text{C}$ (44.6°F) (for 10 minutes continuously)




2.4 Hot Start Control (In Heating Operation Only)

Outline

At startup with thermostat ON or after the completion of defrosting in heating operation, the indoor unit fan is controlled to prevent cold air from blasting out and ensure startup capacity.

Detail




(R19187)

TH₂: Temperature detected by the gas thermistor
 T_c: High pressure equivalent saturation temperature

3. Control Specification

3.1 Thermistor Functions



- ★ The illustration is for the 3-room models as representative and have 3 lines of indoor unit system (A ~ C). The 2-room models have 2 lines (A ~ B).

(1) Outdoor Heat Exchanger Thermistor

1. The outdoor heat exchanger thermistor is used for controlling the target discharge pipe temperature. The system sets the target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge pipe temperature can be obtained.
2. In cooling operation, the outdoor heat exchanger thermistor is used for detecting the disconnection of the discharge pipe thermistor. When the discharge pipe temperature drops below the outdoor heat exchanger temperature by more than a certain value, the discharge pipe thermistor is judged as disconnected.
3. In cooling operation, the outdoor heat exchanger thermistor is used for high pressure protection.

(2) Discharge Pipe Thermistor

1. The discharge pipe thermistor is used for controlling discharge pipe temperature. If the discharge pipe temperature (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency becomes lower or the operation halts.
2. The discharge pipe thermistor is used for detecting disconnection of the discharge pipe thermistor.

(3) Gas Pipe Thermistor

In cooling operation, the gas pipe thermistor is used for gas pipe isothermal control. The system controls electronic expansion valve opening so that the gas pipe temperature in each room becomes equal.

(4) Indoor Heat Exchanger Thermistor

1. The indoor heat exchanger thermistor is used for controlling the target discharge pipe temperature. The system sets the target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge pipe temperature can be obtained.
2. In cooling operation, the indoor heat exchanger thermistor is used for freeze-up protection control. If the indoor heat exchanger temperature drops abnormally, the operating frequency becomes lower or the operation halts.
3. In cooling operation, the indoor heat exchanger thermistor is used for anti-icing function. If any of the following conditions are met in the room where operation halts, it is assumed as icing. The conditions are

$$T_c \leq -1^\circ \text{C} (30.2^\circ \text{F})$$

$$T_a - T_c \geq 10^\circ \text{C} (18^\circ \text{F})$$
 where T_a is the room temperature and T_c is the indoor heat exchanger temperature.
4. In heating operation, the indoor heat exchanger thermistor is used for heating peak-cut control. If the indoor heat exchanger temperature rises abnormally, the operating frequency becomes lower or the operation halts.
5. In heating operation, the indoor heat exchanger thermistor is used for detecting the disconnection of the discharge pipe thermistor. When the discharge pipe temperature drops below the highest indoor heat exchanger temperature by more than a certain value, the discharge pipe thermistor is judged as disconnected.
6. When only one indoor unit is operating, the indoor heat exchanger thermistor is used for subcooling control. The actual subcool is calculated with the liquid pipe temperature and the indoor heat exchanger temperature. The system controls the electronic expansion valve openings to obtain the target subcool.
7. The indoor heat exchanger thermistor is used for wiring error check function. The refrigerant flows in order from the port A to detect the indoor heat exchanger temperature one by one, and then wiring and piping can be checked.

(5) Liquid Pipe Thermistor


1. When only one indoor unit is in heating, the liquid pipe thermistor is used for subcooling control. The actual subcool is calculated with the liquid pipe temperature and the maximum indoor heat exchanger temperature. The system controls the electronic expansion valve openings to obtain the target subcool.
2. In heating operation, the liquid pipe thermistor is used for liquid pipes isothermal control. The system controls the electronic expansion valve opening so that the liquid pipe temperatures in each room becomes equal.

3.2 Mode Hierarchy

Outline

Air conditioner control has normal operation mode, forced operation mode, and power transistor test mode for installation and servicing.

Detail



(R22735)



- Note:**
- Unless specified otherwise, a dry operation command is regarded as cooling operation.
 - Indoor fan operation cannot be made in multiple indoor units. (A forced fan command is made during forced cooling operation.)

Determine Operation Mode

The system judges the operation mode command which is set by each room in accordance with the procedure, and determines the operation mode of the system.

The following procedure is taken when the modes conflict with each other.

*1. The system follows the mode which is set first. (First-push, first-set)


*2. For the rooms where the different mode is set, standby mode is activated. (The operation lamp blinks.)

3.3 Frequency Control

Outline

Frequency that corresponds to each room's capacity is determined according to the difference between the target temperature and the temperature of each room.

When the shift of the frequency is less than zero ($\Delta F < 0$) by PI control, the target frequency is used as the command frequency.



(R18023)

Detail

The compressor's frequency is determined by taking the following steps.

1. Determine command frequency

Command frequency is determined in the following order of priority.

1. Limiting defrost control time
2. Forced cooling/heating
3. Indoor frequency command

2. Determine upper limit frequency

The minimum value is set as upper limit frequency among the frequency upper limits of the following functions:

Compressor protection, input current, discharge pipe temperature, low Hz high pressure limit, heating peak-cut, freeze-up protection, defrost.

3. Determine lower limit frequency

The maximum value is set as the lower limit frequency among the frequency lower limits of the following functions:

Four way valve operation compensation, draft prevention, pressure difference upkeep.

4. Determine prohibited frequency

There is a certain prohibited frequency such as a power supply frequency.

Parameters**Q value**

Indoor unit output determined from indoor unit volume, airflow rate and other factors.

S value: Indoor Unit Capacity

An S value is the capacity of the indoor unit, and is used for frequency command.

Ex:	Capacity	S value	Capacity	S value
	9 kBtu/h	25	18 kBtu/h	50
	12 kBtu/h	35	24 kBtu/h	60

 ΔD signal: Indoor frequency command

The difference between the room thermistor temperature and the target temperature is taken as the ΔD value and is used for ΔD signal of frequency command.

Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	ΔD signal
-2.0°C (-3.6°F)	*OFF	0°C (0°F)	4	2.0°C (3.6°F)	8	4.0°C (7.2°F)	C
-1.5°C (-2.7°F)	1	0.5°C (0.9°F)	5	2.5°C (4.5°F)	9	4.5°C (8.1°F)	D
-1.0°C (-1.8°F)	2	1.0°C (1.8°F)	6	3.0°C (5.4°F)	A	5.0°C (9°F)	E
-0.5°C (-0.9°F)	3	1.5°C (2.7°F)	7	3.5°C (6.3°F)	B	5.5°C (9.9°F)	F

Values depend on the type of indoor unit.

*OFF = Thermostat OFF

Initial Frequency

When starting the compressor, or when conditions are varied due to a change of operating rooms, the frequency must be initialized according to a total of the maximum ΔD value of each room and a total Q value (ΣQ) of the operating room (the room in which the thermostat is set to ON).

PI Control**1. P control**

The $\Sigma \Delta D$ value is calculated in each sampling time (20 seconds), and the frequency is adjusted according to its difference from the frequency previously calculated.

2. I control

If the operating frequency does not change for more than a certain fixed time, the frequency is adjusted according to the $\Sigma \Delta D$ value.

When the $\Sigma \Delta D$ value is low, the frequency is lowered.

When the $\Sigma \Delta D$ value is high, the frequency is increased.

3. Limit of frequency increasing range

When the difference between the input current and the dropping value of the input current is less than 1.5 A, the frequency increasing range must be limited.

4. Frequency control when other controls are functioning

- ◆ When frequency is dropping;
Frequency control is carried out only when the frequency drops.
- ◆ For limiting lower limit;
Frequency control is carried out only when the frequency rises.

5. Upper and lower limit of frequency by PI control

The frequency upper and lower limits are set according to the total of S values. When the indoor unit quiet operation commands come from more than one room or when the outdoor unit quiet operation commands come from all the rooms, the upper limit frequency is lower than the usual setting.

3.4 Controls at Mode Changing/Start-up

3.4.1 Preheating Control

Outline The inverter operation in open phase starts with the conditions of the outdoor temperature and the preheating command from the indoor unit.

Detail

ON Condition

- ◆ When the outdoor temperature is below 6°C (42.8°F), the inverter operation in open phase starts.

OFF Condition

- ◆ When the outdoor temperature is higher than 8°C (46.4°F), the inverter operation in open phase stops.

3.4.2 Four Way Valve Switching

Outline The four way valve coil is energized/not energized depending on the operation mode. (Heating: ON, Cooling/Dry/Defrost: OFF) In order to eliminate the switching sound as the four way valve coil switches from ON to OFF when the heating is stopped, the OFF delay switch of the four way valve is carried out.

Detail

OFF delay switch of four way valve:

The four way valve coil is energized for 150 seconds after the operation is stopped.

3.4.3 Four Way Valve Operation Compensation

Outline At the beginning of operation as the four way valve is switched, the pressure difference to activate the four way valve is acquired when the output frequency is higher than a certain fixed frequency, for a certain fixed time.

Detail

Starting Conditions

1. When the compressor starts and the four way valve switches from OFF to ON
2. When the four way valve switches from ON to OFF during operation
3. When the compressor starts after resetting
4. When the compressor starts after the fault of four way valve switching

The lower limit of frequency keeps **A** Hz for 70 seconds with any conditions 1 through 4 above.


	Cooling	Heating
A (Hz)	42	26

3.4.4 3-Minute Standby

Turning on the compressor is prohibited for 3 minutes after turning off.
(The function is not used when defrosting.)

3.4.5 Compressor Protection Function

When turning the compressor from OFF to ON, the upper limit of frequency is set as follows.
(The function is not used when defrosting.)




	All outdoor units
A (Hz)	26
B (Hz)	48
C (Hz)	70
D (seconds)	120
E (seconds)	500
F (seconds)	180

3.5 Discharge Pipe Temperature Control

Outline

The discharge pipe temperature is used as the internal temperature of the compressor. If the discharge pipe temperature rises above a certain level, the upper limit of frequency is set to keep the discharge pipe temperature from rising further.

Detail



	All outdoor units
A	120°C (248°F)
B	111°C (231.8°F)
C	109°C (228.2°F)
D	107°C (224.6°F) ★
E	107°C (224.6°F) ★

★ The same value continues.

Zone	Control
Stop zone	When the temperature reaches the stop zone, the compressor stops.
Dropping zone	The upper limit of frequency decreases.
Keep zone	The upper limit of frequency is kept.
Reset zone	The upper limit of frequency is canceled.


3.6 Input Current Control

Outline

The microcomputer calculates the input current while the compressor is running, and sets the frequency upper limit based on the input current.

In case of heat pump models, this control is the upper limit control of frequency and takes priority over the lower limit control of four way valve operation compensation.

Detail



Frequency control in each zone

Stop zone

- After the input current remains in the stop zone for 2.5 seconds, the compressor is stopped.

Dropping zone

- The upper limit of the compressor frequency is defined as operation frequency – 2 Hz.
- After this, the output frequency is lowered by 2 Hz every second until it reaches the keep zone.

Keep zone

- The present maximum frequency goes on.

Reset zone

- Limit of the frequency is canceled.

	18 class		24 class	
	Cooling	Heating	Cooling	Heating
A (A)	15.5	17.5	15.5	18.5
B (A)	14.0	15.5	14.0	17.5
C (A)	13.0	14.5	13.0	16.5


Limitation of current dropping and stop value according to the outdoor temperature

- The current drops when outdoor temperature becomes higher than a certain level (depending on the model).

3.7 Freeze-up Protection Control

Outline During cooling operation, the signals sent from the indoor units control the operating frequency limitation and prevent freezing of the indoor heat exchanger. (The signals from the indoor units are divided into zones.)

Detail The operating frequency limitation is judged with the indoor heat exchanger temperature 2 seconds after operation starts and 30 seconds after the number of operation room is changed.




3.8 Heating Peak-cut Control

Outline During heating operation, the indoor heat exchanger temperature determines the frequency upper limit to prevent abnormal high pressure.

Detail

- The operating frequency is judged with the indoor heat exchanger temperature 2 minutes after the operation starts and **F** seconds after the number of operation room is changed.
- The maximum value of the indoor heat exchanger temperature controls the following (excluding stopped rooms).



A	65°C (149°F)
B	55°C (131°F)
C	54°C (129.2°F)
D	52°C (125.6°F)
E	50°C (122°F)

	F (seconds)
When increase	30
When decrease	2

Zone	Control
Stop zone	When the temperature reaches the stop zone, the compressor stops.
Dropping zone	The upper limit of frequency decreases.
Keep zone	The upper limit of frequency is kept.
Up zone	The upper limit of frequency increases.
Reset zone	The upper limit of frequency is canceled.

3.9 Outdoor Fan Control

1. Fan ON control to cool down the electrical box

The outdoor fan is turned ON when the electrical box temperature is high while the compressor is OFF.

2. Fan OFF control during defrosting

The outdoor fan is turned OFF while defrosting.

3. Fan OFF delay when stopped

The outdoor fan is turned OFF 60 seconds after the compressor stops.

4. Fan speed control for pressure difference upkeep

The rotation speed of the outdoor fan is controlled for keeping the pressure difference during cooling operation with low outdoor temperature.

- ◆ When the pressure difference is low, the rotation speed of the outdoor fan is reduced.
- ◆ When the pressure difference is high, the rotation speed of the outdoor fan is controlled as well as normal operation.

5. Fan control when the number of heating room decreases

When the outdoor temperature is more than 10°C (50°F), the fan is turned off for 30 seconds.

6. Fan speed control during forced operation

The outdoor fan is controlled as well as normal operation during the forced operation.

7. Fan speed control during POWERFUL operation

The rotation speed of the outdoor fan is increased during the POWERFUL operation.

8. Fan speed control during indoor/outdoor unit quiet operation

The rotation speed of the outdoor fan is reduced by the command of the indoor/outdoor unit quiet operation.

9. Fan ON/OFF control when operation (cooling, heating, dry) starts/stops

The outdoor fan is turned ON when the operation starts. The outdoor fan is turned OFF when the operation stops.

3.10 Liquid Compression Protection Function

Outline

The compressor stops according to the outdoor temperature for protection.

Detail

Operation stops depending on the outdoor temperature.

The compressor turns off under the conditions that the system is in cooling operation and the outdoor temperature is below -12°C (10.4°F).

3.11 Defrost Control

Outline

Defrosting is carried out by the cooling cycle (reverse cycle). The defrosting time or outdoor heat exchanger temperature must be more than a certain value to finish defrosting.


Detail

Conditions for Starting Defrost

- The starting conditions are determined with the outdoor temperature and the outdoor heat exchanger temperature.
- The system is in heating operation.
- The compressor operates for 6 minutes.
- More than **A** minutes of accumulated time have passed since the start of the operation, or ending the previous defrosting.

Conditions for Canceling Defrost

The judgment is made with the outdoor heat exchanger temperature. (**B**°C (**C**°F))



(R21926)


	All outdoor units
A (minutes)	26
B (°C)	4 ~ 12
C (°F)	39.2 ~ 53.6
D (Hz)	58
E (Hz)	42
F (seconds)	90
G (seconds)	60
H (seconds)	530
J (seconds)	40
K (pulse)	400
L (pulse)	250
M (pulse)	300
N (pulse)	400
P (pulse)	50
Q (pulse)	0

3.12 Low Hz High Pressure Limit

Outline

The system controls the upper limit of the frequency to prevent abnormal high pressure while the frequency is low. Control is carried out according to three zones.

Detail



	All outdoor units
A	52°C (125.6°F)
B	51°C (123.8°F)
C	48°C (118.4°F)

3.13 Electronic Expansion Valve Control

Outline

The following items are included in the electronic expansion valve control.

Electronic expansion valve is fully closed

1. Electronic expansion valve is fully closed when turning on the power.
2. Pressure equalizing control

Room Distribution Control

1. Gas pipe isothermal control
2. SC (subcooling) control
3. Liquid pipe temperature control (with all ports connected and all rooms being air-conditioned)
4. Liquid pipe temperature control for stopped rooms
5. Dew prevention control for indoor rotor

Open Control

1. Electronic expansion valve control when starting operation
2. Electronic expansion valve control when the frequency changes
3. Electronic expansion valve control for defrosting
4. Electronic expansion valve control for oil recovery
5. Electronic expansion valve control when a discharge pipe temperature is abnormally high
6. Electronic expansion valve control when the discharge pipe thermistor is disconnected
7. Electronic expansion valve control for indoor unit freeze-up protection

Feedback Control

Target discharge pipe temperature control

Detail

The followings are the examples of electronic expansion valve control which function in each operation mode.

Operation pattern		Gas pipe isothermal control	SC (subcooling) control	Control when the frequency changes	Control for abnormally high discharge pipe temperature	Oil recovery control	Indoor freeze-up protection control	Liquid pipe temperature control	Liquid pipe temperature control for non-operating units	Dew prevention control for indoor rotor
● : Available — : Not available										
When power is turned on	Fully closed when power is turned on	—	—	—	—	—	—	—	—	—
Cooling, 1 room operation	Open control when starting	—	—	—	●	●	●	—	—	—
	(Control of target discharge pipe temperature)	—	—	●	●	●	●	—	—	●
Cooling, 2 rooms operation to Cooling, 4 rooms operation	Control when the operating room is changed	—	—	—	●	●	●	—	—	●
	(Control of target discharge pipe temperature)	●	—	●	●	●	●	—	—	●
Stop	Pressure equalizing control	—	—	—	—	—	—	—	—	—
Heating, 1 room operation	Open control when starting	—	—	—	●	—	—	—	—	—
	(Control of target discharge pipe temperature)	—	★2	●	●	—	—	★1	★3	—
Heating, 2 rooms operation	Control when the operating room is changed	—	—	—	●	—	—	—	—	—
	(Control of target discharge pipe temperature)	—	★2	●	●	—	—	★1	★3	—
	(Defrost control)	—	—	—	—	—	—	—	—	—
Stop	Pressure equalizing control	—	—	—	—	—	—	—	—	—
Heating operation	Open control when starting	—	—	—	●	—	—	—	—	—
Discharge pipe thermistor disconnection control	Continue	—	●	—	—	—	—	●	●	—
Stop	Pressure equalizing control	—	—	—	—	—	—	—	—	—

(R21181)

- ★1 : When all the indoor units are operating, liquid pipe temperature control is conducted.
- ★2 : SC (subcooling) control is conducted for the operating indoor units, when some of the units are not operating.
- ★3 : Liquid pipe temperature control for stopped room is conducted for the non-operating indoor units.

3.13.1 Fully Closing with Power On

The electronic expansion valve is initialized when the power is turned on. The opening position is set and the pressure is equalized.

3.13.2 Pressure Equalizing Control

When the compressor is stopped, the pressure equalizing control is activated. The electronic expansion valve opens and the pressure is equalized.

3.13.3 Opening Limit Control

Outline

The maximum and minimum opening of the electronic expansion valve are limited.

Detail

- Maximum electronic expansion valve opening in the operating room: 450 pulse
 - Minimum electronic expansion valve opening in the operating room: 64 pulse
- The electronic expansion valve is fully closed in a room where cooling operation is stopped and is opened at a fixed degree during defrosting.

3.13.4 Starting Operation Control/Changing Operation Room

The electronic expansion valve opening is controlled when the operation starts, thus preventing the superheating or liquid compression.

3.13.5 Control when the Frequency Changes

When the target discharge pipe temperature control is active, if the target frequency changes to a specified value in a certain time period, the target discharge pipe temperature control is canceled and the target opening of the electronic expansion valve is changed.

3.13.6 Oil Recovery Function

Outline

The electronic expansion valve opening in the cooling stopped room is set as to open for a certain time at a specified interval so that the oil in the cooling stopped room may not be accumulated.

Detail

During cooling operation, every 1 hour continuous operation, the electronic expansion valves in the operation stopped room is opened by 80 pulses for specified time.

3.13.7 High Discharge Pipe Temperature Control

When the compressor is operating, if the discharge pipe temperature exceeds a certain value, the electronic expansion valve opens and the refrigerant runs to the low pressure side. This procedure lowers the discharge pipe temperature.

3.13.8 Discharge Pipe Thermistor Disconnection Control

Outline

The disconnection of the discharge pipe thermistor is detected by comparing the discharge pipe temperature with the condensing temperature. If the discharge pipe thermistor is disconnected, the electronic expansion valve opens according to the outdoor temperature and the operation frequency, operates for a specified time, and then stops.

After 3 minutes, the operation restarts and checks if the discharge pipe thermistor is disconnected. If the discharge pipe thermistor is disconnected, the system stops after operating for a specified time.

If the disconnection is detected repeatedly, the system is shut down. When the compressor runs for 60 minutes without any error, the error counter is reset.

Detail

Determining thermistor disconnection

When the starting control (630 seconds) finishes, the following adjustment is made.

1. When the operation mode is cooling

When the following condition is fulfilled, the discharge pipe thermistor disconnection is ascertained.

Discharge pipe temperature + 6°C (10.8°F) < outdoor heat exchanger temperature

2. When the operation mode is heating

When the following condition is fulfilled, the discharge pipe thermistor disconnection is ascertained.

Discharge pipe temperature + 6°C (10.8°F) < highest indoor heat exchanger temperature

When the thermistor is disconnected

When the disconnection is ascertained, the compressor continues operation for 9 minutes and then stops.

3.13.9 Gas Pipe Isothermal Control During Cooling

When the units are operating in multiple rooms, the gas pipe temperature is detected and the electronic expansion valve opening is adjusted so that the temperature of the gas pipe in each room becomes equal.

■ When the gas pipe temperature > the average gas pipe temperature,

→ the opening degree of electronic expansion valve in the corresponding room increases.

■ When the gas pipe temperature < the average gas pipe temperature,

→ the opening degree of electronic expansion valve in the corresponding room decreases.

The temperatures are monitored every 40 seconds.

3.13.10 SC (Subcooling) Control

Outline

The liquid pipe temperature and the heat exchanger temperature are detected and the electronic expansion valve opening is compensated so that the SC of each room becomes the target SC.

- When the actual SC is > target SC, open the electronic expansion valve of the room.
- When the actual SC is < target SC, close the electronic expansion valve of the room.

Detail

Start Conditions


After finishing the starting control (630 seconds), (all) the electronic expansion valve(s) for the operating room is/are controlled.

Determine Electronic Expansion Valve Opening

The electronic expansion valve opening is adjusted so that the temperature difference between the maximum heat exchanger temperature of connected room and the liquid pipe temperature thermistor becomes constant.

3.13.11 Target Discharge Pipe Temperature Control

The target discharge pipe temperature is obtained from the indoor and outdoor heat exchanger temperature, and the electronic expansion valve opening is adjusted so that the actual discharge pipe temperature becomes close to the target discharge pipe temperature. (Indirect SH (superheating) control using the discharge pipe temperature)



The electronic expansion valve opening and the target discharge pipe temperature are adjusted every 20 seconds. The target discharge pipe temperature is controlled by indoor heat exchanger temperature and outdoor heat exchanger temperature. The opening degree of the electronic expansion valve is controlled by the followings.

- ◆ Target discharge pipe temperature
- ◆ Actual discharge pipe temperature
- ◆ Previous discharge pipe temperature

3.14 Malfunctions

3.14.1 Sensor Malfunction Detection

Sensor malfunction may occur either in the thermistor or current transformer (CT) system.

Relating to Thermistor Malfunction

1. Outdoor heat exchanger thermistor
2. Discharge pipe thermistor
3. Radiation fin thermistor
4. Gas pipe thermistor
5. Outdoor temperature thermistor
6. Liquid pipe thermistor



Relating to CT Malfunction

Refer to CT or related abnormality on page 156 for detail.

3.14.2 Detection of Overcurrent and Overload

Outline

In order to protect the inverter, an excessive output current is detected and the OL temperature is observed to protect the compressor.

Detail


- If the inverter current exceeds 15.5 ~ 18.5 A (depending on the model), the system shuts down the compressor.
- If the OL (compressor head) temperature exceeds 130°C (266°F), the compressor stops.

3.14.3 Refrigerant Shortage Control

Outline

If the power consumption is below the specified value and the frequency is higher than the specified frequency, it is regarded as refrigerant shortage.

The power consumption is low comparing with that in the normal operation when refrigerant is insufficient, and refrigerant shortage is detected by checking power consumption.



(R23015)



Refer to Refrigerant shortage on page 134 for detail.

3.14.4 Anti-icing Function

During cooling, if the indoor heat exchanger temperature in the operation stopped room drops below the specified temperature for a specified time, the electronic expansion valve is opened in the operation stopped room as specified, and the fully closed operation is carried out. After this, if freezing abnormality occurs longer than a specified time, the system is shut down.


Part 5

Remote Controller


1. CTXS, FTXS Series	77
2. CDXS, FDXS Series	79
3. FVXS Series.....	81
4. FFQ Series.....	83
4.1 <BRC1E71> Wired Remote Controller.....	83
4.2 <BRC1E72/73> Wired Remote Controller.....	88
4.3 <BRC7E830> Wireless Remote Controller	94

1. CTXS, FTXS Series

Signal transmitter



- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is approximately 23 ft. (7 m).



Display (LCD)

- Displays the current settings. (In this illustration, each section is shown with all its displays on for the purpose of explanation.)

TEMPERATURE adjustment buttons

- Changes the temperature setting.

Ⓐ : AUTO	18 ~ 30 °C (64 ~ 86 °F)
☐ : DRY	Not available
❄ : COOL	18 ~ 32 °C (64 ~ 90 °F)
☀ : HEAT	10 ~ 30 °C (50 ~ 86 °F)
🌀 : FAN	Not available

ON/OFF button


- Press this button once to start operation. Press once again to stop it.

POWERFUL*1 button

- POWERFUL operation.

FAN setting button

- Selects the airflow rate setting every time you press this button.



- In indoor unit quiet operation, operation sound becomes weak. (The airflow rate also decreases.)
- In DRY operation, the airflow rate setting is not available.

< ARC452A21 >

(R18852)

Reference

Refer to the following pages for detail.

★1	Inverter POWERFUL operation	P.43
----	-----------------------------	------



Note:

Refer to the operation manual of applicable model for details. You can download operation manuals from Daikin Business Portal:
 Daikin Business Portal → Document Search → Item Category → Installation/Operation Manual
 (URL: https://global1d.daikin.com/business_portal/login/)

Open the Front Cover



MODE button

- Selects the operation mode.

QUIET button

- OUTDOOR UNIT QUIET operation.
- OUTDOOR UNIT QUIET operation is not available in FAN and DRY operation.
- OUTDOOR UNIT QUIET operation and POWERFUL operation cannot be used at the same time. Priority is given to the function you pressed last.

ECONO*4 button


- ECONO operation.

SWING*5 button

- Adjusts the airflow direction.
- When you press the **SWING** button, the flap moves up and down, or (and) the louver moves right and left. The flap (louver) stops when you press the **SWING** button again.

COMFORT*2/SENSOR*3 button

- Every time you press the **COMFORT/SENSOR** button, the setting changes in the following order.



WEEKLY button

- WEEKLY** : **WEEKLY** button
- PROGRAM** button
- COPY** : **COPY** button
- BACK** : **BACK** button
- NEXT** : **NEXT** button
- WEEKLY TIMER*6 operation.

ON TIMER button

- Press this button and adjust the day and time with the **SELECT** button.
- Press this button again to complete **TIMER** setting.

OFF TIMER button

- Press this button and adjust the day and time with the **SELECT** button.
- Press this button again to complete **TIMER** setting.

TIMER CANCEL button

- Cancels the timer setting.
- Cannot be used for the **WEEKLY TIMER** operation.

CLOCK*7 button

SELECT button

- Changes the **ON/OFF TIMER** and **WEEKLY TIMER** settings.

(R21919)

Reference

Refer to the following pages for detail.

★2	COMFORT AIRFLOW operation	P.35, 37
★3	INTELLIGENT EYE operation	P.42
★4	ECONO operation	P.41


★5	Auto-swing	P.34
★6	WEEKLY TIMER operation	P.45
★7	Clock setting	P.44



Note:

Refer to the operation manual of applicable model for details. You can download operation manuals from Daikin Business Portal:
 Daikin Business Portal → Document Search → Item Category → Installation/Operation Manual
 (URL: https://global1d.daikin.com/business_portal/login/)

2. CDXS, FDXS Series



< ARC452A23 >

(R18861)

Reference

Refer to the following pages for detail.

★1 Inverter POWERFUL operation P.43



Note:

Refer to the operation manual of applicable model for details. You can download operation manuals from Daikin Business Portal:
 Daikin Business Portal → Document Search → Item Category → Installation/Operation Manual
 (URL: https://global1d.daikin.com/business_portal/login/)

Open the Front Cover



MODE button

- Selects the operation mode.

QUIET button

- OUTDOOR UNIT QUIET operation.
- OUTDOOR UNIT QUIET operation is not available in FAN and DRY operation.
- OUTDOOR UNIT QUIET operation and POWERFUL operation cannot be used at the same time. Priority is given to the function you pressed last.

ECONO*2 button

- ECONO operation.

SELECT button


- Changes the ON/OFF TIMER settings.

OFF TIMER button

- Press this button and adjust the time with the **SELECT** button. Press this button again to complete TIMER setting.

ON TIMER button

- Press this button and adjust the time with the **SELECT** button. Press this button again to complete TIMER setting.



TIMER CANCEL button

- Cancels the timer setting.

CLOCK*3 button

(R21920)

Reference

Refer to the following pages for detail.


★2	ECONO operation	P.41
★3	Clock setting	P.44



Note:

Refer to the operation manual of applicable model for details. You can download operation manuals from Daikin Business Portal:
 Daikin Business Portal → Document Search → Item Category → Installation/Operation Manual
 (URL: https://global1d.daikin.com/business_portal/login/)

3. FVXS Series



(R23016)

Reference

Refer to the following pages for detail.


★1	Inverter POWERFUL operation	P.43
----	-----------------------------	------



Note:

Refer to the operation manual of applicable model for details. You can download operation manuals from Daikin Business Portal:
 Daikin Business Portal → Document Search → Item Category → Installation/Operation Manual
 (URL: https://global1d.daikin.com/business_portal/login/)

Open the Front Cover



Mode button

• Selects the operation mode.



Econo^{*2} button

• Starts ECONO operation.

Swing^{*3} button

• Adjusts the airflow direction.
• When you press the **Swing** button, the flap moves up and down. The flap stops when you press the **Swing** button again.

Weekly button

Weekly
[Weekly button icon] : Weekly button

[Program button icon] : Program button

Copy
[Copy button icon] : Copy button

Back
[Back button icon] : Back button

Next
[Next button icon] : Next button

• WEEKLY TIMER^{*4} operation.

On Timer button

• Press this button and adjust the day and time with the **Select** button. Press this button again to complete TIMER setting.

Clock^{*5} button

Select button

• It changes the ON/OFF TIMER and WEEKLY TIMER settings.

Quiet button


• OUTDOOR UNIT QUIET operation.
• OUTDOOR UNIT QUIET operation is not available in FAN and DRY operation.
• OUTDOOR UNIT QUIET operation and POWERFUL operation cannot be used at the same time. Priority is given to the function you pressed last.

Off Timer button

• Press this button and adjust the day and time with the **Select** button. Press this button again to complete TIMER setting.

Timer Cancel button

• Cancels the timer setting.
• Cannot be used for the WEEKLY TIMER operation.



(R23017)

Reference

Refer to the following pages for detail.

★2	ECONO operation	P.41
★3	Auto-swing	P.34

★4	WEEKLY TIMER operation	P.45
★5	Clock setting	P.44




Note:

Refer to the operation manual of applicable model for details. You can download operation manuals from Daikin Business Portal:
Daikin Business Portal → Document Search → Item Category → Installation/Operation Manual
(URL: https://global1d.daikin.com/business_portal/login/)

4. FFQ Series

4.1 <BRC1E71> Wired Remote Controller



1. Operation mode selector button

- Press this button to select the operation mode of your preference.
* Available modes vary with the indoor unit model.

2. Fan speed control button

- Press this button to select the fan speed of your preference.
* Available fan speeds vary with the indoor unit model.

3. Menu/OK button

- Used to indicate the main menu.
- Used to enter the selected item.

4. Up button ▲

- Used to raise the setpoint.
- The item above the current selection will be highlighted.
(The highlighted items will be scrolled continuously when the button is continuously pressed.)
- Used to change the selected item.

5. Down button ▼

- Used to lower the setpoint.
- The item below the current selection will be highlighted.
(The highlighted items will be scrolled continuously when the button is continuously pressed.)
- Used to change the selected item.

6. Right button ►

- Used to highlight the next items on the right-hand side.
- Each screen is scrolled in the right-hand direction.

7. Left button ◀

- Used to highlight the next items on the left-hand side.
- Each screen is scrolled in the left-hand direction.

8. On/Off button

- Press this button and system will start.
- Press this button again to stop the system.

9. Operation lamp (Green)

- This lamp illuminates solid during normal operation.
- This lamp blinks if a error occurs.

10. Cancel button

- Used to return to the previous screen.


11. LCD (with backlight)

- The backlight will be illuminated for approximately 30 seconds by pressing any button.
- If two remote controllers are used to control a single indoor unit, only the controller to be accessed first will have backlight functionality.

Liquid Crystal Display



- Two types of liquid crystal display (LCD) are available. The standard display is set by default.
- Detailed display can be selected in the main menu.
- The displayed contents of the screen vary with the operation mode of the indoor unit model. (The following display will appear when the indoor unit is in automatic operation.)

Standard display



Detailed Display

- The air flow direction, clock, and detailed selection items appear on the detailed display screen in addition to the items appearing on the standard display.



1. Operation mode

- Used to display the current operation mode: Cool, Heat, Vent, Fan, Dry or Auto.

2. Fan Speed

- Used to display the fan speed that is set for the indoor unit.
- The fan speed will not be displayed if the connected model does not have fan speed control functionality.

3. Setpoint display

- Used to display the setpoint for the indoor unit.
- Use the Celsius/Fahrenheit item in the main menu to select the temperature unit (Celsius or Fahrenheit).

4. Stand by for Defrost/Hot start

“”

If ventilation icon is displayed in this field:

- Indicates that an energy recovery ventilator is connected.
For details, refer to the Operation Manual of the ERV.

5. Message

The following messages may be displayed.

“**This function is not available**”

- Displayed for a few seconds when an operation button is pressed and the indoor unit does not provide the corresponding function.
- In a remote control group, the message will not appear if at least one of the indoor units provides the corresponding function.

“**Error: Push Menu button**”

“**Warning: Push Menu button**”

- Displayed if an error or warning is detected.



“**Time to clean filter**”

“**Time to clean element**”

“**Time to clean filter & element**”

- Displayed as a reminder when it is time to clean the filter or element.

6. Ventilation

- Displayed when a energy recovery ventilator is connected.
- **Ventilation Mode icon.** “ ”
These icons indicate the current ventilation mode (ERV only) (AUTO, ERV, BYPASS).
- **Air Purify ICON** “ ”
This icon indicates that the air purifying unit (option) in operation.

7. display

- Displayed when the key lock is set.

8. display

- Displayed if the Schedule or Off timer is enabled.

9. Under Centralized control “”

- Displayed if the system is under the management of a multi zone controller (option) and the operation of the system through the remote controller is limited.

10. Changeover controlled by the master indoor unit “” (VRV only)

- Displayed when another indoor unit on the system has the authority to change the operation mode between cool and heat.

11. Setback “”

- The setback icon flashes when the unit is turned on under the setback control.

12. Air Flow Direction “”

- Displayed when the air flow direction and swing are set.
- If the connected indoor unit model does not include oscillating louvers this item will not be displayed.

13. Current Day/Time (12/24 hour time display)

- Displayed if the clock is set.
- If the clock is not set, “ -- : -- ” will be displayed.
- 12 hour time format is displayed by default.
- Select 12/24 hour time display option in the main menu under “Clock & Calendar”.


14. Detailed selection

- Displayed if the detailed display item is selected.
- Detailed items are not selected by default.

15. display

- Displayed when the clock needs to be set.
- The schedule function will not work unless the clock is set.

4.2 <BRC1E72/73> Wired Remote Controller



1. Operation mode selector button

- Press this button to select the operation mode of your preference.
 - * Available modes vary with the indoor unit model.

2. Fan speed control button

- Press this button to select the fan speed of your preference.
 - * Available fan speeds vary with the indoor unit model.

3. Menu/OK button

- Used to enter the main menu.
- Used to enter the selected item.

4. Up button ▲

- Used to raise the setpoint.
- The item above the current selection will be highlighted.
(The highlighted items will be scrolled continuously when the button is continuously pressed.)
- Used to change the selected item.

5. Down button ▼

- Used to lower the setpoint.
- The item below the current selection will be highlighted.
(The highlighted items will be scrolled continuously when the button is continuously pressed.)
- Used to change the selected item.

6. Right button ►

- Used to highlight the next items on the right-hand side.
- Each screen is scrolled in the right-hand direction.

7. Left button ◀

- Used to highlight the next items on the left-hand side.
- Each screen is scrolled in the left-hand direction.

8. On/Off button

- Press this button and system will start.
- Press this button again to stop the system.

9. Operation lamp

- This lamp illuminates solid green during normal operation.
- This lamp flashes if an error occurs.

10. Cancel button

- Used to return to the previous screen.

11. LCD (with backlight)

- The backlight will be illuminated for approximately 30 seconds by pressing any button.
- If two remote controllers are used to control a single indoor unit, only the controller accessed first will have backlight functionality.

Liquid Crystal Display

- Three types of display mode (Standard, Detailed and Simple) are available.
- Standard display is set by default.
- Detailed and Simple displays can be selected in the main menu.

Standard display


10. Changeover controlled by the master indoor unit

9. Under centralized control

1. Operation mode

2. Fan Speed

6. Ventilation



11. Setback

8. (⌚) Scheduled

7. (🔒) Key Lock

3. Setpoint

4. Stand by for Defrost/ Hot start


5. Message

<Standard display example>

Detailed display

- The airflow direction, clock, and selectable item appear on Detailed display screen in addition to the items appearing on Standard display.

12. Airflow Direction (Displayed only when the indoor unit is turned on.)




13. Current Day/Time (12/24 hour time display)

14. Selectable Display Item

<Detailed display example 1>

No Fan speed display (with no fan speed control function)

No Airflow Direction display (with no airflow direction settings)




No Clock display (when the clock has not been set yet)

15. (🔒) Unable to schedule

No Selectable Display Item (with no selectable display item selected)

<Detailed display example 2>

Simple display



Note for all display modes

- Depending on the field settings, while the indoor unit is stopped, OFF may be displayed instead of the operation mode and/or the setpoint may not be displayed.

1. Operation mode

- Used to display the current operation mode: Cool, Heat, Vent, Fan, Dry or Auto.
- In Auto mode, the actual operation mode (Cool or Heat) will be also displayed.
- Operation mode cannot be changed when OFF is displayed.
Operation mode can be changed after starting operation.

2. Fan Speed

- Used to display the fan speed that is set for the indoor unit.
- The fan speed will not be displayed if the connected model does not have fan speed control functionality.

3. Setpoint

- Used to display the setpoint for the indoor unit.
- Use the Celsius/Fahrenheit item in the main menu to select the temperature unit (Celsius or Fahrenheit).

4. Stand by for Defrost/Hot start

“”

If ventilation icon is displayed in this field:

- Indicates that an energy recovery ventilator (ERV) is connected.
For details, refer to the Operation Manual of the ERV.

5. Message

The following messages may be displayed.

“**This function is not available**”

- Displayed for a few seconds when an Operation button is pressed and the indoor unit does not provide the corresponding function.
- In a remote control group, the message will not appear if at least one of the indoor units provides the corresponding function.

“**Error: Push Menu button**”

“**Warning: Push Menu button**”

- Displayed if an error or warning is detected.



“**Time to clean filter**”

“**Time to clean element**”

“**Time to clean filter & element**”

- Displayed as a reminder when it is time to clean the filter and/or element.

6. Ventilation

- Displayed when an energy recovery ventilator is connected.
- **Ventilation Mode icon.** “ AUTO ERV BYPASS”
These icons indicate the current ventilation mode (ERV only) (AUTO, ERV, BYPASS).
- **Air Purify ICON** “ AIR PURIFY”
This icon indicates that the air purifying unit (Optional) is in operation.

7. Key Lock

- Displayed when the key lock is set.

8. Scheduled

- Displayed if the Schedule or Off timer is enabled.

9. Under Centralized control “”

- Displayed if the system is under the management of a multi-zone controller (Optional) and the operation of the system through the remote controller is limited.

10. Changeover controlled by the master indoor unit “” (VRV only)

- Displayed when another indoor unit on the system has the authority to change the operation mode between cool and heat.

11. Setback “”

- The setback icon flashes when the unit is turned on by the setback control.

12. Airflow Direction “”

- Displayed when the airflow direction and swing are set.
- If the connected indoor unit model does not include oscillating louvers this item will not be displayed.

13. Current Day/Time (12/24 hour time display)

- Displayed if the clock is set.
- If the clock is not set, “ -- : -- ” will be displayed.
- 12 hour time format is displayed by default.
- Select 12/24 hour time display option in the main menu under “Clock & Calendar”.


14. Selectable Display Item

- Room temperature is selected by default.
- For other choices see the operation manual.

15. ~~X~~Unable to schedule

- Displayed when the clock needs to be set.
- The schedule function will not work unless the clock is set.

4.3 <BRC7E830> Wireless Remote Controller



(R18863)

(R17873)

	DISPLAY ▲ (SIGNAL TRANSMISSION)
1	This lights up when a signal is being transmitted.
	DISPLAY , , , , (OPERATION MODE)
2	This display shows the current operation mode.
	DISPLAY (SET TEMPERATURE)
3	This display shows the set temperature.
	DISPLAY hr. ⓪ 3 hr. ⓪ 4 (PROGRAMMED TIME)
4	This display shows programmed time of the system start or stop.
	DISPLAY (AIRFLOW FLAP)
5	
	DISPLAY (FAN SPEED)
6	The display shows the set fan speed.
	DISPLAY TEST (INSPECTION/ TEST OPERATION)
7	When the INSPECTION/TEST button is pressed, the display shows the system mode is in.
	ON/OFF BUTTON
8	Press the button and the system will start. Press the button again and the system will stop.
	FAN BUTTON
9	Press this button to select the fan speed, HIGH or LOW, of your choice.
	TEMPERATURE SETTING BUTTON
10	Use this button for setting temperature (Operates with the front cover of the remote controller closed.)

	PROGRAMMING TIMER BUTTON
11	Use this button for programming start and/or stop time. (Operates with the front cover of the remote controller opened.)
	TIMER MODE START/STOP BUTTON
12	
	TIMER RESERVE/CANCEL BUTTON
13	
	SWING BUTTON
14	
	OPERATION MODE SELECTOR BUTTON
15	Press this button to select operation mode.
	FILTER SIGN RESET BUTTON
16	
	INSPECTION/TEST BUTTON
17	This button is used only by qualified service persons for maintenance purposes.
	EMERGENCY OPERATION SWITCH
18	This switch is readily used if the remote controller does not work.
	RECEIVER
19	This receives the signals from the remote controller.
	OPERATING INDICATOR LAMP (Red)
20	This lamp stays lit while the air conditioner runs. It flashes when the unit is in trouble.
	TIMER INDICATOR LAMP (Green)
21	This lamp stays lit while the timer is set.
	AIR FILTER CLEANING TIME INDICATOR LAMP (Red)
22	Lights up when it is time to clean the air filter.
	DEFROST LAMP (Orange)
23	Lights up when the defrosting operation has started.

Part 6

Service Diagnosis

1. General Problem Symptoms and Check Items	97
2. Troubleshooting with LED	98
2.1 Indoor Unit	98
2.2 Outdoor Unit	99
3. Service Diagnosis	100
3.1 CTXS, FTXS, CDXS, FDXS, FVXS Series	100
3.2 FFQ Series	106
4. Code Indication on Remote Controller	112
4.1 CTXS, FTXS, CDXS, FDXS, FVXS Series	112
4.2 FFQ Series	112
4.3 Outdoor Unit	113
5. Troubleshooting for CTXS, FTXS, CDXS, FDXS, FVXS Series	114
5.1 Indoor Unit PCB Abnormality	114
5.2 Freeze-up Protection Control/Heating Peak-cut Control	116
5.3 Fan Motor or Related Abnormality	117
5.4 Thermistor or Related Abnormality	121
5.5 Signal Transmission Error (Between Indoor Unit and Outdoor Unit)	122
5.6 Unspecified Voltage (Between Indoor Unit and Outdoor Unit)	124
6. Troubleshooting for FFQ Series	125
6.1 Indoor Unit PCB Abnormality	125
6.2 Drain Level Control System Abnormality	126
6.3 Fan Motor (AC Motor) or Related Abnormality	127
6.4 Drain System Abnormality	128
6.5 Thermistor or Related Abnormality	129
6.6 Remote Controller Thermistor Abnormality	130
6.7 Signal Transmission Error (Between Indoor Unit and Remote Controller)	131
6.8 Signal Transmission Error (Between MAIN Remote Controller and SUB Remote Controller)	132
6.9 Field Setting Abnormality	133
7. Troubleshooting for Outdoor Unit	134
7.1 Refrigerant Shortage	134
7.2 Low-voltage Detection or Over-voltage Detection	136
7.3 Wiring Error Check Unexecuted	138
7.4 Unspecified Voltage (Between Indoor Unit and Outdoor Unit)/ Anti-icing Control in Other Rooms	139
7.5 Anti-icing Control for Indoor Unit	140
7.6 Outdoor Unit PCB Abnormality	142
7.7 OL Activation (Compressor Overload)	143
7.8 Compressor Lock	145
7.9 DC Fan Lock	146

7.10	Input Overcurrent Detection	147
7.11	Four Way Valve Abnormality	148
7.12	Discharge Pipe Temperature Control	150
7.13	High Pressure Control in Cooling	151
7.14	Compressor Sensor System Abnormality	152
7.15	Position Sensor Abnormality	154
7.16	CT or Related Abnormality	156
7.17	Thermistor or Related Abnormality (Outdoor Unit)	158
7.18	Electrical Box Temperature Rise	160
7.19	Radiation Fin Temperature Rise	161
7.20	Output Overcurrent Detection	162
8.	Check	164
8.1	Thermistor Resistance Check	164
8.2	Indoor Fan Motor Connector Check	165
8.3	Hall IC Check	165
8.4	Power Supply Waveform Check	166
8.5	Electronic Expansion Valve Check	167
8.6	Four Way Valve Performance Check	168
8.7	Inverter Unit Refrigerant System Check	168
8.8	Inverter Analyzer Check	169
8.9	Rotation Pulse Check on the Outdoor Unit PCB	170
8.10	Installation Condition Check	171
8.11	Discharge Pressure Check	171
8.12	Outdoor Fan System Check	172
8.13	Main Circuit Short Check	172
8.14	Capacitor Voltage Check	173
8.15	Power Module Check	174

1. General Problem Symptoms and Check Items

Problem Symptom	Check Item	Details	Reference Page
None of the units operates.	Check the power supply.	Check if the rated voltage is supplied.	—
	Check the types of the indoor units.	Check if the indoor unit type is compatible with the outdoor unit.	—
	Check the outdoor temperature.	Heating operation is not available when the outdoor temperature is 15.5°CWB (59.9°FWB) or higher, and cooling operation is not available when the outdoor temperature is below -10°CDB (14°FDB).	—
	Diagnose with remote controller indication	—	112, 113
	Check the remote controller addresses.	Check if address settings for the remote controller and indoor unit are correct.	187
Operation sometimes stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation. (Operation lamp OFF)	—
	Check the outdoor temperature.	Heating operation is not available when the outdoor temperature is 15.5°CWB (59.9°FWB) or higher, and cooling operation is not available when the outdoor temperature is below -10°CDB (14°FDB).	—
	Diagnose with remote controller indication.	—	112, 113
Some indoor units do not operate.	Check the type of the indoor units.	Check if the indoor unit type is compatible with the outdoor unit.	—
	Diagnose with remote controller indication	—	112, 113
Units operate but do not cool, or do not heat.	Check for wiring and piping errors in the connection between the indoor and outdoor units.	Check the piping. Conduct the wiring error check described on the product diagnosis nameplate.	—
	Check for thermistor detection errors.	Check if the thermistor is mounted securely.	—
	Check for faulty operation of the electronic expansion valve.	Set all the units to cooling operation, and compare the temperatures of the liquid pipes to see if the each electronic expansion valve works.	—
	Diagnose with remote controller indication.	—	112, 113
	Diagnose by service port pressure and operating current.	Check for refrigerant shortage.	134
Large operating noise and vibrations	Check the output voltage of the power module.	—	174
	Check the power module.	—	—
	Check the installation condition.	Check if the required spaces for installation (specified in the installation manual) are provided.	—

2. Troubleshooting with LED


2.1 Indoor Unit

Operation Lamp


The operation lamp blinks when any of the following errors is detected.

1. When a protection device of the indoor or outdoor unit is activated, or when the thermistor malfunctions.
 2. When a signal transmission error occurs between the indoor and outdoor units.
- In either case, conduct the diagnostic procedure described in the following pages.


CTXS/FTXS series




CDXS/FDXS series



FVXS series



BRC1E71/72/73



★The error or warning message also blinks on the basic screen. (R18816)

BRC7E830

In case of wireless remote controller, a signal receiver PCB and a display PCB are installed on indoor unit. When the error occurs, the operation lamp on the display PCB blinks.



- Caution:** When operation stops suddenly and the operation lamp blinks, it could be operation mode conflict.
- 1) Check if the operation modes all the same for the indoor units connected to multi system outdoor unit?
 - 2) If not, set all the indoor units to the same operation mode and confirm that the operation lamp is not blinking.
 - 3) Moreover, when the operation mode is automatic, set all the indoor unit operation mode as cooling or heating and check again if the operation lamp is normal.
- If the lamp stops blinking after the above steps, there is no malfunction.

*Operation stops and operation lamp blinks only for the indoor unit that has a different operation mode set later. (The first set operation mode has priority.)


Service Monitor

The indoor unit has a green LED (LED A or HAP) on the control PCB. When the microcomputer works in order, the LED blinks. (Refer to page 16, 18, 20, 22, 24 for the location of LED.)

2.2 Outdoor Unit

The outdoor unit has a green LED (LED A) and red LEDs (LED 1 ~ LED 5) on the PCB. When the microcomputer works in order, the LED A blinks, and when the system is in normal condition, the red LEDs are OFF.

Even after the error is canceled and the unit operates in normal condition, the LED indication remains.



(R21921)


3. Service Diagnosis

3.1 CTXS, FTXS, CDXS, FDXS, FVXS Series

3.1.1 ARC452 Series Remote Controller

Method 1

- When **TIMER CANCEL** button is held down for 5 seconds, **00** is displayed on the temperature display screen.



- Press **TIMER CANCEL** button repeatedly until a long beep sounds.
 - The code indication changes in the sequence shown below.

No.	Code	No.	Code	No.	Code
1	00	13	E7	25	UR
2	U4	14	R3	26	UX
3	L5	15	H8	27	P4
4	E6	16	H9	28	L3
5	H6	17	E9	29	L4
6	H0	18	E4	30	H7
7	R6	19	E5	31	U2
8	E7	20	J3	32	ER
9	U0	21	J6	33	RX
10	F3	22	E5	34	FR
11	R5	23	R1	35	H1
12	F6	24	E1	36	P9




Note:


- A short beep or two consecutive beeps indicate non-corresponding codes.
- To return to the normal mode, hold **TIMER CANCEL** button down for 5 seconds. When the remote controller is left untouched for 60 seconds, it also returns to the normal mode.
- Not all the error codes are displayed. When you cannot find the error code, try method 2. (→ Refer to page 101.)

Method 2


1. Press the 3 buttons (**TEMP▲**, **TEMP▼**, **MODE**) at the same time to enter the diagnosis mode.



The left-side number blinks.




2. Press **TEMP▲** or **TEMP▼** button and change the number until you hear the two consecutive beeps or the long beep.




3. Diagnose by the sound.
 - ★beep : The left-side number does not correspond with the error code.
 - ★two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.
 - ★long beep : Both the left-side and right-side number correspond with the error code. The numbers indicated when you hear the long beep are the error code. Refer to page 112, 113.


4. Press **MODE** button.



The right-side number blinks.




5. Press **TEMP ▲** or **TEMP ▼** button and change the number until you hear the long beep.




6. Diagnose by the sound.
- ★beep : The left-side number does not correspond with the error code.
 - ★two consecutive beeps : The left-side number corresponds with the error code but the right-side number does not.
 - ★long beep : Both the left-side and right-side number corresponds with the error code.
7. Determine the error code.
The numbers indicated when you hear the long beep are the error code.
Refer to page 112, 113.


8. Press **MODE** button to exit from the diagnosis mode.



The display **7-** means the trial operation mode.
Refer to page 179 for trial operation.



9. Press **ON/OFF** button twice to return to the normal mode.




Note: When the remote controller is left untouched for 60 seconds, it returns to the normal mode.

3.1.2 ARC466 Series Remote Controller

Method 1

1. When **Timer Cancel** button is held down for 5 seconds, **00** is displayed on the temperature display screen.



< ARC466 Series >

(R21282)

2. Press **Timer Cancel** button repeatedly until a long beep sounds.

- The code indication changes in the sequence shown below.

No.	Code	No.	Code	No.	Code
1	00	14	UD	27	UR
2	RS	15	EN	28	UR
3	EN	16	R3	29	P4
4	F3	17	MB	30	MT
5	F6	18	MS	31	U2
6	L3	19	EN	32	ER
7	L4	20	EN	33	RR
8	L5	21	EN	34	FR
9	U4	22	J3	35	H1
10	ES	23	US	36	PS
11	MS	24	ES	37	E3
12	MD	25	R1	38	M3
13	RS	26	E1		




Note:


1. A short beep or two consecutive beeps indicate non-corresponding codes.
2. To return to the normal mode, hold **Timer Cancel** button down for 5 seconds. When the remote controller is left untouched for 60 seconds, it also returns to the normal mode.
3. Not all the error codes are displayed. When you cannot find the error code, try method 2. (→ Refer to page 104.)

Method 2


1. Press the center of **Temp** button and **Mode** button at the same time.




5C is displayed on the LCD.




2. Select 5C (service check) with **Temp ▲** or **Temp ▼** button.
3. Press **Mode** button to enter the service check mode.



The left-side number blinks.




4. Press **Temp ▲** or **Temp ▼** button and change the number until you hear the two consecutive beeps or the long beep.




5. Diagnose by the sound.
 - ★ beep: The left-side number does not correspond with the error code.
 - ★ two consecutive beeps: The left-side number corresponds with the error code but the right-side number does not.
 - ★ long beep: Both the left-side and right-side numbers correspond with the error code.
The numbers indicated when you hear the long beep are the error code.
Refer to page 112, 113.


6. Press **Mode** button.



The right-side number blinks.




7. Press **Temp ▲** or **Temp ▼** button and change the number until you hear the long beep.



8. Diagnose by the sound.
 - ★ beep: The left-side number does not correspond with the error code.
 - ★ two consecutive beeps: The left-side number corresponds with the error code but the right-side number does not.
 - ★ long beep: Both the left-side and right-side numbers correspond with the error code.

9. Determine the error code.
The numbers indicated when you hear the long beep are the error code.
Refer to page 112, 113.

10. Press **Mode** button for 5 seconds to exit from the service check mode.
(When the remote controller is left untouched for 60 seconds, it returns to the normal mode also.)




3.2 FFQ Series

3.2.1 BRC1E71/72/73


Note: The illustrations are for BRC1E72 as representative.

Relations Between Modes



Service Check Function

The following message is displayed on the screen when an error (or a warning) occurs during operation. Check the error code and take the corrective action specified for the particular model.



(R18817)

(1) Check if it is error or warning.


	Operation status		Display
Abnormal shutdown	The system stops operating.	The operation lamp (green) starts to blink. The message Error: Push Menu button blinks at the bottom of the screen.	<p>(R18971)</p>
Warning	The system continues its operation.	The operation lamp (green) remains on. The message Warning: Push Menu button blinks at the bottom of the screen.	<p>(R18972)</p>

(2) Take corrective action.

- Press **Menu/OK** button to check the error code.



- Take the corrective action specific to the model.




(R18820)

3.2.2 BRC7E830

Relations Between Modes

The following modes can be selected by using the **INSPECTION/TEST** button on the remote controller.








Service Check Function



To find the error code, proceed as follows:

Step	Action
1	<p>Press INSPECTION/TEST button to enter the inspection mode. Then the figure 00 blinks on the UNIT No. display.</p> <p>The diagram shows a remote controller with various buttons: ON/OFF, TEMP TIME, UP, DOWN, FAN, RESERVE, CANCEL, TIMER, MODE, SWING, and INSPECTION/TEST. The INSPECTION/TEST button is specifically labeled with an arrow.</p>

(R14392)

Step	Action								
<p>2</p>	<p>Press UP or DOWN button and change the UNIT No. until the receiver of the remote controller starts to beep.</p> <div data-bbox="743 308 1274 846" style="text-align: center;">  <p style="margin-left: 150px;">UP button DOWN button</p> </div> <p style="text-align: right;">(R15408)</p> <table border="1" data-bbox="630 925 1388 1166" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">If you hear...</th> <th style="text-align: left;">Then...</th> </tr> </thead> <tbody> <tr> <td>3 short beeps</td> <td>Follow all steps below.</td> </tr> <tr> <td>1 short beep</td> <td>Follow steps 3 and 4. Continue the operation in step 4 until you hear a continuous beep. This continuous beep indicates that the error code is confirmed.</td> </tr> <tr> <td>1 continuous beep</td> <td>There is no abnormality.</td> </tr> </tbody> </table>	If you hear...	Then...	3 short beeps	Follow all steps below.	1 short beep	Follow steps 3 and 4. Continue the operation in step 4 until you hear a continuous beep. This continuous beep indicates that the error code is confirmed.	1 continuous beep	There is no abnormality.
If you hear...	Then...								
3 short beeps	Follow all steps below.								
1 short beep	Follow steps 3 and 4. Continue the operation in step 4 until you hear a continuous beep. This continuous beep indicates that the error code is confirmed.								
1 continuous beep	There is no abnormality.								
<p>3</p>	<p>Press MODE button. The left  (upper digit) indication of the error code blinks.</p> <div data-bbox="760 1244 1258 1783" style="text-align: center;">  <p style="margin-left: 150px;">MODE button</p> </div> <p style="text-align: right;">(R15410)</p>								

Step	Action								
4	<p>Press UP or DOWN button to change the error code upper digit until the receiver of the remote controller starts to beep.</p>  <p style="text-align: right;">(R15411)</p> <table border="1" data-bbox="630 925 1388 1074"> <thead> <tr> <th>If you hear...</th> <th>Then...</th> </tr> </thead> <tbody> <tr> <td>2 short beeps</td> <td>The upper digit matches.</td> </tr> <tr> <td>1 short beep</td> <td>No digits match.</td> </tr> <tr> <td>1 continuous beep</td> <td>Both upper and lower digits match.</td> </tr> </tbody> </table>	If you hear...	Then...	2 short beeps	The upper digit matches.	1 short beep	No digits match.	1 continuous beep	Both upper and lower digits match.
If you hear...	Then...								
2 short beeps	The upper digit matches.								
1 short beep	No digits match.								
1 continuous beep	Both upper and lower digits match.								
5	<p>Press MODE button. The right ⌘ (lower digit) indication of the error code blinks.</p>  <p style="text-align: right;">(R15412)</p>								

Step	Action
<p>6</p>	<p>Press UP or DOWN button and change the error code lower digit until the receiver of the remote controller generates a continuous beep.</p>  <p>(R15413)</p>
<p>7</p>	<p>Press MODE button to return to the normal mode. If you do not press any button for 1 minutes, the remote controller automatically returns to the normal mode.</p>  <p>(R18821)</p>

4. Code Indication on Remote Controller

4.1 CTXS, FTXS, CDXS, FDXS, FVXS Series

Error Codes	Description	Reference Page	
00	Normal condition	—	
P1	Indoor unit PCB abnormality	114	
P5	Freeze-up protection control/heating peak-cut control	116	
P6	Fan motor or related abnormality	DC motor (CTXS, FTXS, FVXS series)	117
		AC motor (CDXS, FDXS series)	119
C4	Indoor heat exchanger thermistor or related abnormality	121	
C9	Room temperature thermistor or related abnormality	121	
U4	Signal transmission error (between indoor unit and outdoor unit)	122	
UR	Unspecified voltage (between indoor unit and outdoor unit)	124	

4.2 FFQ Series

Error Codes	Description	Reference Page
00	Normal condition	—
P1	Indoor unit PCB abnormality	125
P3	Drain level control system abnormality	126
P6	Fan motor (AC motor) or related abnormality (See the Note below.)	127
P6	Drain system abnormality	128
C4	Indoor heat exchanger thermistor 1 or related abnormality	129
C5	Indoor heat exchanger thermistor 2 or related abnormality	129
C9	Room temperature thermistor or related abnormality	129
CJ	Remote controller thermistor abnormality	130
U5	Signal transmission error (between indoor unit and remote controller)	131
U8	Signal transmission error (between MAIN remote controller and SUB remote controller)	132
UR	Field setting abnormality	133

: Error code displays automatically and system stops.
Inspect and solve the error.

: In the case of the shaded error codes, inspection is not displayed. The system operates, but be sure to inspect and solve the error.



Note: When there is a possibility of open phase power supply, also check power supply.

4.3 Outdoor Unit

☀: ON, ●: OFF, ⦿: Blinks

Outdoor Unit LED Indication						Error Codes	Description	Reference Page
Green	Red							
A	1	2	3	4	5			
⦿	●	●	●	●	●	00	Normal condition	—
						UR	Unspecified voltage (between indoor unit and outdoor unit)	139
						UR	Anti-icing control in other rooms	139
⦿	●	●	☀	☀	●	(UR)	Refrigerant shortage	134
⦿	☀	●	●	☀	●	U2	Low-voltage detection or over-voltage detection	136
⦿	●	☀	●	●	●	U3	Wiring Error Check Unexecuted	138
⦿	☀	●	☀	☀	●	RS	Anti-icing control for indoor unit	140
⦿	☀	☀	☀	●	●	E1	Outdoor unit PCB abnormality	142
⦿	☀	●	☀	●	●	(EE)	OL activation (compressor overload)	143
⦿	●	☀	☀	●	●	(EE)	Compressor lock	145
⦿	☀	☀	☀	☀	●	E7	DC fan lock	146
⦿	●	☀	●	☀	●	E8	Input overcurrent detection	147
⦿	☀	●	●	●	●	ER	Four way valve abnormality	148
⦿	☀	●	☀	●	●	F3	Discharge pipe temperature control	150
⦿	☀	●	☀	☀	●	F5	High pressure control in cooling	151
⦿	☀	☀	●	●	●	H0	Compressor sensor system abnormality	152
						H5	Position sensor abnormality	154
						H8	CT or related abnormality	156
						H9	Outdoor temperature thermistor or related abnormality	158
						J3	Discharge pipe thermistor or related abnormality	158
						J5	Outdoor heat exchanger thermistor or related abnormality	158
						J8	Liquid pipe thermistor or related abnormality	158
						J9	Gas pipe thermistor or related abnormality	158
						P4	Radiation fin thermistor or related abnormality	158
⦿	☀	☀	●	☀	●	L3	Electrical box temperature rise	160
⦿	●	●	●	☀	●	L4	Radiation fin temperature rise	161
⦿	●	●	☀	●	●	L5	Output overcurrent detection	162
☀	—	—	—	—	—	—	See the note 4.	—
●	—	—	—	—	—	—	Check the power supply.	—



Note:

- The error codes in the parenthesis () are displayed only when the system is shut down.
- When a sensor error occurs, check the remote controller display to determine which sensor is malfunctioning.
If the remote controller does not indicate the error code, conduct the following procedure.
 - * Turn the power off and then on again. If the same LED indication appears again immediately after the power is turned on, the fault is in the thermistor.
 - * If the above condition does not result, the fault is in the CT.
- The indoor unit error code may take the precedence in the remote controller display.
- Turn the power off and then on again. If the same LED indication appears again, outdoor unit PCB is faulty. Replace the outdoor unit PCB.

5. Troubleshooting for CTXS, FTXS, CDXS, FDXS, FVXS Series


5.1 Indoor Unit PCB Abnormality

Error Code	A1
Method of Error Detection	The system checks if the circuit works properly within the microcomputer of the indoor unit.
Error Decision Conditions	The system cannot set the internal settings.
Supposed Causes	<ul style="list-style-type: none">■ Wrong models interconnected■ Defective indoor unit PCB■ Disconnection of connector■ Reduction of power supply voltage

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R20421)



Note: Check the following connector.


Model Type	Connector
CTXS, FTXS, CDXS, FDXS, FVXS series	Terminal board ~ Control PCB (H1, H2, H3)

5.2 Freeze-up Protection Control/Heating Peak-cut Control

Error Code	A5
Method of Error Detection	<ul style="list-style-type: none"> ■ Freeze-up protection control During cooling operation, the freeze-up protection control (operation halt) is activated according to the temperature detected by the indoor heat exchanger thermistor. ■ Heating peak-cut control During heating operation, the temperature detected by the indoor heat exchanger thermistor is used for the heating peak-cut control (operation halt, outdoor fan stop, etc.)
Error Decision Conditions	<ul style="list-style-type: none"> ■ Freeze-up protection control During cooling operation, the indoor heat exchanger temperature is below 0°C (32°F). ■ Heating peak-cut control During heating operation, the indoor heat exchanger temperature is above 65°C (149°F).
Supposed Causes	<ul style="list-style-type: none"> ■ Short-circuited air ■ Clogged air filter of the indoor unit ■ Dust accumulation on the indoor heat exchanger ■ Defective indoor heat exchanger thermistor ■ Defective indoor unit PCB

Troubleshooting


Check No.01
 Refer to P.164



(R21064)

5.3 Fan Motor or Related Abnormality

5.3.1 DC Motor (CTXS, FTXS, FVXS Series)

Error Code	R6
Method of Error Detection	The rotation speed detected by the Hall IC during fan motor operation determines abnormal fan motor operation.
Error Decision Conditions	The detected rotation speed does not reach the demanded rotation speed of the target tap, and is less than 50% of the maximum fan motor rotation speed.
Supposed Causes	<ul style="list-style-type: none">■ Remarkable decrease in power supply voltage■ Layer short inside the fan motor winding■ Breaking of wire inside the fan motor■ Breaking of the fan motor lead wires■ Defective capacitor of the fan motor■ Defective indoor unit PCB

Troubleshooting




Check No.02
Refer to P.165



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Note: The rotation pulse is the feedback signal from the indoor fan motor.

(R22444)

5.3.2 AC Motor (CDXS, FDXS Series)

Error code	FE
Method of Error Detection	The rotation speed detected by the Hall IC during fan motor operation determines abnormal fan motor operation.
Error Decision Conditions	The detected rotation speed does not reach the demanded rotation speed of the target tap.
Supposed Causes	<ul style="list-style-type: none">■ Power supply voltage is not as specified.■ Layer short inside the fan motor winding■ Breaking of wire inside the fan motor■ Breaking of the fan motor lead wires■ Defective capacitor of the fan motor■ Defective indoor unit PCB


Troubleshooting



Check No.04
Refer to P.165



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R22267)

5.4 Thermistor or Related Abnormality

Error Code	U4, U9
Method of Error Detection	The temperatures detected by the thermistors determine thermistor errors.
Error Decision Conditions	The voltage between the both ends of the thermistor is 4.96 V and more or 0.04 V and less during compressor operation.
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of connector ■ Thermistor corresponding to the error code is defective. ■ Defective indoor unit PCB

Troubleshooting




Check No.01
Refer to P.164



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R21870)

U4 : Indoor heat exchanger thermistor

U9 : Room temperature thermistor

5.5 Signal Transmission Error (Between Indoor Unit and Outdoor Unit)

Error Code	U4
Method of Error Detection	The data received from the outdoor unit in signal transmission is checked whether it is normal.
Error Decision Conditions	The data sent from the outdoor unit cannot be received normally, or the content of the data is abnormal.
Supposed Causes	<ul style="list-style-type: none">■ Reduction of power supply voltage■ Wiring error■ Breaking of the connection wires between the indoor and outdoor units (wire No. 3)■ Defective outdoor unit PCB■ Short circuit inside the fan motor winding■ Defective indoor unit PCB■ Disturbed power supply waveform


Troubleshooting



Check No.11
Refer to P.166



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R21193)

5.6 Unspecified Voltage (Between Indoor Unit and Outdoor Unit)

Error Code	U8
Method of Error Detection	The supply power is detected for its requirements (pair type is different from multi type) by the indoor/outdoor transmission signal.
Error Decision Conditions	The pair type and multi type are interconnected.
Supposed Causes	<ul style="list-style-type: none"> ■ Wrong models interconnected ■ Wrong wiring of connecting wires ■ Wrong indoor unit PCB or outdoor unit PCB mounted ■ Defective indoor unit PCB ■ Defective outdoor unit PCB

Troubleshooting



6. Troubleshooting for FFQ Series


6.1 Indoor Unit PCB Abnormality

Error Code	A1
Method of Error Detection	The system checks the data from EEPROM.
Error Decision Conditions	<p>The data from the EEPROM is not received correctly.</p> <p>EEPROM (Electrically Erasable Programmable Read Only Memory): A memory chip that holds its content without power. It can be erased, either within the computer or externally and usually requires more voltage for erasure than the common +5 volts used in logic circuits. It functions like non-volatile RAM, but writing to EEPROM is slower than writing to RAM.</p>
Supposed Causes	<ul style="list-style-type: none"> ■ Defective indoor unit PCB ■ External factor (noise etc.)

Troubleshooting


Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R22247)


6.2 Drain Level Control System Abnormality

Error Code	A3
Method of Error Detection	The float switch detects error.
Error Decision Conditions	The water level reaches its upper limit and the float switch turns OFF.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective drain pump ■ Improper drain piping work ■ Clogged drain piping ■ Defective float switch ■ Defective indoor unit PCB ■ Defective short circuit connector X15A on indoor unit PCB

Troubleshooting




(R22268)

 **Note:** For the location of the switch (SS1), refer to page 24.


6.3 Fan Motor (AC Motor) or Related Abnormality

Error Code	R6
Method of Error Detection	The signal from the fan motor detects abnormal fan speed.
Error Decision Conditions	The fan rotations are not detected while the output voltage to the fan is at its maximum.
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection, short circuit or disengagement of connector in fan motor harness ■ Defective fan motor (disconnection, poor insulation) ■ Abnormal signal from fan motor (faulty circuit) ■ Defective indoor unit PCB ■ Momentary fluctuation of power supply voltage ■ Fan motor lock (Caused by motor or other external factors) ■ Fan does not rotate due to tangled foreign matters

Troubleshooting


Note:

1. Check the connector of fan motor. (Power supply cable)
2. Turn OFF the power.
3. Measure the resistance between the terminals at the motor side connectors to check that there is no short circuit, while the connector is disconnected.



Measuring points	Resistance for judgement
(1) - (3)	88.2 Ω ± 10%
(2) - (3)	85.5 Ω ± 10%


6.4 Drain System Abnormality

Error Code	AF
Method of Error Detection	Water leakage is detected based on the float switch ON/OFF changeover while the compressor is not operating.
Error Decision Conditions	The float switch changes from ON to OFF while the compressor is OFF.
Supposed Causes	<ul style="list-style-type: none"> ■ Error in the drain pipe installation ■ Defective float switch ■ Defective indoor unit PCB

Troubleshooting



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R16022)

6.5 Thermistor or Related Abnormality

Error Code	ℰ4, ℰ5, ℰ9
Method of Error Detection	The temperatures detected by the thermistors determine thermistor errors.
Error Decision Conditions	The voltage between the both ends of the thermistor is 4.96 V and more or 0.04 V and less during compressor operation.
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of connector ■ Thermistor corresponding to the error code is defective. ■ Defective indoor unit PCB

Troubleshooting If the cause of the problem is related to the thermistors, the thermistors should be checked prior to changing the indoor unit PCB.




Check No.01
Refer to P.164

To check the thermistors, proceed as follows:

Step	Action
1	Disconnect the thermistor from the indoor unit PCB.
2	Read the temperature and the resistance value.
3	Check if the measured values correspond with the values in the table of thermistor resistance check.

Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R21870)

- ℰ4 : Indoor heat exchanger thermistor 1 (liquid pipe) (R2T)
- ℰ5 : Indoor heat exchanger thermistor 2 (R3T)
- ℰ9 : Room temperature thermistor (R1T)

6.6 Remote Controller Thermistor Abnormality

Error Code	
Method of Error Detection	Even if remote controller thermistor is faulty, system is possible to operate by system thermistor. Malfunction detection is carried out by the temperature detected by the remote controller thermistor.
Error Decision Conditions	The remote controller thermistor is disconnected or shorted while the unit is running.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective thermistor ■ Broken wire

Troubleshooting




(R21111)

Note: To delete the record of error codes, press **ON/OFF** button for 4 seconds or more while the error code is displayed in the inspection mode.

6.7 Signal Transmission Error (Between Indoor Unit and Remote Controller)

Error Code	U5
Method of Error Detection	In case of controlling with 2 remote controllers, check the system using microcomputer if signal transmission between indoor unit and remote controller (main and sub) is normal.
Error Decision Conditions	Normal transmission does not continue for specified period.
Supposed Causes	<ul style="list-style-type: none"> ■ Connection of 2 main remote controllers (when using 2 remote controllers) ■ Defective indoor unit PCB ■ Defective remote controller ■ Transmission error caused by noise
Troubleshooting	




(R22251)

6.8 Signal Transmission Error (Between MAIN Remote Controller and SUB Remote Controller)

Error Code	U8
Method of Error Detection	In case of controlling with 2 remote controllers, check the system using microcomputer if signal transmission between MAIN remote controller and SUB remote controller is normal.
Error Decision Conditions	Normal transmission does not continue for specified period.
Supposed Causes	<ul style="list-style-type: none"> ■ Remote controller is set to SUB when using 1 remote controller ■ Connection of 2 sub remote controllers (when using 2 remote controllers) ■ Defective remote controller PCB

Troubleshooting




(R21113)

6.9 Field Setting Abnormality

Error Code	U8
Error Decision Conditions	Incorrect field setting
Supposed Causes	<ul style="list-style-type: none"> ■ Defective indoor unit PCB ■ Defective outdoor unit PCB ■ Improper power supply ■ Indoor-outdoor, indoor-indoor unit transmission wiring ■ Defective remote controller wiring




Troubleshooting



(R22125)

7. Troubleshooting for Outdoor Unit

7.1 Refrigerant Shortage

Error Code	U0						
Outdoor Unit LED Display	A  1 ● 2 ● 3  4  5 ●						
Method of Error Detection	Refrigerant shortage is detected by checking the input current value and the compressor output frequency. If the refrigerant is short, the input current is smaller than the normal value.						
Error Decision Conditions	<p>The following conditions continue for 7 minutes.</p> <ul style="list-style-type: none"> ◆ Input current $\leq A \times$ output frequency + B ◆ Output frequency > C <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>A (-)</th> <th>B (A)</th> <th>C (Hz)</th> </tr> </thead> <tbody> <tr> <td>27/1000</td> <td>2</td> <td>40</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 60 minutes without any other error 	A (-)	B (A)	C (Hz)	27/1000	2	40
A (-)	B (A)	C (Hz)					
27/1000	2	40					
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of the discharge pipe thermistor, indoor or outdoor heat exchanger thermistor, room or outdoor temperature thermistor ■ Closed stop valve ■ Refrigerant shortage (refrigerant leakage) ■ Poor compression performance of compressor ■ Defective electronic expansion valve 						

Troubleshooting




Check No.01
Refer to P.164



Check No.12
Refer to P.167








Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R20401)

7.2 Low-voltage Detection or Over-voltage Detection



Error Code	U2
Outdoor Unit LED Display	A  1  2  3  4  5
Method of Error Detection	<p>★ Indoor Unit</p> <p>The zero-cross detection of the power supply is evaluated by the indoor unit PCB.</p> <p>★ Outdoor Unit</p> <p>Low-voltage detection: An abnormal voltage drop is detected by the DC voltage detection circuit.</p> <p>Over-voltage detection: An abnormal voltage rise is detected by the over-voltage detection circuit.</p>
Error Decision Conditions	<p>★ Indoor Unit</p> <p>There is no zero-cross detection in approximately 10 seconds.</p> <p>★ Outdoor Unit</p> <p>Low-voltage detection:</p> <ul style="list-style-type: none"> ■ The voltage detected by the DC voltage detection circuit is below 150 V for 0.1 second. ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 60 minutes without any other error <p>Over-voltage detection:</p> <ul style="list-style-type: none"> ■ An over-voltage signal is fed from the over-voltage detection circuit to the microcomputer. ■ The compressor stops if the error occurs, and restarts automatically after 3-minute standby.
Supposed Causes	<ul style="list-style-type: none"> ■ Power supply voltage is not as specified. ■ Defective DC voltage detection circuit ■ Defective over-voltage detection circuit ■ Defective PAM control part ■ Disconnection of compressor harness ■ Short circuit inside the fan motor winding ■ Noise ■ Momentary drop of voltage ■ Momentary power failure ■ Defective outdoor unit PCB ■ Defective indoor unit PCB

Troubleshooting




(R22370)

7.3 Wiring Error Check Unexecuted


Error Code	U3
Outdoor Unit LED Display	A  1 ● 2  3 ● 4 ● 5 ●
Method of Error Detection	The system checks if wiring error check is executed after clearing the memory.
Error Decision Conditions	An error is determined when the unit is operated by the remote controller without executing wiring error check after the memory was cleared.
Supposed Causes	The wiring error switch (SW3) may have been pressed for 10 seconds or more and the memory may have been deleted. The unit cannot be operated unless wiring error check is executed.

Troubleshooting




(R22429)

7.4 Unspecified Voltage (Between Indoor Unit and Outdoor Unit)/Anti-icing Control in Other Rooms

Error Code	UR, UR
Outdoor Unit LED Display	A  1 ● 2 ● 3 ● 4 ● 5 ●
Method of Error Detection	A wrong connection is detected by checking the combination of indoor and outdoor units on the microcomputer.
Error Decision Conditions	<ul style="list-style-type: none"> ■ Anti-icing control in other rooms ■ Unspecified internal and/or external voltages ■ Mismatching of indoor and outdoor units
Supposed Causes	<ul style="list-style-type: none"> ■ Anti-icing function in other rooms ■ Power supply voltage is not as specified. ■ Wrong models interconnected ■ Wrong indoor unit PCB or outdoor unit PCB mounted

Troubleshooting









(R21922)



Note: Refer to Anti-icing control for indoor unit on page 140 for detail.

7.5 Anti-icing Control for Indoor Unit

Error Code	A5
Outdoor Unit LED Display	A  1  2  3  4  5 
Method of Error Detection	During cooling operation, indoor unit icing is detected by checking the temperatures sensed by the indoor heat exchanger thermistor and room temperature thermistor that are located in a shut-down room.
Error Decision Conditions	<ul style="list-style-type: none"> ■ In cooling operation, the both conditions (A) and (B) are met for 5 minutes. <ul style="list-style-type: none"> (A) Room temperature – Indoor heat exchanger temperature $\geq 10^{\circ}\text{C}$ (18°F) (B) Indoor heat exchanger temperature $\leq -1^{\circ}\text{C}$ (30.2°F) ■ If the error repeats, the system is shut down. ■ Reset condition: 3-minute standby is over and the indoor heat exchanger temperature is above 0°C (32°F)
Supposed Causes	<ul style="list-style-type: none"> ■ Wrong wiring or piping ■ Defective electronic expansion valve ■ Short-circuited air ■ Defective indoor heat exchanger thermistor ■ Defective room temperature thermistor

Troubleshooting



Check No.01
Refer to P.164




Check No.12
Refer to P.167



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R21923)

7.6 Outdoor Unit PCB Abnormality






Error Code	E1
Outdoor Unit LED Display	A ● 1 ● 2 ● 3 ● 4 ● 5 ●
Method of Error Detection	Detect within the program of the microcomputer.
Error Decision Conditions	The program of the microcomputer is in abnormal running order.
Supposed Causes	<ul style="list-style-type: none"> ■ Defective outdoor unit PCB ■ Noise ■ Momentary drop of voltage ■ Momentary power failure

Troubleshooting



(R21809)

7.7 OL Activation (Compressor Overload)

Error Code	E5
Outdoor Unit LED Display	A  1  2  3  4  5
Method of Error Detection	A compressor overload is detected through compressor OL.
Error Decision Conditions	<ul style="list-style-type: none"> ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 60 minutes without any other error
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of discharge pipe thermistor ■ Defective discharge pipe thermistor ■ Disconnection of connector S40 ■ Disconnection of 2 terminals of OL (Q1L) ■ Defective OL (Q1L) ■ Broken OL harness ■ Defective electronic expansion valve or coil ■ Defective four way valve or coil ■ Defective outdoor unit PCB ■ Refrigerant shortage ■ Water mixed in refrigerant ■ Defective stop valve

Troubleshooting



Check No.01
Refer to P.164



Check No.12
Refer to P.167




Check No.13
Refer to P.168



Check No.14
Refer to P.168



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



Note: OL (Q1L) activating temperature: 130°C (266°F)
OL (Q1L) recovery temperature: 95°C (203°F)

7.8 Compressor Lock

Error Code	E6
Outdoor Unit LED Display	A ● 1 ● 2 ● 3 ● 4 ● 5 ●
Method of Error Detection	A compressor lock is detected by checking the compressor running condition through the position detection circuit.
Error Decision Conditions	<ul style="list-style-type: none"> ■ Judging from the current waveform generated when high-frequency voltage is applied to the compressor. ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 5 minutes without any other error
Supposed Causes	<ul style="list-style-type: none"> ■ Closed stop valve ■ Defective outdoor unit PCB ■ Defective compressor ■ Defective electronic expansion valve

Troubleshooting



Check No.12
Refer to P.167




Check No.15
Refer to P.169



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.
(Precaution before turning on the power again)
Make sure the power has been off for at least 30 seconds.




(R21067)

7.9 DC Fan Lock

Error Code	E7
Outdoor Unit LED Display	A 1 2 3 4 5 ●
Method of Error Detection	An error is determined with the high-voltage fan motor rotation speed detected by the Hall IC.
Error Decision Conditions	<ul style="list-style-type: none"> ■ The fan does not start in 30 seconds even when the fan motor is running. ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 5 minutes without any other error
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of the fan motor ■ Foreign matter stuck in the fan ■ Defective fan motor ■ Defective outdoor unit PCB

Troubleshooting

Check No.16
Refer to P.170



7.10 Input Overcurrent Detection

Error Code	E8
Outdoor Unit LED Display	A ● 1 ● 2 ● 3 ● 4 ● 5 ●
Method of Error Detection	Detected by checking the input current value
Error Decision Conditions	<ul style="list-style-type: none"> ■ The input current is at a certain value (depending on the condition) for 2.5 seconds. ■ The compressor halts if the error occurs, and restarts automatically after 3-minute standby.
Supposed Causes	<ul style="list-style-type: none"> ■ Outdoor temperature is out of operation range. ■ Defective compressor ■ Defective power module ■ Defective outdoor unit PCB ■ Short circuit

Troubleshooting

 **Check No.15**
Refer to P.169


 **Check No.17**
Refer to P.171

 **Check No.18**
Refer to P.171





Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

* An input overcurrent may result from wrong internal wiring. If the system is interrupted by an input overcurrent after the wires have been disconnected and reconnected for part replacement, check the wiring again.



(R21863)

7.11 Four Way Valve Abnormality

Error Code	EA						
Outdoor Unit LED Display	A  1  2 ● 3 ● 4 ● 5 ●						
Method of Error Detection	The liquid pipe thermistor and the outdoor heat exchanger thermistor are checked to see if they function within their normal ranges in the operating mode.						
Error Decision Conditions	<p>A following condition continues for A seconds after the compressor has started.</p> <table border="1"> <thead> <tr> <th></th> <th>A (seconds)</th> </tr> </thead> <tbody> <tr> <td>Other than below</td> <td>240</td> </tr> <tr> <td>Heating (when outdoor temperature is below -15°C (5°F))</td> <td>460</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ■ Cooling operation The lowest liquid pipe temperature among the rooms in operation –Tde > 45°C (81°F) ■ Heating operation The highest liquid pipe temperature among the rooms in operation –Tde < 0°C (0°F) <p>Tde: outdoor heat exchanger temperature</p>		A (seconds)	Other than below	240	Heating (when outdoor temperature is below -15°C (5°F))	460
	A (seconds)						
Other than below	240						
Heating (when outdoor temperature is below -15°C (5°F))	460						
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of four way valve coil ■ Defective four way valve, coil, or harness ■ Defective outdoor unit PCB ■ Defective thermistor ■ Refrigerant shortage ■ Water mixed in refrigerant ■ Defective stop valve 						

Troubleshooting



Check No.01
Refer to P.164




Check No.13
Refer to P.168



Check No.14
Refer to P.168



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.




(R20405)

7.12 Discharge Pipe Temperature Control

Error Code	F3				
Outdoor Unit LED Display	A 1 2 3 4 5				
Method of Error Detection	An error is determined with the temperature detected by the discharge pipe thermistor.				
Error Decision Conditions	<ul style="list-style-type: none"> ■ If the temperature detected by the discharge pipe thermistor rises above A, the compressor stops. ■ The error is cleared when the discharge pipe temperature is dropped below B. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>A</th> <th>B</th> </tr> </thead> <tbody> <tr> <td>120°C (248°F)</td> <td>107°C (224.6°F)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 60 minutes without any other error 	A	B	120°C (248°F)	107°C (224.6°F)
A	B				
120°C (248°F)	107°C (224.6°F)				
Supposed Causes	<ul style="list-style-type: none"> ■ Defective discharge pipe thermistor (Defective outdoor heat exchanger thermistor or outdoor temperature thermistor) ■ Defective electronic expansion valve or coil ■ Refrigerant shortage ■ Defective four way valve ■ Water mixed in refrigerant ■ Defective stop valve ■ Defective outdoor unit PCB 				

Troubleshooting

- Check No.01**
Refer to P.164
- Check No.12**
Refer to P.167
- Check No.14**
Refer to P.168




7.13 High Pressure Control in Cooling

Error Code	F6
Outdoor Unit LED Display	A 1 2 3 4 5
Method of Error Detection	High pressure control (operation halt, frequency drop, etc.) is activated in cooling operation if the temperature sensed by the outdoor heat exchanger thermistor exceeds the limit.
Error Decision Conditions	<ul style="list-style-type: none"> ■ The temperature sensed by the outdoor heat exchanger thermistor rises above 65°C (149°F). ■ The error is cleared when the temperature drops below about 49°C (120.2°F).
Supposed Causes	<ul style="list-style-type: none"> ■ The installation space is not large enough. ■ Dirty outdoor heat exchanger ■ Defective outdoor fan motor ■ Defective stop valve ■ Defective electronic expansion valve or coil ■ Defective outdoor heat exchanger thermistor ■ Defective outdoor unit PCB






Troubleshooting


- Check No.01**
Refer to P.164
- Check No.12**
Refer to P.167
- Check No.17**
Refer to P.171
- Check No.18**
Refer to P.171
- Check No.19**
Refer to P.172



(R20418)

7.14 Compressor Sensor System Abnormality


Error Code	H0
Outdoor Unit LED Display	A  1  2  3  4  5
Method of Error Detection	<ul style="list-style-type: none"> ■ The system checks the power supply voltage and the DC voltage before the compressor starts. ■ The system checks the DC current of the compressor right after the compressor starts.



(R22001)






Error Decision Conditions	<ul style="list-style-type: none"> ■ The power supply voltage and the DC voltage is obviously low or high. ■ The DC current of the compressor does not flow when the compressor starts.
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of reactor ■ Disconnection of compressor harness ■ Defective outdoor unit PCB ■ Defective compressor

Troubleshooting



(R20419)

7.15 Position Sensor Abnormality

Error Code	H6
Outdoor Unit LED Display	A  1  2  3  4  5
Method of Error Detection	A compressor start-up failure is detected by checking the compressor running condition through the position detection circuit.
Error Decision Conditions	<ul style="list-style-type: none"> ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 5 minutes without any other error
Supposed Causes	<ul style="list-style-type: none"> ■ Power supply voltage is not as specified. ■ Disconnection of the compressor harness ■ Defective compressor ■ Defective outdoor unit PCB ■ Start-up failure caused by the closed stop valve ■ Input voltage is outside the specified range.

Troubleshooting



Check No.15
Refer to P.169




Check No.18
Refer to P.171



Check No.20
Refer to P.172








Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R22270)

7.16 CT or Related Abnormality

Error Code	H8				
Outdoor Unit LED Display	A  1  2  3  4  5				
Method of Error Detection	A CT or related error is detected by checking the compressor running frequency and CT-detected input current.				
Error Decision Conditions	<ul style="list-style-type: none"> ■ The compressor running frequency is more than A Hz and input current is less than B A. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th style="padding: 2px;">A (Hz)</th> <th style="padding: 2px;">B (A)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 2px;">55</td> <td style="text-align: center; padding: 2px;">0.5</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 60 minutes without any other error 	A (Hz)	B (A)	55	0.5
A (Hz)	B (A)				
55	0.5				
Supposed Causes	<ul style="list-style-type: none"> ■ Defective power module ■ Broken or disconnected wiring ■ Defective reactor ■ Defective outdoor unit PCB 				

Troubleshooting



Check No.15
Refer to P.169



Check No.21
Refer to P.173



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.


Turn off the power. Then, turn on the power to restart the system.

Start operation.

* Running current as shown at right with relay cable 1 or 2?

YES

Replace the outdoor unit PCB (main PCB).



NO

Check No. 21
Check the capacitor voltage.

Within $320 + \frac{100}{50}$ VDC?

YES

Turn off the power. Disconnect the harnesses U, V, and W.

Check No.15
Check with the inverter analyzer.

* Inverter analyzer: RSUK0917C

Any LED OFF?

YES

Correct the power supply or replace the outdoor unit PCB (main PCB).

NO

Turn off the power and reconnect the harnesses. Then turn on the power again and restart operation.

Compressor running?

NO

Replace the compressor.

YES

Replace the outdoor unit PCB (main PCB).

Measure the rectifier input voltage.

Voltage within the allowable range (Power supply voltage $\pm 15\%$)?

NO







Check the power supply voltage.

YES

Replace the outdoor unit PCB (main PCB).

(R22271)

7.17 Thermistor or Related Abnormality (Outdoor Unit)

Error Code	<i>H3, U3, U6, U8, U9, P4</i>
Outdoor Unit LED Display	A  1  2  3  4  5
Method of Error Detection	This fault is identified based on the thermistor input voltage to the microcomputer. A thermistor fault is identified based on the temperature sensed by each thermistor.
Error Decision Conditions	<ul style="list-style-type: none"> ■ The voltage between the both ends of the thermistor is above 4.96 V or below 0.04 V with the power on. ■ <i>U3</i> error is judged if the discharge pipe temperature is lower than the heat exchanger temperature. ■ The system is shut down if all the units are judged as the <i>U3</i> error.
Supposed Causes	<ul style="list-style-type: none"> ■ Disconnection of the connector for the thermistor ■ Thermistor corresponding to the error code is defective. ■ Defective heat exchanger thermistor in the case of <i>U3</i> error (outdoor heat exchanger thermistor in cooling operation, or indoor heat exchanger thermistor in heating operation) ■ Defective outdoor unit PCB
Troubleshooting	<p>In case of <i>P4</i></p> <p> Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.</p> <p>Replace the outdoor unit PCB (main PCB).</p> <p><i>P4</i> : Radiation fin thermistor</p>

Troubleshooting


In case of *H9, J3, J5, J8, J9*


Check No.01
 Refer to P.164



Caution

Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.



(R21118)

- H9* : Outdoor temperature thermistor
- J3* : Discharge pipe thermistor
- J5* : Outdoor heat exchanger thermistor
- J8* : Liquid pipe thermistor
- J9* : Gas pipe thermistor


7.18 Electrical Box Temperature Rise

Error Code	L3						
Outdoor Unit LED Display	A ● 1 ☀ 2 ☀ 3 ● 4 ☀ 5 ●						
Method of Error Detection	An electrical box temperature rise is detected by checking the radiation fin thermistor with the compressor off.						
Error Decision Conditions	<ul style="list-style-type: none"> ■ With the compressor off, the radiation fin temperature is above A. ■ The error is cleared when the temperature drops below B. ■ To cool the electrical components, the outdoor fan starts when the radiation fin temperature rises above C and stops when the radiation fin temperature drops below B. 						
	<table border="1"> <thead> <tr> <th>A</th> <th>B</th> <th>C</th> </tr> </thead> <tbody> <tr> <td>100°C (212°F)</td> <td>70°C (158°F)</td> <td>85°C (185°F)</td> </tr> </tbody> </table>	A	B	C	100°C (212°F)	70°C (158°F)	85°C (185°F)
A	B	C					
100°C (212°F)	70°C (158°F)	85°C (185°F)					
Supposed Causes	<ul style="list-style-type: none"> ■ Defective outdoor fan motor ■ Short circuit ■ Defective radiation fin thermistor ■ Disconnection of connector ■ Defective outdoor unit PCB 						

Troubleshooting

 **Check No.17**
Refer to P.171

 **Check No.19**
Refer to P.172




(R22272)

7.19 Radiation Fin Temperature Rise

Error Code	L4				
Outdoor Unit LED Display	A 1 ● 2 ● 3 ● 4 5 ●				
Method of Error Detection	A radiation fin temperature rise is detected by checking the radiation fin temperature with the compressor on.				
Error Decision Conditions	<ul style="list-style-type: none"> ■ The radiation fin temperature with the compressor on is above A. ■ The error is cleared when the temperature drops below B. <table border="1"> <thead> <tr> <th>A</th> <th>B</th> </tr> </thead> <tbody> <tr> <td>90°C (194°F)</td> <td>85°C (185°F)</td> </tr> </tbody> </table> <ul style="list-style-type: none"> ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 60 minutes without any other error 	A	B	90°C (194°F)	85°C (185°F)
A	B				
90°C (194°F)	85°C (185°F)				
Supposed Causes	<ul style="list-style-type: none"> ■ Defective outdoor fan motor ■ Short circuit ■ Defective radiation fin thermistor ■ Disconnection of connector ■ Defective outdoor unit PCB ■ Silicone grease is not applied properly on the radiation fin after replacing the outdoor unit PCB. 				



Troubleshooting

- Check No.17**
Refer to P.171
- Check No.19**
Refer to P.172



Note: Refer to Silicone Grease on Power Transistor / Diode Bridge on page 197 for detail. (R22540)

7.20 Output Overcurrent Detection

Error Code	U5
Outdoor Unit LED Display	A  1 ● 2 ● 3  4 ● 5 ●
Method of Error Detection	An output overcurrent is detected by checking the current that flows in the inverter DC section.
Error Decision Conditions	<ul style="list-style-type: none"> ■ A position signal error occurs while the compressor is running. ■ A rotation speed error occurs while the compressor is running. ■ An output overcurrent signal is fed from the output overcurrent detection circuit to the microcomputer. ■ If the error repeats, the system is shut down. ■ Reset condition: Continuous run for about 5 minutes without any other error
Supposed Causes	<ul style="list-style-type: none"> ■ Poor installation condition ■ Closed stop valve ■ Defective power module ■ Wrong internal wiring ■ Abnormal power supply voltage ■ Defective outdoor unit PCB ■ Supply voltage is not as specified. ■ Defective compressor

Troubleshooting



Check No.15
Refer to P.169



Check No.17
Refer to P.171



Check No.18
Refer to P.171




Check No.22
Refer to P.174



Caution Be sure to turn off the power switch before connecting or disconnecting connectors, or parts may be damaged.

* An output overcurrent may result from wrong internal wiring. If the system is interrupted by an output overcurrent after the wires have been disconnected and reconnected for part replacement, check the wiring again.



Possible causes
* Momentary drop of power supply voltage
* Compressor overload
* Short circuit

Not a malfunction.
Keep observing.
Check the connectors and
other components.

* Inverter analyzer:
RSUK0917C

(R21438)

8. Check

8.1 Thermistor Resistance Check



Check No.01

Disconnect the connectors of the thermistors from the PCB, and measure the resistance of each thermistor using multimeter.

The data is for reference purpose only.

Thermistor temperature		Resistance (k Ω)
$^{\circ}\text{C}$	$^{\circ}\text{F}$	
-20	-4	197.8
-15	5	148.2
-10	14	112.1
-5	23	85.60
0	32	65.93
5	41	51.14
10	50	39.99
15	59	31.52
20	68	25.02
25	77	20.00
30	86	16.10
35	95	13.04
40	104	10.62
45	113	8.707
50	122	7.176

(R25 $^{\circ}\text{C}$ (77 $^{\circ}\text{F}$) = 20 k Ω , B = 3950 K)




- When the room temperature thermistor is soldered on a PCB, remove the PCB from the control PCB to measure the resistance.
- When the connector of indoor heat exchanger thermistor is soldered on a PCB, remove the thermistor and measure the resistance.

8.2 Indoor Fan Motor Connector Check

Check No.02

CTXS, FTXS, FVXS Series

1. Check the connection of connector.
2. Check motor power supply voltage output (pins 4 - 7).
3. Check motor control voltage (pins 4 - 3).
4. Check rotation command voltage output (pins 4 - 2).
5. Check rotation pulse input (pins 4 - 1).



(R19654)

8.3 Hall IC Check

Check No.04


CDXS, FDXS Series

1. Check the connector connection.
2. With the power on, operation off, and the connector connected, check the following.
 - (1) Output voltage of about 5 V between pins 1 and 3.
 - (2) Generation of 3 pulses between pins 2 and 3 when the indoor fan motor is operating.

If NG in step (1) → Defective PCB → Replace the PCB (control PCB).

If NG in step (2) → Defective Hall IC → Replace the indoor fan motor.

If OK in both steps (1) and (2) → Replace the PCB (control PCB).



(R14211)


8.4 Power Supply Waveform Check

Check No.11


Measure the power supply waveform between No. 1 and No. 2 on the terminal board, and check the waveform disturbance.

- Check if the power supply waveform is a sine wave (Fig.1).
- Check if there is waveform disturbance near the zero-cross (sections circled in Fig.2)

[Fig.1]



[Fig.2]



8.5 Electronic Expansion Valve Check

Check No.12

Conduct the followings to check the electronic expansion valve (EV).

1. Check if the EV connector is correctly inserted in the PCB. Match the EV unit number and the connector number.
2. Turn the power off and on again, and check if all the EVs generate a latching sound.
3. If any of the EVs does not generate a latching sound in the above step 2, disconnect that connector and check the continuity using a multimeter.
Check the continuity between the pins 1 - 6, 3 - 6, 2 - 5, 4 - 5 (between the pins 1 - 5, 2 - 5, 3 - 5, 4 - 5 for the harness 5P models). If there is no continuity between the pins, the EV coil is faulty.
4. If no EV generates a latching sound in the above step 2, the outdoor unit PCB is faulty.
5. If the continuity is confirmed in the above step 3, mount a good coil (which generated a latching sound) in the EV unit that did not generate a latching sound, and check if that EV generates a latching sound.
*If a latching sound is generated, the outdoor unit PCB is faulty.
*If a latching sound is not generated, the EV unit is faulty.





Note: Please note that the latching sound varies depending on the valve type.

If the system keeps operating with a defective electronic expansion valve, the following problem may occur.

Valve opening position	Possible problem	Check method
Open	<p>Cooling:</p> <ul style="list-style-type: none"> ■ Flowing noise of refrigerant in the unit which is not in operation ■ Water leakage at the unit which is not in operation ■ Operation half due to anti-icing function <p>Heating:</p> <ul style="list-style-type: none"> ■ Flowing noise of refrigerant in the unit which is not in operation ■ The unit does not heat the room. 	<p>Reset power supply and conduct cooling operation unit by unit.</p> <p>Check the liquid pipe temperature of no-operation unit.</p> <p>Almost the same as the outdoor temperature?</p> <p>NO → The EV is not defective.</p> <p>YES → Replace the EV of the room. (R16019)</p>
Close	<p>Cooling:</p> <ul style="list-style-type: none"> ■ The problem unit does not cool the room. ■ Only the problem unit is in operation, the unit starts pump down. (The low pressure of the unit becomes vacuum.) ■ Abnormal discharge pipe temperature <p>Heating:</p> <ul style="list-style-type: none"> ■ Refrigerant shortage due to stagnation of liquid refrigerant inside the faulty indoor unit ■ The unit does not heat the room. ■ Abnormal discharge pipe temperature 	<p>Reset power supply and conduct cooling operation unit by unit.</p> <p>Check the low pressure.</p> <p>Does the pressure become into vacuum zone?</p> <p>NO → The EV is not defective.</p> <p>YES → Replace the EV of the room. (R16020)</p>


8.6 Four Way Valve Performance Check

Check No.13



8.7 Inverter Unit Refrigerant System Check

Check No.14



8.8 Inverter Analyzer Check

Check No.15

■ Characteristics

Inverter analyzer: RSUK0917C

If an abnormal stop occurs due to compressor startup failure or overcurrent output when using an inverter unit, it is difficult to judge whether the stop is caused by the compressor failure or some other failure (main PCB, power module, etc.). The inverter analyzer makes it possible to judge the cause of trouble easily and securely. (Connect an inverter analyzer as a quasi-compressor instead of compressor and check the output of the inverter)

■ Operation Method

Step 1


Be sure to turn the power off.

Step 2

Install an inverter analyzer instead of a compressor.

Note:

Make sure the charged voltage of the built-in smoothing electrolytic capacitor drops to 10 VDC or below before carrying out the service work.



(R22731)

Reference:

If the terminals of the compressor are not FASTON terminals (difficult to remove the wire on the terminals), it is possible to connect wires available on site to the outdoor unit from output side of PCB. (Do not connect them to the compressor at the same time, otherwise it may result in incorrect detection.)

Step 3

Activate the power transistor test operation from the outdoor unit.

1) Press the forced cooling operation ON/OFF switch for 5 seconds.

(Refer to page 176 for the position.)

→ Power transistor test operation starts.


■ **Diagnose method (Diagnose according to 6 LEDs lighting status.)**

- (1) If all the LEDs are lit uniformly, the compressor is defective.
→ Replace the compressor.
- (2) If the LEDs are not lit uniformly, check the power module.
→ Refer to **Check No.22**.
- (3) If NG in **Check No.22**, replace the power module.
(Replace the main PCB. The power module (IPM1) is united with the main PCB.)
If OK in **Check No.22**, check if there is any solder cracking on the PCB.
- (4) If any solder cracking is found, replace the PCB or repair the soldered section.
If there is no solder cracking, replace the PCB.



Caution

- (1) When the output frequency is low, the LEDs blink slowly. As the output frequency increases, the LEDs blink quicker. (The LEDs look like they are lit.)
- (2) On completion of the inverter analyzer diagnosis, be sure to re-crimp the FASTON terminals. Otherwise, the terminals may be burned due to loosening.



8.9 Rotation Pulse Check on the Outdoor Unit PCB

Check No.16

<Outdoor fan motor>

Make sure that the voltage of $320 \pm_{50}^{100}$ V is applied.


1. Set operation off and power off. Disconnect the connector S70.
2. Check that the voltage between the pins 4 - 7 is 320 VDC.
3. Check that the control voltage between the pins 3 - 4 is 15 VDC.
4. Check that the rotation command voltage between the pins 2 - 4 is 0 ~ 15 VDC.
5. Keep operation off and power off. Connect the connector S70.
6. Check whether 4 pulses (0 ~ 15 VDC) are input at the pins 1 - 4 when the outdoor fan motor is rotated 1 turn by hand.

When the fuse is melted, check the outdoor fan motor for proper function.

If NG in step 2 → Defective PCB → Replace the outdoor unit PCB (main PCB).


If NG in step 4 → Defective Hall IC → Replace the outdoor fan motor.

If OK in both steps 2 and 4 → Replace the outdoor unit PCB (main PCB).




8.10 Installation Condition Check

Check No.17



8.11 Discharge Pressure Check


Check No.18



8.12 Outdoor Fan System Check

Check No.19

DC motor



(R21195)


8.13 Main Circuit Short Check

Check No.20

Check to make sure that the voltage between (+) and (-) of the diode bridge (DB1) is about 0 V before checking

- Measure the resistance between the pins of the DB1 referring to the table below.
- If the resistance is ∞ or less than 1 k Ω , short circuit occurs on the main circuit.

Positive terminal (+) of digital multimeter	~ (2, 3)	+ (4)	~ (2, 3)	- (1)
Negative terminal (-) of digital multimeter	+ (4)	~ (2, 3)	- (1)	~ (2, 3)
Resistance is OK.	several k Ω ~ several M Ω			
Resistance is NG.	0 Ω or ∞			




(R21937)

8.14 Capacitor Voltage Check


Check No.21

Before this check, be sure to check the main circuit for short circuit.

With the circuit breaker still on, measure the voltage according to the drawing of the model in question. Be careful never to touch any live parts.



- To prevent an electrical shock, use a multimeter to check that the voltage between FU2 and DC- is 50 V or less.
- The surface of the test points (DC-) may be covered with the coating. Be sure to make firm contact between the multimeter probes and the test points.




8.15 Power Module Check

Check No.22

Check to make sure that the voltage between (+) and (-) of the power module is about 0 V before checking.

- Disconnect the compressor harness connector from the outdoor unit PCB. To disengage the connector, press the protrusion on the connector.
- Follow the procedure below to measure resistance between the (+) or (-) terminal of the power module and the U, V, or W terminal of the compressor with a multimeter. Evaluate the measurement results referring to the following table.

Positive terminal (+) of digital multimeter	Power module (+)	UVW	Power module (-)	UVW
Negative terminal (-) of digital multimeter	UVW	Power module (+)	UVW	Power module (-)
Resistance is OK.	several kΩ ~ several MΩ			
Resistance is NG.	0 Ω or ∞			



Part 7

Trial Operation and Field Settings


1. Pump Down Operation	176
2. Wiring Error Check Function	177
3. Trial Operation	179
3.1 CTXS, FTXS, CDXS, FDXS, FVXS Series	179
3.2 FFQ Series	181
4. Field Settings	183
4.1 Outdoor Unit	183
4.2 CTXS, FTXS, CDXS, FDXS, FVXS Series	185
4.3 FFQ Series	190
5. Silicone Grease on Power Transistor / Diode Bridge	197

1. Pump Down Operation

Pump Down Operation

In order to protect the environment, be sure to conduct pump down operation when relocating or disposing of the unit.


1. Remove the valve caps from the liquid stop valve and the gas stop valve.
2. Carry out forced cooling operation.
3. After 5 ~ 10 minutes, close the liquid stop valve with a hexagonal wrench.
4. After 2 ~ 3 minutes, close the gas stop valve and stop the forced cooling operation.



(R14566)

Forced cooling operation

Procedure	<ol style="list-style-type: none"> 1. Turn the power off. 2. Remove the switch cover. 3. Turn off all the switches of SW5 and SW6 on the service monitor PCB. 4. Set the operation mode switch (SW2) to COOL. 5. Screw the switch cover again. 6. Turn the power on. 7. Wait until the 3-minute standby mode finishes. 8. Press the forced cooling operation ON/OFF switch (SW1).
Command frequency	30 Hz
Ending conditions	<ol style="list-style-type: none"> 1. Press the forced cooling operation ON/OFF switch (SW1) again. 2. The operation ends automatically after 60 minutes.



(R22273)

2. Wiring Error Check Function

Outline

Wiring error check function is designed for the microcomputer to correct wiring errors itself. If local wiring is unclear in the case of buried piping, for example, just press the wiring error check switch on the outdoor unit. Even if the connections for Room A and Room B are confused, the system may run without a hassle. Note that this check function does not work in the following cases.


- For 3-minute standby period after the power is turned on or after the compressor has stopped.
 - When the outdoor temperature is below 5°C (41°F).
 - If the indoor unit is in trouble (also in case of all-room transmission failure).
- When the piping and wiring are perfect, there is no need to use this function.

Procedure

1. Press the wiring error check switch (SW3) on the service monitor PCB of the outdoor unit, and the wiring error check function is activated.
2. In about 15 ~ 20 minutes, the check finishes automatically.
3. When the check is over, the service monitor LED indicators start blinking.

LED	1	2	3	4	5	Judgment
Status	Blinking one after another					Self-correction completed
	All blinking					Self-correction impossible
	Any of the LEDs stay on.					Emergency stop


- Self-correction completed...The LED indicators 1 ~ 2 (18 class), or 1 ~ 3 (24 class) blink one after another.
- Self-correction impossible...The LED indicators blink all at the same time.
 - * Transmission failure occurs at any of the indoor units.
 - * The indoor heat exchanger thermistor is disconnected.
 - * An indoor unit is in trouble (if a trouble occurs during the wiring error checking).
- Emergency stop...If any of the LED indicators stay on, follow the diagnostic procedure.




Details

- Refrigerant flows from Port A and on. The indoor heat exchanger temperatures are detected one by one to check up the matching between the piping and wiring.
- With this function on, freezing (crackling) noise may be heard from the indoor unit. This is not a problem. (This is because the indoor heat exchanger temperature is made to drop below 0°C (32°F) in order to increase the detection accuracy.)
- The indoor fan turns on or off during wiring checking.
- The results can be checked by looking at the service monitor LED indicators, when the wiring error checking is over. The LED indicators stop blinking when the ordinary operation starts.
 LED1...Room A wiring, LED2...Room B wiring
 1st blinking LED...Port A piping, 2nd blinking LED...Port B piping
 The 1st blinking LED means the room that is connected with Port A. The 2nd blinking LED means the one connected with Port B.

Ex: Suppose the LED indicators are blinking as follows.



The above means that Port A is connected with Room B, and Port B with Room A (or self-corrected this way.)



Note:

1. Wrongly connected liquid and gas pipes cannot be self-corrected. Be sure to make the liquid pipe and the gas pipe in pairs.
2. To cancel the wiring error check procedure halfway, press the wiring error check switch again. In this case, the memory of the microcomputer returns to its initial status (Room A wiring → Port A piping, Room B wiring → Port B piping).
3. When replacing the outdoor unit PCB, be sure to use this function.
4. Make the priority room setting after wiring error check. If you set the priority room before wiring error check, the prioritized room may be changed after self-correction.

3. Trial Operation

3.1 CTXS, FTXS, CDXS, FDXS, FVXS Series

Outline

Carry out the trial operation in accordance with the operation manual to ensure that all functions and parts, such as flap movement, are working properly.


Trial operation should be carried out in either cooling or heating operation.

Detail

1. Measure the power supply voltage and make sure that it falls within the specified range.
2. In cooling operation, select the lowest programmable temperature (18°C (64°F)); in heating operation, select the highest programmable temperature (30°C (86°F)).
 - ◆ Trial operation may be disabled in either operation mode depending on the room temperature.
 - ◆ After trial operation is complete, set the temperature to a normal level (26 ~ 28°C (78 ~ 82°F) in cooling, 20 ~ 24°C (68 ~ 75°F) in heating).
 - ◆ For protection, the system does not start for 3 minutes after it is turned off.


ARC452 Series

- (1) Press **ON/OFF** button to turn on the system.
- (2) Press both of **TEMP** buttons and **MODE** button at the same time.
- (3) Press **MODE** button twice.
(? appears on the display to indicate that trial operation is selected.)
- (4) Press **MODE** button and select the operation mode.
- (5) Trial operation terminates in about 30 minutes and switches into normal mode. To quit trial operation, press **ON/OFF** button.



ARC466 Series

- (1) Press **On/Off** button to turn on the system.
- (2) Press the center of **Temp** button and **Mode** button at the same time.
- (3) Select 7[°] (trial operation) with **Temp ▲** or **Temp ▼** button.
- (4) Press **Mode** button to start the trial operation.
- (5) Press **Mode** button and select operation mode.
- (6) Trial operation terminates in about 30 minutes and switches into normal mode. To quit trial operation, press **On/Off** button.



3.2 FFQ Series

3.2.1 Checkpoints

To carry out test operation, check the following:



- Check that the temperature setting of the remote controller is at the lowest level in cooling operation or use test operation mode.
- Go through the following checklist:




Checkpoints	Cautions or warnings
Are all units securely installed?	<ul style="list-style-type: none"> ● Dangerous for turning over during storm ● Possible damage to pipe connections
Is the ground wire installed according to the applicable local standard?	Dangerous if electric leakage occurs.
Are all air inlets and outlets of the indoor and outdoor units unobstructed?	<ul style="list-style-type: none"> ● Poor cooling ● Poor heating
Does the drain flow out smoothly?	Water leakage
Is piping adequately heat-insulated?	Water leakage
Have the connections been checked for refrigerant leakage?	<ul style="list-style-type: none"> ● Poor cooling ● Poor heating ● Stop
Is the power supply voltage conform to the specifications on the name plate?	Incorrect operation
Are the cable sizes as specified and according to local regulations?	Damage of cables
Are the remote controller signals received by the unit?	No operation

3.2.2 Test operation



BRC1E71/72/73

Note: The illustrations are for BRC1E72 as representative.

Step	Action	Remote controller
Before test operation		
1	Turn on the power supply more than 6 hours before test operation.	
2	Open the gas stop valve.	
3	Open the liquid stop valve.	
How to activate test operation		
4	Press and hold Cancel button for 4 seconds to enter Service Settings menu.	
5	Use the ▼▲ buttons to select Test Operation and push Menu/OK button.	 <p style="text-align: right;">(R18827)</p>
6	Test Operation is displayed on the bottom of the basic screen.	 <p style="text-align: right;">(R18828)</p>
7	Push On/Off button within 10 seconds to start the test operation.	

Step	Action	Remote controller
How to check airflow direction		
8	Push Menu/OK button to enter Main Menu .	
9	Use ▼▲ buttons to select Airflow Direction and push Menu/OK button.	 <p>Main Menu 1/2 Airflow Direction Quick Start Schedule Off Timer Celsius / Fahrenheit Maintenance Information Setting</p> <p>(R18829)</p>
10	Check that the airflow direction is actuated according to the setting and push Menu/OK button.	 <p>Airflow Direction Swing</p> <p>Setting</p> <p>(R18830)</p>
How to deactivate test operation		
11	Press and hold Cancel button for 4 seconds to enter Service Settings menu.	
12	Use ▼▲ buttons to select Test Operation in the menu and push Menu/OK button.	 <p>Service Settings 1/3 Test Operation Maintenance Contact Field Settings Energy Saving Options Prohibit Function Min Setpoints Differential Setting</p> <p>(R18827)</p>

BRC7E830

Step	Action
1	Turn on the power supply more than 6 hours before test operation.
2	Open the gas stop valve.
3	Open the liquid stop valve.
4	Set to cooling operation with the remote controller and start operation by pressing ON/OFF button.
5	Press INSPECTION/TEST button ( /TEST) 2 times and operate at test operation mode for 3 minutes.
6	Press SWING button to make sure the unit is in operation.
7	Press INSPECTION/TEST button ( /TEST) and operate normally.
8	Confirm all the function of unit according to the operation manual.
9	If the decoration panel has not been installed, turn off the power after the test operation.

4. Field Settings

4.1 Outdoor Unit


4.1.1 Priority Room Setting

Outline

1. Operation mode
The operation mode of the prioritized room takes precedence. For example, when the prioritized indoor unit starts cooling operation, the other indoor units which have been in heating operation enter the standby mode. Heating operation will resume if the prioritized indoor unit stops cooling operation.
2. POWERFUL operation
The electronic expansion valves are controlled to provide more capacity to the prioritized room and the capacities for the other indoor units will be slightly reduced.
3. OUTDOOR UNIT QUIET operation
When the OUTDOOR UNIT QUIET operation is selected in the prioritized room, the outdoor unit runs quietly.
(Without priority room setting, OUTDOOR UNIT QUIET operation starts only when the function is set for all the operating indoor units.)

Procedure

1. Turn the circuit breaker off before changing the setting.
2. Turn on the one of the switches of the SW4 on the service monitor PCB.
Only one room can be set as the priority room.
3. Turn the power on.




(R22006)

4.1.2 COOL/HEAT Mode Lock

Use S15 connector to set the unit to cooling only or heating only.
 Setting to heating only (H): Short-circuit the pins 1 and 3 of the connector S15.
 Setting to cooling only (C): Short-circuit the pins 3 and 5 of the connector S15.
 The following specifications apply to the connector housing and pins.

- JST products:
 Housing: VHR-5N
 Pin: SVH-21T-1, 1

Note that forced operation is also possible in cooling/heating mode.



(R22007)


4.1.3 NIGHT QUIET Mode

Outline

If NIGHT QUIET mode is to be used, initial settings must be made when the unit is installed. Explain the function of NIGHT QUIET mode, as described below, to the customer, and confirm whether or not the customer wants to use NIGHT QUIET mode. NIGHT QUIET mode function reduces operating noise of the outdoor unit at nighttime. This function is useful if the customer is worried about the effects of the operating noise on the neighbors. However, if NIGHT QUIET mode is running, cooling capacity is reduced.

Procedure

Turn on the SW6-1 on the service monitor PCB of the outdoor unit.




(R22008)

4.2 CTXS, FTXS, CDXS, FDXS, FVXS Series

4.2.1 Model Type Setting

ARC452A21, ARC452A23


- The remote controller is common to the heat pump model and cooling only model.
- Make sure the DIP switch is set to the left side. The heating operation will not be available when the DIP switch is set to the right side.



(R18201)

ARC466A21

- The remote controller is common to the heat pump model and cooling only model.



(R18451)




Caution Replace the remote controller if you cut the jumper on the left side.
The heating operation will not be available when the jumper on the left side is cut.

4.2.2 Temperature Display Switch

You can select Fahrenheit or Celsius for temperature display.


ARC452A21, ARC452A23

- Press **TEMP▲** and **TEMP▼** buttons at the same time for 5 seconds to change the unit of temperature display.



ARC466A21

- Press the upper side of **Temp** button and **On** button at the same time for 5 seconds to change the unit of temperature display.



4.2.3 When 2 Units are Installed in 1 Room

Outline

When 2 indoor units are installed in 1 room, 1 of the 2 indoor units and the corresponding wireless remote controller can be set for different address.

Both the indoor unit PCB and the wireless remote controller need alteration.



The method of address setting varies depending on the type of indoor unit and the series of wired remote controller. Refer to the following pages for the appropriate indoor unit and wireless remote controller.

CTXS, FTXS Series

- (1) Remove the front grille.
- (2) Remove the electrical box.
- (3) Remove the shield plate of the electrical box.
- (4) Cut the address setting jumper JA on the PCB.

CTXS07LVJU, FTXS09/12LVJU

FTXS15/18LVJU




Caution

Replace the PCB if you accidentally cut a wrong jumper.

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.

CDXS, FDXS Series

- Cut the jumper JA on PCB.





Caution

Replace the PCB if you accidentally cut a wrong jumper.

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.

FVXS Series

- (1) Remove the front grille.
- (2) Lift the sensor PCB fixing plate and remove the front shield plate.
- (3) Disconnect the connectors S1, S41, S42.
- (4) Remove the electric box (1 screw).
- (5) Pull out the indoor heat exchanger thermistor.
- (6) Remove the shield plate (8 tabs).
- (7) Cut the address setting jumper JA on the indoor unit PCB.



Caution


Replace the PCB if you accidentally cut a wrong jumper.

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.

Wireless Remote Controller


- (1) Remove the cover and take it off.
- (2) Cut the address setting jumper.

ARC452 series



(R12065)

ARC466 series



* Do not cut the left jumper.

(R18416)



Caution

Replace the remote controller if you accidentally cut a wrong jumper.

Jumpers are necessary for electronic circuit. Improper operation may occur if you cut any of them.

4.2.4 Jumper Settings

Jumper (on indoor unit PCB)	Function	When connected (factory setting)	When cut
JB	Fan speed setting when compressor stops for thermostat OFF. (effective only at cooling operation)	Fan speed setting; Remote controller setting	The fan stops.
JC	Power failure recovery function	Auto-restart	The unit does not resume operation after recovering from a power failure. Timer settings are cleared.

FVXS series

Switch (on indoor unit PCB)	Function	OFF (factory setting)	ON
SW2-4	Upward airflow limit setting	Exposed or half embedded installation	Set the switch to ON position when you install the indoor unit embedded in the wall to avoid condensation.



For the location of the jumper, refer to the following pages.

CTXS07LVJU, FTXS09/12LVJU: page 16

FTXS15/18LVJU: page 18

FDXS09/12LVJU, CDXS15/18LVJU: page 20

FVXS09/12/15/18NVJU: page 22

4.3 FFQ Series


4.3.1 How to Change the Field Settings

Outline

If optional accessories are mounted on the indoor unit, the indoor unit setting may have to be changed. Refer to the instruction manual for each optional accessory.


BRC1E71/72/73

Note: The illustrations are for BRC1E72 as representative.




- a Unit No.
- b First code No.
- c Second code No.
- d Mode

Step	Action	Remote controller
1	Press and hold Cancel button for 4 seconds to enter Service Settings menu.	
2	Use ▼▲ buttons to select Field Settings and push Menu/OK button.	<p>(R18832)</p>
3	Use ▼▲ buttons to select the desired Mode.	<p>(R18831)</p>
4	During group control, when setting by each indoor unit (Mode 20, 21, 22 or 23 have been selected), push the ◀ button to highlight and ▼▲ buttons to select the Unit No. to be set. This operation is unnecessary when setting by group.	
5	Highlight the second code No. to be changed using ◀▶ buttons, and use ▼▲ buttons to select the desired second code No.	<p>(R18833)</p> <p>When setting by group, all of the second code No. that may be set are displayed as *.</p>

Step	Action	Remote controller
6	Push Menu/OK button to display the confirmation screen.	
7	Use ◀▶ buttons to select Yes and push Menu/OK button.	 <p>(R18834)</p> <p>When multiple setting changes are needed, repeat steps 3 to 7.</p>
8	Push Cancel button 2 times to return to basic screen.	

BRC7E830



To set the field settings, you have to change:

- Mode No.
- First code No.
- Second code No.

Step	Action
1	Press INSPECTION/TEST button for 4 seconds during normal mode to enter the field setting mode.
2	Press MODE button to select the desired mode No.
3	Press UP button to select the first code No.
4	Press DOWN button to select the second code No.
5	Press RESERVE button to confirm the setting.
6	Press INSPECTION/TEST button to return to the normal mode.

4.3.2 Overview of the Field Settings

Mode No.	First Code No.	Description of setting		Second Code No.					
				01	02	03	04		
10 (20)	0	Filter cleaning sign interval	Ultra longlife filter	Light	Approx. 10,000 hrs.	Heavy	Approx. 5,000 hrs.	—	—
			Longlife filter		Approx. 2,500 hrs.		Approx. 1,250 hrs.		
	1	Longlife filter type		Longlife filter	Ultra longlife filter	—	—		
	2	Remote controller thermistor		Enabled	Disabled	—	—		
	3	Filter cleaning sign		Display	No display	—	—		
11 (21)	0	Indoor unit number of simultaneous operation system		Pair	Twin	Triple	Double twin		
	1	Simultaneous operation system individual setting		Unified setting	Individual setting	—	—		
	2	Fan OFF at thermostat OFF		Standard	Fan OFF	—	—		
	7	External static pressure setting		Airflow adjustment is OFF	Completion of airflow adjustment	Start of airflow adjustment	—		
12 (22)	0	Optional accessories output selection (field selection of output for adaptor for wiring)		Compressor	—	Operation output	Error output		
	1	Forced ON/OFF function		Forced OFF	ON/OFF operation	—	—		
	2	Thermostat differential changeover (setting for when using remote sensor)		1°C (1.8°F)	0.5°C (0.9°F)	—	—		
13 (23)	0	High air outlet velocity (for high ceiling applications)		≤ 8-7/8 ft (2.7 m)	8-7/8 ~ 9-7/8 ft (2.7 ~ 3.0 m)	9-7/8 ~ 11-7/16 ft (3.0 ~ 3.5 m)	—		
	1	Selection of airflow direction (setting for when a blocking pad kit has been installed)		4-way flow	3-way flow	2-way flow	—		
	3	Selection of airflow function (setting for when using a decoration panel for outlet)		Equipped	Not equipped	—	—		
	4	Airflow direction range setting		Upper	Normal	Lower	—		
	6	External static pressure		Standard	High	Low	—		
15 (25)	3	Drain pump operation with humidifying		Not equipped	Equipped	—	—		

■ : factory setting



Note: Any function that is not available on the indoor unit is not displayed.



4.3.3 MAIN/SUB Setting when Using 2 Wired Remote Controllers

Outline

The MAIN/SUB setting is necessary when 1 indoor unit is controlled by 2 remote controllers. When you use 2 remote controllers (control panel and separate remote controller), set one to MAIN and the other to SUB.

Detail

The remote controllers are factory set to MAIN, so you only have to change one remote controller from MAIN to SUB.

Step	Action	Remote controller
1	Put on the power for both remote controllers.	
2	Determine which one is the sub/main remote controller.	
3	When Checking the connection. Please stand by. is displayed on both remote controllers, push and hold Mode button of the sub remote controller for 4 seconds.	 <p style="text-align: right;">(R18973)</p>
4	The sub remote controller now displays Sub RC. Note) The main remote controller still displays Main RC.	 <p style="text-align: right;">(R18974)</p>
5	After a few seconds, the basic screen is displayed.	




4.3.4 Address and MAIN/SUB Setting for Wireless Remote Controller

Outline


If several wireless remote controller units are used together in the same room (including the case where both group control and individual remote controller control are used together), be sure to set the addresses for the receiver and wireless remote controller. (For group control, see the attached installation manual for the indoor unit.) If using together with a wired remote controller, you have to change the MAIN/SUB setting on the signal receiver PCB.


Signal Receiver PCB

Set the address setting switch (SS2) on the signal receiver PCB according to the table below.

Unit No.	No.1	No.2	No.3
Address setting switch (SS2)	 (S1935)	 (S1936)	 (S1937)

When using both a wired and a wireless remote controller for 1 indoor unit, the wired controller should be set to MAIN. Therefore, set the MAIN/SUB setting switch (SS1) on the signal receiver PCB to SUB.


	MAIN	SUB
MAIN/SUB setting switch (SS1)	 (S1938)	 (S1939)



After completing setting, seal off the opening of the address setting switch (SS2) and the MAIN/SUB setting switch (SS1) with the attached sealing pad.


Wireless Remote Controller (Factory Set is 1)

1. Hold down **FILTER SIGN RESET** (☐) button and **INSPECTION/TEST** button at the same time for at least 4 seconds to enter the field setting mode. (SETTING is indicated on the display).
2. Press **FAN** button and select A or B. Each time the button is pressed, the display switches between A and B.
3. Press **UP** button and **DOWN** button to set the address.



Address can be set from 1 ~ 6, but set it to 1 ~ 3 and to same address as the receiver. (The receiver does not work with address 4 ~ 6.)

4. Press **RESERVE** button to confirm the setting.
5. Hold down **INSPECTION/TEST** button for at least 1 second to exit the field setting mode and return to the normal display.




Multiple Settings A or B

When the indoor unit is controlled by an outside controller (central remote controller, etc.), it sometimes does not respond to ON/OFF command or temperature setting command from the remote controller. Check what setting the customer needs and make the multiple setting as shown below.

Remote Controller		Indoor Unit	
Multiple Setting	Remote Controller Display	Controlled by other air conditioners or devices	Other condition
A: Standard	All items are displayed.	ON/OFF command and temperature setting command cannot be accepted. (1 long beep or 3 short beeps emitted)	
B: Multiple display	Operations set only is displayed shortly after execution.	All the commands can be accepted (2 short beeps)	

After Setting

Stick the unit No. label at the decoration panel air discharge outlet as well as on the back of the wireless remote controller.



(R12961)



Note: Set the unit No. of the receiver and the wireless remote controller to be the same. If the settings differ, the signal from the remote controller cannot be received.

5. Silicone Grease on Power Transistor / Diode Bridge

Outline


Apply the specified silicone grease to the heat radiation part of a power transistor / diode bridge when you replace an outdoor unit PCB. The silicone grease encourages the heat radiation of a power transistor / diode bridge.

Detail


1. Wipe off the old silicone grease completely.
2. Apply the silicone grease evenly. See the illustrations below for examples of application.
3. Tighten the screws of the power transistor / diode bridge.
4. Make sure that the heat radiation parts are firmly contacted to the radiation fin.

Note: Smoke emission may be caused by bad heat radiation when the silicone grease is not appropriately applied.


- OK: Evenly applied



- NG: Not evenly applied



- NG: Foreign matter is stuck.




Part 8 Appendix

1. Piping Diagrams.....	199
1.1 Indoor Unit.....	199
1.2 Outdoor Unit.....	201
2. Wiring Diagrams.....	202
2.1 Indoor Unit.....	202
2.2 Outdoor Unit.....	207

1. Piping Diagrams


1.1 Indoor Unit

CTXS07LVJU, FTXS09/12LVJU




4D074606

FTXS15/18LVJU




4D074609

FDXS09/12LVJU




4D074621

CDXS15/18LVJU



4D075271


FVXS09/12NVJU



REFRIGERANT FLOW
 —> COOLING
 - -> HEATING

4D091794


FVXS15/18NVJU



REFRIGERANT FLOW
 —> COOLING
 - -> HEATING

4D091795A

FFQ09/12/15/18LVJU




MODEL	A	B
FFQ09 · 12LVJU	1/4 (6.4)	3/8 (9.5)
FFQ15 · 18LVJU	1/4 (6.4)	1/2 (12.7)

4D080624


1.2 Outdoor Unit

2MXL18QMVJU



3D101223

3MXL24QMVJU




3D093191A

2. Wiring Diagrams

2.1 Indoor Unit

CTXS07LVJU, FTXS09/12LVJU




C: 3D058246L



Note: PCB1: Control PCB
 PCB2: Signal receiver PCB
 PCB3: Display PCB
 PCB4: INTELLIGENT EYE sensor PCB
 Refer to Part 3 for Printed Circuit Board Connector Wiring Diagram.

FTXS15/18LVJU




C: 3D060942R



Note: PCB1: Control PCB
 PCB2: Signal receiver PCB
 PCB3: Display PCB
 PCB4: INTELLIGENT EYE sensor PCB
 Refer to Part 3 for Printed Circuit Board Connector Wiring Diagram.

FDXS09/12LVJU, CDXS15/18LVJU




C: 3D073998B



Note: A1P: Control PCB
A2P: Display PCB
Refer to Part 3 for Printed Circuit Board Connector Wiring Diagram.

FVXS09/12/15/18NVJU




C: 3D090604A



Note: PCB1: Sensor PCB
 PCB2: Control PCB
 PCB3: Service PCB
 PCB4: Display PCB
 Refer to Part 3 for Printed Circuit Board Connector Wiring Diagram.


FFQ09/12/15/18LVJU

A1P	PRINTED CIRCUIT BOARD	H1P	PILOT LAMP (ON-RED)
C1	CAPACITOR (M1F)	H2P	PILOT LAMP (TIMER-GREEN)
F1U	FUSE (F. 5A, 250V)	H3P	PILOT LAMP (FILTER SIGN-RED)
HAP	PILOT LAMP (SERVICE MONITOR GREEN)	H4P	PILOT LAMP (DEFROST-ORANGE)
KPR	MAGNETIC RELAY (M1P)	SS1	SELECTOR SWITCH (MAIN/SUB)
M1F	FAN MOTOR	SS2	SELECTOR SWITCH (WIRELESS ADDRESS SET)
M1S	DRAIN PUMP MOTOR	X24A	CONNECTOR (WIRELESS REMOTE CONTROLLER)
M1S	SWING LOUVER MOTOR	X33A	CONNECTOR (ADAPTOR FOR WIRING)
Q1M	THERMAL PROTECTOR FOR MOTOR	X35A	CONNECTOR (GROUP CONTROL ADAPTOR)
R1T	THERMISTOR (AIR)	X40A	CONNECTOR (ON/OFF INPUT FROM OUTSIDE)
R2T	THERMISTOR (COIL-1)		
R3T	THERMISTOR (COIL-2)		
S1L	FLOAT SWITCH		
T1R	TRANSFORMER (208-230V/25V)		
V1TR	TRIAC		
X1M	TERMINAL BLOCK		
X2M	TERMINAL BLOCK		
TC	SIGNAL TRANSMISSION CIRCUIT		
WRC	WIRED REMOTE CONTROLLER (RECEIVER/DISPLAY UNIT)		
R1T	THERMISTOR (AIR)		
WRC	WIRED REMOTE CONTROLLER (RECEIVER/DISPLAY UNIT)		
A3P	PRINTED CIRCUIT BOARD		
A4P	PRINTED CIRCUIT BOARD		
BS1	PUSH BUTTON SWITCH (ON/OFF)		



NOTES)

- : TERMINAL
 = : FIELD WIRING
 □ : CONNECTOR
 ⊕ : PROTECTIVE GROUND (SCREW)
 ⚡ : NOISELESS GROUND
- IN CASE USING CENTRAL REMOTE CONTROLLER, CONNECT IT TO THE UNIT IN ACCORDANCE WITH THE ATTACHED INSTALLATION MANUAL.
- X24A, X33A, X35A AND X40A ARE CONNECTED WHEN THE OPTIONAL ACCESSORIES ARE USED.
- GROUND THE SHIELD OF THE REMOTE CONTROLLER CORD TO THE INDOOR UNIT (IN CASE OF USING SHIELD WIRE).
- SYMBOLS SHOW AS FOLLOWS: RED: RED BLK: BLACK WHT: WHITE YLW: YELLOW GRN: GREEN BLU: BLUE



○ : CONNECTOR DISCRIMINATION COLOR FOR COMPONENTS.
 ○ : CONNECTOR COLOR FOR COMPONENTS.
 ○ : CONNECTOR COLOR FOR PRINTED CIRCUIT BOARD.

C: 3D080351A




Note: For the location of the switch (SS1) on the control PCB (A1P), refer to page 24.

2.2 Outdoor Unit

2MXL18QMVJU


WIRING DIAGRAM



Note: PCB1: Main PCB
 PCB2: Service monitor PCB
 Refer to Part 3 for Printed Circuit Board Connector Wiring Diagram.

3MXL24QMVJU

WIRING DIAGRAM



Note: PCB1: Main PCB
 PCB2: Service monitor PCB
 Refer to Part 3 for Printed Circuit Board Connector Wiring Diagram.

Revision History

Month / Year	Version	Revised contents
03 / 2016	SiUS121602E	First edition

Warning



- Daikin products are manufactured for export to numerous countries throughout the world. Prior to purchase, please confirm with your local authorized importer, distributor and/or retailer whether this product conforms to the applicable standards, and is suitable for use, in the region where the product will be used. This statement does not purport to exclude, restrict or modify the application of any local legislation.
- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorized parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Read the user's manual carefully before using this product. The user's manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any inquiries, please contact your local importer, distributor and/or retailer.

Cautions on product corrosion

1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.

Dealer

© All rights reserved

● Specifications, designs and other content appearing in this brochure are current as of March 2016 but subject to change without notice.