


Powermatic Scissor 17ft Telescopic Crane (JB-SCSR-00)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.



15V AC Adapter



Flight Case



ATTENTION: PLEASE READ THIS BEFORE USING THE CRANE TO PREVENT DAMAGE!

Assembly Caution:

Be attentive when assembling Dolly, Tripod & Crane to prevent equipment damage. Avoid assembly under the influence of alcohol or drugs.

Watch Your Hands:

Operate cautiously to avoid pinching hands or fingers between arms. Ensure secure connection of all Crane sections.

Stability Check:

Operate the Crane only on a leveled, stable surface. Connect steel cables for stabilization without hindering Crane movements.

Weather Awareness:

Exercise caution when operating in bad weather. Protect the pan-tilt/gimbal head and control bar from rain to prevent damage.

Safety Precautions:

Avoid operation near high-voltage power cables. Keep the Crane's surroundings clear and establish the correct weight balance before telescoping.

Battery Maintenance:

Monitor battery levels to prevent functional issues. Fold the Crane for longer transfers and use locking pins for stability when adjusting height.

Technical Support:

For further assistance or queries, contact our sales representative for online technical support. Operating the Crane safely ensures better shots and smooth operation.

FOLLOWING THESE GUIDELINES WILL PROVIDE BETTER SHOTS AND TROUBLE-FREE OPERATION. IF YOU NEED ADDITIONAL INFORMATION, YOU CAN AVAIL TECHNICAL ASSISTANCE 'ONLINE' BY CONTACTING OUR SALES REPRESENTATIVE.

Scissor Telescopic Crane **Setup**

- Insert the bolt into the hub mounting hole of the Scissor Crane.
- Now, secure the bolt using a 18mm wrench.





- Place Scissor Jib with the Hub Mounting on top of the Jib Stand.
- Insert the Locking knob on the bottom of the Hub Mounting and tighten it.





FEATURE: You can check the leveling of the Scissor Jib using the Bubble Leveler after which the stand's height can me adjusted to keep your Jib levelled.





- Loosen the bolt of the Gimbal bracket and open it.
- Then, insert the two guide rods on either side of the Crane.





• After inserting the two guide rods, tighten the bolts to secure them.



 Insert the cable guide rod into the boom lock bracket and secure the rod by tightening the bolt.





Feature: Pan Lock enables locking the jib's pan movement for achieving high/low angle shots. Tilt Lock allows you to fix the jib's tilt angle to get linear tracking shots.





NOTE: While using the jib at extremely high angle, the rear part of Gimbal will touch Gimbal Bracket. Therefore, adjust the angle of Gimbal Bracket by loosening the bolt of Guide Rod Mount.





Weight Rod **Setup**

• Insert the Weight rod into the weight holder of the controller box and tighten the knob.





• Insert weights into the weight rod.

NOTE: Weight will be added according to the setup requirement to balance the camera securely.





 Insert the weight closer and press its lever to secure it.





- Loosen the knob of the Jib Controller and slide it into the weight rod.
- Tighten the Jib controller's knob to secure it.

NOTE: Telescope/ Retract the length of Scissor Jib using Jib Controller. Precise Controller conveniently pushes out/ pulls in the jib length and controls the movements.

• Connect the Jib Controller cable to the 6-pin cable connector (Remote Out).









• Connect the Motor Driver Cable to the 2-pin cable connector (Motor Out).




 Now, mount your V-Mount Battery (Not Included) onto the Battery Plate.

NOTE: The system is integrated with a V-Mount Battery Plate, which adapts a 14.8V V-Mount battery to power the drive system.





- After attaching the V-mount battery, you can operate the Scissor Jib in 2 alternate ways.
- **1.** If you press the button from battery side, it will run on the V-mount battery.
- **2.** If you press it from the power side, it will run on the electric power supply.









LCD Monitor Arm Setup

 Connect the Monitor Arm to the Hub Mounting of the jib and tighten it using the provided screws.

Feature: The LCD Mounting Arm helps in attaching an LCD monitor for better viewing of shots; the arm can be mounted on either side of the Hub Mounting.





• Fix LCD Monitor (Not Included) on Monitor Arm and lock it using the knob.





 To power your LCD, insert its first port in the power plug of the motor and the second port in the back side of the LCD.





• Now, the LCD is assembled and ready to use.



Gimbal Fluid Head **Setup**

• Slide the Gimbal Fluid Head to the Jib's mounting plate and tighten the knob.

NOTE: Gimbal Fluid Head comes attached with the Jib plate. In case it gets detached, you can easily mount it.






- To adjust the tension on the Fluid Head, loosen or tighten the Gimbal Fluid Head's knob per your requirement.
- Now, slide the Ronin (Not Included) on the Gimbal Fluid Head and tighten the knob to lock it in its position.


NOTE: Without any camera setup this jib gets balanced at 24kg weight. If the camera weight is 1kg, the jib is balanced with 24+3.5 = 27.5kg.







- Loosen the side knob of the Ronin Controller bracket and slide it onto the weight rod and tighten the controller's knob to secure it.
- Now, loosen the top knob of the Ronin Controller bracket and insert the controller into the controller bracket's knob and tighten it.






Attaching the Cable Tie

- After completing Scissor Jib installation, retract the jib arm.
- Attach cable ties to the hole of each frame.
- Starting from the Hub Mounting, insert the cables into the cable tie.
- Now, tighten the cable ties.

NOTE: Maximize the length of scissor jib arm to ensure that the cables remain spiraled, as shown in the image.





Maintenance

Bearing Maintenance

If after some time your bearings don't work smoothly, lubricate them with light machine oil. Be sure to keep oil away from your camera, & clean up in case of over-spill.

Cleaning

Do not use solvents or harsh cleaners on your Crane. If the unit becomes dirty, use a damp soft cloth or sponge and a mild detergent to gently clean external parts.

Balancing Tips:

Jib self balancing With 24kg Weight

If the camera weight is 1kg, the jib is balanced with 24+3.5 = 27.5kg

If the camera weight is 2kg, the jib is balanced with 24+7= 31kg

If the camera weight is 10kg, the jib is balanced with 24+35= 59kg

YOUR PROAIM POWERMATIC SCISSOR 17FT CAMERA JIB CRANE ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.