



User Manual

Version 1.0.0 Oct 2021

DNP-211

DNP3 Master to Modbus TCP Server Gateway



Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, nor for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2021 ICP DAS Co., Ltd. All rights are reserved.

Trademarks

Names are used for identification purposes only and may be registered trademarks of their respective companies.

Document Revision

Version	Author	Date	Description
1.0.0	Ming	2021/10/06	First Released Revision

Contents

1. Introduction	4
1.1. IEC-61850 Introduction.....	4
1.2. Modbus TCP Introduction.....	4
1.3. About IEC850-211-S	5
1.4. Features.....	5
1.5. Specifications.....	5
2. Hardware	7
2.1. Dimensions	7
2.2. Appearance.....	8
2.3. LED Indicator.....	9
3. Getting Started With IEC850-211-S	10
3.1. Preparations for Devices.....	10
3.2. Hardware Wiring.....	10
3.3. IEC850-211-S Utility	10
3.4. Update Firmware	錯誤! 尚未定義書籤。

1. Introduction

1.1. DNP3 Introduction

DNP3 (Distributed Network Protocol 3) is a communication protocol used between automation components. The protocol is formulated with reference to IEC 870-5. The purpose is to unify the communication method of SCADA so that SCADA can use the DNP3 protocol to communicate with master stations, remote terminal units (RTUs), intelligent electronic devices (IEDs), etc., and are mainly used in utilities such as electric and water companies.

The DNP3 protocol has certain of reliability and allows reliable communications in the adverse environments that electric utility automation systems are subjected to being specifically designed to overcome distortion induced by electromagnetic interference (EMI), aging components, and poor transmission media. A large number of CRC check codes are used in the protocol to ensure the accuracy of data. It is suitable for high security, Data communication field of medium speed and medium amount of data.

1.2. Modbus TCP Introduction

Modbus TCP is a variant of the Modbus family of simple, vendor-neutral communication protocols intended for supervision and control of automation equipment. Specifically, it covers the use of Modbus messaging in an "Intranet" or "Internet" environment using the TCP/IP protocols. The most common use of the protocols at this time is for Ethernet attachment of PLC' s, I/O modules, and gateways to other simple field buses or I/O networks.

1.3. About DNP-211

DNP-211 is a gateway that supports DNP3 master and Modbus TCP server protocol conversion. As long as the master device supports Modbus TCP protocol, it can connect the existing DNP3 network with the Ethernet-based master device. For DNP3 network, DNP-211 is a DNP3 master device. It supports several commonly used data groups and variables and can communicate with slave devices. From the perspective of Modbus TCP network, DNP-211 is a Modbus TCP server, which can receive commands from Modbus TCP client, and process these commands to reply or send related DNP3 data. All DNP3 I/O data and Modbus mapping can be configured through DNP-211 utility software.

1.4. Features

- Read / Write DNP3 outstations via Modbus TCP
- Configurable DNP3 Master
- Configurable Modbus TCP server
- Support Data Group 1, 10, 12, 20, 30, 40, 41
- Support Modbus function code 1, 2, 3, 4, 15, 16
- Provides Modbus register of connection status of DNP3 outstations
- Supports up to 32 DNP3 outstations
- Supports up to 16 Modbus client connections

1.5. Specifications


System	
CPU	Cortex-A8, 1 GHz
SDRAM	512 MB
Flash	512 MB
FRAM	64 KB
LED Indicators	PWR (Power), RUN (System run), L1 (Firmware run), L2 (Modbus TCP connection), L3 (DNP3 connection)
Communication Ports	

VGA	1 (reserved)	
Ethernet	RJ-45 x 2, 10/100/1000 Based-TX (Auto-negotiating, Auto MDI/MDI-X, LED indicators)	
USB 2.0	2 (reserved)	
Console Port	RS-232 (RxD, TxD and GND); Non-isolated	
ttyO2	RS-485 (Data+, Data-); Non-isolated	
ttyO4	RS-232 (RxD, TxD and GND); Non-isolated	
ttyO5	RS-485 (Data+, Data-); 2500 VDC isolated	
Protocol		
Modbus	Identity	Modbus TCP server
	Function	1, 2, 3, 4, 15, 16
	Connection	Max. 16 Modbus TCP clients
DNP3	Identity	DNP3 master
	Connection	Max. 5 MMS clients
	Group	1, 10, 12, 20, 30, 40, 41
	Data Point	DI: 8192 DO: 8192 Count: 2048 AI: 2048 AO: 2048
Power		
Supply Voltage	+12 to +48 VDC	
Consumption	4.8 W	
Connector	3-pin Removable Terminal Block	
Mechanism		
Dimensions	35 mm x 167 mm x 119 mm	
Casing	Metal	
Installation	DIN-Rail	
Environment		
Operating Temp.	-25°C ~ +75°C	
Storage Temp	-30°C ~ +85°C	
Humidity	10 ~ 90% RH, non-condensing	


2. Hardware

2.1. Dimensions

Unit: mm




2.2. Appearance



2.3. LED Indicator

There are five LEDs to indicate the various states of the DNP-211. The following is the illustration of these five LEDs.



LED Name	LED Status	Description
PWR	ON	Power on
	OFF	Power failure
RUN	Blink	OS is running
	OFF	OS stops running
L1	Flash every second	Firmware is running
	Other	Firmware stops running
L2	Flash every 500 ms	Modbus TCP disconnected
	OFF	No Warning
L3	Flash every 500 ms	At least one DNP3 outstation disconnected
	OFF	No Error

3. Getting Started With DNP-211

3.1. Preparations for Devices

In addition to the DNP-211, please prepare the following:

1. **Power Supply: +12 ~ +48 VDC** (Ex: DP-665)
2. **Ethernet Hub or Switch** (Ex: NS-205)
3. **PC/NB:** Can connect to the network and set the network

3.2. Hardware Wiring

Connect the DNP-211 with the RJ-45 Ethernet port LAN1 to an Ethernet hub/switch and PC. You can also link directly the DNP-211 to PC with an Ethernet cable.

After power is connected, please **wait 1 minute** for DNP-211 start-up procedure. When the "RUN" indicator starts **flashing** and "PWR" indicator is **constantly lit**, it represents the boot is complete. After the module boots successfully, if the "L1" indicator flashes every second, it means the firmware is running.

3.3. DNP-211 Utility

3.3.1. Download DNP-211 Utility

(補上網頁下載位置圖)

Download and install IEC850_211_S_Utility

 DNP_211_Utility_v100.zip	2021/9/30 下午 0...	壓縮的 (zipped) ...	343 KB
			
名稱	修改日期	類型	大小
 DNP_211_Utility_v100.exe	2021/9/30 上午 1...	應用程式	53 KB
 Renci.SshNet.dll	2021/1/24 下午 0...	應用程式擴充	786 KB

3.3.2. DNP-211 Utility Introduction

The DNP_211_Utility is as below:

DNP-211 Utility v1.00

Gateway Type: DNP3 Master to Modbus Slave

Gateway IP: 172.17.3.152 Port: 502

ComPort Baud: 115200 Databit: 8 Parity: None Stopbit: One

DNP3 Master ID: 1 Modbus Slave ID: 1 Slave Amount: 1

IO Parameter

Communication Mode: TCP Remote IP: 172.17.12.2 Remote Port: 20000

Outstation ID: 2

Set Outstation Config: None

IO Setting

I/O Type: Binary_Input Group_Variation: G1V1

Start Index: Amount: Output mode: Select and Operate

Description: Add Delete

Item Num	Group/Variation	Start Index	Amount	Output mode	Description
*					

DNP-211 Communication Configure

DNP-211 Utility v1.00

Gateway Type: DNP3 Master to Modbus Slave

Gateway IP: 172.17.3.152 Port: 502

ComPort Baud: 115200 Databit: 8 Parity: None Stopbit: One

DNP3 Master ID: 1 Modbus Slave ID: 1 Slave Amount: 1

Gateway Type: Display gateway type of the DNP-211.

Gateway IP: Modbus TCP IP address of the DNP-211 (LAN1 IP).

Port: Modbus TCP port of the DNP-211

ComPort Baud: Com port data baud rate of DNP3 side (ttyO2, 4, 5).

Databit: Com port data bit of DNP3 side (ttyO2, 4, 5).

Parity: Com port data parity of DNP3 side (ttyO2, 4, 5).

Stopbit: Com port data stop bit of DNP3 side (ttyO2, 4, 5).

DNP3 Master ID: Master ID, cannot be the same as slave (0 ~ 65519).

Modbus Slave ID: Modbus ID of the DNP-211.

Slave Amount: Number of DNP3 slaves.

DNP3 Outstation Communication Configure

The screenshot shows the 'IO Parameter' dialog box with the 'IO Parameter' tab selected. The 'Communication Mode' is set to 'TCP'. The 'Remote IP' is '172.17.12.2' and the 'Remote Port' is '20000'. The 'Outstation ID' is '2'. A 'Set' button is visible, and the 'Outstation Config' is 'None'.

The screenshot shows the 'IO Parameter' dialog box with the 'IO Parameter' tab selected. The 'Communication Mode' is set to 'UDP'. The 'Remote IP' is '172.17.12.2' and the 'Remote Port' is '20000'. The 'Outstation ID' is '2'. The 'Source IP' is '192.168.255.1' and the 'Source Port' is '20000'. A 'Set' button is visible, and the 'Outstation Config' is 'None'.

The screenshot shows the 'IO Parameter' dialog box with the 'IO Parameter' tab selected. The 'Communication Mode' is set to 'Serial'. The 'ComPort' is 'ttyO2'. The 'Outstation ID' is '2'. A 'Set' button is visible, and the 'Outstation Config' is 'None'.

Number tab: Select outstation

Communication Mode: Select connection mode (TCP, UDP, Serial)

TCP mode:

Remote IP, Remote Port: IP and port of target outstation.

UDP mode:

Remote IP, Remote Port: IP and port of target outstation.

Source IP, Source Port: IP and port of the DNP-211.

Serial mode:

ComPort: Select the Com port connected to outstation.
 Communication ID: DNP3 outstation ID (0~65519).
 Set button: Set the connection parameter of the selected outstation.

Outstation I/O Configure

Item Num	Group/Variation	Start Index	Amount	Output mode	Description
1	G1V1	0	10		Only For Test
*					

I/O Type: Added I/O type of the slave (map with Group_Variation)
 Group_Variation: Added I/O type of the slave (map with I/O Type)
 Start Index: Added I/O start address at the DNP3 slave
 Amount: Amount of the I/O item
 Output mode: DO / AO output mode (only for write command)
 Description: User' s self-filled description

Utility Button

Import: Import the existing GatewayConfig.toml configuration file
 Export: Export the current settings to the GatewayConfig.toml
 Modbus Map: Display the Modbus Address table for currently set
 Upload: Upload the GatewayConfig.toml configuration file or
 d2m_XXXXXXX.tar.gz firmware file to DNP-211

Note: DNP-211 must be rebooted after upload configuration or firmware file.