Remote Monitoring and Management software (RMM) supports the networked printers which are noted below.

To monitor and manage your fleet with RMM software, the printers must be connected over Ethernet. The printers connected with USB are not supported, even if the USB is used for only the issuance software.



USB 🗄 🔁

PRINTER MODEL		RMM VERSION	MINIMUM FIRMWARE VERSION	PRINTER MODEL		RMM	MINIMUM FIRMWARE VERSION	
	DIRECT-T	O-CARD		EMBOSSING				
	CD800™ CLM	√ RMM 6.4	D3.14.8.6		280P	×	NA	
	CD800™ D	✓ RMM 6.4	D3.14.8.6		450	×	NA	
	CD800™ S	√ RMM 6.4	D3.14.8.6		CE840™	√ RMM 6.5	D3.14.8.6	
	CD820™	✓ RMM 6.0	D3.14.8.6		CE870™	√ RMM 6.0	D3.14.8.6	
	FP65i™	×	NA		CE870™ K	√ RMM 6.5	D3.14.8.6	
	SD160™	×	NA		CE875™	√ RMM 6.3	R4S.3.1-1	
					RETRANSFER			
-	SD260™ C	×	NA		CR500™	√ RMM 6.0	U1.32.1-5000	
	SD260™ L	×	NA		CR805™	√ RMM 6.4	R4S.3.1-1	
	SD360™	√ RMM 6.5	D3.14.8.6		CR825™	✓ RMM 6.3	R4S.3.1-1	
	SD460™	√ RMM 6.5	D3.14.8.6		SR200 SR300	×	NA	

Supported in the current release (RMM 6.5)

X Not supported by RMM

🜔 Entrust Datacard

Corporate Headquarters

Entrust Datacard, Datacard, Adaptive Issuance and the hexagon design are registered trademarks, trademarks and/or service marks of Entrust Datacard Corporation in the United States and/or other countries. ©2017 Entrust Datacard Corporation. All rights reserved.

Phone: +1 952 933 1223 | www.datacard.com | info@entrustdatacard.com