TOMAHAWK

TW2 and TW3
GAS POWERED WATER PUMPS

Instruction Manual



	Spar	k Plug
	Valu	Clearance
	No L	and Speed
MAINTENAN	Discharge Head (ft.)	120 190 80 60 40 20 0
ő		0

and Diagrams22	
and Diograms	

-,			
		W. S. G.	


Engine			Engine	
Displacement		21200	Displacement	
Engine Type		Horizontal Single Cylinder 4 stroke OHV EPA phase III compliant	Engine Type	
Cooling System		Forced air cooled	Cooling System	
Fuel	Туре	87+ octane unleaded pasoline	Fuel	Type
ruei	Capacity	0.9 Gallons / 3.6 Liters	rom	Capacity
Engine Oil	Type SAE	10W-30 above 32" F 5W30 at 32" F or below	Engine Oil	Type SAE
	Capacity	0.5 Quarts / 0.5 Liters		Capacity
Run Time @ 50%	Load with full tank	3 Nr.	Run Time @ 50%	
Sound Level at 22 feet		104 dB	Sound Level at 22 feet	
Bore x Stroke		70 mm x 55 mm	Bore x Stroke	
Compression Ratio		8.0.1	Compression Ratio	
Rotation viewed frogover takeoff - the		Counterslockwise	Rotation viewed for (power takeoff - the	
	Shaft	3/4" x 2.41"		Shaft
Shaft .	Keyway	3/16" (4.76 mm)	Shaft	Keyway
	End Tapped	5/16" - 24 UNF	11	End Tappe
Spark Plus	Туре	NGK [®] BP-6ES NHSP [®] / Toruh [®] FSTC	Spark Phys	Туре
	Cap	0.7 - 0.8 mm	.,	Cap
Value Cleananne	Intake	0.10 - 0.15 mm	Valva Clasrenna	Intake
varie Clearance	Exhaust	0.15 - 0.20 mm	vave Clearance	Exhaust
No Load Speed		3,800 a100 RPM	No Load Speed	

PERFORMAN

151 GPs 97.5 ft.

fechanical Sea			
cluded Acces	sories		
ngine			
isplacement			
ngine Type			
coling System		_	
uel Type Capacity			
ingine Oil	Type SAE		
	Capacity		
un Time @ 50	% Load with full tank		
ound Level at	22 feet		
iore x Stroke			
ompression R	Min		

\			
,	120	150	





WARNING SYMBOLS AND DEFINITIONS

A	Obey all safety messages that follow this symbol to avoid possible injury or death.
▲ DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
AWARNING	Indicates a hazardous situation which, if not avoided,

Indicates a hazardous situation which, if not avoided, could result in death or serious injury. Indicates a hazardous situation which, if not avoided. could result in minor or moderate injury

Addresses practices not related to personal injury.

CAUTION Symbol Definitions

^

ACAUTION

NOTICE

Symbol	Property or Statement
RPM	Revolutions Per Minute
HP	Horsepower
	WARNING marking concerning

Risk of Eve Injury. Wear ANSI-approved safety goggles with side shields.

Read the manual before set-up and/or use.





Property or Statement Risk of Respiratory Injury. Operate engine OUTSIDE and far away from windows, doors, and vents.







fety Warnings

WARNING! Read all instructions. Failure to follow all instructions listed below may result in fire, serious injury and/or DEATH.

The warnings and precautions discussed in this manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

SAVE THESE INSTRUCTIONS

Set up Precautions

- Gasoline fuel and fumes are flammable, and potentially explosive. Use proper fuel storage or other flammable materials nearby.
- and handling procedures. Do not store fuel Have multiple ABC class fire extinguishers nearby. 3. Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.
- well-ventilated surface.
- Set up and use only on a flat, level. 5. Use only lubricants and fuel recommended in the Specifications chart of this manual.
 - Wear ANSI-approved safety googles, heavy-duty work gloves, and dust mask/respirator during set up.

Engine Precautions Follow engine precautions and instructions in the included engine instruction manual.

Operating Precautions



CARBON MONOXIDE HAZARD Using an engine indoors CAN KILL YOU IN MINUTES. Engine exhaust contains carbon

monoxide. This is a poison you cannot see or smell.





NEVER use inside a home or garage, EVEN IF doors and windows are open.





- doors, and vents. Keep children away from the equipment.
- especially while it is operating
- 3. Do not touch Pump engine during use. Never store fuel or other flammable materials near the Pump engine.

- 5. Industrial applications must follow OSHA requirements. Do not leave the equipment unattended when it is
- running. Turn off the equipment (and remove safety keys, if available) before leaving the work area. Engine can produce high noise levels.
 - Prolonged exposure to noise levels above 85 dBA is hazardous to hearing. Always wear ear protection when operating or working around the gas engine while it is operating. Wear ANSI-approved safety glasses, hearing
- protection, and NIOSH-approved dust mask/ respirator under a full face shield along with steel-toed work boots during use People with pagemakers should consult their
- physician(s) before use. Electromagnetic fields in close proximity to a heart pacemaker could cause nacemaker interference or nacemaker failure Caution is necessary when near the engine's magneto or recoil starter. 10. Use only accessories that are recommended
- byTomahawk Power LLC for your model. Accessories that may be suitable for one piece of equipment may become hazardous when used on another piece of equipment.
- 11. Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Gasoline-powered engines may ignite the dust or fumes.

Operating Precautions (cont.) 12. Stay alert, watch what you are doing and

- use common sense when operating this piece of equipment. Do not use this piece of equipment while tired or under the influence of drugs, alcohol or medication.
- 13. Do not overreach. Keep proper footing and balance at all times. This enables better control of the equipment in unexpected situations
- 14. Dress properly. Do not wear loose clothing or jewelry. Keep hair, dothing and gloves away from moving parts. Loose clothes, iewelry or long hair can be caught in moving parts. 15. Parts, especially exhaust system components.
- get very hot during use. Stay clear of hot parts. 16. Do not cover the engine or equipment during operation.
- 17. Keep the equipment, engine, and surrounding area clean at all times.
- 18. Use the equipment, accessories, etc., in accordance with these instructions and in the manner intended for the particular type of equipment, taking into account the working conditions and the work to be performed. Use of the equipment for operations different from those intended could result in a hazardous situation.

- 19. Do not operate the equipment with known leaks in the engine's fuel system. 20. This product contains or, when used, produces a
- chemical known to the State of California to cause cancer and hirth defects or other reproductive harm (California Health & Safety Code § 25249.5, et seq.) 21. When spills of fuel or oil occur, they must be cleaned up immediately. Dispose of fluids and
- cleaning materials as per any local, state, or federal codes and regulations. Store oil rags in a bottom-ventilated, covered, metal container. 22. Keep hands and feet away from moving
- parts. Do not reach over or across equipment while operating. 23. Before use, check for misalignment or binding of moving parts, breakage of parts.
- and any other condition that may affect the equipment's operation. If damaged, have the equipment serviced before using. Many accidents are caused by poorly maintained equipment. 24. Use the correct equipment for the application.
- Do not modify the equipment and do not use the equipment for a purpose for which it is not intended.

Service Precautions

- 1. Before service, maintenance, or cleaning: a. Turn the engine switch to its "OFF" position.
 - b. Allow the engine to completely cool. c. Then, remove the spark plug
 - cap from the spark plug.
- 2. Keep all safety quards in place and in proper working order. Safety guards include muffler, air cleaner, mechanical quards. and heat shields, among other guards.
- 3. Do not alter or adjust any part of the equipment or its engine that is sealed by the manufacturer or distributor. Only a qualified service technician may adjust parts that may increase or decrease governed engine speed. Wear ANSI-approved safety appoles, heavy-duty
- work gloves, and dust mask/respirator during service. Maintain labels and nameplates on the equipment. These carry important information. If unreadable or missing, contact
- Tomahawk Power LLC for a replacement.

- 6. Have the equipment serviced by a qualified repair person using only identical replacement parts This will ensure that the safety of the equipment is maintained. Do not attempt any service or maintenance procedures not explained in this manual or any procedures that you are uncertain about your ability to perform safely or correctly. 7. Store equipment out of the reach of children.

Refueling: 1. Do not smoke, or allow sparks, flames,

- or other sources of ignition around the equipment, especially when refuelling. 2. Do not refill the fuel tank while the
- engine is running or hot. 3. Do not fill fuel tank to the top. Leave a little
- room for the fuel to expand as needed. 4. Refuel in a well-ventilated area only. 5. Wipe up any spilled fuel and allow excess
 - to evaporate before starting engine. To prevent FIRE, do not start the engine while the smell of fuel hangs in the air.



SAVE THESE INSTRUCTIONS.

WARNING

TO PREVENT SERIOUS INJURY: Operate only with proper spark arrestor installed.

Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

High Altitude Operation Above 3000 feet

AWARNING! To prevent serious injury from fire: Follow instructions in a well-ventilated area away from ignition sources. If the engine is hot from use, shut the engine off and wait for it to cool before proceeding. Do not smoke. NOTICE Warranty void if necessary adjustments are not made for high altitude use

At high altitudes, the engine's carburetor, governor (if so equipped), and any other parts that control the fuel-air ratio will need to be adjusted by a qualified mechanic to allow efficient high-altitude use and to prevent damage to the engine and any other devices used with this product. The fuel system on this engine may be influenced by operation at higher altitudes. Proper operation can be ensured by installing an altitude kit at altitudes higher than 3000 ft. above sea level. At elevations above 8000 ft, the engine may experience decreased performance, even with the proper main jet. Operating this engine without the proper altitude kit installed may increase the engine's emissions and decrease fuel economy and performance. The kit should be installed by a qualified mechanic.

- 1. Turn off the engine.
- Close the fuel valve.
- Place a bowl under the fuel cup to catch any spilled fuel.
- CAUTION! Carburetor bowl may have gas in it which will leak upon removing the bolt. Unthread the bolt holding the fuel cup
- 5. Remove the bolt. Bolt Seal, fuel cup. Fuel Cup Seal and Main Jet from the body of the carburetor assembly. A carburetor screwdriver (not included) is needed to remove and install the Main Jet.
- Note: The mixing tube is held in place by the Main Jet and might fall out when it is removed. If it falls out, replace it in the same orientation before replacing the Main Jet.
 - Replace the Main Jet with the replacement Main Jet needed for your altitude range (part 1a or 2a).
- Note: The Fuel Cup Seal and Bolt Seal may be damaged during removal and should be replaced with the new ones from the kit.
- Replace the Fuel Cup Seal (4a) fuel cup. Bolt Seal (3a), and bolt. Tighten in place.
- CAUTION: Do not cross thread bolt when tightening. Finger tighten first and then use a wrench to make sure the bolt is properly threaded. Wipe up any spilled fuel and allow excess to evaporate
- before starting engine. To prevent FIRE, do not start the engine while the smell of fuel hangs in the air.

High.	Altitude	Kit	Parts	List	- 4

Part	Description	Qty
1a	Main Jet 3000-6000 ft.	1
2a	Main Jet 6000-8000 ft.	1
3a	Bolt Seal	1
40	Fuel Cun Seal	1



Page 6

Bolt Seal

Grounding

The Generator must be properly grounded before use. Have the unit grounded by a qualified electrician if you are not qualified to do so.

To ground the Generator, connect a #6 AWG grounding wire (not included) from the Grounding Terminal on the Control Panel to a grounding rod (not included) that has been driven at least 24 inches deen into the earth. The profunding not must be an earth-driven.

Grounding Terminal on the Control Panel to a grounding rod (not included) that has been driven at least 24 inches deep into the earth. The grounding of ormust be an earth-driven copper or brass rod (electrode) which can adequately ground the Generator. CAUTION: This generator is not intended to owner sensitive electronic equipment without the addition of an


appropriate line conditioner and surge protector (both not included). Sensitive electronic equipment includes, but is not limited to, audiovideo equipment, some television sets, computers, and printers. Sensitive electronic equipment should be operated on approved inverter type generators or pure sine wave generators.

Note: For additional information regarding the parts listed in the following pages.

TW 20-0

refer to the Assembly Diagram near the end of this manual.

Controls



Note: Hose coupling components and hoses not included. Note: The Suction Hose (not included) MUST has coinforced with braided material or have

be reinforced with braided material or have non-collapsible construction. Do not use a hose with an inside diameter smaller than 2"or 3" (pump's intake and discharge port diameters). CAUTION: Do not over-tighten Hose Clamps as the

clamp may damage the hose or other components.

1. Slide one of the Hose Coupling Rings over one of the Hose Couplers (a), then place a Gasket on the end of the Hose Coupler (b).




 Thread the Hose Coupling Ring onto the Intake Port (a), and turn clockwise until fastened securely (b).




 Slide one of the Hose Clamps over the end of the suction hose (a). Slide the Hose onto the Hose Coupler (b). Use a screwdriver (not included) to tighten the Hose Clamp until secure.

CAUTION: Use only a non-collapsible intake hose.



suction hose (a). Slide the Intake Strainer into the end of the suction hose (b). Use a screwdriver to tighten the Hose Clamp until secure.



over the remaining Hose Coupler (a) and place a Gasket onto the end of the Hose Coupler (b).





Thread the Hose Coupling Ring clockwise onto



7. Slide a Hose Clamp over the end of the

Discharge Hose (a), Slide the Discharge Hose

Locating the Water Pump

Locate the Water Pump on a flat, level, sturdy surface capable of supporting the weight of the Pump.

For best Pump performance, place the Pump near the water level and use hoses that are no longer than necessary. This will allow the Pump to produce the greatest output with the least self-priming time. See diagram below.

closer to the water level) will also help reduce self-priming time. This is the time it takes the Pump to bring the water from the water level to the Pumo during the initial operation.

2. Route the Intake Hose with the Intake Strainer fully immersed in the water supply source.

Minimizing suction head (placing the Pump

3. Place Strainer into water to be pumped. CAUTION: Immerse strainer fully in water. Do not operate Pump without Strainer connected to end of suction hose. Keep Strainer out of sand

or silt by placing Strainer in a bucket or on stones. NOTICE: If there is an air leak in the suction line. you may not be able to prime the pump.



As the head (pumping height) increases. pump output decreases. The length, type, and size of the suction and discharge hoses can also significantly affect Pump output.

Discharge head capability is always greater than suction head capability. This means pumping height for the Intake Hose (suction head) should be shorter than the pumping height for the Discharge Hose.



Secure the Intake Hose in place to keep it from moving once the Pump is turned on. The Intake Hose should be as short as possible for more efficient operation.

5. Route the discharge hose to the desired discharge location. If necessary, connect additional discharge hoses to direct the discharge to the desired location. Make sure to secure the discharge hose in place to keep it from moving once the Water Pump is turned on. The discharge hose should be kept as short as possible for more efficient operation.

Operation Concerns

 CAVITATION: This is the sudden formation and collapse of low-pressure vapor (bubbles) across the vanes of the impeller.
 Cause: When the surface pressure on a liquid

becomes low encugh, the liquid will begin to boil (even at room temperature). With centrifugal pumps, cavitation can occur when the suction vacuum becomes too great, allowing water vapor or bubbles to form at the impelier. The rapid pressure increase can cause impelier damage. Solution: Minimizing suction head and using the largest practical suction hose diameter will reduce the likelihood of cavitation. Do not use a suction hose with a diameter smaller than the Pump's Intake Port (2" or 3" diameter). WATER HAMMER PRESSURE: This is

energy sent back to the Pump due to sudden stoppage of water flowing from the Pump. Cause: Water hammer pressure is more likely to occur when using a very long discharge hose. If the

occur when using a very long discharge hose. If the flow of vater at the end of the discharge hose is shut off sudderly, energy is sent back to the purp. This causes a large pressure spike in the Pump housing leading to potential diamage to the Pump casing Solution: Use as short a discharge hose as possible and turn off water pump before closing vater flow.

Ï

Read the ENTIRE IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Prime the Pump

Before starting the engine, fill the Pump with water. To do this:

- Unthread the Priming Water Filler Cap by turning it counterclockwise.
- Fill the unit with clean water up to the top of the opening. Replace the Priming Water Filler Cap and tighten securely.

IMPORTANT! Always check for water in the Pump Housing before each use. Never attempt to run the Water Pump without the Pump Housing FULL of water. Running the Water Pump without water for an extended period of time will damage the Water Pump and void the Warranty.



Checking and Filling Engine Oil CAUTION! Your Warranty is VOID if the engine's crankcase is not properly filled with oil before each use. Before each use, check the oil level.

Do not run the engine with low or no engine oil.
Running the engine with no or low engine oil
WILL permanently damage the engine.

- . Make sure the engine is stopped and is level.
- 2. Close the Fuel Valve.
- Clean the top of the Dipstick and the area around it. Remove the Dipstick by threading it counterclockwise, and wipe it off with a clean lint free rag.



- Reinsert the Dipstick without threading it in and remove it to check the oil level. The oil level should be up to the full level as shown above.
- 5. If the oil level is at or below the low mark add the appropriate type of oil until the oil level is at the proper level. SAE 10W-30 oil is recommended for general use. (The SAE Viscosity Grade chart on page 14 in the Service section shows other viscostities to use in different average temperatures.)
- Thread the dipstick back in clockwise.

 CAUTION! Do not on the project with ten little oil

CAUTION! Do not run the engine with too little oil.
The engine will be permanently damaged.

WARNING! TO PREVENT SERIOUS INJURY FROM FIRE:

Fill the fuel tank in a well-ventilated area away from ignition sources. If the engine is hot from use, shut the engine off and wait for it to cool before adding fuel.

Do not smoke. 1. Clean the Fuel Cap and the area around it.

- Unscrew and remove the Fuel Cap.
- 3. If needed, fill the Fuel Tank to about

Checking and Filling Fuel

1" under the fill neck of the Fuel Tank with 87 octane or higher unleaded gasoline.

10% ethanol (E10). Do not use E85 ethanol.

Note: Do not use gasoline containing more than Note: Do not use gasoline that has been stored in a metal fuel container or a dirty fuel container. It can cause particles to enter the carburetor, affecting engine performance and/or causing damage.

- 4. Then replace the Fuel Cap. 5. Wipe up any spilled fuel and allow excess
 - to evaporate before starting engine. To prevent FIRE, do not start the engine while the smell of fuel hangs in the air.

Starting the Engine

 To start a cold engine, move the Choke to the CHOKE position. To restart a warm engine, leave the Choke in the RUN position.







Open the Fuel Valve.

3. Slide the Throttle to 1/3 away from the SLOW position (the "turtle"), TW3.0-C don't have throttle, is alredy calibrated for efficient use.









4. Turn the Engine Switch on.







5. Grip the Starter Handle of the Engine loosely and pull it slowly several times to allow the gasoline to flow into the Engine's carburetor. Then pull the Starter Handle gently until resistance is felt. Allow Cable to retract fully and then pull it quickly. Repeat until the engine starts.

Note: Do not let the Starter Handle snap back against the engine. Hold it as it recoils so it doesn't hit the engine.

Allow the Engine to run for several seconds.
 Then, if the Choke lever is in the CHOKE position, move the Choke Lever very slowly to its RUN position.

NOTE: Moving the Choke Lever too fast could stall the engine.

IMPORTANT: Allow the engine to run at no load for five minutes with no load after each start-up so that the engine can stabilize.

Adjust the Throttle as needed. (TW3.0-C)*
 Break-in Period:

. Break-in Period

a. Breaking-in the engine will help to ensure proper equipment and engine operation.
 b. The operational break-in period will last about 3 hours of use. During this period:

Do not apply a heavy load to the equipment.

Do not operate the engine at its maximum speed.

c. The maintenance break-in period will last about 20 hours of use. After this period:

Change the engine oil. Note: Failure to change the oil regularly may damage the engine and void the warranty.
 Under normal operating conditions subsequent maintenance follows the schedule explained in the MANTENANCE AND SERVICING section.

Stopping the Engine

 To stop the engine in an emergency, turn the Engine Switch off.



a. Slide the Throttle to SLOW (the "turtle"). (TW3.0-C)*



b. Turn the Engine Switch off.

(TW3.0-C)*: Don't have throttle, is alredy calibrated for efficient use.





· WARNING

TO PREVENT SERIOUS INJURY FROM ACCIDENTAL STARTING-

Turn the Power Switch of the equipment to its "OFF" position, wait for the engine to cool, and disconnect the spark plug cap before performing any inspection, maintenance, or cleaning procedures.

TO PREVENT SERIOUS INJURY FROM EQUIPMENT FAILURE: Do not use damaged equipment. If abnormal noise, vibration, or excess

smoking occurs, have the problem corrected before further use.

Follow all service instructions in this manual. The engine may fail critically if not serviced properly. Many maintenance procedures, including any not detailed in this manual, will need to be performed by a qualified technician for safety. If you have any doubts about your ability to safely service the equipment or engine, have a qualified technician service the equipment instead.

Cleaning, Maintenance, and Lubrication Schedule

Note: This maintenance schedule is intended solely as a general guide. If performance decreases or if equipment operates unusually, check systems immediately. The maintenance needs of each piece of equipment will differ depending on factors such as duty cycle, temperature, air quality, fuel quality, and other factors. Note: The following procedures are in addition to the regular checks and maintenance

Procedure	Before Each Use	Monthly or every 20 hr. of use	Every 3 mo. or 50 hr. of use	Every 6 mo. or 100 hr. of use	Yearly or every 300 hr. of use	Every 2 Years
Brush off outside of engine	V	✓	✓	✓	✓	1
Check engine oil level	V	V	✓	√	✓	1
Check air cleaner	V		✓	✓	✓	V
Check deposit cup	V			✓	✓	1
Change engine oil		✓		√	✓	1
Clean/replace air cleaner			√×	✓	√	1
Check and clean spark plug				✓	✓	V
Check/adjust idle speed						
Check/adjust valve clearance						
 Clean fuel tank, filter and carburetor 					V**	V**
 Clean carbon build-up from combustion chamber 						
Replace fuel line if necessary						V**

^{*}Service more frequently when used in dusty areas.



^{**}These items should be serviced by a qualified technician.

Checking and Filling Fuel ! WARNING! TO PREVENT SERIOUS INJURY FROM FIRE: Fill the fuel tank in a well-ventilated area for it to cool before adding fuel.

hot from use, shut the engine off and wait

Do not smoke

1. Clean the Fuel Cap and the area around it.

Unscrew and remove the Fuel Cap.

3. If needed, fill the Fuel Tank to about 1" under the fill neck of the Fuel Tank with 87 octane or higher unleaded gasoline. Note: Do not use gasoline containing more than

10% ethanol (E10). Do not use E85 ethanol.

Note: Do not use gasoline that has been stored in a metal fuel container or a dirty fuel container. It can cause particles to enter the carburetor, affecting engine performance and/or causing damage.

Then replace the Fuel Cap.

Wipe up any spilled fuel and allow excess to evaporate before starting engine. To prevent FIRE, do not start the engine while the smell of fuel hangs in the air.

Engine Oil Change CAUTION! Oil is very hot during operation and can

cause burns. Wait for engine to cool before changing oil. 1. Make sure the engine is stopped and is level. away from ignition sources. If the engine is Close the Fuel Valve.

3. Place a drain pan (not included) underneath the crankcase's drain plug.

4 Remove the drain plug and if possible

tilt the crankcase slightly to help drain the oil out. Recycle used oil.

5 Replace the drain plup and tighten it

6. Clean the top of the Dipstick and the area around it.

Remove the Dipstick by threading it counterclockwise.

and wipe it off with a clean lint free rag.



the full level. SAF 10W-30 oil is recommended for general use. The SAE Viscosity Grade chart shows other viscosities to use in different average temperatures.



8. Thread the dipstick back in clockwise. CAUTION! Do not run the engine with too little oil. The engine will be permanently damaged



up on the Filter Cover Tab, pivoting the cover at the Base Hinge. Remove the filter and check for dirt. Clean or replace as described below.

Air Filter Element Maintenance



1. To remove the air filter cover, push in and lift



2. Cleaning: · Foam filter element:

- Wash the element in warm water and mild detergent several times. Rinse. Squeeze
- out excess water and allow it to dry completely. Soak the filter in lightweight oil briefly, then squeeze out the excess oil. 3. Install the new filter or the cleaned filter.
 - Secure the Air Cleaner Cover before use.



Spark Plug Maintenance



- Using a spark plug wrench, remove the spark plug. 3. Inspect the spark plug.
- If the electrode is oily, clean it using a clean, dry rag. If the electrode has deposits on it, polish it
- using emery paper. If the white insulator is cracked or chipped, the spark plug needs to be replaced.



plug may damage the engine.

- 4. When installing a new spark plug, adjust the plun's gap to the specification on the Technical
 - Specifications chart. Do not pry against the electrode, the spark plug can be damaged.
- 5. Install the new spark plug or the cleaned spark plug into the engine Gasket-style: Finger-tighten until the gasket contacts the cylinder head, then about 1/2-2/3 turn more. Non-gasket-style: Finger-tighten until the plug contacts the head, then about 1/16 turn more.

NOTICE: Tighten the spark plug properly If loose, the spark plug will cause the engine to overheat. If overtightened, the threads in the engine block will be damaged.

- Apply dielectric spark plug boot protector (not included) to the end of the spark plug and reattach the wire securely.



When the equipment is to remain idle for longer than

20 days, prepare the engine for storage as follows: 1 CLEANING: Wait for engine to cool, then clean engine with dry cloth. NOTICE: Do not clean using water.

The water will gradually enter the engine and cause rust damage.

Apply a thin coat of rust preventive oil to all metal parts.


2. FUEL:

WARNING! TO PREVENT SERIOUS INJURY FROM FIRE: Drain the fuel tank in a well-ventilated area

away from ignition sources. If the engine is hot from use, shut the engine off and wait for it to cool before draining fuel.

Do not smoke

 a. Place a funnel leading to a proper gasoline container below the carburetor.



h. Remove the drain holt from the holtom of the carburetor bowl and allow the fuel to drain.

- c. Remove the small sediment cup next to the bowl and allow the fuel to drain from there as well. d. Open the fuel valve.
- After all fuel has drained, reinstall the drain bolt and sediment cup and tighten securely. 3. LUBRICATION:

a. Change engine oil.

- b. Clean out area around spark plug.
- Remove spark plug and pour one tablespoon of engine oil into cylinder through spark plug hole. Replace spark plug, but leave
 - spark plug cap disconnected.
- d. Pull Starter Handle to distribute oil in cylinder. Stop after one or two revolutions when you feel the piston start the compression stroke (when you start to feel resistance). 4. BATTERY:

Disconnect battery cables (if equipped).

Recharge batteries monthly while in storage. STORAGE AREA:

Cover and store in a dry, level, well-ventilated area out of reach of children. Storage area

should also be away from ignition sources. such as water heaters, clothes divers, and furnaces 6. AFTER STORAGE: Before starting the engine after storage, keep in

mind that untreated gasoline will deteriorate guickly. Drain the fuel tank and change to fresh fuel if untreated gasoline has been sitting for a month, if treated casoline has been sitting beyond the fuel stabilizer's recommended time period. or if the engine does not start properly.



Problem	Possible Causes	Likely Solutions	
Pump overheats	Incorrect lubrication or not enough lubrication. Worn parts.	Lubricate using recommended oil or grease according to directions. Have qualified technician inspect internal mechanism and replace parts as needed.	1
	Low engine speed.	Qualified technician should increase no load speed to 3.800+100 RPM	1

Severely clogged air filter.
 Replace air filter.
 Check for proper oil level.
 Pump is not primed.
 Prime Pump.

Pump is too high above water surface.

Pump is not primed.
 In take Strainer clogged.
 In take Strainer or replace if damaged.
 Air leak at intake connector.
 Sectore Coupling Gasket or tighten damo.

by adjusting pressure switch.

7. Locate Pump at a lower level so it doesn't

Air leak at intake connector.
 A. Hose leaks.
 Suction hose has collapsing wall.
 Hose has too small diameter.
 Behose has too small diameter.

1. Suction hose collapsed, damaged, by home to work so hard to lift the water.
 1. Suction hose collapsed, damaged, by looking or dameter is too small.
 1. Speace or algalaction hose.
 1. Speace or Collapsed, and the success of the



Unit stalls

Pump does not

pump water

Pump Troubleshooting

Follow all safety precautions whenever diagnosing or servicing the equipment or engine.

FUEL RELATED:

2. Choke not in CHOKE

position, cold engine.

Possible Causes

No fuel in tank or fuel valve closed.

Probable Solutions

1. Fill fuel tank and open fuel valve.

2. Move Choke to CHOKE position.

FUEL RELATED:

Problem

Engine will not start

YT3		Gasoline with more than 10% ethanol used. (E15, E20, E85, etc.)	3.	Clean out ethanol rich gasoline from fuel system. Replace components damaged by ethanol. Use fresh 87+ octane unleaded gasoline only. Do not use gasoline with more than 10% ethanol (E1s, E2o, E8s, etc.).
		Low quality or deteriorated, old gasoline.	4.	Use fresh 87+ octane unleaded gasoline. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.).
		Carburetor not primed.	5.	Pull on Starter Handle to prime.
(0		Dirty fuel passageways.	6.	Clean out passageways using fuel additive. Heavy deposits may require further cleaning.
SETUP		Carburetor needle stuck. Fuel can be smelled in the air.	7.	Gently tap side of carburetor float chamber with screwdriver handle.
P		Too much fuel in chamber. This can be caused by the carburetor needle sticking.	8.	Turn Choke to RUN position. Remove spark plug and pull the start handle several times to air out the chamber. Reinstall spark plug and set Choke to CHOKE position.
		Clogged Fuel Filter.	9.	Replace Fuel Filter.
		IGNITION (SPARK) RELATED:	IG	NITION (SPARK) RELATED:
		 Spark plug cap not connected securely. 	1.	Connect spark plug cap properly.
		Spark plug electrode wet or dirty.	2.	Clean spark plug.
		Incorrect spark plug gap.	3.	Correct spark plug gap.
0		 Spark plug cap broken. 	4.	Replace spark plug cap.
멾		Incorrect spark timing or faulty ignition system.	5.	Have qualified technician diagnose/ repair ignition system.
≨ I		COMPRESSION RELATED:	C	OMPRESSION RELATED:
OPERATION		Cylinder not lubricated. Problem after long storage periods.	1.	Pour tablespoon of oil into spark plug hole. Crank engine a few times and try to start again.
		Loose or broken spark plug. (Hissing noise will occur when trying to start.)	2.	Tighten spark plug. If that does not work, replace spark plug. If problem persists, may have head gasket problem, see #3.
		Loose cylinder head or damaged head gasket. (Hissing noise will occur when trying to start.)	3.	Tighten head. If that does not remedy problem, replace head gasket.
<u>s</u>		Engine valves or tappets mis-adjusted or stuck.	4.	Have qualified technician diagnose/ repair ignition system.
MAINTENANO	Follow all	safety precautions whenever diagnosing o	rse	rrvicing the equipment or engine.

Probable Solutions

Check wire connections.

3. Replace spark plug cap.

4. Use only fresh 87+ octane

2. Re-gap or replace spark plug.

	Incorrect compression.	unleaded gasoline. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.). 5. Diagnose and repair compression. (Use Engine will not start: COMPRESSION RELATED section.)
Engine stops suddenly	Low oil shutdown.	Fill engine oil to proper level. Check engine oil before EVERY use.
	Fuel tank empty or full of impure or low quality gasoline.	Fill fuel tank with fresh 87+ octane unleaded gasoline. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.).
	Defective fuel tank cap creating vacuum, preventing proper fuel flow.	Test/replace fuel tank cap.
	Faulty magneto.	4. Have qualified technician service magneto
	Disconnected or improperly connected spark plug cap.	Secure spark plug cap.
Engine stops when	Dirty air filter	Clean or replace element.
under heavy load	Engine running cold.	Allow engine to warm up prior to operating equipment.
Engine knocks	Old or low quality gasoline.	Fill fuel tank with fresh 87+ octane unleaded gasoline. Do not use gasoline with more than 10% ethanol (£15, £20, £85, etc.).
	Engine overloaded.	Do not exceed equipment's load rating.
	 Incorrect spark timing, deposit buildup, worn engine, or other mechanical problems. 	Have qualified technician diagnose and service engine.
Engine backfires	Impure or low quality gasoline.	Fill fuel tank with fresh 87+ octane unleaded gasoline. Do not use gasoline with more than 10% ethanol (E15, E20, E85, etc.).
	2. Engine too cold.	Use cold weather fuel and oil additives to prevent backfiring.
	Intake valve stuck or overheated engine.	 Have qualified technician diagnose and service engine.
I	Incorrect timing.	Check engine timing.

Engine Troubleshooting (cont.)

Possible Causes

1. Spark plug cap loose.

2. Incorrect spark plug gap or

damaged spark plug. 3. Defective spark plug cap.

4. Old or low quality gasoline.

Problem

Engine misfires

Follow all safety precautions whenever diagnosing or servicing the equipment or engine.

Limited 90 Day Warranty

Tomahawk Power LCC. makes every effort to assure that its products meet high quality and durability standards. and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly. to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING THE WARRANTIES OF MERCHANTARII ITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Emission Control System Warranty

United States Emission Control Defects Warranty Statement

The United States Environmental Protection Agency (herein EPA) and Tomahawk Power LCC(herein TPL) are pleased to

Small Off-Road Engine (berein engine). Within the United States. new off-road, spark-ignition engines certified for model year 2014-2015, must meet similar standards set forth by the EPA TPL must warrant the emission control system on your engine for the periods of time described below, provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the carburetor or fuel-injection system, and the ignition system. Also included may be hoses, belts. connectors and other emission-related assemblies

Where a warrantable condition exists, TPL will repair your engine at no cost to you including diagnosis, parts and labor.

Manufacturer's Warranty Coverage The 2014-2015 engines are warranted for two (2) years.

If any emission-related part on your engine is defective. the part will be repaired or replaced by TPL

Tomahawk Power LCC Emission Control Defects Warranty Coverage

Engines are warranted for a period of two (2) years relative to emission control parts defects, subject to the provisions defective the part will be repaired or replaced by TPI.

- Owner's Warranty Responsibilities . As the engine owner, you are responsible for the performance
- of the required maintenance listed in your Owner's Manual TPL recommends that you retain all receipts covering maintenance on your engine, but TPL cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.
- · As the engine owner, you should, however, be aware that TPL may deny you warranty coverage if your engine or a part has failed due to abuse, neglect, improper maintenance, or unapproved modifications. · You are responsible for shipping your engine to a TPL warranty
- station as soon as a problem exists. Contact the TPL Customer Service department at the number below to make shipping arrangements. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.
- If you have any questions regarding your warranty rights and responsibilities, you should contact the Tomahawk Powerl CCCustomer Service Department at 1-619-255-7478

Tomahawk Power LCCEmission Control **Defects Warranty Provisions** 1. Length of Coverage

TPL warrants to a first retail purchaser and each defects in materials and workmanship that cause the failure of warranted parts for a period of two (2) years. after the date of delivery to the first retail purchaser.

2. No Charge Repair or Replacement Repair or replacement of any warranted part will be performed at

contact the TPL Customer Service Department at 1-619-255-7478 3. Consequential Damages Coverage Coverage under this warranty shall also extend to the failure of any engine components caused by the failure of any

warranted part while it is still covered under this warranty. 4. Coverage Exclusions Warranty claims shall be filed in accordance with the provisions

of the TPL warranty policy explained in the box at the top of the previous page. TPL shall not be liable for any loss of use of

the engine for any alternative usage for any damage to goods. loss of time, or inconvenience. Warranty coverage shall also be excluded for any part which fails, malfunctions, or is damaged due to failure to follow the maintenance and operating instructions set forth in the Owner's Manual including, but not limited to: a) Use of parts which are not authorized by TPI

- b) Improper installation, adjustment or repair of the engine or of any warranted part unless performed by an authorized warranty
- Failure to follow recommendations on fuel use contained in the
- Owner's Manual d) Improper or inadequate maintenance of any warranted parts Repairs performed outside of the authorized warranty
- service dealers Alterations by changing, adding to or removing parts from

5. Service and Maintenance Component parts which are not scheduled for replacement as required maintenance or are scheduled only for regular

no charge to the owner if the work is performed through a warranty Inspection, Cleaning, and Maintenance section in this manual. station authorized by TPL. For emissions warranty service, Warranted Parts 1) Fuel Metering System

to perform all required maintenance, as outlined in the Carburetor and its internal parts Airifuel ratio feedback and control system.

inspection to the effect of 'repair or replace as necessary'

are warranted for the warranty period. Any warranted part which is scheduled for replacement as required maintenance

is warranted for the period of time up to the first scheduled

it is equivalent in durability and performance, may be used in performance of maintenance or repairs. The owner is

replacement point for that part. Any replacement part, provided

responsible for commissioning a qualified technician/mechanic


- iii) Cold start enrichment system. in) Fruel Tarris
- Air Induction System Controlled hot air intake system
- ii) Intake manifold. iii) Air Shar Ignition System
 - Spark Plugs. Magneto or electronic ignition system
 - Exhaust Gas Recirculation (EGR) System (if so equipped)
- i) EGR valve body, and carburetor spacer ii) EGR rate feedback and control system. Air Injection System
 - i) Air pump or pulse valve. ii) Valves affecting distribution of flow
 - III) Distribution manifold Catalyst or Thermal Reactor System (if so equipped)
 - Catalytic converter ii) Thermal reactor
 - iii) Exhaust manifold Particulate Controls
 - Traps, filters, precipitators, and any other device used to capture particulate emissions.

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BLIVER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

s	
⋗	
=	
4	
=	
➣	
z	
\overline{a}	

Part	Description	Qty	Part	Description	Q
1	Gasket, Cylinder Head	1	69	Gasket, Carburetor	
2	Cover Subassembly, Cylinder Head	1	70	Plate, Carburetor Insulator	
3	Gasket, Cylinder Head Cover	1	71	Gasket, Carburetor Insulator	$\overline{}$
4	Tube. Breather	1 1	72	Nut	
5	Bolt	4	73	Cleaner, Air	-
6	Stud	1 1	74	Gasket, Exhaust Outlet	-
7	Stud	1	75	Nut	
8	Stud	2	76	Muffler Assy	-
9	Pin	2	77	Tank, Fuel	-
10	Bolt, Cylinder Head	4	78	Strainer Cuel	-
11	Plug, Spark	1 7	79	Strainer, Fuel Cover, Fuel Tank	-
12	Head Subassembly, Cylinder	++	80	Outlet Subassembly, Fuel Tank Oil	+
12	nead Subassembly, Cylinder				-
13	Crankcase Subassembly.	1	81	Clamp	F
14	Sensor, Engine Oil	1	82	Tube, Fuel	
15	Gear Assy, Governor	1	83	Bolt	
16	Arm, Governor	1	84	Nut	
17	Bolt, Drain Plug	2	85	Nut, Flywheel	
18	Washer	2	88	Pulley,Starter	-
10	Bearing	1	87	Impeller	-
20	Seal, Oil	1 1	88	Flywheel Subassembly	_
20 21 22	Washer	1 1	89	Rolt .	1
22	Pin	1 1	90	Coil, Ignition	+
23	Bolt	+ ÷	91	Control Assy, Throttle	+
24	Cover. Crankcase	1 1		Bolt Rossy, Inroduce	-
24	Cover, Cranxcase		92		-
25	Bearing	1	93	Spring, Governor	-
26	Seal, Oil	1	94	Rod, Governor	
27	Gasket, Crankcase	1	95	Spring, Throttle Valve Returning	
28	Pin	2	96	Bolt, Governor Support	Т
29	Dipstick Subassembly, Oil	1 1	97	Nut	-
30	Plug Subassembly, Engine Oil	1 1	98	Support Subassembly, Governor	_
31	Bolt	6	99	Hoop Assy, Hose	+
32	Crankshaft Assv.	1	100	Cover, Filter	_
22	Clip. Piston Pin	2	101	Filter	-
33	Piston	1 1	102	Bolt	+
	Pin. Piston	++	102	Washer	-
35					-
36	Rod, Connecting	1	104	Washer	
37	Ring, The First	1	105	Inlet, Water	_
38	Ring, The Second	1	106	Gasket, Inlet Water	1
39	Ring Set, Oil	1	107	Plug, Thread	
40	Camshaft Assy.	1	108	Washer, Screw Plug	
41	Valve, Exhaust	1 1	109	Outlet, Water	Т
42	Valve, Intake	1	110	Gasket Outlet	$\overline{}$
43	Seat. Valve Spring	1	111	Pump Body	
44	Retainer, Exhaust Valve	11	112	Ring, Whorl Case Sealing	+
45	Rotator, Valve	11	113	Case. Whorl	-
46	Guide, Seal	+ +	114	Rolt Wilde	+
47	Guide, deal	1 4			-
	Tappet, Valve	1 4	115	Washer	-
48	Lifter, Valve	2	116	Impeller, Water Pump	_
49	Plate Subassembly, Lifter Stopper	1	117	Key	_
50	Bolt, Valve Adjusting	2	118	Cushion, Water Pump Joint	
51	Rocker, Valve	2	119	Ring, Impeller Seal	Т
52	Nut, Valve Adjusting	2	120	Seal, Porcelain	
53	Nut. Valve Lock	2	121	Seal Assy, Mechanism	-
54	Spring, Valve	2	122	Joint, Water Pump	
55	Starter Assy. Recoil	1 1	123	Washer	-
56	Bolt Starter Assy, Recon	3	124	Bolt	+
67		1 1	125		-
57 58 59	Shroud		125	Pump Assy, Water	-
28	Shroud, Cylinder Body	1	126	Frame Assy, Engine	+
59	Shield,Lower	1	127	Bolt	
60	Protector, Oil	1	128	Seat, Engine Frame Shock Absorption	\blacksquare
61	Switch Subassembly, Stop Engine	1	129	Core Nut	
62	Bolt	2	130	Bolt	
63	Belt	1	131	Nut	
64	Collar	1	132	Jacket Rubber	
65	Bolt	11	133	Valve. One Way	+
66	Bolt	4	134	Clamp	+
67	Carburetor Assv.	1 7	134	Hose, Fuel Steam Rubber	-



NOME: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.

Note: If product has no serial number, record month and year of purchase instead

TOMAHAWK

San Diego, CA USA

Sales & Service sales@tomahawk-power.com (866) 577-4476