
V20200070

CW-3000 Series

INDUSTRIAL REFRIGERATION CHILLER

USER MANUAL

Thank you for choosing us for your industrial chilling needs. Please read these instructions carefully before installation and use. Keep them for future reference.



CONTENTS

Warnings.....	1
Parts Diagram.....	2
Installation.....	3
Alarms.....	4
Maintenance.....	5
Specifications.....	5
Troubleshooting.....	6

PACKAGE CONTENTS

- 1 × Industrial Chiller
- 1 × Power Cord
- 1 × Alarm Signal Output Plug
- 1 × Spare Fuse (held near the rear power socket)
- 1 × Instruction Manual

WARNINGS

- DO NOT run this chiller without first providing adequate water (See p. 3). Deionized or distilled water is preferable.
- Ensure that the power supply is well-connected and stable and the chiller is well grounded. Use only with 110V/60Hz power.
- Place this chiller in a well-ventilated, dry environment away from heat sources but warm enough to avoid freezing temperatures.
- Leave at least 1 ft. (30 cm) of space behind its rear air outlet.
- Leave at least 4 in. (10 cm) of space around the two side air inlets.
- To protect your laser devices, the radiator fan of the chiller will suspend work when the water temperature is lower (around 50°F or 10°C) and resume when the water is warmer

(around 70°F or 20°C).

- Clean the air filter regularly.
- Disconnect the power and drain all water from the chiller before storage or transport.
- Pay attention to possible condensation on the chiller and its water lines. If condensation is observed, raise the water temperature, keep the water lines and cooled components warmer, or reduce ambient humidity until no condensation occurs.
- When cooling a laser engraver, take care that this device does not cause the room's humidity to exceed safe levels.
- Do not allow children or untrained persons to use this chiller.


PARTS DIAGRAM

FRONT

- TEMPERATURE CONTROLLER
- SYSTEM ERROR LIGHT (red)
- NORMAL OPERATION INDICATOR LIGHT (green)
- POWER SWITCH



BACK




INSTALLATION

It is very simple to install this industrial chiller.



Open the package to check if the machine is intact and all the necessary accessories are included.



Plug in the power and flip the power switch. The pump will begin working.

There may be some bubbles at first. These should disappear after a minute or two.

Don't worry if the fans and other components of the chiller do not activate. They are usually automatically controlled (See p. 1) and will not begin working until they are needed by the machine.


In different conditions, the time for startup may vary from seconds to a few minutes. Do not become frustrated and switch the machine on and off, except when necessary to add water.



Open the injection port and add water. For best results, use deionized water.

Pour slowly and do not fill the chiller completely. There should be about 3–6 inches (8–15 cm) between the opening and the top of the water in the machine. Do not allow the water to overflow.


For cooling carbon steel equipment, the water should have an appropriate amount of anticorrosive additive.



Check the water level of the water tank again, as with step 2.

The water level of the chiller may be lowered as it fills the cooling path in your device. If necessary, carefully add more water to the chiller to maintain a level about 3–6 inches (8–15 cm) below the top of the device.

If the water level drops sharply or continues to go down during normal use, turn off your devices and examine the water pipes and cooling path for leakage. Repair any such leaks before restarting the devices and continuing work.



Connect the water inlet and outlet pipes to the system you wish to cool.


ALARMS

1. Alarm Lights and Sounds

DISPLAY CONDITION	Normal light	Alarm light	Buzzer	H1, H2 Output	H1, H3 Output
Normal	● On	⊗ Off	⊗ No sounds	⊗ Off	⊔ On
Blocked pathway	⊗ Off	● On	⊗ Sounds	⊔ On	⊗ Off
Water above 140°F (60°C)	⊗ Off	● On	⊗ Sounds	⊔ On	⊗ Off
Faulty pump	⊗ Off	● On	⊗ Sounds	⊔ On	⊗ Off
Water shortage	⊗ Off	● On	⊗ Sounds	⊔ On	⊗ Off
Electrical circuit failure	⊗ Off	● On	⊗ Sounds	⊔ On	⊗ Off
Power interruption	⊗ Off	● On	⊗ Sounds	⊔ On	⊗ Off

Note that the flow alarm is connected to relay contacts requiring that the operating current be less than 5A and working voltage less than 300V.

2. Alarm Circuit



MAINTENANCE

To ensure good heat dissipation, please open the lid and clean out any dust or dirt after the chiller has been used for a while.

SPECIFICATIONS

MODEL	CW-3000AG	CW-3000DG	CW-3000AF	CW-3000DF	CW-3000AK	CW-3000DK
Voltage	220-240V AC	100-120V AC	220-240V AC	100-120V AC	220-240V AC	100-120V AC
Frequency	50/60Hz					
Current	0.45A	0.9A	0.45A	0.9A	0.5A	1.0A
Cooling	50W/°C				60W/°C	
Capacity	9L					
Inlet and outlet hold	External Ø10mm brass connector		Ø8mm brass connector		Ø6mm brass connector	
Max. Lift	10M				70M	
Max. Flow	10L/min				2L/min	
Protection	Flow alarm					
Net Weight	9.5kg				12Kg	
Gross Weight	12Kg				14.5Kg	
Dimensions	19×11×15 in.					
Packing dimensions	22×15×18 in.					

TROUBLESHOOTING

Never use a dangerous system like a laser engraver if the water cooling system is malfunctioning. If the laser or other dangerous device is already on, shut it down immediately and correct the problem with the chiller before using it again.

Failure	Approach
The machine has no power.	Check that the power cord is firmly connected.
	Cut the device's power and pull out the fuse box from the back of the machine. If the fuse has blown, ensure that the power supply is stable or install a voltage regulator. Replace the fuse with the spare stored in the fuse box.
The machine is on, but the water does not flow.	Check that there are no leaks in the water pipes or cooling pathway. Then add more water until it reaches the correct height.
The water is flowing but there is an alarm.	Check that there are no leaks in the pipes and add more water.
The water temperature is too high.	Check that the chiller has proper room for ventilation and the air filter is clean.
	Ensure that the power supply is stable or install a voltage regulator.
	Ensure that there is sufficient time for refrigerator to occur before activating the device you want to cool. At most, with a functioning machine, this should take less than 5 minutes.
	Reduce the heat load or upgrade to a stronger chiller.
The fan does not turn on.	This is normal when the water is below 70°F (See p. 1). If the water is heated and the fan still does not operate, contact customer service.
The room temperature is too high.	Ensure the chiller has proper room for ventilation (See p. 1). If it already does, take action to cool the surrounding work space.
There is constant condensation around the machine and the water lines.	Increase the water temperature or heat the area around the cooling path. Failing this, take action to reduce the ambient humidity of the surrounding work space.
Water drains slowly.	Open the injection port.

CONTACT US

Thank you for choosing our products! If you have any questions or comments, contact us at help@cs-supportpro.com and we'll resolve your issue ASAP! For a .pdf copy of the latest version of these instructions, use the appropriate app on your smartphone to scan the QR code to the right.

