

PIPE & WALL VIDEO INSPECTION SYSTEMS USER MANUAL

For
4188KX SERIES

ASSEMBLING AND OPERATING INSTRUCTIONS



(4188KA)



(Front view)



(4188KB)

Read instructions carefully before operating this system

WARNING

1. Never use this device in an environment with explosive materials such as GAS, OIL, ETC.
2. Avoid using the device in extremely cold, hot or humid environment; otherwise it may damage the device. Do not drop or press hard on the device.
3. Avoid using the parts / components from other manufacturers to this system, which may damage the equipment due to the un-compatibility.
4. Warranty invalidation if the device is disassembled by users or if there are any physical damages.
5. Always back up your data before connecting your USB stick / Micro SD Card to this system. The manufacturer is not responsible for any data damage or loss on your USB stick / Micro SD Card for any reason.
6. Do not disconnect the unit while recording or playing. It may damage the unit and/or the USB stick / Micro SD Card.
7. Don't misuse the Battery Charger Cable and Power Cord, otherwise the battery pack may be damaged or the system can not work properly.
8. The system's PUSH CABLE made of fiberglass is very rigid and not flexible. It CAN NOT be bent sharply or pushed too hard; otherwise it will be broken.
9. If you have an extra portable cable reel, and try to put it in the case after use, you must put it in the right position; otherwise, LCD monitor may be broken by the part on the reel when you close the case.
10. Please forgive that if any change of products will not make additional specify in advance.

CONTENTS

Assembly Drawing and Parts List.....	1
Specifications.....	2
User Manual.....	2
Application.....	2
Know your Device.....	3-4
Display Part.....	5
Remark.....	5-6
4188KA Cable Reel Basel.....	6-7
4188KB Cable Reel Basel.....	7
C23 Series Camera Head	8
C28 Series Camera Head	9-10
Remote Control (For Operating DVR/ SD Card Recording).....	10
System Set-Up.....	10-11
System Menu Setting.....	11
DVR RECORDING or SNAPPING PICTURE	12
Recording Time Limit.....	12
Recording via USB Stick/Micro SD Card.....	12
Video Recording Format.....	13
Voice Recording	13
Video Playing.....	13
Select the Video File.....	13
Fast Forwarding and Rewinding.....	13
Compatible Video Format.....	13
How to use the text writer.....	14-15
Video Player Software Installation.....	16
Recharging the Battery.....	17
Trouble Shooting	18

Assembly Drawing and Parts List

Part	Description
1	Function case&60M FIBERGLASS CABLE
2	POWER ADAPTER&BATTERY CHARGER
3	CAMERA (C23), OPTIONAL FOR OTHER SERIES CAMERA
4	CAMERA (C28), OPTIONAL FOR OTHER SERIES CAMERA
5	T-B SPRING KIT (OPTION: T-B SPRING KIT WITH 512Hz TRANSMITTER)
6	6 CORE SIGNAL CABLE (Connected with cable reel)
7	REMOTE CONTROL
8	Sponge column cleaning(option)
9	Scrape mud silicone sheet(option)



Note: The small parts above are under the keyboard in the function case. Please open up the keyboard from the position of "OPEN" character, when you want to take them.



Specifications

Item	Description
Power adapter	110VAC~240VAC 13.5V DC 1700mA
Battery (In the case)	LI-ION battery, DC 12V, 6600mAh
Length of Cable	□ 60M
Camera Light Source	12PCS LED
Camera Angle-of-View	FOV=90° /120° F2.8/2.42mm
Camera Image	Effective Pixel Array: 976 (H) x 496(V)
Monitor Screen Size	10" TFT LCD Color Monitor
Monitor Picture Resolution	800 * 600 pixel
Storage Device	USB &TF(8G~64G)
DVR Format	AVI
System Operating Temperature	-20°C to 60°C

User Manual

Application


1. WATER SUPPLY
2. WASTE WATER
3. ELECTRICAL AIR CONDITIONER
4. CABLE DUCTING
5. DUCTED VACCUM SYSTEMS
6. PLUMBING
7. BUILDINGS

WARNING:

NEVER USE THIS DEVICE IN AN ENVIRONMENT WITH EXPLOSIVE MATERIALS SUCH AS GAS, OIL, ETC

Know Your Device

Control Box



①、meter counter

M/FT: Metric or Imperial switching

RESET: Reset the counter number to zero

#Press the key to clear, press the key two times to switch

②、Camera Input

CAM1: Common camera (four core interface) .

CAM2: 360° rotation camera (five core interface) .

③、360°Rotation Camera Button

LEFT: Control camera rotate to the left.

RIGHT: Control camera rotate to the right.

UP: Control camera rotate to the upward.

DOWN: Control camera rotate to the downward.

RESET: Camera reset.

④、LED+: Increase the brightness.

LED-: Decrease the brightness.

⑤、BATTERY: Battery indicator.

Discharge instructions state: When the unit is turned ON, the battery level will be reflected by the green LEDs. When the LEDs flash from green to red light, the battery is

insufficient and needs to be recharged.

Charging indicator status: with increase of battery charging, the green light will be lighted up one by one;when the green light turns into the bright green, the battery is fully recharged.

⑥、 FOCUS+: Adjust the lens focal length+.

FOCUS-: Adjust the lens focal length -.

⑦、 DVR Control Button

REC: Record video button.

STOP/EXIT: Exit DVR video playing or return to the next higher level submenu.

SETUP: DVR system setup.

UP: DVR user menu up operation button.

DOWN: DVR user menu down operation button.

PLAY/ENT: DVR play or select button.

⑧、 ⑨、 USB& TF Pin

When use U disk &TF card as a storage device, please insert the right port

⑩、 MIC on/off: MIC switch. When recording using the microphone during video recording, press the green button switch. The indicator LED will light up. After the end of the video, you must press the switch again, otherwise there is no audio signal output and the audio will not be recorded onto the video.

⑪、 The power adapter input. Can be used as the machine power supply or charging the battery.

⑫、 POWER: Power switch.

⑬、 LED Indicators

IR: The remote control work lamp.

ERR: Indicator system or USB device error.

USB: When users insert a new USB&TF card, this indicator shining.

REC: Video recording work lamp.

DVR: DVR Indicator system work.


REM: Remote control receiving window.

⑭、 Keyboard Input

Using the keyboard to input character (English letters、 Numbers and symbols), this is a new equipment which can input characters superposing on the real-time monitoring images ,showing three lines of characters below

the display line.

Display Part



Remark:

After pressing MENU button, the following information will show on the screen:

“ENGLISH,DEUTSCH,FRANC,ESPAKOL,PORTUG,ITALIANO,ENGLES, PNCK
BRIGHT-----50
CONTRAST-----50
COLOR-----50
SHARP-----50
LED BRIGHT-----80
HUE-----50
ENGLISH “

Use Set/Up/Down buttons to choose the language and to adjust the picture and

Led light.

Press MANU again, system exits.

2) DOWN: Press DOWN key, the image changes mirror up/down.

3) UP: Press UP key, the image changes mirror lift/right.

4) SEL key: Press SEL key to switch the image between 16:9 and 4:3 (except 10 inch monitor)

Please Note: To get a regular image, the cursor on the screen should be at the bottom left. If not, you can press the UP or DWON button to move the cursor to the bottom left to get a regular image.

4188KA Cable Reel Base



1) Φ 6mm fiberglass cable

2) handle

3) camera head holder

4) Muddy water cleaner


5) locker

6) Equipment base


7) tooling bag

8) Rubber plug

Muddy water cleaner setup steps and announcements



picture 1




picture 2

1. when put the push rod cable into the cleaner, both grooves must be at the same direction (as picture 1)
2. After set the push rod cable well, then turn the both catches to two different directions before using (as picture 2)

warning:

1. When put in or take out the push rod cable, both grooves must be adjusted to same direction.
2. When rolling the cable back into the cable reel, please be careful not to forcefully over-bend the cable to avoid breaking the cable.

4188KB Cable Reel Base



- 1) Φ 8mm fiberglass cable

2)female connector for 28mm camera head

C23 Series Camera Head



I. Working environment:

1. Temperature: -20°C~60°C
2. Humidity: 90%RH (non-condensation)

II. Main Technical Indicators:

1. Power source input: DC 9-13.5V
2. Camera module:
 - 1) Image sensor: 1/3" color CMOS PC1099
 - 2) Effective Pixel Array: 976 (H) x 496(V)
 - 3) Horizontal resolution: 900TV LINES
 - 4) Minimum illumination: 0.01LUX/F1.2
 - 5) SNR: >45dB (AOC on)
 - 6) Video Output: 1.0 Vp-p / 75 Ω (CVBS) with horizontal dynamic balance
 - 7) Input voltage: DC 9-13.5V
 - 8) Current consumption: 65mA Max(ALL LEDS LIGHTS ON≤200mA)

3. Lighting source:

- 1) LED quantity: 12pcs
- 2) Luminous flux: 107~114 lm (180 mA)
Working Current: 0~180 mA
- 3) Light Cup Angle: 45°

III.External Interface:

CAM1: Pin 1 to 4 are separately connected to VIDEO, GND, +12V, LED.

CAM2: Pin 1 to 6 are separately connected to 485A, 485B, +12V, GND, NC, VIDEO.

C28 Series Camera Head



I. Working environment:

1. Temperature: $-20^{\circ}\text{C} \sim +55^{\circ}\text{C}$
2. Humidity: 90%RH (non-condensation)

II. Technic Specs:

1. Power input: DC 9~15V,8W (maximum)

2.Camera module:

- 1).Image sensor:1/3 Inch CMOS
- 2).Effective Pixel Array: 4Billion
- 3).Horizontal resolution: 800 TVL
- 4). Minimum illumination: 12900LUX
- 5).SNR: >45dB
- 6). Video Output: 1 Vp-p / 75 Ohms
- 7). Input voltage: DC3.5V
- 8).Current consumption: 60mA-200mA

3.Swing motor:

- 1).Camera swing angle: 180°

4. Rotating motor:

- 1).Camera rotating angle: 360°

5. Focus motor:

- 1).Can adjust 20 steps.

6. Lighting source:

- 1). LED quantity: 2pcs
- 2). Luminous flux: 107~114 lm (180 mA)

3). Working Current: 0~200 mA

4).Light Cup Angle: 45°

7. Camera Inclination Detection:

1).Measuring range: -90°~ +90°

2).Resolution: 1°

8. 485 communication:

1). Baud rate: 9600 Bit/S,8 data bits,1 stop bit, no parity

2). Isolation voltage: 560V

3). ESD protection: ±15KV

4). Transient simulation capabilities: 25KV/us

5). Improve protection: Fault (open circuit, short circuit) protection, thermal shutdown protection

Remote Control(For operate DVR /Micro SD card recording)

1) Enter: Enter to view and play video

2) Up: Go to up/previous item

3) REC: Start recording / snap shooting (only available for new versions)

4) Setup: System setup and recording features

5) POWER: System in

6) Down: Select down/next item

7) STOP: Stop or exit from current menu

8) Left: Select Left item

9) Right: Select Right item

10) Rewind: Review video

11) Forward: forward video



System Set-Up

1. IMPORTANT: When you connect the Camera to the Monitor, the power must be off; otherwise both units will be damaged.
2. Connect the reel cable to the Monitor.
3. Plug the Power Adapter cord into the wall AC socket and the other end into the "DC 13.5V" jack.

Note : Don't misuse the Power Cord and Battery Charger Cable, otherwise the system can not work properly, or the battery pack may be damaged.

4. Press the POWER button on the front of the Monitor.
5. Gently lower the Camera into a pipe duct, etc and reel out the Cable until it is at the desired depth.
6. Record the pictures if you need (see DVR Operating).
7. Video Out: By using a video cable you can transfer the picture to other larger Screen.

When you finish the job, carefully remove the Camera head from the pipe duct, etc, clean it with a clean, soft and dry cloth and then put the Camera into the previous position

System Menu Setting





Clock setting: set date and time	
*Time Format	Select: 24Hour - 12Hour
Year	Set year
Month	Set month
Day	Set day
Hour	Set hour
Minute	Set minutes
Second	Set seconds
Language Setting	Select: English - Chinese
System: showing software version, product version, free space and used space (when USB/ Micro SD Card is connected)	
Record setup: Storage Device Selection ---USB Device or Micro SD card	
Play Mode: No circle, One circle, List circle	
Master reset: press OK again to perform a master reset	
Firmware update: locate the directory where new firmware is stored	
Browse File:Showing all files on the current USB/ Micro SD Card medium.	
Remove USB/Micro SD Card device (only when USB/Micro SD Card device is connected)	
Always use this option before safely removing the USB /Micro SD Card device from the USB/Micro SD Card port	


Remark: When you plug in the USB key/Micro SD card before starting the device, maybe the device can't find the USB stick/Micro SD card. In this case, please

remove them and try again.

DVR/Micro SD RECORDING OPERATION

(Recording via MICRO SD Card is only available for the new versions)

1. Set the Screen Video Button on Video 2.
2. Take off the isolation sheet from the Remote Control Battery.
3. Press the Remote Control Button  to enter the Recording system, you can see DVR system Recorder **PLAY VIDEO** manual on the screen.
4. Insert your USB stick/ removable hard disc etc into the **USB** Port, or Micro SD Card into Micro SD Card Slot, you can see **USB stick/ Micro SD Card Connected** on the screen and the LED light indicator is on.
5. Press Remote Control Button 3  to start the recording and the RECORDING LED light is on. In recording, if you press the RECORDING button again, the DVR will take a photo and it is saved in the USB key or Micro SD card (only available for new versions).
6. Press Remote Control Button 7  to stop recording.
7. Press Remote Control Button 1  to review recording.

If you need to manage your recorded pictures, press Remote Control Button 4  You can also manage the files by selecting the **SETTING** on **PLAY VIDEO** manual on the screen.

NOTE:

DVR system sometimes need 10 - 20 seconds for reposition before it can work properly, please let it run about 20 seconds each time when you try to record.

USB flash disk and Micro SD card max memory is 8G bit.

The recorded video files will be found in a directory of USB/Micro SD devices. You can use the on-screen menu or press (REC) button to start recording. Press (■/EXIT) button to stop recording. During the recording, the screen will display recording time and time limit (up to 60 minutes).

Recording time limit

This unit is featured with a recording time limit. The default time limit is 60 minutes. The system will record with a new file every 60 minutes.

Schedule recording

You can schedule a recording in advance. Simply enable the schedule recording feature under SETUP menu and then the unit will ask user to setup timing.

Recording schedule can only set one at a time, you have to reset the schedule for next recording.

Recording via USB Stick / Micro SD Card

The unit can be used to record video and voice via USB devices / Micro SD Card. The recorded video will be stored in the USB devices / Micro SD Card and played back on the TV screen.

Video recording format

The default video recording resolution is 640*480. A One-hour recording will take the storage of 500MB. Users may select 320*240 to save storage space.

Voice recording

A microphone button located on the front panel allows the user to press the button on to record a voice while the video is recording (This function is only available for new versions).

Video Playing

You can use the on-screen menu to enter “play video” mode. The unit will display the recorded video and other compatible videos stored in a USB stick / Micro SD Card. It will not list the non-compatible videos.

Select the Video File.

When you enter “play video” mode, the set will display all of the available video files on the screen. You can use the [▲] or [▼] button to select desired video and press the [▶/ENT] button to play. Press and hold the [▲] or [▼] button to go to the previous or next video.

Use the [▶/ENT] button to start or pause the playing. Use the [■/exit] button to stop or go back to the previous menu.

The screen will display “loading, please wait ...” for a few seconds before playing the video.

Fast Forwarding and Rewinding

You can use the [▶] or [◀] button on the remote control to fast-forwarding or rewind (1x, 2x, 4x, or 8x, speed). Always press the [▶/ENT] button to go back to normal playing.

Compatible video format:

Divx3.11/Divx4/Divx5/MPEG1/MPEG2/MPEG4 (MPEG4 video file format: .avi, .m4v, .MPG, MPEG, .VOB)

Note: The video player of the device may not support some downloaded videos.

How to use the text writer?

With the signal overlay technology, the text writer is a device that can display the input characters from the keyboard on the video (only support English input). The Keyboard input function is the same as the computer keyboard operation.



I. Keyboard Functions

1. It supports the display of 3 pages.
2. The keyboard has a 0-9 number input with symbol switching through the Shift + “key”
3. 26 English letters input and case switching with Caps Lock.
4. F5 is the character display/hide switch key. When you press F5, all the characters are hidden. Press F5 again, all characters are displayed.
5. Move the cursor through the four arrow keys of the keyboard to enter the character at the position where you want.
6. Keys:
 - 1) See Appendix 1 for other punctuations, Appendix 2 for function keys.
 - 2) Keys without functions: Esc、 F2、 F3、 F4、 F6、 F7、 F8、 F9、 F10、 Num Lock、 Prtscsysrq、 Tab、 Ctrl、 Fn、 Alt

II. How to Operate

1. To start the device, press the VIDEO button on the LCD monitor to enter the VIDEO2 channel if your system coming with 2 channels.
2. After DVR is empowered, press the DVR ON/OFF button to turn off the DVR and then the screen will enter the preview state. At this time, there is the flashing cursor "I" on the screen.
3. Once the cursor showing on the screen, press the DVR ON/ OFF button

on the control panel to turn on the DVR. You can now record videos, take snapshot, or input the text on the screen.

Appendix 1: Punctuations

'	•	()	?
:	;	*	/	@
-	<	>		
-	<	>		

Appendix 2: Function Keys

F1	Clear all characters
F5	Display/hide character switch
Caps lock	Case Switching
Four arrow keys	Up, Down, Left and Right Movement
Backspace、 Delete	To delete
Enter	Enter Key
Shift+ Key	Input the symbol on the corresponding key
space key	Space bar

Video Player Software Installation

Generally, the recorded videos can be played on the computer purchased after the year 2006. If you can not open the recorded document on a computer, there are two options:

Option 1: Go to the website “<http://www.kmplayer.com>” and download the KMPlayer software for free.

Option 2: Install the Media Player Software with the Disc


Steps: 1. Create a new folder on the computer

2. Put the disc in the computer drive, open the files in the disc and copy all the files to the above new folder on the computer.

3. Click fullplaye.exe in the new folder

csfcodec	2018/5/9 14:45
hotkey	2018/5/9 14:45
lang	2018/5/9 14:45
UPD	2018/4/16 14:38
binkw32.dll	2014/8/13 11:02
CSMX.dll	2014/8/13 11:02
dh264.ax	2014/8/13 11:02
Es.dll	2014/8/13 11:02
fullplayer.exe	2014/8/13 11:02
haalis.ax	2014/8/13 11:02
install.exe	2014/8/13 11:02
ir41_32.ax	2014/8/13 11:02
ir50_32.dll	2014/8/13 11:02
ivm.dll	2014/8/13 11:02
IVMSource.ax	2014/8/13 11:02
mc.dll	2014/8/13 11:02
media.db	2014/8/13 11:02
Microsoft.VC90.CRT.manifest	2014/8/13 11:02
mkunicode.dll	2014/8/13 11:02
mkzlib.dll	2014/8/13 11:02
mmamrdrm.ax	2014/8/13 11:02
mp4.dll	2014/8/13 11:02
msvcr90.dll	2014/8/13 11:02

Open the media player



Click the icon “Open File” and choose the videos in AVI format to open.

Recharging the Battery

- 1) Plug the charger into the AC socket on the wall and insert the other end into the DC jack (See Figure2- A).
- 2) The battery can be charged while the device is being used. However, once the power in the battery runs completely out, it can only be charged when the device is turned off.




Figure 2

IMPORTANT MESSAGE: Do not overcharge the battery! Overcharging can result in acid leaking from or damage to the battery.

Battery specifications:

1. TOTAL POWER $\leq 15W$
2. LI-ION BATTERY 12VDC MAX. $\leq 79Wh$
3. CHARGER 13.5V 1700mA
4. CHARGE TIME 6 HOURS
5. WORKING TIME ≥ 200 MINUTES
6. PROTECTIVE VOLTAGE 8.1V
7. THE VOLTAGE BEFOR DISCHARGING 12.6V
8. LOAD CURRENT 1200mA(INPUT 12.2V)

WARNING: Batteries are dangerous goods. Customers/users are prohibited from disassembling and repairing this battery pack by themselves. Otherwise, the manufacturing is not responsible for any consequence and losses.

TROUBLE SHOOTING

Trouble	Reason / Solution
Black screen	1. Change the fuse
	2. Recharge the battery
	3. Check power cable and connect it again.
No signal	1. Read the manual again and reconnect it.
	2. Check the camera head and screw down
	3. Clean the camera pins
	4. Check the pins, make sure they are not stuck by dirt.
The camera head lights too weak or no lighted on	Press the "MENU" button, locate the LED brightness setting and then adjust the brightness.
DVR cannot record	1. For the system with 2 Channels, press the "Video" button and change to Video 2
	2. Press POWER button and the monitor indicator light is green.
	3. Use another USB stick / micro SD card and try again
DVR Recording abnormality	Turn off the unit and restart it again in correct steps
Pictures Flashing	1. Check the battery power
	2. Please recharge the battery with the right cable
Battery cannot be recharged	Make sure a right battery recharger cable is used.

WARNING: Batteries are dangerous goods. Customers/users are prohibited from disassembling and repairing this battery pack by themselves. Otherwise, the manufacturing is not responsible for any consequence and losses.