INSTALLATION & INSTRUCTIONS

INLINE AXIAL FAN

Model No. SF100S SF125S SF150S SF100T SF125T SF150T



Read this manual and follow all safety recommendation SAVE THIS MANUAL FOR FUTURE REFERENCE and operating instructions before operating

INSTRUCTIONS OBSERVING ALL SAFETY INFORMATION. FAILURE TO COMPLY WITH MAINTAIN THE PRODUCT DESCRIBED. PROTECT YOURSELF AND OTHERS BY READ CAREFULLY BEFORE ATTEMPTING TO ASSEMBLE, INSTALL, OPERATE OR COULD RESULT IN PERSONAL INJURY AND/OR PROPERTY

GENERAL SAFETY INFORMATION

POSITION INSTALLED. MAKE SURE ELECTRICAL SERVICE TO THE FAN IS LOCKED IN OFF WARNING: DO NOT CONNECT POWER SUPPLY UNTIL FAN reduce the risk of fire, electric shock and injury to person, including the following: When using electrical appliances, basic precautions should always be followed to IS COMPLETELY

- 1. Read all instructions before installing or using exhaust fan.
- questions, contact the manufacturer 2. Use this unit only in the manner intended by the manufacturer. If you have
- service disconnecting means to prevent power from being switched on accidentally 3. Before servicing or cleaning the unit, switch power off at service panel and lock the
- prominent warning device, such as a tag, to the service panel When the service disconnecting means cannot be locked, securely fasten a
- accordance with all applicable codes and standards, including fire -related L. Installation work and electrical wiring must be done by qualified person(s) in

construction

published by the Build Code of local , and the local council regulations heating equipment manufacturer's guideline and safety standards such as the flue (chimney) of fuel burning equipment to prevent back drafting. Follow the 5. Sufficient air is needed for proper combustion and exhausting of gases through

HAZARDOUS OR EXPLOSIVE MATERIALS AND VAPORS CAUTION: FOR GENERAL VENTILATING USE ONLY, DO NOT USE TO EXTROD

6. When cutting or drilling into wall or ceiling, do not damage electrical wiring and

7. This unit has rotating parts and safety precautions should be exercised during other hidden utilities.

installation, operation and maintenance

- meters of working level or when deemed advisable for safety. Guards must be installed when fan is within reach of personnel or within 2.3
- 9. NEVER place a switch where it can be reached from a tub or shower.
- 10. Do not insert or allow fingers or foreign objects to enter the motor.

WARNING: DO NOT USE IN KITCHENS

Safety Warnings

reduce the risk of fire, electric shock and injury to persons, including the followings: When using electrical appliances, basic precautions should always be followed to

- To prevent fire or shock hazard, DO NOT expose this appliance to rain or
- electric shock, personnel only. Dangerous high voltages are present inside the motor DO NOT open the motor enclosure. Refer all servicing to qualified enclosure.
- drawn into the fan. Ensure the fan is not placed near drapes, curtains, or any objects that may be
- unit, plug or cord in water or spray it with liquids To protect against fire, electrical shock and injury to persons, do not immerse the
- No naked flames sources, such as candles, should be placed on the product.
- Ventilation should not be impeded by covering the ventilation openings. product and to protect it from overheating. and opening are provided for ventilation to ensure reliable operation of the

- Place the fan on a stable level surface when operating to avoid overturning.
- Only connect to a suitably AC 220-240V~50Hz.
- Do not operate fan in the presence of explosive and/or flammable fumes. Do not
 place the fan or any parts near an open flame, cooking or other heating appliance.
- Precautions must be taken to prevent backflow of gasses into the room from the open flue of gas or other fuel-burning appliances.
- Do not operate the fan with a damaged cord or plug, after a malfunction or if there is dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physica I, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Switch the fan OFF when it is not in use, when moving fan from one location to another and before cleaning.
- Do not attempt to repair, disassemble or modify the appliance. There are no user-serviceable parts inside.

INSTA

STARTIN

NOTE: TH

NEED TO

NOTE: FO

VENT SHO

Preparir

1. When se

a) Mounting Mounting

from being

moving the

b) Service

Installing Using th

suitable

Ensure t

INSTALLATION INSTRUCTIONS

STARTING INSTALLATION. CAUTION: MAKE SURE POWER IS SWITCHED OFF AT SERVICE PANEL BEFORE NOTE: THIS EXHAUST FAN IS FITTED WITH A SUPPLY CABLE, THUS THERE IS NO

NOTE: FOR NEED TO OPEN THE FAN FOR WIRING BEST PERFORMANCE, THE LOCATION OF THE INLET AND OUTLET

Preparing for Fan Installation

VENT SHOULD BE WITHIN 6M IN DUCT LENGTH

- 1. When selecting fan mounting location, the following criteria should be considered:
- a) Mounting to minimize noise generated by fan operation:

from being transmitted back through the duct work. If the fan is to be b) Service accessibility. Fan location should allow sufficient access for service moving the air between two rooms, a central point along the duct may Mounting the fan as far as possible from the intake point will minimize used fan operating noise be optimal as a booster for

Installing the Fan


suitable Using the surface, joist, or structure made for the fan screws provided, Secure the fixing plastic bracket 0


Make Ensure the direction of the airflow is correct when securing the Note: Fan mounting can be at any sure the supply cable is within reach of the mains point along the duct socket outlet.

outdoor, then position the fan near the outlet to prevent back of outdoor air middle of the duct to reduce fan noise. If the outlet vent is TIPS:If the outlet is to another room, then the fan should be in MeJD

Please For best performance, place the fan motor as close to the possible. These fans pay attention to the direction of airflow pull air better than they push it sticker located

on the fan. (see





0

8

7

NOTE: Fan mounting can be at any point along the duct.

outlet to prevent back draw of outdoor air. to reduce fan noise. TIPS: If the outlet is to another room, then the fan should be in the middle of the duct If the outlet vent is to outdoor, then position the fan near the

fans pull air better than they push it. performance, place the fan motor as close to the outlet as possible. These

Please pay attention to the direction of airflow sticker located on the fan

SPECIFICATION

150	250	25	220-240	SF150S
	210	20	220-240	SF125S
100	100	15	220-240	SF100S
150	250	25	220-240	SF150T
120	210	20	220-240	SF125T
100	100	15	220-240	SF100T
(mm)	(m ³ /h)	(W)	(VAC)	
Size	Air-Flow	Input	Rated voltage	Model


MAINTENANCE & SERVICE

power supply. Before carrying out any maintenance, ensure the power is switched OFF from the main

- Wipe down the fascia and grilles with a wet soapy cloth only. Do not allow water to contact electrical part, such as motor
- N Never use petrol, benzene, thinner or any other such chemicals for cleaning the ventilating fan.
- ·w Do not immerse resin parts into hot water over 60°c.
- 4 Do not place hot objects near or install nearby hot appliances


HOW TO OPERATING FUNCTIONS OF THE TIMER For model SF100T/SF125T/SF150T

when the overrun time expires after the switch has Overtime:approx.1...20 min.(Knob:A) Please no/off with the switch, Fan switches off immediately been operated




A). WITH LIGHT

TIMER or HUMIDITY WIRING CONNECTION




B). WITHOUT LIGHT

TIMER or HUMIDITY



Single Point Exhaust System



Multi-Point Exhaust System




Figure 2. Installing:

- Loosen the two 1.To install the unit the fan motor wheel assembly must first be removed. spring clips around the casing and remove.
- 2. Secure the mounting bracket fan flange assembly to a fixed structure.
- 3. Replace the fan motor wheel assembly and tighten the two spring clips to secure the

